

Operating Manual

Translation of the original operating manual

VDL (E3.1) Vacuum Drying Oven

with microprocessor program controller MB2

Model	Model version	Art. No.
VDL 23	VDL023-230V	9630-0009
VDL 23-UL	VDL023UL-120V	9630-0013
VDL 56	VDL053-230V	9630-0010
VDL 56-UL	VDL053UL-120V	9630-0014
VDL 115	VDL115-230V	9630-0011
VDL 115-UL	VDL115UL-120V	9630-0015

BINDER GmbH

- ► Address: Post office box 102, 78502 Tuttlingen, Germany ► Phone: +49 7462 2005 0
- ► Fax: +49 7462 2005 100 ► Internet: http://www.binder-world.com
- ► E-mail: info@binder-world.com ► Service Hotline: +49 7462 2005 555
- ▶ Service Fax: +49 7462 2005 93 555 ▶ Service E-Mail: service@binder-world.com
- Service Hotline USA: +1 866 885 9794 or +1 631 224 4340 x3
- ▶ Service Hotline Asia Pacific: +852 390 705 04 or +852 390 705 03
- ▶ Service Hotline Russia and CIS: +7 495 988 15 16

Contents

1.	SAFETY	. 8
11	Personnel Qualification	8
1.2	Operating manual	8
1.3	Legal considerations	9
1.4	Structure of the safety instructions	10
1.4	4.1 Signal word panel	10
1.4	1.2 Safety alert symbol	10
1.4	1.3 Explosion protection symbol	10
1.4	4.4 Pictograms in this manual	11
1.4	Localization / position of safety labels on the chamber	12
1.0	Type plate	13
1.7	Safety instructions on installing and operating the vacuum drving oven	14
1.7	7.1 Safety instructions on installation and ambient conditions of the chamber	14
	1.7.1.1 Aeration / ventilation of the installation site	15
	1.7.1.2 No installation in potentially explosive areas of Zone 1 or 0	15
	1.7.1.3 Equipotential bonding according to the grounding concept	16
	1.7.1.4 Accessibility to the disconnection from the power grid	16
4 -	1.7.1.5 Technical ventilation (extraction)	16
1.7	7.2 Safety instructions on vacuum supply	17
	1.7.2.1 Selection and location of a suitable pump	10
	1.7.2.2 Observing the permissible gas linet temperature	18
1 7	7.3 Safety instructions on the charging material	19
1.7	7.4 Safety instructions on operating the vacuum drving oven	20
1.8	Ex classification of the chamber and immediate surroundings	23
1.9	Intended use	25
1.10	Foreseeable Misuse	27
1 1 1		~ ~
1.11	Residual Risks	29
2.	OPERATOR RESPONSIBILITY, DOCUMENTATION, AND MEASURES	29 32
2.1	Residual Risks OPERATOR RESPONSIBILITY, DOCUMENTATION, AND MEASURES Risk assessment / explosion protection document.	29 32 .32
2.1 2.2	Residual Risks OPERATOR RESPONSIBILITY, DOCUMENTATION, AND MEASURES Risk assessment / explosion protection document Employee training and protocols	29 32 .32 .32
2.1 2.2 2.3	Residual Risks OPERATOR RESPONSIBILITY, DOCUMENTATION, AND MEASURES Risk assessment / explosion protection document Employee training and protocols Operating instructions	29 32 .32 .32 .33
2.1 2.2 2.3 2.4	Residual Risks OPERATOR RESPONSIBILITY, DOCUMENTATION, AND MEASURES Risk assessment / explosion protection document Employee training and protocols Operating instructions Safety data sheets	29 32 .32 .32 .33 .33 .33
2.1 2.2 2.3 2.4 2.5	Residual Risks OPERATOR RESPONSIBILITY, DOCUMENTATION, AND MEASURES Risk assessment / explosion protection document Employee training and protocols Operating instructions Safety data sheets Protective equipment	29 32 32 33 33 33 33
2 .1 2.2 2.3 2.4 2.5 2.6	Residual Risks OPERATOR RESPONSIBILITY, DOCUMENTATION, AND MEASURES Risk assessment / explosion protection document Employee training and protocols Operating instructions Safety data sheets Protective equipment Standard Operating Procedures (SOPs)	29 32 32 33 33 33 33 34
2 .1 2.2 2.3 2.4 2.5 2.6 2.7	Residual Risks OPERATOR RESPONSIBILITY, DOCUMENTATION, AND MEASURES Risk assessment / explosion protection document Employee training and protocols Operating instructions Safety data sheets Protective equipment Standard Operating Procedures (SOPs) Testing and maintenance	29 32 32 33 33 33 33 34 35
2.1 2.2 2.3 2.4 2.5 2.6 2.7 2.8	Residual Risks OPERATOR RESPONSIBILITY, DOCUMENTATION, AND MEASURES Risk assessment / explosion protection document Employee training and protocols Operating instructions Safety data sheets Protective equipment Standard Operating Procedures (SOPs) Testing and maintenance Operation log	29 32 32 33 33 33 33 34 35 35
2.1 2.2 2.3 2.4 2.5 2.6 2.7 2.8 3.	Residual Risks OPERATOR RESPONSIBILITY, DOCUMENTATION, AND MEASURES Risk assessment / explosion protection document. Employee training and protocols. Operating instructions Safety data sheets Protective equipment Standard Operating Procedures (SOPs) Testing and maintenance. Operation log.	29 32 32 33 33 33 33 33 34 35 35 37
2.1 2.2 2.3 2.4 2.5 2.6 2.7 2.8 3. 3.1	Residual Risks OPERATOR RESPONSIBILITY, DOCUMENTATION, AND MEASURES Risk assessment / explosion protection document. Employee training and protocols. Operating instructions Safety data sheets Protective equipment Standard Operating Procedures (SOPs) Testing and maintenance Operation log. DESCRIPTION OF THE EQUIPMENT Manufacturer's safety plan: Protective measures and equipment.	 29 32 32 32 33 33 34 35 35 37 38
2.1 2.2 2.3 2.4 2.5 2.6 2.7 2.8 3. 3.1 3.2	Residual Risks OPERATOR RESPONSIBILITY, DOCUMENTATION, AND MEASURES Risk assessment / explosion protection document Employee training and protocols Operating instructions Safety data sheets Protective equipment Standard Operating Procedures (SOPs) Testing and maintenance Operation log DESCRIPTION OF THE EQUIPMENT Manufacturer's safety plan: Protective measures and equipment Chamber overview	 29 32 32 32 33 33 34 35 35 37 38 43
2.1 2.2 2.3 2.4 2.5 2.6 2.7 2.8 3.1 3.2 3.3	Residual Risks OPERATOR RESPONSIBILITY, DOCUMENTATION, AND MEASURES Risk assessment / explosion protection document. Employee training and protocols. Operating instructions Safety data sheets Protective equipment Standard Operating Procedures (SOPs) Testing and maintenance. Operation log. DESCRIPTION OF THE EQUIPMENT Manufacturer's safety plan: Protective measures and equipment Chamber overview Triangular instrument box with MB2 controller.	 29 32 32 33 33 34 35 35 37 38 43 44
2.1 2.2 2.3 2.4 2.5 2.6 2.7 2.8 3.1 3.2 3.3 3.4	Residual Risks OPERATOR RESPONSIBILITY, DOCUMENTATION, AND MEASURES Risk assessment / explosion protection document. Employee training and protocols. Operating instructions Safety data sheets Protective equipment Standard Operating Procedures (SOPs) Testing and maintenance Operation log. DESCRIPTION OF THE EQUIPMENT Manufacturer's safety plan: Protective measures and equipment Chamber overview Triangular instrument box with MB2 controller. Connections on the rear of the chamber	 29 32 32 32 33 33 34 35 35 37 38 43 44 44
2.1 2.2 2.3 2.4 2.5 2.6 2.7 2.8 3.1 3.2 3.3 3.4 3.5	Residual Risks OPERATOR RESPONSIBILITY, DOCUMENTATION, AND MEASURES Risk assessment / explosion protection document. Employee training and protocols. Operating instructions Safety data sheets Protective equipment Standard Operating Procedures (SOPs) Testing and maintenance. Operation log. DESCRIPTION OF THE EQUIPMENT Manufacturer's safety plan: Protective measures and equipment Chamber overview Triangular instrument box with MB2 controller. Connections on the rear of the chamber Area classification, information for the zone classification	29 32 32 33 33 33 33 35 35 35 37 38 43 44 44 46
2.1 2.2 2.3 2.4 2.5 2.6 2.7 2.8 3.1 3.2 3.3 3.4 3.5 3.5 3.5	Residual Risks OPERATOR RESPONSIBILITY, DOCUMENTATION, AND MEASURES Risk assessment / explosion protection document. Employee training and protocols. Operating instructions Safety data sheets Protective equipment Standard Operating Procedures (SOPs) Testing and maintenance. Operation log. DESCRIPTION OF THE EQUIPMENT Manufacturer's safety plan: Protective measures and equipment. Chamber overview Triangular instrument box with MB2 controller. Connections on the rear of the chamber. Area classification, information for the zone classification. 5.1	29 32 32 33 33 33 34 35 37 38 43 44 46 47
2.1 2.2 2.3 2.4 2.5 2.6 2.7 2.8 3.1 3.2 3.3 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5	Residual Risks OPERATOR RESPONSIBILITY, DOCUMENTATION, AND MEASURES Risk assessment / explosion protection document. Employee training and protocols. Operating instructions Safety data sheets Protective equipment Standard Operating Procedures (SOPs) Testing and maintenance. Operation log. DESCRIPTION OF THE EQUIPMENT Manufacturer's safety plan: Protective measures and equipment Chamber overview Triangular instrument box with MB2 controller. Connections on the rear of the chamber Area classification, information for the zone classification. 5.1 Area classification inside the chamber	 29 32 32 33 33 34 35 35 37 38 43 44 46 47 48
2.1 2.2 2.3 2.4 2.5 2.6 2.7 2.8 3.1 3.2 3.3 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.5 3.4 3.5 3.5 3.5 3.5 3.5 3.5 3.5 3.5 3.5 3.5	Residual Risks OPERATOR RESPONSIBILITY, DOCUMENTATION, AND MEASURES Risk assessment / explosion protection document. Employee training and protocols. Operating instructions Safety data sheets Protective equipment Standard Operating Procedures (SOPs) Testing and maintenance. Operation log. DESCRIPTION OF THE EQUIPMENT Manufacturer's safety plan: Protective measures and equipment Chamber overview Triangular instrument box with MB2 controller. Connections on the rear of the chamber Area classification, information for the zone classification. 5.1 Area classification inside the chamber 5.2 Area classification in the surroundings of the chamber: extraction lead to the pump, locatio of the pump.	29 32 32 33 33 33 35 35 37 38 44 44 46 47 48 n 49
2.1 2.2 2.3 2.4 2.5 2.6 2.7 2.8 3.1 3.2 3.3 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5	Residual Risks OPERATOR RESPONSIBILITY, DOCUMENTATION, AND MEASURES Risk assessment / explosion protection document. Employee training and protocols. Operating instructions Safety data sheets Protective equipment Standard Operating Procedures (SOPs) Testing and maintenance Operation log. DESCRIPTION OF THE EQUIPMENT Manufacturer's safety plan: Protective measures and equipment. Chamber overview Triangular instrument box with MB2 controller. Connections on the rear of the chamber Area classification inside the chamber 1 Area classification inside the chamber 3 Area classification in the surroundings of the chamber: extraction lead to the pump, location of the pump	29 32 32 33 33 33 33 35 35 37 38 43 44 44 46 47 48 n 49
2.1 2.2 2.3 2.4 2.5 2.6 2.7 2.8 3.1 3.2 3.3 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 4.3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.5 3.4 3.5 3.5 3.4 3.5 3.5 3.5 3.5 3.5 3.5 3.5 3.5 3.5 3.5	Residual Risks OPERATOR RESPONSIBILITY, DOCUMENTATION, AND MEASURES Risk assessment / explosion protection document. Employee training and protocols. Operating instructions Safety data sheets Protective equipment Standard Operating Procedures (SOPs) Testing and maintenance. Operation log. DESCRIPTION OF THE EQUIPMENT Manufacturer's safety plan: Protective measures and equipment Chamber overview Triangular instrument box with MB2 controller. Connections on the rear of the chamber Area classification inside the chamber 1 Area classification inside the chamber 2 Area classification in the surroundings of the chamber: 3 Area classification in the surroundings of the chamber: extraction lead to the pump, locatio of the pump. COMPLETENESS OF DELIVERY, TRANSPORTATION, STORAGE, AND INSTALLATION.	29 32 32 33 33 33 35 35 37 38 43 44 46 47 48 n 49 50
2.1 2.2 2.3 2.4 2.5 2.6 2.7 2.8 3.1 3.2 3.3 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 4. 3.4	Residual Risks OPERATOR RESPONSIBILITY, DOCUMENTATION, AND MEASURES Risk assessment / explosion protection document. Employee training and protocols. Operating instructions Safety data sheets Protective equipment Standard Operating Procedures (SOPs) Testing and maintenance. Operation log. DESCRIPTION OF THE EQUIPMENT Manufacturer's safety plan: Protective measures and equipment Chamber overview Triangular instrument box with MB2 controller. Connections on the rear of the chamber Area classification inside the chamber 2 Area classification inside the chamber 3 Area classification in the surroundings of the chamber: 3 Area classification in the surroundings of the chamber: 5 Area classification in the surroundings of the chamber. 5 Area classification in the surroundings of the chamber. 5 Area classification in the surroundings of the chamber. 5 Area classification in the surroundings of the chamber. 5 Area classification in the surroundings of the chamber. 5 Area classification in the surroundings of the chamber. 5<	32 32 32 33 33 33 35 37 38 43 44 46 47 48 n 49 50
2.1 2.2 2.3 2.4 2.5 2.6 2.7 2.8 3.1 3.2 3.3 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.4 3.5 3.4 3.4 3.5 3.4 3.4 3.5 3.4 3.4 3.5 3.4 3.4 3.5 3.4 3.4 3.5 3.4 3.5 3.4 3.4 3.5 3.4 3.5 3.4 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.5 3.4 3.5 3.5 3.4 3.5 3.5 3.4 3.5 3.5 3.5 3.5 3.5 3.5 3.5 3.5 3.5 3.5	Residual Risks OPERATOR RESPONSIBILITY, DOCUMENTATION, AND MEASURES Risk assessment / explosion protection document. Employee training and protocols. Operating instructions Safety data sheets Protective equipment Standard Operating Procedures (SOPs) Testing and maintenance. Operation log. DESCRIPTION OF THE EQUIPMENT Manufacturer's safety plan: Protective measures and equipment. Chamber overview Triangular instrument box with MB2 controller. Connections on the rear of the chamber Area classification inside the chamber 5.1 Area classification in the surroundings of the chamber 5.2 Area classification in the surroundings of the chamber 5.3 Area classification in the surroundings of the chamber: extraction lead to the pump, locatio of the pump COMPLETENESS OF DELIVERY, TRANSPORTATION, STORAGE, AND INSTALLATION. Unpacking, and checking equipment and completeness of delivery Outdoling for ache itime or and transportation	29 32 32 33 33 33 34 35 37 38 43 44 46 47 48 49 50 50
2.1 2.2 2.3 2.4 2.5 2.6 2.7 2.8 3.1 3.2 3.3 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.4 3.5 3.5 3.4 3.5 3.5 3.4 3.5 3.5 3.5 3.5 3.5 3.5 3.5 3.5 3.5 3.5	Residual Risks OPERATOR RESPONSIBILITY, DOCUMENTATION, AND MEASURES Risk assessment / explosion protection document. Employee training and protocols. Operating instructions Safety data sheets Protective equipment Standard Operating Procedures (SOPs) Testing and maintenance. Operation log. DESCRIPTION OF THE EQUIPMENT Manufacturer's safety plan: Protective measures and equipment. Chamber overview Triangular instrument box with MB2 controller. Connections on the rear of the chamber Area classification inside the chamber 5.1 Area classification in the surroundings of the chamber 5.2 Area classification in the surroundings of the chamber 5.3 Area classification in the surroundings of the chamber: extraction lead to the pump, location of the pump COMPLETENESS OF DELIVERY, TRANSPORTATION, STORAGE, AND INSTALLATION. Unpacking, and checking equipment and completeness of delivery. Guidelines for safe lifting and transportation.	29 32 32 333 333 34 35 37 38 44 46 47 48 19 50 51

5.	LOCATION OF INSTALLATION AND AMBIENT CONDITIONS	51
5.1	General requirements for installation	.51
5.2	Ventilation and extraction (technical ventilation)	.53
5.2	2.1 Ventilation for heat removal in normal operation	.53
0.2	of the pump	.53
5.2	2.3 Air supply (breaking the vacuum) during operation with inert gas	.54
5.3	Equipotential bonding	.54
5.4	Ambient conditions	.54
5.5	Compressed air / ment gas supply for sweeping the area for electrical equipment and controller	54
5.6	Fire extinguisher	.54
5.7	Lightning protection device	.55
6.	INSTALLATION AND CONNECTIONS	55
61	Vacuum expansion racks and rack holders	55
6.2	Mounting the pressure regulator	.57
6.3	Connecting compressed air / inert gas supply for sweeping the area for electrical equipment and	
0.4	controller housing	.59
6.4 67	Pump module (option)	.60
6.4	4.2 Achieving equipotential bonding acc. to the grounding plan	.61
6.4	4.3 Connection of an extraction system at the pump module	.62
6.5	Vacuum connection	.62
6.5	5.1 Instructions for using vacuum pumps	.63
0.0 6.5	5.2 Vacuum pump VP4 (option) 5.3 Installation of the vacuum pump VP4 in the pump module (option)	60.
6.5	5.4 Note on the use of a flame arrester	.67
6.5	5.5 ATEX connection kit for vacuum pump VP4 (option)	.68
6.6	Connecting inert gas supply	.68
6./	Achieving equipatential banding / Crounding concent	.69
0.0 6.9	Electrical connection	72
7		74
7.	EXPLOSION SAFETY TESTS BEFORE COMMISSIONING	14
7.1	Scope of the functional test	.74
7.2 7.3	Objective of testing	.74
7.4	Testing before initial commissioning	.75
7.4	4.1 Scope of the test	.75
	7.4.1.1 Testing the plausibility of the explosion protection plan and measures	.75
	7.4.1.2 Verifying the implementation of measures	.75
	7.4.1.3 Checking the deadlines for the recurring tests	76
7.4	1.2 Tests of technical ventilation systems, gas warning devices, inerting devices, devices,	
	protective systems or safety, control or regulating devices, and other technical devices	for
7 5	explosion protection	.77
7.5 7.6	Inspection after changes requiring review	.//
7.0 Q		70
0.	Consisting functions in normal diaplay	70
0.1 8.2	Display views: Normal display, program display, chart-recorder display	.79
8.3	MB2 controller icons overview	.81
8.4	MB2 controller operating modes	.83
8.4	4.1 MB2 controller menu structure	.83
8.4 ຂ /	t.∠ IVIaI⊓ MENU	.84 85
8.4	1.4 "Service" submenu	.85

8.5 8.6	Principle of controller entries Performance during and after power failures	86 87
9.	START UP AND PERFORMING THE DRYING PROCESS	88
9. 9.1 9.2 9.3 9.4 9.2 9.5 9.6 9.7 9.8 9.9 9.10 9.10 9.2 9.10 9.2 9.10 9.2 9.10 9.2 9.2 9.3 9.4 9.2 9.2 9.2 9.2 9.2 9.2 9.2 9.2 9.2 9.2	START UP AND PERFORMING THE DRYING PROCESS Requirements for safe commissioning Setting the pressure regulator for sweeping with compressed air / inert gas Overview of the drying process Sweeping the area for electrical equipment and controller housing (triangular instrument box) 1.1 Sweeping before starting up the chamber 4.2 Sweeping during chamber operation Condition after establishing the power connection Standby mode Turning on and off the vacuum drying oven Controller settings upon start up Loading. Evacuation Breaking the vacuum (flooding) 10.2 Operation with inert gas 10.3 Ventilation after completing the drying procedure (flooding with ambient air or inert gas) 10.3 Ventilation / breaking the vacuum in case of a power failure 10.4 Ventilation before completing the drying procedure (flooding with ambient air or inert gas) Unloading the loading material Removing the full condensate catchpot of the pump Prenaring a new drying process Prenaring a new drying process	. 88 89 90 92 92 92 92 93 94 97 97 97 97 97 98 99 99 100
9.13 10.	SET-POINT ENTRY	100 101
10 10	.1.1 Set-point entry through the "Setpoints" menu.1.2 Direct setpoint entry via Normal display	101 102
11.	SETTING SPECIAL CONTROLLER FUNCTIONS	03
11.1 11 11.2 11.3 11.4 11.5 11.6	Menu structure	103 103 104 104 105 105 106 107 108
12.	AUTHORIZATION LEVELS AND PASSWORD PROTECTION	10
12.1 12.2 12.3 12.4 12.5 12 12 12 12	 User management, authorization levels and password protection Log in Log out User change Password assignment and password change 5.1 Password change 5.2 Deleting the password for an individual authorization level 5.3 New password assignment for "service" or "admin" authorization level when the password function was deactivated 	110 113 114 114 115 115 117 118
12.6	Activation code	119
13.	GENERAL CONTROLLER SETTINGS AND INFORMATION	20
13.1 13.2 13.3 13.4 13 13.5 13.5 13.6	Selecting the controller's menu language Setting date and time Selecting the temperature unit Display configuration .4.1 Adapting the display parameters .4.2 Touchscreen calibration Event list Service contact page	120 122 122 122 122 123 124 124

13.7 13.8	Current operating parameters	
14.	TEMPERATURE SAFETY DEVICES	126
14.1 14.2 14 14 14 14	Safety temperature limiter (TL) class 2 2 Overtemperature safety controller class 2 14.2.1 Safety controller mode 14.2.2 Setting the safety controller 14.2.3 Message and measures in the state of alarm 14.2.4 Function check.	
15.	TOLERANCE RANGE SETTINGS	129
15.1 15	Setting the alarm delay times and the tolerance ranges I5.1.1 Alarm condition	
16.	NOTIFICATION AND ALARM FUNCTIONS	130
16.1 16.2 16.3 16.4 16.5	 Information messages Alarm messages Resetting an alarm Activating / deactivating the audible alarm (buzzer) Test alarm of the safety temperature limiter (TL) 	
17.		
17.1 17.2 17.2 17 17 17.3	Starting a timer program 17.1.1 Performance during program delay time 2 Stopping a running timer program 17.2.1 Pausing a running timer program 17.2.2 Cancelling a running timer program 17.2.3 Performance after the end of the program	
18.	TIME PROGRAMS	137
18. 18.1 18.2 18.3 18.3 18.4 18.5 18.6 18 18.7 18 18.7 18 18.7 18 18.7 18 18.7 18 18.7 18 18.7 18 18.7 18.7 18 18.5	TIME PROGRAMS Starting an existing time program 18.1.1 Performance during program delay time 2 Stopping a running time program 18.2.1 Pausing a running time program 18.2.2 Cancelling a running time program 18.2.1 Pausing a new time program 18.2.2 Cancelling a running time program 18.2.1 Deleting a time program 18.5.1 Deleting a time program 18.5.1 Deleting a time program section 18.6.1 Add a new program section 18.6.2 Copy and insert or replace a program section 18.6.3 Deleting a program section 18.6.4 Add use metry for a program section 18.7.5 Section duration 18.7.2 Set-point ramp and set-point step	137 137 138 138 138 138 138 139 140 140 140 141 142 142 143 143 144 145 145 145 145 145 145 145 145 145
18. 18.1 18.2 18 18.3 18.4 18.5 18.6 18 18.7 18 18.7 18 18 18 18 18 18 18 18 18 18	TIME PROGRAMS Starting an existing time program 18.1.1 Performance during program delay time 2 Stopping a running time program 18.2.1 Pausing a running time program 18.2.2 Cancelling a running time program 18.2.2 Cancelling a running time program 18.2.1 Pausing a running time program 18.2.2 Cancelling a running time program 2 Performance after the end of the program 3 Performance after the end of the program 4 Creating a new time program management 18.5.1 Deleting a time program management 18.5.1 Deleting a time program section 18.6.1 Add a new program section 18.6.2 Copy and insert or replace a program section 18.6.3 Deleting a program section 18.6.3 Deleting a program section 18.7.1 Section duration 18.7.2 Set-point ramp and set-point step 18.7.3 Special controller functions 18.7.4 Setpoint entry 18.7.5 Tolerance range 18.7.6 Repeating one or several sections within a time program	137 138 138 138 138 138 138 139 140 140 141 142 143 143 143 144 145 145 145 145 145 145 145 145 145

19.5 19 19 19.6 19 19 19 19 19 19	Section editor: section management. 0.5.1 Add a new program section	
20.		
20.1	Ethernet	
20	0.1.1 Configuration	
20 2	0.1.2 Display of MAC address	
20.2	E-Mail	
21.	USB MENU: DATA TRANSFER VIA USB INTERFACE	
21.1	Using the USB connection during chamber operation	
22.	CHART RECORDER DISPLAY	
22.1	Views	
22	2.1.1 Show and hide legend	165
22	2.1.2 History display	
22.2		
23.		
23.1	Checking the temperature in the inner chamber	
23	8.1.1 Checking the controller display	
24.	OPTIONS	170
24.1	APT-COM™ 4 Multi Management software (option)	170
24.2	Analog outputs for temperature and pressure (option)	170
24.3	Measuring access port for vacuum, 9 poles (option)	170
24.4	Object temperature display with flexible Pt 100 temperature sensor (option)	
24 24	I.4.1 Connection of the object temperature sensor I.4.2 Display on the MB2 controller	
2- 2E		470
25.		
25.1	Safety instructions on cleaning and decontamination	
25.2 25.3	Decontamination / chemical disinfection	
26.	MAINTENANCE AND SERVICE, TROUBLESHOOTING, REPAIR, TES	TING.176
26 1	General information personnel qualifications	176
26.2	Simple troubleshooting	
26.3	Maintenance, Service	180
26	5.3.1 Safety instructions on maintenance work	
26	5.3.2 Maintenance intervals	
∠0.4 26	Service Reminder	182 182
26.5	Sending the chamber back to BINDER GmbH	
27.	DISPOSAL	
27.1	Disposal of the transport packing	
27.2	Decommissioning	

27.3 27 4	Disposal of the chamber in the Federal Republic of Germany	
27.5	Germany Disposal of the chamber in non-member states of the EU	
28.	TECHNICAL DESCRIPTION	187
28.1 28.2 28.3 28.4 28.5 28.6 28 28 28 28 28 28 28	Factory calibration and adjustment Over current protection VDL / VDL-UL technical data Equipment and options (extract) Accessories and spare parts (extract) Dimensions 6.1 VDL 23 6.2 VDL 56 6.3 VDL 115	187 187 187 187 189 190 192 192 192 193 194
29.	INDEX	195
30.	CERTIFICATES AND DECLARATIONS OF CONFORMITY	197
30.1	EU Declaration of Conformity	
31.	PRODUCT REGISTRATION	200
32.	CONTAMINATION CLEARANCE CERTIFICATE	201
32.1 32.2	For chambers located outside USA and Canada For chambers located in USA and Canada	201 204

List of figures

Figure 1: Position of labels on the chamber (example)	12
Figure 2: Type plate (example of VDL 115)	13
Figure 3: VDL 115 with MB2 controller	43
Figure 4: Triangular instrument box (controller housing) with MB2 program controller and USB interface	ce44
Figure 5: Chamber rear (example: VDL 115)	44
Figure 6: Rear connection panel VDL with options	45
Figure 7: Area classification of the closed chamber (view without housing, insulation, heater and oute	er
chamber)	47
Figure 8: Area classification in the surroundings of the chamber (schematic representation)	48
Figure 9: Area classification in the surroundings of the chamber during operation (example)	49
Figure 10: Operating the expansion racks	56
Figure 11: Mounting the pressure regulator on the chamber rear	57
Figure 12: Compressed air connection on the pressure regulator	59
Figure 13: VDL mounted on pump module	60
Figure 14: Pump module, rear view (example size 115)	60
Figure 15: Position of the Vacuum connection on the chamber rear (example size 115)	62
Figure 16: Vacuum pump VP 4 (MZ2C EX)	65
Figure 17: Variable length of the tilt protection holder depending on the bend	69
Figure 18: Possibilities of grounding (schematic representation)	70
Figure 19: Mounting the grounding cable on the VDL	71
Figure 20: Normal display of the MB2 program controller (sample values)	78
Figure 21: Operating functions of the MB2 controller in normal display (example values)	79
Figure 22: Pressure regulator for compressed air sweeping on the chamber rear, top right	89
Figure 23: analog pressure display (manometer) for compressed air sweeping on the chamber front	89
Figure 24: Schematic timing of the drying process and drying monitoring	.108
Figure 25: Pin configuration of the SUB-D socket "Analog output" (8) for the analog outputs option	.170
Figure 26: Measuring connection (12) with measuring access port and supplied plug	.170
Figure 27: SUB-D socket to connect the optional Pt 100 in the rear connection panel of the chamber	.171
Figure 28: Measuring connection (12) with measuring access port	.172

Dear customer,

For the correct operation of the VDL vacuum drying oven, it is important that you read this operating manual completely and carefully and observe all instructions as indicated. Failure to read, understand and follow the instructions may result in personal injury. It can also lead to damage to the chamber and/or poor equipment performance.

1. Safety

1.1 Personnel Qualification

The chamber must only be installed, tested, and started up by personnel qualified for assembly, startup, and operation of the chamber with additional skills in explosion protection (ATEX). Qualified personnel are persons whose professional education, knowledge, experience and knowledge of relevant standards allow them to assess, carry out, and identify any potential hazards in the work assigned to them. They must have been trained and instructed, and be authorized, to work on the chamber. This includes a basic knowledge of explosion protection (ATEX training), instruction based on the risk assessment by the operator (chap. 2.2) and knowledge of the Operating Instruction by the operator.

The device shall only be operated by laboratory personnel especially trained for this purpose and familiar with all precautionary measures required for working acc. to ATEX Directive 2014/37/EU. Observe the national regulations on minimum age of laboratory personnel.

1.2 Operating manual

This operating manual is part of the components of delivery. Always keep it handy for reference in the vicinity of the chamber. If selling the unit, hand over the operating manual to the purchaser.

To avoid injuries and property damage observe the safety instructions of the operating manual. Failure to follow instructions and safety precautions can lead to significant risks and to the loss of explosion protection.

0	
1	Explosion hazard due to failure to observe the instructions and safety precautions.
	Serious injuries and chamber damage. Risk of death.
	Observe the safety instructions in this Operating Manual.
	Follow the operating procedures in this Operating Manual.
	Carefully read the complete operating instructions of the chamber prior to installing and using the chamber.
	Keep the operating manual for future reference.

A	Make sure that all persons who use the chamber and its associated work equipment have
S	read and understood the Operating Manual.

This Operating Manual is supplemented and updated as needed. Always use the most recent version of the Operating Manual. When in doubt, call the BINDER Service Hotline for information on the up-to-dateness and validity of this Operating Manual.

1.3 Legal considerations

This operating manual is for informational purposes only. It contains information for correct and safe installing, start-up, operation, decommissioning, cleaning and maintenance of the product. The content of this operating manual takes into account the applicable regulatory requirements and the latest technology. Note: the contents and the product described are subject to change without notice.

Understanding and observing the instructions in this operating manual are prerequisites for hazard-free use and safety during operation and maintenance. Images are to provide basic understanding. They may deviate from the actual version of the chamber. The actual scope of delivery can, due to optional or special design, or due to recent technical changes, deviate from the information and illustrations in these instructions this operating manual. In no event shall BINDER be held liable for any damages, direct or incidental arising out of or related to the use of this manual.

This operating manual cannot cover all conceivable applications. If you would like additional information, or if special problems arise that are not sufficiently addressed in this manual, please ask your dealer or contact us directly, e.g. by phone at the number located on page one of this manual.

Furthermore, we emphasize that the contents of this operating manual are not part of an earlier or existing agreement, description, or legal relationship, nor do they modify such a relationship. All obligations on the part of BINDER derive from the respective purchase contract, which also contains the entire and exclusively valid statement of warranty administration and the general terms and conditions, as well as the legal regulations valid at the time the contract is concluded. The statements in this manual neither augment nor restrict the contractual warranty provisions.

Furthermore, relevant national and international regulations on occupational safety apply. The operator must know, comply with, and implement these requirements. In particular, this includes the provisions of ATEX Operational Directive 1999/92/EC ("ATEX 137") (implemented for Germany in the Industrial Safety Regulation (BetrSichV) and the Ordinance on Hazardous Substances (GefStoffV)). The operator is responsible for choosing suitable work equipment for the areas classified as explosion hazards and for installing and operating equipment in accordance with respective requirements.

Limitation of liability

BINDER GmbH is not liable for any damage arising from the following causes:

- Non-observance of Instruction Manual
- Improper use
- Improper installation, setup, maintenance, repair
- Inspections not being performed (testing before initial commissioning, recurring tests, testing before recommissioning
- Negligence or willful intent
- Incorrect response to malfunctions
- Assignment of improperly or insufficiently trained personnel
- Technical changes and modifications made by the operator and not approved by the manufacturer
- · Use of non-approved accessories and replacement parts

We reserve the right to technical changes as part of improvements to operating characteristics and further development.

Have repairs performed only by experts authorized by BINDER. Repaired chambers must comply with the quality standard specified by BINDER. In particular, carry out an inspection before recommissioning after maintenance or repairs. These can only be performed by the manufacturer or specially trained personnel (in Germany: Qualified Persons per BetrSichVO).

1.4 Structure of the safety instructions

In this operating manual, the following safety definitions and symbols indicate dangerous situations following the harmonization of ISO 3864-2 and ANSI Z535.6.

1.4.1 Signal word panel

Depending on the probability of serious consequences, potential dangers are identified with a signal word, the corresponding safety color, and if appropriate, the safety alert symbol.



Indicates an imminently hazardous situation that, if not avoided, will result in death or serious (irreversible) injury.



Indicates a potentially hazardous situation which, if not avoided, could result in death or serious (irreversible) injury.

Indicates a potentially hazardous situation which, if not avoided, may result in moderate or minor (reversible) injury.

NOTICE

Indicates a potentially hazardous situation, which, if not avoided, may result in damage to the product and/or its functions or to property in its proximity.

1.4.2 Safety alert symbol

Use of the safety alert symbol indicates a risk of injury
 Observe all measures that are marked with the safety alert symbol in order to avoid death or injury.

1.4.3 Explosion protection symbol

Use of the explosion protection symbol warns against **explosion hazards**. Observe all measures in this operating manual to avoid the formation of explosive atmosphere as well as explosions.

Warning signs			
Danger of injury	Electrical hazard	Hot surface	Explosive atmosphere
Stability hazard	Lifting hazard	Inhalation hazard	Suffocation hazard
Harmful substances	Biohazard	Risk of corrosion and / or chemical burns	Pollution Hazard
Mandatory action signs			
			<u>\$-</u> ?
Mandatory regulation	Read operating instructions	Disconnect the power plug	Lift with several persons
Environment protection	Wear protective gloves	Wear eye protectors	Ground before use
~	B	(TO)	
Release before mainte- nance or repairs	Wear ESD shoes (antistatic shoes)	Wipe with damp cloth only	
Prohibition signs			I
Do NOT touch	Do NOT spray with water	Do not place anything on the chamber	
Information to be observed in order to ensure optimum function of the product.			

1.4.4 Pictograms in this manual

1.4.5 Word message panel structure

Type and cause of hazard.

Possible consequences.

- $\ensuremath{\varnothing}$ Instruction how to avoid the hazard: prohibition
- > Instruction how to avoid the hazard: mandatory action

Observe all other notes and information not necessarily emphasized in the same way, in order to avoid disruptions that could result in direct or indirect injury or property damage.

1.5 Localization / position of safety labels on the chamber

The following labels are located on the chamber door:

Safety labels			
	Hot surface		
	Do not place anything on the chamber	Observe sweeping time, read operating manual Service label	
		Service - Hotline	
	Wipe surfaces with damp cloth only	International: + 49 (0) 7462 / 2005-555 USA Toll Free: + 1 866 885 9794 or: + 1 631 224 4340 Россия и CHF: + 7 459 58815 17 service@binder.world.com	



Figure 1: Position of labels on the chamber (example)



Keep safety labels complete and legible.

Replace safety labels that are no longer legible. Contact BINDER Service for these replacements.

1.6 Type plate

Position of type plate: left chamber side (seen from front), at the bottom right-hand.

Nominal temp.	110 °C 230 °F 20	1,60 kW / 7,0 230 V / 50 Hz 230 V / 60 Hz 1 N ~		≥c∈ ¶[EXPLOSION PROOF INNER CHAMBER EX CLASSIF. ACC. TO 2014/34/EU EX II 2/3/- G IIB T3 GB/GC/- X MAX. TEMP. OF INNER CHAMBER SURFACE IN CAT 2: +160 °C
Safety device Class	DIN 12880 2.0				MAX. TEMP. OF HEATING SURFACE
Art. No.	9630-0011				TEMP. CLASS T3
Project No. Built	2020	VACUUM DRY	ING OVEN		
BINDER			NDER GmbH Mittleren Ösch 5 532 Tuttlingen / Germany w.binder-world.com	VDL 115 E3.1	Serial No. 00000000000000 Made in Germany

Figure 2: Type plate (example of VDL 115)

Indications of the typ (example)	e plate	Information
BINDER		Manufacturer: BINDER GmbH
VDL 115		Model designation
Vacuum Drying Oven		Chamber name: Vacuum drying oven
Serial No.	000000000000	Serial No. of the chamber
Built	2020	Year of construction
Nominal temperature	110 °C 230 °F	Nominal temperature
IP protection	20	Type of IP protection acc. to standard EN 60529
Temp. safety device	DIN 12880	Temperature safety device acc. to standard DIN 12880:2007
Class	2.0	Class of temperature safety device
Art. No.	9630-0011	Art. No. of the chamber
Project No.		Optional: Special application acc. to project no.
1,60 kW		Nominal power
7,0 A		Nominal current
230 V / 50 Hz		Nominal voltage $\pm 10\%$ at the indicated power frequency
230 V / 60 Hz		Norminal voltage +/- 10% at the indicated power nequency
1 N ~		Current type
Explosion proof inner chamber		Explosion proof inner chamber
Ex classification acc. to 2014/34/EU		Ex classification according to ATEX Directive 2014/34/EU
Ex II 2/3/- G IIB T3 Gb/Gc/- X		
Max. temp. of inner ch cat. 2: +160 °C	amber surface in	Maximum temperature of the inner chamber surfaces: 160 °C / 320 °F (Device category 2)
Max. temp. of heating surface in cat. 3: +185 °C		Maximum temperature of the surfaces at the heater: 185 °C / 365 °F (Device category 3)
Temp. class T3		Temperature class acc. to IEC 60079-0 for the entire cham- ber

Symbol on the type plate	Information
CE	CE conformity marking
(Ex)	Explosion protection symbol. Ex classification acc. to ATEX Directive 2014/34/EU



Symbol on the type plate	Information
	Electrical and electronic equipment manufactured / placed on the market in the EU after 13 August 2005 and to be dis- posed of in a separate collection according to Directive 2012/19/EU on waste electrical and electronic equipment (WEEE).
ERC	The chamber is certified according to Customs Union Tech- nical Regulation (CU TR) for the Eurasian Economic Union (Russia, Belarus, Armenia, Kazakhstan Kyrgyzstan).

1.7 Safety instructions on installing and operating the vacuum drying oven

With regard to operating the vacuum drying oven VDL and to the installation location, please observe the relevant national regulations (for Germany in particular: DGUV guidelines 213-850 on safe working in laboratories, issued by the employers' liability insurance association; Industrial Safety Regulation (Be-trSichV); Ordinance on Hazardous Substances (GefStoffV); Technical Regulations on Industrial Safety and Health (TRBS 1201 Part 1).

The central element of the Industrial Safety Regulation is the **risk assessment** performed by competent personnel which enables an employer to evaluate risks that may arise before using work equipment and to derive necessary and suitable tests and measures.

Explosion protection plan

The **explosion protection plan** to be created by the operator represents the entirety of the technical and organizational measures for explosion protection determined and specified on the basis of the risk assessment. In accordance with ATEX Operational Directive 1999/92/EC, these measures serve

- to prevent the formation of or to limit explosive atmospheres or to limit hazardous explosive mixtures
- to avoid the combustion of explosive atmospheres
- to limit the spread of an explosion and to minimize its effects on personnel in order to ensure the health and safety of employees

The explosion protection document serves to document the results of the risk assessment in accordance with § 6 Para. 9 GefStoffV (for Germany).

BINDER GmbH is only responsible for the safety features of the chamber provided skilled electricians or qualified personnel authorized by BINDER perform all maintenance and repair, and if components relating to chamber safety are replaced in the event of failure with original spare parts.

To operate the chamber, use only original BINDER accessories or accessories from third-party suppliers authorized by BINDER. The user is responsible for any risk caused by using unauthorized accessories.

1.7.1 Safety instructions on installation and ambient conditions of the chamber

Familiarize yourself with the local conditions, particularly allocation to a defined potentially explosive area (zones) and the according technical safety requirements. During installation, commissioning and operation of the vacuum drying oven and the connected vacuum pump or in-house vacuum supply, always follow the requirements defined by the classification of the installation site.

1.7.1.1 Aeration / ventilation of the installation site

NOTICE
Danger of overheating due to lack of aeration.
Damage to the chamber.
Ø Do NOT install the chamber in unventilated recesses.
Ensure sufficient ventilation for dispersal of heat.
Observe the prescribed minimum distances when installing the chamber (chap. 5.1)

The vacuum drying ovens were constructed in accordance with the applicable VDE regulations and were routinely tested in accordance with VDE 0411-1 (IEC 61010-1). The production underlies an internal monitoring according to ATEX Directive 2014/34/EU appendix VIII.

For the user there is no risk of temporary overvoltages in the sense of EN 61010-1:2010.

1.7.1.2 No installation in potentially explosive areas of Zone 1 or 0

Even when the equipment is used properly, there exists a residual risk of explosion that cannot be excluded, particularly in relation to the environment of the chamber. To minimize this risk, strictly observe the legal regulations about how to select an appropriate location. Do not install and operate the vacuum drying oven VDL in occasionally or continuously / for long periods / frequently potentially explosive areas.

EX	
	Explosion hazard due to combustible dusts or explosive mixtures in the vicinity of the equipment.
	Serious injury or death from burns and / or explosion pressure.
	\varnothing Do NOT operate the chamber in in occasionally or continuously / for long periods / frequently potentially explosive areas. It is not intended for installation in a zone 1 or 0.
	KEEP combustible dusts AWAY from the equipment
	Make sure that air-solvent mixtures are NOT occasionally or continuously / for long periods / frequently in the vicinity of the equipment.
	 Reliably prevent spreading of an explosive atmosphere to unprotected areas (see chap. 3.5).
	Strictly observe the relevant legal regulations about how to select an appropriate loca- tion.

1.7.1.3 Equipotential bonding according to the grounding concept

The walkable installation and operating surface of the chamber must be conductive. This installation and operating surface must be connected to the vacuum drying oven according to the grounding concept (chap. 6.8). Cyclic measurements of the equipotential bonding are required.

	Explosion hazard by electric sparking due to missing or improperly implemented equipotential bonding.
	Serious injury or death from burns and / or explosion pressure.
	Connect all equipment elements in the installation and operating area (VDL / pump module / pump) with the conductive surface and/or with each other. Proceed according to the grounding concept (Chap. 6.8).
	Measure the equipotential bonding prior to commissioning the equipment.
	Provide cyclic measurements of the equipotential bonding.

1.7.1.4 Accessibility to the disconnection from the power grid

To completely separate the chamber from the power supply, you must disconnect the power plug. Install the chamber in a way that the power plug is easily accessible and can be easily pulled in case of danger.

The chamber's power plug is unprotected. The electrical connection must therefore be established outside a zone.

1.7.1.5 Technical ventilation (extraction)

The operator shall provide active extraction (technical ventilation according to country-specific regulations (TRBS 2152 Part 2 for Germany) before commissioning the chamber. Extraction must include the entire installation area of the vacuum drying oven and a vacuum pump. Observe the area classification in the surroundings of the chamber (chap. 3.5.3). Extraction must be active during the entire chamber operation. Operation, loading and unloading of the loading material and removal of the filled condensate catchpot of the pump must always take place under technical ventilation. If the technical ventilation fails, automatically switch off power to the chamber.

This will prevent spreading of an explosive atmosphere to unprotected areas (see chap. 3.5).

<u>/EX</u>	Explosion hazard due to the spread of an explosive atmosphere to unprotected are- as and ignition due to electric sparking or hot surfaces.		
	Serious injury or death from burns and / or explosion pressure.		
	Provide active suction (technical ventilation according to country-specific regulations (TRBS 2152 Part 2 for Germany) prior to commissioning the chamber.		
	Extraction must include the entire installation area of the vacuum drying oven; in addi- tion.		
	Make sure that the chamber is automatically turned off if the technical ventilation fails.		

1.7.2 Safety instructions on vacuum supply

Prior to commissioning the chamber make sure that all relevant national and international regulations are observed. Within the European Union, units that will be operated in potentially explosive areas have to meet the requirements of ATEX Directive 2014/34/EU.

If combustible solvent is introduced into the drying chamber, the vacuum pump must be constructed in a suitable explosion-proof manner.



Observe the safety instructions of the pump manufacturer.

1.7.2.1 Selection and location of a suitable pump

The mixtures extracted from the inner chamber must be carried away making sure that there is no danger by ignition of these atmospheres. Sparking in the pump motor or the switching elements, electrostatic discharges, as well as hot pump parts can ignite solvent vapors in the event of an error. To minimize this risk, use an ATEX Directive 2014/34/EU compliant vacuum pump suitable for suction from Zone 0 or 1 and, if appropriate, from the zone of its installation site. See chap. 6.5.1.

EX	
	Explosion hazard due to the spread of an explosive atmosphere to unprotected pump parts and ignition due to electric sparking on the pump motor or switching elements, electrostatic discharges, or hot surfaces.
	Serious injury or death from burns and / or explosion pressure.
	Use only suitable, explosion-proof pumps. See chap. 6.5.1.
	Operate the pump in a stationary position and secure it so it is immobile.
	Make sure that the suction line to the vacuum connection (6) of the VDL is fixed and conductive.
	Ensure sufficient solvent condensation, e.g., in an exhaust waste vapor condenser, to avoid that ignitable solvent concentrations are conducted from the pump. Otherwise, the exhaust pipe after the pump must be fixed and conductive and suction must be done in an explosion-proof area.
	Ensure equipotential bonding between the pump, the VDL vacuum drying oven and, if appropriate, the pump module using the connections of the grounding conductors ac- cording to the grounding concept (Chap. 6.8).
	Confirm that the vacuum pump is designed for a gas inlet temperature corresponding to the used drying temperature, or take appropriate measures to cool down the extracted vapor before it enters the vacuum pump.
	Use ATEX compliant vacuum pumps providing an integral protective device for the pump OR Install a current-dependent, delayed protective device for the pump (for the triggering time of this protective device, see the manufacturer's specifications). The pro- tective and monitoring device must not be able to turn on independently again or be re- leased.
	Use ATEX compliant vacuum pumps providing an integral explosion proof switch OR make sure that the switch gear box is either installed outside the hazardous area or that it is explosion proof.

A Contraction

The ATEX compliant vacuum pump offered by BINDER provides an integral protective device for the pump and an integral explosion proof switch.

1.7.2.2 Observing the permissible gas inlet temperature

Confirm that the vacuum pump / vacuum system is designed for a gas inlet temperature corresponding to the used drying temperature, or take appropriate measures to cool down the extracted vapor before it enters the vacuum pump / vacuum system. If the gas inlet temperature is too high and then becomes even warmer by compression in the pump, the resulting temperature (of the gas-solvent mixture inside the pump) could exceed the solvent's temperature class and auto-ignition temperature. **The ATEX compliant vacuum pumps offered by BINDER are designed for a gas inlet temperature of 40 °C / 104 °F max.** Do NOT exceed this temperature.

EX	Fire and explosion hazard by exceeding the auto-ignition temperature of the solvent due to excessive gas inlet temperature
	Damage to the vacuum pump. Serious injury or death from burns and / or explosion pressure.
	Ø Do NOT exceed the maximum gas inlet temperature of the pump (ATEX compliant vacuum pumps from BINDER: 40 °C).
	When operating with a higher set-point temperature take appropriate measures to cool down the extracted vapor before it enters into to the vacuum pump.

1.7.2.3 Technical Ventilation (extraction)

When manipulating the vacuum pump (removing the filled condensate catchpot of the pump) or in the event of an error (e.g. dropping or spilling the filled condensate catchpot) spreading of an explosive atmosphere to unprotected parts of the pump or the vacuum drying oven would be possible.

The operator must provide active extraction (technical ventilation according to country-specific regulations – TRBS 2152 Part 2 for Germany) prior to commissioning and manipulating the vacuum pump. Extraction must include the entire installation area of the vacuum drying oven, the pump and, if appropriate, the pump module. Handling the pump always takes place under technical ventilation.

This will prevent spreading of an explosive atmosphere to unprotected chamber parts other than the defined area (see Chap. 3.5).

<u>/EX</u>	Explosion hazard due to the spread of an explosive atmosphere to unprotected parts of the pump or the vacuum drying oven and ignition due to electric sparking or hot surfaces.		
	Serious injury or death from burns and / or explosion pressure.		
	Provide active suction (technical ventilation according to country-specific regulations (TRBS 2152 Part 2 for Germany) prior to commissioning the vacuum pump.		
	Extraction must include the entire installation area of the vacuum drying oven, the pump and, if appropriate, the pump module.		
	When using the pump module, connect an extraction system to the provided exhaust port as described in the mounting instructions of the pump module (Art. no. 7001-0137).		

1.7.3 Safety instructions on the charging material

The temperature class of the inner chamber according to IEC 60079-0 can be T1, T2, or T3. Only introduce substances with an auto-ignition temperature that is higher than 200 °C / 392 °F. You can use a solvent which would form an explosive mixture with air under normal conditions.

If the auto-ignition temperature of a solvent contained in the drying material is exceeded during the drying process, there is an immediate risk of fire and explosion. This chamber is not suitable to dry substances with an auto-ignition temperature below 200 °C / 392 °F. Substances falling under explosion group / gas group IIC are not permitted (e.g. carbon disulfide, hydrogen).

Combustible dusts are generally not permitted, neither in the vicinity nor as a load.



Familiarize yourself with the physical and chemical properties of the charging material, as well as the contained moisture constituent and its behavior with the addition of heat energy and changes in pressure. No dangerous chemical reactions must occur during the drying process.

Fire and explosion hazard caused by chemical reactions with the addition of heat energy and changes in pressure.
Serious injury or death from burns and / or explosion pressure.
Make sure that no dangerous chemical reactions of the loading material can occur dur- ing the drying process.

3	Familiarize yourself with any potential health risks caused by the charging material, the con-
S	tained moisture constituent or by reaction products that may arise during the drying process.
	Take adequate measures to exclude such risks prior to putting the VDL vacuum drying oven
	into operation.

1.7.4 Safety instructions on operating the vacuum drying oven

Ŕ	Note the following points before starting up the oven:
5	When loading the chamber and possibly at the moment of unloading, also in the context of intended use, an explosive mixture may form in the working space. Define a safety area of at least 1m from the chamber front and ensure active extraction (technical ventilation).
	The walkable installation and operating surface of the chamber must be conductive. This installation and operating surface must be connected to the vacuum drying oven according to the grounding concept. Cyclic measurements of the equipotential bonding are required.
	The operator must ensure an appropriate ventilation of the loading area in front of the ov- en front prior to commissioning of the chamber.
	Ensure that at no time any solvent vapors could enter in the area of the electrical installa- tion room and the operating panel.
	Provide technical ventilation in the area of the vacuum pump stand, particularly in the areas of the condensate catchpot (when emptying it) and the exhaust air of the vacuum pump.
	The personal protective equipment (PPE) of the operating personnel must be ESD pro- tected.
	Only trained personnel with password authorization may work on the VDL vacuum drying oven.
-	



Electrical hazard by water entering the chamber. Deadly electric shock.

- Ø The equipment must NOT become wet during operation, cleaning, or maintenance.
- $\ensuremath{\varnothing}$ Do NOT install the equipment in damp areas or in puddles.
- > Set up the equipment in a splash-proof manner.



Electrical hazard due to damage to the equipment

Deadly electric shock.

- $\varnothing\,$ Do NOT insert any objects, particularly metallic objects, in louvers or other openings or slots on the chamber
- ${\it \oslash}~$ Do NOT operate the chamber if the housing is damaged.
- \varnothing Do NOT operate the chamber if the power cord is damaged.
- > Disconnect the chamber from the power supply in case of an obvious malfunction.



Danger of burning when touching the hot inner surfaces during operation. Burns.

 $\varnothing\,$ Do NOT touch the inner surfaces or the charging material during and after operation.

When operating the VDL vacuum drying oven with inert gas correctly follow the technical ventilation measures, as described in the DGUV guidelines 213-850 on safe working in laboratories (for Germany).

Do not start up the chamber without active technical ventilation .

During operation with inert gas the chamber is supplied with an oxygen displacing gas (e.g. N_2). Inert gases in high concentrations are hazardous to health. They are colorless and almost odorless and therefore practically imperceptible. Inhalation of inert gases can cause drowsiness up to respiratory arrest. When the O_2 content of the air decreases below 18%, there is risk of death from lack of oxygen. Any gas that might escape has to be led out via good room ventilation or a suitable exhaust system.



- > Respect the relevant regulations for handling inert gases.
- > When decommissioning the vacuum drying oven, shut off the inert gas supply.

If solvent-containing air penetrates the electrical area of the oven, explosions may result.







DANGER

Explosion hazard due to operating the oven with material containing solvent that may be able to form an explosive mixture with air.

Serious injury or death from burns and / or explosion pressure.

Follow the measures listed below for operation with solvent-containing materials that can form an explosive mixture with air.

If the following precautions are not followed,	the vapors	resulting from	heating of th	he solvent car	n ignite on
the hot walls of the inner chamber		-	-		-

(k)	Required measures for operation with solvent-containing materials that can form an explosive mixture with air:
	• Sweep the area for electrical equipment and controller housing with compressed air or inert gas with maximum overpressure for at least 10 minutes. Subsequent sweeping of the area for electrical equipment and controller housing with an overpressure of at least 25 Pa (recommendation: 40 Pa) must take place during the entire operating cycle and must be monitored at the manometer on the chamber front.
	 Only after completing this sweeping time, put the chamber in operation.
	• Take the auto-ignition temperature from the safety specifications of the solvent. In the case of solvent mixtures, use the auto-ignition temperature of the material with the lowest auto-ignition temperature. Make sure that the auto-ignition temperature is above 200 °C.
	 Enter the temperature set-point (drying temperature) on the controller.
	 Set the safety controller (temperature limiter class 2). Recommended setting: safety con- troller mode "Limit", safety controller value approx. 5 °C above the set-point.
	• During the drying process, use only those solvents for which the auto-ignition temperature has been entered.
	 Make sure that the technical ventilation is active. Introduce the drying material.
	• Start the drying process. The heating unit is only released when a pressure threshold of 100 mbar is reached.
	 Make sure that sweeping the area for electrical equipment and controller housing with at least 25 Pa overpressure (see manometer display) takes place during the entire operating cycle. Recommended value: 40 Pa.
	• The duration of the drying process can be determined by means of the pressure display on the controller. When the pressure drops to the set-point, the drying process is finished.
	• Make sure that the technical ventilation is active. After termination of the drying process, ventilate the vacuum drying oven with ambient air or inert gas. Unload the loading material and turn off the oven.
	• Sweep the area for electrical equipment at least 10 minutes with compressed air or inert gas (recommended).
	• Make sure that the technical ventilation is active when emptying the condensate catchpot of the vacuum pump.
	 Make sure that sweeping the area for electrical equipment and controller housing with at least 25 Pa overpressure (see manometer display) is active when emptying the conden- sate catchpot of the vacuum pump. Recommended value: 40 Pa.
	 Before starting a new drying process with a different solvent, check again the auto-ignition temperature at the safety specifications of the solvent. In the case of solvent mixtures, use the auto-ignition temperature of the material with the lowest auto-ignition temperature. Make sure that the auto-ignition temperature is above 200 °C.

1.8 Ex classification of the chamber and immediate surroundings

The VDL vacuum drying oven is an assembly in the sense of ATEX Directive 2014/34/EU with the following Ex classification:

🕼 II 2/3/- G IIB T3 Gb/Gc/- X

Explanation:

П	Use of the device above ground
2	Device category 2 per ATEX Directive 2014/34/EU Suitability for areas in which explosive atmospheres may occur occasionally. Inner chamber (drving chamber), tubing / line to the vacuum pump, areas inside the vacuum
	pump. See images of the areas in Chap. 3.5.
3	Device category 3 per ATEX Directive 2014/34/EU
	Suitability for areas in which explosive atmospheres may occur, on a rare and temporary basis:
	The entire device, with the exception of the device plug, is designed in Device category 3 in relation to the environment
	Heater tubes (without electrical connections), Safety temperature limiter (TL), Pt 100 controller sensor, Pt 100 heating sensor
	Surrounding of the chamber, loading area, area of installation of the vacuum pump, pump mod- ule. See images of the areas in Chap. 3.5.
-	No category per ATEX Directive 2014/34/EU
	Device power plug (unprotected device area).
	The device power plug is unprotected. The electrical connection must therefore be established outside a zone.
	See images of the areas in Chap. 3.5.
G	Device category G per ATEX Directive 2014/34/EU
	Gas: Do not introduce combustible dust into the chamber or allow combustible dusts to be pre- sent in the vicinity of the chamber.
IIB	Equipment group IIB
	Substances falling under Gas group / Explosion group IIA or IIB are permitted. Substances falling under Gas group / Explosion group IIC are not permitted.
Т3	Temperature class of the inner chamber: T3 acc. to IEC 60079-0
	Materials of temperature classes T4, T5, and T6 are not permitted. Introduce into the chamber only materials whose auto-ignition temperature exceeds 200 °C / 392 °F
Gb	Equipment protection level (EPL) Gb acc. to EN IEC 60079-0 / EN ISO 80079-36
	Suitability for areas in which explosive atmospheres may occur occasionally.
	Inner chamber (drying chamber), tubing / line to the vacuum pump.
Gc	Equipment protection level (EPL) Gc acc. to EN IEC 60079-0 / EN ISO 80079-36
	Suitability for areas in which explosive atmospheres may occur on a rare and temporary basis (fault):
	Chamber areas flushed with compressed air: Electrical installation area, electrical connection of the heater.
-	No equipment protection level (EPL) Gc acc. to EN IEC 60079-0 / EN ISO 80079-36
	Device power plug (unprotected device area)



Х	Specific operating conditions:		
	Technical ventilation required		
	Equipotential bonding		
	• Sweeping the area for electrical equipment for at least 10 minutes before turning on		
	 Ambient temperature during operation: +18 °C up to +32 °C. 		
	Use only humid cloths to wipe the chamber		

The "VDL vacuum drying oven" assembly includes the following components and devices in the sense of the ATEX directive 2014/34/EU:

• Inner chamber (Container, not a device in the sense of the ATEX directive 2014/34/EU)

It is a purely mechanical component with no risk of ignition. No classification.

• **Control** (controller)

The controller is located in the overpressure-swept controller housing (instrument triangle). No classification.

• Heating pipes: Zone 2 is possible at the place of installation

There is no risk of ignition from these mechanical components. No classification

• **Safety temperature limiter** (TL): Mechanical temperature monitoring by means of an expansion vessel, which switches a relay, which in turn leads to the heating being switched off, and on a self-holding circuit, which is reset by disconnecting and reconnecting the power plug. No classification

The expansion vessel is located in the area of the heating piping (zone 2 possible). It is a purely mechanical component with no risk of ignition.

The relay and self-holding circuit are located in the overpressure-swept electrical installation area

• Pt 100 controller sensor and heating sensor

Both sensors are located on the heating piping (zone 2 possible)

Ex [ic]	Ignition protection Intrinsic safety "i" per EN IEC 60079-11
	Mechanical component
	Equipment protection level: Increased protection "ic", suitable for placement in Zone 2
	🕼 II 3 G Ex ic IIB T3 Gc

• Optional Object temperature sensor (simple equipment) with barrier (isolation amplifier)

 Ex [ib]
 Ignition protection Intrinsic safety "i" per EN IEC 60079-11

 Equipment protection level: high protection "ib", suitable for placement in Zone 1 (chamber interior) or 2

 Image: Second Second

• Pressure sensor with barrier (isolation amplifier)

Ex [ib]	Ignition protection Intrinsic safety "i" per EN IEC 60079-11		
	Equipment protection level: high protection "ib", suitable for placement in Zone 1 (chamber interior) or 2		
	II 2 G Ex ib IIB T3 Gb		

• **Pressure switch** (limit switch and relay) 100 mbar

It is located in the overpressure-swept electrical installation area. No classification

• **Power plug**: Connection outside of a zone required

No classification, unprotected.

• Electrical installation area and controller housing: enclosure (overpressure, sweeping with compressed air)

Ex pzc	Ignition protection Pressurized enclosure "p" per EN IEC 60079-2
	Equipment protection level: Increased protection "pzc", suitable for use in Zone 2 (chamber housing as protection against an explosive atmosphere in the event of a fault)
	🕼 II 3 G Ex pzc IIB T3 Gc

1.9 Intended use

(ky)	Following the instructions in this operating manual and conducting regular maintenance work (chap. 25) are part of the intended use.
------	--

Any use of the chambers that does not comply with the requirements specified in this Operating Manual shall be considered improper use.

Other applications than those described in this chapter are not approved.

Use

VDL vacuum drying ovens are suitable for drying and heat treatment of solid or nonflammable pulverized charging material, as well as bulk material, using the supply of heat under vacuum.

During this process, the contained solvent may be able to form an explosive mixture with air under normal conditions. Ignition of an explosive atmosphere is prevented in the VDL vacuum drying ovens by various safety measures. The maximum drying temperature lies by a standard safety factor below the maximum permitted auto-ignition temperature. The drying temperature must lie below the sublimation point of the loading material.

The VDL vacuum drying ovens are approved for drying of materials with organic solvents. This may cause unlimited amounts of solvents to appear temporarily. The chambers are equipped with an explosion-proof inner chamber.

The VDL vacuum drying ovens are not intended for installation in a Zone 1 or 0. The chamber must not be installed or operated in an occasionally or continuously / for long periods / frequently potentially explosive area. Measures must be taken to prevent the spread of explosive atmospheres to unprotected areas.

The chamber plug (power plug) is unprotected because it must be disconnected in case of an emergency to completely separate the chamber from the power supply. therefore the electrical connection must be established outside a zone.

Temperature class

The temperature class of the inner chamber according to IEC 60079-0 is T3. It depends on the maximum operation temperature inside the oven. The auto-ignition temperature is determined from the safety specifications of the solvent used. In the case of solvent mixtures, the solvent with the lowest auto-ignition temperature as this is critical.

According to IEC 60079-0 the VDL vacuum drying ovens are NOT suitable for the temperature classes T4, T5 and T6. Insert only substances with an auto-ignition temperature that is higher than 200 °C / 392 °F.

The information listed on the on the type plate.for explosion protection is essential for classification.

For the Device category, refer to the area classification information on the site of installation in Chap. 3.5.

Requirements for the chamber load

Insert only substances with an auto-ignition temperature that is higher than 200 °C / 392 °F into the VDL vacuum drying ovens. The chambers are not suitable to dry substances with an auto-ignition temperature below 200 °C / 392 °F. Substances falling under Gas group / Explosion group IIC are not permitted (e.g. carbon disulfide, acetylene, hydrogen. Substances falling under groups II A and II B may be introduced.

The VDL vacuum drying ovens are NOT suitable for the heat treatment of substances, which tend towards exothermal decomposition, or for materials that come under the legal definition of explosives. Such substances must not be introduced into the oven. Dangerous chemical reactions must not occur during the drying process. Exothermal reactions must definitely be excluded. Familiarize yourself with the physical and chemical properties of the loading material, as well as the contained moisture constituent and its behavior with the addition of heat energy and changes in pressure. Familiarize yourself with any potential health risks caused by the loading material, the contained moisture constituent or by reaction products that may arise during the temperature process. Take adequate measures to exclude such risks prior to putting the chamber into operation.

VDL vacuum drying ovens are NOT suitable for use in conjunction with explosive dust atmospheres or hybrid mixtures. Combustible dust are generally not permitted.





The loading material shall not contain any corrosive ingredients that may damage the machine components made of stainless steel and aluminum. Such ingredients include in particular acids and halides. Any corrosive damage caused by such ingredients is excluded from liability by BINDER GmbH.

Medical devices

The chambers are not classified as medical devices as defined by the Medical Device Directive 93/42/EEC.

Equipotential bonding

Safe grounding can avoid electrostatic ignition hazards. The most important protective measure is to connect and ground all conductive parts. All conductive parts must have electrical potential. The grounding plan (Chap. 6.8) must be implemented.



Avoid electrostatic charges. Clean the device only with a damp cloth. Avoid rubbing with non-conductive materials.

Personnel Requirements

Only trained personnel with knowledge of explosion protection and knowledge of the Operating Manual can set up and install the chamber, start it up, operate, clean, and take it out of operation. Service and repairs call for further technical requirements (e.g. electrical know-how), as well as knowledge of the service manual. Follow the requirements for PPE (ESD protection).

Installation site requirements

The chambers are designed for setting up inside a building (indoor use).

Provide active extraction (technical ventilation according to country-specific regulations – TRBS 2152 Part 2 for Germany). It must cover the entire installation area of the VDL and the vacuum pump stand. Observe the area classification in the surroundings of the chamber (chap. 3.5.3). Suction must be active during the entire operation of the chamber and when handling the condensate catchpot of the pump. Suction must be conducted into an explosion-proof area.

If the technical ventilation fails, automatically switch off power to the device.

VDL vacuum drying chambers are not intended for installation in a Zone 0 or 1. Measures must be taken to prevent the spread of explosive atmospheres to unprotected areas. It must be possible to turn off the device immediately in the event of a fault: Pull the power plug or operate e.g. a customer's explosion-protected emergency stop switch.

The requirements described in the Operating Manual for installation site and ambient conditions (Chap. 5) must be met.

In case of foreseeable use of the chamber there is no risk for the user through the integration of the chamber into systems or by special environmental or operating conditions in the sense of EN 61010-1:2010. For this, the intended use of the chamber and all its connections must be observed.

1.10 Foreseeable Misuse

Other applications than those described in chap. 1.8 are not approved.

This expressly includes the following misuses (the list is not exhaustive), which pose risks despite the inherently safe construction and existing technical safety equipment:

- Non-observance of the Operating Manual
- Non-observance of information and warnings on the chamber (e.g. controller messages, safety identifiers, warning signals)
- Installation, startup, operation, maintenance and repair by untrained, insufficiently qualified, or unauthorized personnel
- Missed or delayed maintenance and testing
- Non-observance of traces of wear and tear
- Operating the equipment without ESD protective equipment (e.g., clothing, gloves, shoes)
- Setting down the material to be loaded in the area around or on top of the chamber
- Occurrence of an impermissible zone outside specified areas (see Chap. 3.5)
- Improper termination of the drying process after incorrect loading with inadmissible solvent with too low an ignition temperature: Ventilating or opening the chamber without waiting for it to cool
- Passing on passwords for the admin level to users
- Emptying the condensate catchpot of the pump without having prior turned off the vacuum pump
- Insertion of materials, which are excluded or not permitted by this Operating Manual and/or are not permissible according to the Labeling on the type plate.

- Non-compliance with the admissible parameters for processing the respective material.
- · Installation, testing, service or repair in the presence of solvents
- Material to be loaded remaining in the chamber after turning off.
- Loading non-approved solvents
- Incomplete ground connections for all system parts in the installation area
- Introduction of rust into the device
- Installation of replacement parts and use of accessories and operating resources not specified and authorized by the manufacturer
- Structural changes to the chamber without a subsequent risk assessment by the operator's ATEX representative
- Failure to observe the inspection and maintenance regulations (inspection before initial commissioning, recurring tests, inspection after maintenance or repairs, qualification of the tester)
- Commissioning after maintenance or repairs without passing the electrical safety test
- Commissioning after maintenance or repairs without passing the explosion protection test.
- Commissioning without correctly and completely grounding in accordance with the grounding plan
- Non-observance of traces of wear and tear, in particular rust
- Installation, startup, operation, maintenance or repair of the chamber in absence of a risk assessment and operating instructions from the operator
- Deliberate or careless handling of the chamber during operation (except the permitted operation of the controller).
- Bypassing or changing protective systems, operation of the chamber without the designated protective systems
- · Establishing or disconnecting an electrical connection in the presence of an explosive atmosphere
- Non-observance of messages regarding cleaning and disinfection of the chamber.
- Wiping the chamber with a dry cloth, generating static charge
- Spilling water or cleaning agent on the chamber, water penetrating into the chamber during operation, cleaning or maintenance.
- Cleaning activity while the chamber is turned on.
- Operation of the chamber with a damaged housing or damaged power cord
- Continued operation of the chamber during an obvious malfunction
- Insertion of objects, particularly metallic objects, in louvers or other openings or slots on the chamber
- Human error (e.g. insufficient experience, qualification, stress, exhaustion, laziness)

To prevent these and other risks from incorrect operation, the operator shall issue operating instructions (chap. 2.3). The operator is also recommended to create Standard Operating Procedures (SOPs) (chap. 2.6, certain example avoidance measures are provided here).



Explosion hazard due to formation of explosive atmosphere in the pres- ence of hot surfaces during air supply	Serious injury or death from burns and / or explo- sion pressure.	Observe the safety instructions in the operating manual and follow the instructions for correct air supply (breaking the vacuum). The "Manual ventilation" plug (7) must not be removed while the drying process is still running. If the drying process has not been completed, the interior of the chamber must have cooled down sufficiently before air supply and opening the door.
Normal operation with high concentration of inert gas	Danger of suffocation. Death by suffocation.	On the chamber side, gassing with inert gas is automatically interrupted when the ambient pressure is reached. Observe the warnings in the Operating Manual and follow the instructions for installation, tech- nical ventilation measures, and decommission- ing. Respect the relevant regulations for handling inert gas.
Explosion hazard due to mechanical spark for- mation in an explosive atmosphere by inserting or removing the slide-in modules in the pres- ence of an explosive atmosphere	Serious injury or death from burns and / or explo- sion pressure.	Observe the warnings in the Operating Manual and follow the instructions for inserting or remov- ing the expansion racks.
Explosion hazard due to mechanical formation in an explosive atmos- phere due to rust	Serious injury or death from burns and / or explo- sion pressure.	Observe the warnings in the operating instruc- tions and follow the instructions for checking the chamber and expansion racks for corrosion. Do not use corroded components. Never allow rust to permeate into the chamber.

1.11 Residual Risks

The unavoidable design features of a chamber, as well as its proper field of application, can also pose risks for the user, even during correct operation. These residual risks include hazards which, despite the inherently safe design, existing technical protective equipment, safety precautions and supplementary protective measures, cannot be ruled out.

Messages on the chamber and in the Operating Manual warn of residual risks. The consequences of these residual risks and the measures required to prevent them are listed in the Operating Manual. Moreover, the operator must take measures to minimize hazards from unavoidable residual risks. This includes, in particular the Operator measures described in chap. 2. Residual hazards are to be taken into account by the operator in their risk assessment. This includes, in particular, issuing operating instructions.

The following list summarizes the hazards against which this Operating Manual and the Service Manual warn, and specifies protective measures at the appropriate spots (list is not exhaustive):

• Flames, explosion

Unpacking, Transport, Installation

- Sliding or tilting the chamber
- Setup of the chamber in unauthorized areas
- Installation of a damaged chamber
- Installation of a chamber with damaged power cord
- Inappropriate site of installation
- Missing protective conductor connection
- Use of unsuitable pump or vacuum systems
- Improperly connected pump
- Missing or improperly executed equipotential bonding
- Incorrect connection and insulation of the switch contacts for the measuring access port (optional)
- · Missing or improperly designed technical ventilation in the installation area

Normal operation

- Assembly errors
- · Lack of electrical testing before initial commissioning or recommissioning
- Insufficient or missing technical ventilation (extraction) at the installation area of VDL and pump
- · Contact with hot surfaces on the housing
- · Contact with hot surfaces in the interior and inside of doors
- Emission of non-ionizing radiation from electrical operating resources
- Use of inert gas in higher concentration (optional)
- Use of unsuitable pump and discharge
- Excessively high gas intake temperature or insufficient cooling of the extracted vapor before entering the vacuum pump
- Contact with live parts in normal state

Cleaning and Decontamination

- Explosive atmosphere during cleaning and decontamination
- Electrostatic charges
- Penetration of water into the chamber
- Inappropriate cleaning and decontamination agents
- Enclosure of persons in the interior

Malfunction and Damage

- Continued operation of the chamber during an obvious malfunction or outage of the heater or vacuum system
- Contact with live parts during error status
- Operation of a unit with damaged power cord

Maintenance

- Maintenance work on live parts.
- Explosive atmosphere during maintenance
- Execution of maintenance work by untrained/insufficiently qualified personnel

- Electrical safety analysis during annual maintenance not performed
- Verification of explosion protection during annual maintenance not performed
- Incorrect and incomplete grounding before recommissioning

Trouble-shooting and Repairs

- Non-observance of warning messages in the Service Manual
- Trouble-shooting of live parts without specified safety measures
- Absence of a plausibility check to rule out erroneous inscription of electrical components
- Performance of repair work by untrained/insufficiently qualified personnel
- Inappropriate repairs which do not meet the quality standard specified by BINDER
- Use of replacement parts other than BINDER original replacement parts
- Electrical safety analysis not performed after repairs
- Verification of explosion protection not performed after repairs

2. Operator responsibility, documentation, and measures

This is NOT an exhaustive list of the required measures and documents! Follow applicable national and international regulations.

The chamber is intended for commercial use. The operator must know, comply with, and implement the relevant regulations on occupational safety. In particular, this includes the conditions of the Industrial Safety Regulation 1999/92/EC (Title: Improvement of the Health Protection and Safety of Workers Who May Be Endangered by Explosive Atmospheres). Known as ATEX 137, this directive was implemented in Germany through the Industrial Safety Regulation (BetrSichV) and the Ordinance on Hazardous Substances (GefStoffV).

2.1 Risk assessment / explosion protection document

First, a **risk assessment** is carried out to determine the hazards that are present where the chamber is used due to the working conditions. When documenting the risk assessment, the operator must provide specific evidence of the hazards posed by explosive mixtures in the **explosion protection document**.

When creating the explosion protection document, follow applicable national regulations (for Germany: Industrial Safety Regulation (BetrSichV); Ordinance on Hazardous Substances (GefStoffV)).

In particular, the explosion protection document must indicate

- Determination and evaluation of explosion hazards
- Explosion protection plan

The explosion protection plan to be created by the operator represents the entirety of the technical and organizational measures for explosion protection determined and specified on the basis of the risk assessment. These measures should prevent the formation of hazardous explosive mixtures or to limit or prevent their ignition. They should also minimize the spread of an explosion and its effects

The explosion protection document serves to document the results of the risk assessment in accordance with § 6 Para. 9 GefStoffV (for Germany).

- Classification as explosion protection zones
- Explosion protection measures
- Cooperation with various companies
- Test findings on explosion protection and technical protection measures

2.2 Employee training and protocols

The operator must ensure that all employees have read and understood the Operating Manual.

Before employees use the vacuum drying oven and related work equipment for the first time, the operator must provide them with sufficient and suitable information on the hazards presented and measures to be taken in a form and language that is understandable.

This includes the information resulting from the risk assessment:

- Hazards when using the vacuum drying oven and related work equipment, in particular fire and explosion hazards, functioning of protective devices
- Required protective measures and code of conduct
- Necessity of wearing personal protective equipment, which must be implemented ESD protected.

- Procedure for cleaning and repair work
- Measures for operational interruptions, accidents, and first aid for emergencies

The operator must clearly define the responsibilities for installation, operation, troubleshooting, maintenance, and cleaning. It must be ensured that untrained personnel have no access to the chamber and related work equipment and systems.

The operator must instruct employees with regard to their activity before they begin using the vacuum drying oven and related work equipment. Following this, further instruction must be provided at regular intervals, at least once per year. The date of each instruction and the names of the instructed persons must be recorded in writing.

It is essential for safe and secure operation of the device that the user be familiar with the safety plan from the manufacturer and the explosion protection plan from the operator.

Do not work on the chamber or in its surroundings, under any circumstances, after consuming alcohol, drugs, and certain medications which may impair the ability to perceive, assess, and react.

2.3 Operating instructions

The measures to avoid hazards resulting from the risk assessment (Chap. 2.1) are to be specified as **Operating instructions**. Before employees use the vacuum drying oven and related work equipment for the first time, the operator must specify instructions for safe use in one or more operating instructions. These must comply with regulatory requirements and be verified regularly to ensure that they are up to date.

When creating the operating instructions, follow applicable national regulations (for Germany: Industrial Safety Regulation (BetrSichV); Ordinance on Hazardous Substances (GefStoffV)).

Keep these operating instructions with the chamber at all times in a place where they are clearly visible. They must be comprehensible and written in the language of the employees.

2.4 Safety data sheets

A central component of the VDL safety plan is determining the correct **auto-ignition temperature** of the solvent used. The corresponding maximum drying temperature (safety temperature) is then determined according to the information panel "Temperature setting". In the case of solvent mixtures, using the solvent with the lowest auto-ignition temperature is essential. The data sheets for the solvents used must therefore be available at all times. They can be maintained in writing or electronically. If they are stored electronically, it must be ensured that all employees have access when needed. If an electronic medium is – temporarily – not available, another source must be found or work must be postponed for this time. (DGUV 4.1)

2.5 **Protective equipment**

The operator must provide the operating personnel with the necessary protective equipment.

The personal protective equipment (PPE) of the operating personnel must be implemented ESD protected.

When using gloves make sure that they are conductive. The same applies for shoes and other elements that can lead to electrostatic charges.

2.6 Standard Operating Procedures (SOPs)

The operator is responsible to determine the correct auto-ignition temperature of the solvent. To ensure this, creating **Standard Operating Procedures** (SOPs) is recommended.

In particular, this should prevent the **Residual Risks due to incorrect operation** specified in Chap. 1.11 and the exceeding of the auto-ignition temperature of the solvent.

When creating Standard Operating Procedures, take into account the information and instructions in this Operating Manual. The following are some **examples** of these risks and suggestions for measures to be taken. These are to be created, adapted, and supplemented by the operator using the risks determined and respective conditions at the installation site.

Risk	Measures
Operation of the device by untrained users	 Ensure knowledge of the Operating Manual Use only ATEX-trained personnel Create operating instruction and standard operating procedures
Use of an unsuitable solvent with a too low ignition temper- ature Cause: Assumption of wrong solvent	 Prior to each new drying procedure check again the auto-ignition temperature with the safety specifications. Clearly label the material to be dried to avoid confusion Information: There is no risk during the proper drying process, since this takes place in a vacuum. There is only a risk in the event of premature air supply (termination of the drying process. Avoid premature air supply. Also observe the instructions in the Operating Manual.
Reloading with the a material with a lower auto-ignition tem- perature	• Prior to each new drying procedure check again the auto-ignition temperature with the safety specifications and the desired drying temperature. If appropriate, let the chamber cool down before reloading
Termination of the drying pro- cess due to inadmissible sol- vent with a too low ignition temperature. Ventilation with ambient air or opening the still hot chamber Cause: 2 operating errors: incorrect loading with an in- admissible solvent; improper Termination of the drying pro- cess	 Disconnect the power plug and turn off the pump. Let the chamber cool down to room temperature. Do NOT remove the "Manual ventilation" plug. Only ventilate when the interior temperature has cooled to room temperature. Only then open the door.
Unnoticed sensor drift or fail- ure of safety devices due to missing or delayed mainte- nance and tests	 Perform regular maintenance and the prescribed tests of the chamber. Create detailed maintenance and testing plans and ensure they are implemented.

This list is NOT exhaustive. The risks result from the risk assessment to be done by the operator (Chap. 2.1). The measures must be determined by the operator of the device based on the risks determined and the respective conditions at the installation site.

2.7 Testing and maintenance

The operator must ensure that the chamber is always in a technically functional state.

Observe the maintenance intervals specified by the manufacturer. If there is above-average strain, the intervals must be shortened accordingly.

The operator must regularly verify that the safety-related devices are functioning correctly.

Document tests with results and measures that were potentially initiated, as well as maintenance and repairs, in a system book.

For testing before commissioning, see Chap. 7

For recurring tests and maintenance, see Chap. 7.5, 7.6, 25.

2.8 Operation log

For safety reasons, keeping an operation log which documents each individual drying process is recommended.

The following contents should be entered and recorded:

- Type of solvent
- Auto-ignition temperature of the solvent; in the case of solvent mixtures: solvent with the lowest Auto-ignition temperature
- Entered temperature set-point (drying temperature)
- Drying temperature set-point
- Set safety controller mode temperature (Limit/Offset)
- Set safety controller value
- Date
- Signature

Use the following page as a specimen or compile it in a suitable form.

Operation log for the VDL vacuum drying oven

Solvent. In the Drying temcase of solvent Auto-ignition perature / Safety controller mixtures: solvent Safety controltemperature temperature mode Signature Date with the lowest ler value [unit] set-point [unit] Limit/Offset Auto-ignition [unit] temperature

Serial number.....
3. Description of the equipment

Vacuum drying is used for special drying problems, for which conventional drying methods cannot offer a solution due to physical limitations..

The VDL vacuum drying oven is approved for drying materials with organic solvents.

Ex classification

The chamber is equipped with an explosion proof inner chamber and additional measures for explosion protection.

The Ex classification of the vacuum drying oven VDL (assembly) acc. to ATEX Directive 2014/34/EU is

🔄 II 2/3/- G IIB T3 Gb/Gc/- X

The description of explosion protection on the type plate determines the chamber's classification.

Detailed information on the Ex classification of the assembly and the individual devices can be found in chap. 1.8.

The maximum possible surface temperature of the chamber interior is 160 °C / 320 °F.

Installation

The VDL vacuum drying oven may be installed in areas in which explosive atmospheres may occur on a rare and temporary basis. The entire chamber with the exception of the power plug is classified in category 3 in relation to the environment. The chamber plug (power plug) is unprotected, therefore the electrical connection must be established outside a zone

Temperature class

The temperature class of the inner chamber acc. to EN 60079-0 is **T3**. The temperature class of the entire chamber equals the temperature class of the inner chamber.

Controller

The chambers are equipped with a multifunctional microprocessor display controller with 2-channel technology for temperature and pressure. Temperature is indicated accurate to one-tenth of a degree, the pressure inside the chamber accurate to one 1 mbar. Pressure is measured by a firmly installed pressure sensor.

The chamber is regularly equipped with the MB2 display program controller. This efficient program controller is equipped with a multitude of operating functions, in addition to recorder and alarm functions. Programming of test cycles is easily accomplished via the modern MB2 touch screen controller and is also possible directly with a computer via Intranet in connection with the APT-COM[™] 4 Multi Management Software (option, chap. 24.1).

The chamber comes equipped with an Ethernetserial interfacefor computer communication and with a USB interface. In addition, the BINDER APT-COM[™] 4 Multi Management Software permits networking up to 100 chambers and connecting them to a PC for controlling and programming, as well as recording and representing temperature and pressure data. For further options, see chap. 24.

Material

The inner chamber is made of especially corrosion resistant stainless steel V4A (German material no. 1.4404, US equivalent AISI 316L) micro-polished. The rack holder and all of the chamber's vacuum connections and valves are made of especially corrosion resistant stainless steel V4A (German material no. 1.4571, US equivalent AISI 316Ti). The housing is RAL 7035 powder-coated. All corners and edges of the housing are also completely coated. When operating the chamber at temperatures above 150 °C / $302 \ ^{\circ}F$, the impact of the oxygen in the air may cause discoloration of the metallic surfaces (yellowishbrown or blue) by natural oxidation processes. These colorations are harmless and will in no way impair the function or quality of the chamber.

The chambers are jacket-heated. The preheating chamber technique ensures a completely homogeneous jacket temperature, ensuring uniform heat transfer into the inner chamber. The low-loss heat transfer to the material uses the aluminum vacuum expansion racks (or optionally available in stainless steel). The elastic-mounted safety glass window reliably compensates any overpressure or explosions that may occur. The laminated safety glass pane ensures proven and effective splinter protection in the event of an implosion.

The chambers provide a universal connection for inert gas / ambient air, a compressed air connection for sweeping the electrical installation area and the controller housing, and a measuring connection serving to connect a measuring access port.

All installable items, such as racks and rack holders, can be easily removed. The completely smooth inner chamber with its rounded corners and internally welded seams is easy to clean.

The minimum working temperature of the vacuum drying oven is approx. 10 °C / 18 °F above room temperature. The maximum temperature is 110 °C / 230 °F.

Vacuum pumps with a suction capacity of 1 m^3/h to 30 m^3/h are suitable for the VD vacuum drying oven.

3.1 Manufacturer's safety plan: Protective measures and equipment

The following measures were taken on the manufacturer's side in order to prevent ignition and explosions.

• Ignition source monitored via safety temperature limiter (TL) class 2

Only solvents with an auto-ignition temperature above 200 ° C may be entered into the chamber.

There is a safety margin of 20% of the minimum permissible auto-ignition temperature of 200 °C, related to the hottest point in the interior (where the heating is attached to the inner chamber). The maximum surface temperature of the inner chamber is 160 °C. Therefore, when operated correctly, the hot surfaces are always below the auto-ignition temperature of permitted substances.

The safety temperature limiter (TL) serves to protect the vacuum drying oven, its environment and loading material against exceeding the permitted temperature. It has a fixed switching threshold and prevents exceeding the maximum surface temperature of the inner chamber of 160 °C in the event of a fault. If this temperature is exceeded, the heater turns off. The TL protects the VDL vacuum drying oven, its environment and the loading material against impermissible excess temperatures and prevents exceeding the maximum surface temperature in case of a fault.

The safety temperature limiter (TL) provides mechanical temperature monitoring through an expansion tank. If the permissible temperature is exceeded, the heating is switched off via a relay and an additional self-holding circuit is activated, which is only reset when the power plug is removed and reconnected. This prevents the heating from being automatically switched on again via the relay. When the TL is triggered, an alarm message is displayed on the controller. An annual function check by the operator is recommended, for this a controller test routine is provided (chap. 16.5).

The setpoint can only be set up to the maximum drying temperature of 110 °C / 230 °F.

Control technology ensures that there are no temperature overshoots when heating up.

The interior is hermetically sealed against the heating system. The heating elements are always below the auto-ignition temperature.



Normal operation when used correctly: Even without taking into account the pressure control, which is also effective in practice, there is no ignition source during the drying process. This also applies in the event that the system is ventilated before the drying process finishes.

Fault: Incorrect loading with inadmissible solvent with a too low ignition temperature: Due to the vacuum, there is no ignition source during the drying process. The drying process could safely be ended. In order to cancel the drying process, it is the chamber must first have cooled to room temperature before ventilation and opening (chap. 9.10.4).

• Taking into account the volume dependence of the auto-ignition temperature

The surface temperature is not to exceed 80% of the auto-ignition temperature of the gas or fluid, measured in °C.

Action: The safety margin of 20% of the auto-ignition temperature. is sufficiently large (EN1127-1:2019).

• Safety pressure monitoring with heater release by pressure switch

There is no explosive atmosphere in a vacuum. The heater is only released starting with a pressure threshold of 100 mbar.

There is thus always a vacuum \leq 100mbar during drying.

The protective measure of ignition source monitoring provides redundant safety during the drying process: There are no hot surfaces at a pressure > 100 mbar, and, when used correctly, after the heater is released the hot surfaces are always below the auto-ignition temperature of permitted materials.

• Sweeping the area for electrical equipment and the controller housing (triangle instrument box) with compressed air

The area for electrical equipment and the controller housing are protected against penetration of explosive atmosphere by a technical ventilation system (minimum overpressure: 25 Pa). The user must monitor the pressure on the manometer on the chamber front, especially when loading and removing the loading material This reliably prevents explosive atmosphere to reach electrical or electronic parts of the VDL safety vacuum drying oven (protection against solvent-containing ambient air).

Heater shutdown in the event of component failure

In case of failure of the controller Pt100 temperature sensor or the heater Pt100 temperature sensor. The heater is turned off. On the controller an alarm message is displayed.

• Measures for lacking / incorrect maintenance / adjustment / sensor drift

Proper maintenance requires that the controller sensor is correctly adjusted. The safety temperature limiter (TL) provides sufficient safety against heating sensor drift.

Regular adjustment intervals for the controller sensor (annually) are specified (chap. 26.3).

• Prevention of electrostatic charges / grounding plan

All chamber components are at a common potential. The interior parts of the chamber are grounded. The outer powder-coated housing plates have a layer thickness of 60 μ m and are connected with the earth potential via the protective conductor connection.

A detailed grounding plan for the VDL, the pump module, the pump and the installation and loading area is provided, all components are prepared accordingly for grounding: Connections are available to ground the device and accessories. Achieving equipotential bonding according to the grounding plan of the manufacturer is mandatory, see operating manual chap. 6.8.

To create the connection between the vacuum drying oven and the pump, an antistatic PTFE hose is used. All conductive parts have the same electrical potential. Also the door handle is conductive.

Any clothing, shoes and gloves worn by the user shall be ESD protected.

When installed and operated as intended, there will be equipotential bonding for loading and unloading and there is no risk of charges that are hazardous to operation.

• Extraction

Active extraction (technical ventilation) during operation of the VDL is mandatory.

The extraction has to be provided as technical ventilation according to country-specific regulations (TRBS 2152 Part 2 for Germany). It must include the entire installation area of the vacuum drying oven and pump. In normal operation, it affects in particular the loading area of the chamber to limit and reduce any possible explosive atmosphere when loading the device.

Spreading of an explosive atmosphere to non-protected areas is prevented by the prescribed technical ventilation.

Fault: If solvents or solvent vapors inadvertently reach areas of the installation location (e.g. if the material to be loaded or the filled condensate catchpot of the pump fall down), the chamber must be turned off immediately (pull the power plug or operate e.g., a customer's explosion-protected emergency stop switch) in order to prevent explosive atmosphere from penetrating into non-protected areas. The technical ventilation at the installation site reduces the explosive atmosphere.

If, during a fault of the technical ventilation, material containing a solvent is located in the loading area of the chamber, it must be removed immediately. If material containing a solvent is located inside the chamber because it is being loaded at that moment, close the chamber door. The operator must ensure that no explosive atmosphere remains in the area around the chamber when there is no active technical ventilation. Ensure that the operator can manually turn off the chamber immediately (pull the power plug or operate e.g., a customer's explosion-protected emergency stop switch) in order to prevent the chamber from restarting automatically.

If, during a fault of the technical ventilation caused by a power failure, material containing a solvent is located in the loading area of the chamber, the operator must ensure that after the power has been restored, the technical ventilation and sweeping the electrical installation area and controller housing with maximum overpressure have been active for at least 10 minutes before turning on the chamber.

Sealing

The area for electrical equipment is sealed so far that an overpressure can be built up. In combination with sweeping with compressed air and the specified technical ventilation (extraction) provided by the operator, the penetration of solvent vapors into the area for electrical equipment, the chamber housing, and the controller housing is prevented when loading the device as well as when unloading material that has not completely dried.

Authorization levels of the chamber controllers with password assignment

This makes it easier to restrict the use to trained users.

• Construction of the pump module and mandatory extraction, requirements for vacuum pumps

Various constructive features and measures to be taken by the operator prevent solvent vapors from penetrating into the hot pump motor and into the electrical installation area in the event of incorrect operation, e.g. spilling the content of the condensate catchpot of the pump when emptying it:

- Installation of the entire system under extraction (technical ventilation), this must run when emptying.
- Use of Ex pumps corresponding to the zoning is mandatory
- An extraction system provided by the customer must be connected to the port of the pump module. This keeps the concentration in the pump module low
- The condensate collecting tray provided in the pump module prevents leakage



- The grounding plan / equipotential bonding prevents sparking
- The operator is responsible for the correct installation. He must ensure active extraction (technical ventilation) when emptying the condensate catchpot of the pump (with or without a pump module)
- The grounding plan / equipotential bonding prevents sparking
- The operator is responsible for the correct installation. He must ensure active extraction (technical ventilation) when emptying the condensate catchpot of the pump (with or without a pump module)

• Spring-mounted safety glass panel

The VDL vacuum drying oven is equipped with a large-surface area safety valve. The inspection window, consisting of ESG glass (toughened safety glass), is adjustable spring-mounted and serves as a safety valve in the event of explosion. The laminated safety glass pane provides splinter-protection.

Further measures to prevent accidents

· Indications on the type plate

For Ex classification, temperature classes and electrical data, please refer to the operating manual Chap. 1.6.

• Operating manual

An operating manual is available for each chamber.

• Temperature monitoring; safety, measurement, and control equipment

The chamber is equipped with a temperature display, which can be read from outside.

The safety, measuring, and control equipment is easily accessible.

Non-ionizing radiation

Non-ionizing radiation is not intentionally produced, but released only for technical reasons by electrical equipment (e.g. electric motors, power cables, solenoids). The machine has no permanent magnets. If persons with active implants (e.g. pacemakers, defibrillators) keep a safe distance (distance of field source to implant) of 30 cm, an influence of these implants can be excluded with high probability.

• Safety controller (temperature safety device class 2)

Temperature limitation via the controller by the safety controller serves to protect the vacuum drying oven, its environment and loading material against impermissible temperature exceeding., that could pose a fire risk. If the entered safety controller temperature is exceeded. The heater is turned off at all poles until manual reset (class 2).

The safety controller must be checked according to its function at appropriate intervals. Test: Set the safety controller value below the temperature set-point. The chamber must not reach the temperature set-point, but must turn off the heater when the safety controller value is reached.

Recommended setting: safety controller mode "Limit".

Visual and additionally activatable audible (buzzer) signals indicate temperature exceeding.

Protection against touchable surfaces

Tested according to EN ISO 13732-1:2008.

BINDER

• Floors

See operating manual chap. 5 for correct installation.

• Cleaning

See operating manual chap. 25.

• Maintenance

For maintenance instructions for the user, please refer to operating manual chap. 26. Detailed instructions are included in the service manual for this chamber.



3.2 Chamber overview



Figure 3: VDL 115 with MB2 controller

- (A) Area for electrical equipment
- (B) Triangular instrument box (controller housing) with chamber controller
- (C) Chamber door
- (D) Door handle
- (E) Elastic-mounted safety glass window



3.3 Triangular instrument box with MB2 controller

Figure 4: Triangular instrument box (controller housing) with MB2 program controller and USB interface



3.4 Connections on the rear of the chamber

BINDER







Figure 6: Rear connection panel VDL with options



- (1) Power cable
- (2) Connection cable to Ethernet interface for computer communication
- (3) 2 connection sockets (3a) and (3b):
 - (3a) Connection "Object temperature input" (option) for optional object temperature display
 - (3b) Connection "Analog output" (option) for optional analog outputs for temperature and pressure
- (4) Universal connection for inert gas / ambient air "GAS/AIR", adapter with hose olive Ø 8 mm / 0.31 *in*
- (5) Additional universal connection for inert gas / ambient air "GAS/AIR 2" (option), adapter with hose olive Ø 8 mm / 0.31 in
- (6) Vacuum connection with small flange DN16
- (7) Plug "Manual ventilation" for emergency ventilation in case of power failure
- (8) Heatsink
- (9) Pressure regulator for sweeping / overpressure
- (10) Compressed air connection for sweeping / overpressure

3.5 Area classification, information for the zone classification

The operator is to classify the zones. The following areas are identified below:

- Unprotected areas. The spread of an explosive atmosphere to unprotected device parts must be reliably prevented.
- Areas where, depending on the substances used, explosive atmospheres may occur on a rare and temporary basis. The creation of a zone outside the defined areas must be reliably prevented.



3.5.1 Area classification inside the chamber

Figure 7: Area classification of the closed chamber (view without housing, insulation, heater and outer chamber)

- (A) Controller housing (swept with compressed air)
- (D) Electrical installation area (swept with compressed air)
- (H) Inner chamber (usable volume)
- (7) Plug "Manual ventilation" for emergency ventilation
- (4) Universal connection for inert gas / ambient air "GAS/AIR"
- (5) Additional universal connection for inert gas / ambient air "GAS/AIR 2" (option)
- (6) Vacuum connection
- (12) Measuring connection

Occurrence of an explosive atmosphere:

occasionally: Inner chamber with tubing / line to the vacuum pump, and connections

3.5.2 Area classification in the surroundings of the chamber

The VDL vacuum drying oven with the exception of the power plug is classified in category 3 in relation to the environment . It may be installed in areas in which explosive atmospheres may occur on a rare and temporary basis.

The chamber plug (power plug) is unprotected because it must be disconnected in case of an emergency to completely separate the chamber from the power supply. therefore the electrical connection must be established outside a zone.

Spreading of an explosive atmosphere, which may occur on a rare and temporary basis, to unprotected areas must be reliably prevented by measures of the operator. In particular, this includes a sufficiently dimensioned one technical ventilation according to country-specific regulations (TRBS 2152 Part 2 for Germany).



Figure 8: Area classification in the surroundings of the chamber (schematic representation)

Occurrence of an explosive atmosphere:

occasionally: in the chamber interior with tubing

on a rare and temporary basis: in the ambiance of the chamber with the exception of the power plug

never (unprotected areas): Connection location of the power plug



3.5.3 Area classification in the surroundings of the chamber: extraction lead to the pump, location of the pump



Figure 9: Area classification in the surroundings of the chamber during operation (example)

Occurrence of an explosive atmosphere:

ccasionally: interior of VDL, line to the vacuum pump, pump

on a rare and temporary basis: surroundings of VDL and pump, interior of the pump module

4. Completeness of delivery, transportation, storage, and installation

4.1 Unpacking, and checking equipment and completeness of delivery

After unpacking, please check the chamber and its optional accessories, if any, based on the delivery receipt for completeness and for transportation damage. Inform the carrier immediately if transportation damage has occurred.

The final tests of the manufacturer may have caused traces of the shelves on the inner surfaces. This has no impact on the function and performance of the chamber.

Please remove any transportation protection devices and adhesives in/on the chamber and on the doors and remove the operating manuals and accessory equipment.

Due to different installation heights above sea level, a slight negative pressure in the inner chamber may prevent the door from being opened. Therefore after unpacking the chamber, remove the plug "Manual ventilation" (7) for emergency ventilation from the tube to ensure pressure equalization. After this, thoroughly reinstall the plug.



If you need to return the chamber, please use the original packing and observe the guidelines for safe lifting and transportation (chap. 4.2).

For disposal of the transport packing, see chap. 27.1.

If you ordered the optional pump module with a chemical membrane pump, the pump will be delivered in a separate box and must be fitted into the pump module and connected at the place of installation (see chap. 6.5.3).

Note on second-hand chambers (Ex-Demo-Units):

Second-hand chambers are chambers that were used for a short time for tests or exhibitions. They are thoroughly tested before resale. BINDER ensures that the chamber is technically sound and will work flawlessly.

Second-hand chambers are marked with a sticker on the chamber door. Please remove the sticker before commissioning the chamber.

4.2 Guidelines for safe lifting and transportation

After operation, please observe the guidelines for temporarily decommissioning the chamber (chap. 27.2).



• Permissible ambient temperature range during transport: -10 °C / 14 °F to +60 °C / 140 °F.

You can order transport packing for moving or shipping purposes from BINDER Service.

4.3 Storage

Intermediate storage of the empty chamber is possible in a closed and dry room. Observe the guidelines for temporary decommissioning (chap. 27.2).

- Permissible ambient temperature range during storage: -10 °C / 14 °F to +60 °C / 140 °F.
- Permissible ambient humidity: max. 70 % r.h., non-condensing

When after storage in a cold location you transfer the chamber to its warmer installation site, condensation may form. Before start-up, wait at least one hour until the chamber has attained ambient temperature and is completely dry.

5. Location of installation and ambient conditions

5.1 General requirements for installation

Set up the vacuum drying oven on a flat, even and non-flammable surface, free from vibration, in a wellventilated, dry location and align it using a spirit level or laser. The site of installation must be capable of supporting the chamber's weight (see technical data, chap. 28.3). The chambers are designed for setting up inside a building (indoor use). Provide active extraction (technical ventilation, chap. 5.2.2).

Minimum distances

- Distance between several chambers of the same size: 250 mm / 9.8 in
- Wall distances to rear: 100 mm / 3.9 in
- Lateral wall distances: 70 mm / 2.76 in
- Spacing above and behind the chamber: 100 mm / 3.9 in.





Permissible areas

The VDL vacuum drying oven may be installed in areas in which explosive atmospheres may occur on a rare and temporary basis. The entire chamber with the exception of the power plug is classified in category 3 in relation to the environment. The chamber plug (power plug) is unprotected, therefore the electrical connection must be established outside a zone.

VDL vacuum drying ovens are not intended for installation in a Zone 1 or 0. The chamber must not be installed or operated in an occasionally or continuously / for long periods / frequently potentially explosive area. Measures must be taken to prevent the spread of explosive atmospheres to unprotected areas. Spreading of an explosive atmosphere to the unprotected areas must be reliably prevented. Observe the information on zone classification (chap. 3.5).

Observe the instructions on extraction (technical ventilation, chap. 5.2.2). When installed as intended, there is no Zone 1 or 0 in the vicinity of the chamber.

Explosion hazard by penetration of an explosive atmosphere to unprotected areas.
Concus injury of dealth from burns and / of explosion pressure.
quently potentially explosive areas. It is not intended for installation in a zone 1 or 0.
Make sure that there are NO combustible dusts in the vicinity of the chamber
Make sure that air-solvent mixtures are NOT occasionally or continuously / for long periods / frequently in the vicinity of the chamber.
Strictly observe the relevant legal regulations about how to select an appropriate loca- tion.

The operator is responsible for the correct installation of the pump or other equipment (zone classification). Sufficient extraction (technical ventilation, chap. 5.2.2) also in the event of an error (e.g. damage / overfilling the condensate catchpot of the pump, or spilling or dropping containers or material to be loaded with solvents) must be provided.

The operator is responsible to use suitable pumps for pumping from zone 0 or 1.



Follow country-specific regulations for explosion protection.

If you ordered the optional pump module with chemical membrane pump, the vacuum pump will be delivered in a separate box and must be fitted into the module and connected at the place of installation (chap. 6.5.3).

Electrical connection

To completely separate the chamber from the power supply, you must disconnect the power plug. Install the chamber in a way that the power plug is easily accessible and can be easily pulled in case of danger. It is also possible to use a customer's explosion-protected emergency stop switch or a comparable power disconnector.

The chamber plug (power plug) is unprotected because it must be disconnected in case of an emergency to completely separate the chamber from the power supply. therefore the electrical connection must be established outside a zone.



For the user there is no risk of temporary overvoltages in the sense of EN 61010-1:2010.

5.2 Ventilation and extraction (technical ventilation)

5.2.1 Ventilation for heat removal in normal operation

Install the vacuum drying oven in a well-ventilated place.

NOTICE				
Danger of overheating due to lack of ventilation.				
Damage to the chamber.				
Do NOT set up chambers in non-ventilated recesses.				
Ensure sufficient ventilation for dispersal of the heat.				
Observe the prescribed minimum distances when installing the chamber (chap. 5.1)				

5.2.2 Technical ventilation during chamber operation and when emptying the condensate catchpot of the pump

Provide active extraction at the location of installation. The extraction shall be provided as technical ventilation according to country-specific regulations (TRBS 2152 Part 2 for Germany). It must include the entire installation area of the chamber.

In normal operation, it affects in particular the loading area of the chamber for the spatial limitation and reduction of any possible explosive atmosphere when loading the chamber. Also in the event of a fault (e.g. if the material to be loaded or the filled condensate catchpot of the pump falls down), it causes spatial limitation and reduction of any possible explosive atmosphere.

Suction must be active during the entire operation of the chamber and when handling the condensate catchpot of the pump. Extraction must lead into an explosion-proof area.



The operator must ensure active extraction before starting up the chamber. Extraction must be provided during the entire operation of the chamber as well as when handling the condensate catchpot of the pump. This ensures that solvent vapors never reach unprotected areas or accumulate in an impermissible manner.

If the technical ventilation fails, the power to the vacuum drying oven must be switched off. It must be ensured that the device can be switched off by the operator using an explosion-protected device: Pull out the power plug or operate e.g., a customer's explosion-protected emergency stop switch.

5.2.3 Air supply (breaking the vacuum) during operation with inert gas

When operating the VDL safety vacuum drying oven with inert gas, correctly follow the technical ventilation measures, as described in the DGUV guidelines 213-850 on safe working in laboratories, issued by the employers' liability insurance association (for Germany).

5.3 Equipotential bonding

The accessible installation and operating surface of the chamber must be electrically conductive. The accessible installation and operating surface of the chamber must be electrically conductive. This installation and operating surface must be connected to the vacuum drying oven and other equipment (e.g. Pump module, vacuum pump) according to the grounding concept. Provide cyclic measurements.

For the grounding concept see chap. 6.8.

When inserting or loading objects into the loading area , note that there may be a potential equalization. The personal protective equipment (PPE) of the operating personnel must be implemented ESD protected.

5.4 Ambient conditions

• Permissible ambient temperature during operation: +18 °C / 64 °F to +32 °C / 90 °F.



The ambient temperature should not be substantially higher than the indicated ambient temperature of +22 °C +/- 3 °C / 71.6 °F +/-5.4 °F to which the specified technical data relate. Deviations from the indicated data are possible for other ambient conditions.

- Permissible ambient humidity: 70 % r.h. max., non-condensing.
- Installation height: max. 2000 m / 6562 ft above sea level.

The maximum permissible ambient temperature of the vacuum pumps delivered by BINDER is 40 °C / 104 °F.

5.5 Compressed air / inert gas supply for sweeping the area for electrical equipment and controller housing

Before commissioning the chamber, connect the vacuum drying oven to the compressed air supply (chap. 6.3).

5.6 Fire extinguisher



During operation a fire extinguisher must be available.

5.7 Lightning protection device

The building in which the vacuum drying oven is installed must have a lightning protection system. All internal connections in the operator's building must contain lightning protection in accordance with EN/IEC 62305-3.

Lightning protection measures must be taken in order to prevent melting and spraying effects. The operator's zone classification shall be used to plan lightning protection measures. The lightning discharge paths must be designed so that heat or ignitable / spray sparks cannot become the ignition source for an explosive atmosphere.

6. Installation and connections

The chambers may only be installed, connected, and commissioned by specialist personnel. Specialist personnel must have knowledge of the types of ignition protection and regulations and ordinances for equipment used in hazardous areas (Ex areas).

Verify whether the Ex classification (Ex classification label on the type plate) is suitable for the application.

6.1 Vacuum expansion racks and rack holders

Vacuum expansion racks and rack holders can easily be removed from the chamber. This offers the advantage of an inner chamber with smooth walls, which is easy to clean.

Inserting or loosening an expansion rack and inserting or removing the rack holders may only be done in the absence of solvents and under extraction (technical ventilation).

The rack holders can only be removed from the chamber after removing the expansion racks.

Rack holder installation: Align the rack holders to the cams in the bottom of the inner chamber and insert them.

Prior to insertion check the expansion racks and rack holders for corrosion . If corrosion is detected, the affected element must not be used.





The vacuum expansion racks made of aluminum (also optionally available in stainless steel) allow low-loss heat transfer to the material. The strong tension causes the racks to fit tightly against the interior wall and their large-surface contact area ensures rapid and effective heat transfer.

The removable rack holders allow for easy positioning.

You can remove the expansion racks for easy cleaning. Do not remove them too often in order to prevent wear.



Figure 10: Operating the expansion racks

- Pushing the locking lever: The expansion rack is released and can be removed.
- Pulling the locking lever: The expansion rack is pressed against the inner chamber walls.



Remove or insert the vacuum expansion racks only when the chamber is empty and has cooled down. NO explosive atmosphere must be present. Active extraction (technical ventilation) is mandatory.



Following each new tightening of an expansion rack, check that the lateral parts of the rack fit closely over their whole surface to the inner chamber wall. This is necessary in order to ensure the specified temperature exactitude.

!	NOTICE
	Risk of invalid calibration due to modified heat transmission when changing be- tween aluminum and stainless steel racks.
	Undefined heating behavior.
	arnothing Do NOT change between aluminum and stainless steel racks
	arnothing Use the supplied expansion racks only.

6.2 Mounting the pressure regulator

The pressure regulator is included with the chamber and must be mounted on the chamber rear

Accessory pack for mounting the pressure regulator			
(a) pressure regulator			
(c) 6 screws	(a) (c)		
(d) brass nozzle for compressed air connection	(d)		
(e) bracket	(e)		
(f) cable connector	(f)		
(g) 2 nuts			
for the bolts with thread on the chamber rear	🔇 🔇 (g)		
Connections on the chamber rear as supplied			
(h) hole for the cable connection			
(i) 2 bolts with thread	(h) (i) (i)		



Figure 11: Mounting the pressure regulator on the chamber rear



Proceed in the following order:





6.3 Connecting compressed air / inert gas supply for sweeping the area for electrical equipment and controller housing

The compressed air flows through the area for electrical equipment and the controller housing, which prevents a possible concentration of a solvent-containing atmosphere in the presence of live electrical components.

You can alternatively connect inert gas or nitrogen to the compressed air connection. Use only dry gas.

In order to avoid that any oil coming from the compressed-air piping enters the vacuum drying oven, the compressor of the compressed air system must be equipped with an oil separator, or the compressed air system must be constructed oil-free.

Connection:

Before commissioning, the pressure regulator on the rear of the chamber must be connected to a compressed air line (compressed air system) or to an inert gas supply.

Connection: Plug-in coupling for DL quick coupling NW5

There must be an overpressure of at least 1.5 bar / 44.3 inHg in the supply network.

The maximally permitted pressure is 16 bar.



Figure 12: Compressed air connection on the pressure regulator

If solvent-containing air penetrates the electrical area of the chamber, explosions may result.

Λ	
EX	Explosion hazard by solvent-conta chamber
	Serious injury or death from burns
	arnothing Make sure that the air for the comp

ining air penetrating the electrical area of the

DANGER

and / or explosion pressure.

pressed air supply is NOT taken from explosive atmospheres.

Do NOT start the VDL vacuum drying oven when the chamber is not connected to the compressed air supply, or if the specified overpressure is not reached.

Notes when using inert gas:

When operating the VDL vacuum drying oven with inert gas, correctly follow the technical ventilation measures, as described in the DGUV guidelines 213-850 on safe working in laboratories, issued by the employers' liability insurance association (for Germany).

During sweeping the area for electrical equipment with inert gas, the chamber is supplied with an oxygen displacing gas (e.g. N₂). Inert gases in high concentrations are hazardous to health. They are colorless and almost odorless and therefore practically imperceptible. Inhalation of inert gases can cause drowsiness up to respiratory arrest. When the O₂ content of the air decreases below 18%, there is risk of death from lack of oxygen. Any gas that might escape has to be led out via good room ventilation or a suitable exhaust system.





6.4 Pump module (option)



The mounting instructions Art. no. 7001-0137 supplied with the pump moduledescribe how to mount the vacuum drying oven onto the pump module and installing the suction line into the pump module.



Figure 13: VDL mounted on pump module (example size 115)



Figure 14: Pump module, rear view (example size 115)

- (11) Connection to extraction
- (13) Fixation screw fitting for grounding

The following steps 6.4.1 to 6.4.3 are described in detail in the mounting instructions Art. no. 7001-0137. Please proceed accordingly.

6.4.1 Mounting

- Placing the vacuum drying oven on the vacuum module
- Mounting the connecting plate
- Installing the suction line: Hose connection at the VDL vacuum connection (11) and fixing the hose at the housing rear
- Installing the condensate collecting tray

Inappropriate execution of the connections can lead to the risk of explosion.



Danger of ignition and explosion by inappropriate installation.
Serious injury or death from burns and / or explosion pressure.
> It is obligatory to follow the instructions of the mounting instructions Art. no. 7001-0137

regarding correct installation.

DANGER

Observe the safety advice as in chap. 1.7.2.

6.4.2 Achieving equipotential bonding acc. to the grounding plan

- The conductive connection between the VDL and the pump module is established by mounting the connecting plate.
- To establish a conductive connection between the vacuum pump and the pump module a grounding cable is supplied, which is already fixed at the pump mcdule. It will be connected to the pump.
- To establish a conductive connection between the condensate collecting tray and the pump module the front edge of the tray is screwed on the front of the vacuum module
- To establish a conductive connection between the pump module and the conductive surface of the installation site a grounding cable is supplied with the pump module. It is screwed on the fixation screw fitting for grounding of the pump module and connected to the conductive surface of the installation site.



6.4.3 Connection of an extraction system at the pump module



Avoid the solvent accumulation in the pump module as this would cause the pump module to become an occasionally or continuously / for long periods / frequently potentially explosive area (Zone 0 or 1). The VDL vacuum drying oven located on top of the module is constructed in device category 3 in regards to its surroundings.

EX	Explosion hazard due to the spread of an explosive atmosphere to unprotected chamber parts and ignition due to electric sparking or hot surfaces
	Serious injury or death from burns and / or explosion pressure.
	 Provide active extraction (technical ventilation according to country-specific regulations – TRBS 2152 Part 2 for Germany) prior to commissioning the chamber.
	Extraction must include the entire installation area of the vacuum drying oven and pump module.
	> Connect an extraction system to the provided port on the rear of the pump module.

6.5 Vacuum connection

Connect the vacuum drying oven to a vacuum pumpor to a domestic vacuum system. For this purpose, the vacuum connection (6) with small flange DN16 must be connected to the back of the chamber at the top with the vacuum pump or domestic vacuum system via a vacuum suction hose or a fixed vacuum pipe.



Figure 15: Position of the Vacuum connection on the chamber rear (example size 115)

When using a vacuum suction hose BINDER recommends the connection kit for the VP4 pump from BINDER (chap. 6.5.5). The optional pump module (chap.) provides an appropriate hose port on the rear.

6.5.1 Instructions for using vacuum pumps



Vacuum pumps with a suction capacity of 1-30 m³/h are suitable for the VDL vacuum drying oven.

For use of vacuum pumps in the European Union, note the following points:

- Units that will be operated in potentially explosive areas have to meet the requirements of ATEX Directive 2014/34/EU. Observe the safety instructions in chap. 1.7.
- If combustible solvent will be introduced into the inner chamber, the vacuum pump must be constructed in a suitable explosion-proof manner. The mixtures extracted from the drying chamber must be carried away making sure that there is no danger by ignition of these atmospheres.



Follow the safety instructions of the pump manufacturer.

In the event of an error, sparking in the pump motor or the switching elements, electrostatic discharges, as well as hot pump parts can ignite solvent vapors. Minimize this risk by using an ATEX Directive 2014/34/EU compliant vacuum pump suitable for suction from Zone 0 or 1 and, if appropriate, from the zone of its installation site.

Explosion hazard caused by emerging solvent vapors, which can ignite due to sparking in the pump motor or the switching elements, electrostatic discharges and hot pump parts.
Serious injury or death from burns and / or explosion pressure.
Use only suitable, explosion-proof pumps
Operate the pump in a stationary position and secure it so it is immobile.
Make sure that the suction line to the vacuum connection (6) is installed fix and conduc- tive.
Avoid that the exhaust pipe conducts ignitable solvent concentrations by sufficient solvent condensation e.g., in an exhaust waste vapor condenser
Make sure that the exhaust pipe is installed fix and conductive in case it may still con- duct ignitable solvent concentrations.
Ensure equipotential bonding between the pump housing and the housing of the VDL vacuum drying oven via the connected equipment grounding conductors of both units.
When using ATEX Directive 2014/34/EU non-compliant pumps:
Provide a current-dependent, delayed protective device for the pump (for the triggering time of this protective device, see the manufacturer's specifications). The protective and monitoring device must not be able to independently turn on again or be released.
Install the switch gear box outside the hazardous area or provide it with explosion pro- tection.

The ATEX Directive 2014/34/EU compliant pumps offered by BINDER provide an integral protective device and an integral explosion proof switch.

Make sure that the vacuum source is designed for a gas inlet temperature corresponding to the used drying temperature, or take appropriate measures to cool down the extracted vapor before it enters into the vacuum source.

Observe the permissible gas inlet temperature of the vacuum pump in use. Do NOT exceed this temperature. If the gas inlet temperature is too high and then becomes even warmer by compression in the pump, the resulting temperature (of the gas-solvent mixture inside the pump) could exceed the solvent's temperature class and auto-ignition temperature.

BINDER

EX	Fire and explosion hazard by exceeding the auto-ignition temperature of the solvent with a too high gas inlet temperature.				
	Damage to the vacuum pump. Serious injury or death from burns and / or explosi pressure.				
	Do NOT exceed the maximum gas inlet temperature of the pump. Adjust the tempera- ture set-point accordingly.				
	With a higher set-point temperature, take appropriate measures to cool down the ex- tracted vapor before it enters into the vacuum pump.				
Extracted var	pors can have a health damaging and/or corrosive effect on the chamber and pump.				

Health hazard due to release of extracted vapors.
Corrosion of oven and pump. Damage to health.
Conduct the extracted vapors e.g., into a fume extractor facility. Connect a suitable hose to the vacuum pump outlet that may be located in the pump module.

To avoid condensation inside the chamber and in the suction system, select an appropriate vacuum source to ensure its sufficient performance in relation to the released amount of steam. Coordinate drying temperature, suction performance of the vacuum source and the amount of loading material.

6.5.2 Vacuum pump VP4 (option)

. The VP4 chemical membrane pump is located in a separate transport packaging. It is delivered as complete pump stand with a separator and an exhaust waste vapor condenser.

We recommend to install the vacuum pump in the optional pump module. For installation of the pump, please refer to chap. 6.5.3.



Figure 16: Vacuum pump VP 4 (MZ2C EX)

Defining the zone of the installation site of the vacuum pump (Directive 1999/92/EC)

If the pump module is defined as Zone 1, the operating chamber of the vacuum pump must be swept with inert gas. A flow of at least 1 liter per minute (without pressure) is needed. For Zone 2 or without any zone sweeping with inert gas is not required. In addition to sweeping with inert gas, in case of condensing media, you can connect a gas ballast in order to avoid condensation.

The ATEX Directive 2014/34/EU compliant vacuum pump offered by BINDER is designed for a gas inlet temperature of 40 °C / 104 °F max. Do NOT exceed this temperature. If the gas inlet temperature is too high and then becomes even warmer by compression in the pump, the resulting temperature (of the gas-solvent mixture inside the pump) could exceed the solvent's temperature class and auto-ignition temperature.



The maximum permissible ambient temperature of the vacuum pumps supplied by BINDER is 40 $^{\circ}$ C / 104 $^{\circ}$ F.

6.5.3 Installation of the vacuum pump VP4 in the pump module (option)

Avoid the solvent accumulation in the pump module as this would cause the pump module to become an occasionally or continuously / for long periods / frequently potentially explosive area (Zone 0 or 1). The VDL vacuum drying oven located on top of the module is constructed in device category 3 in regards to its surroundings.

Installation of the supplied vacuum pump

- The vacuum drying oven is mounted onto the pump module as described in the mounting instructions Art. No. 7001-0137.
- The suction line to the pump module is installed as described in the mounting instructions Art. No. 7001-0137. Connect the vacuum connection (6) (small flange DN 16) on the back of the chamber to a vacuum suction lead. When using a vacuum tube BINDER recommends the BINDER connection kit for VP4 (chap. 6.5.5). The optional pump module has a corresponding hose outlet on its rear.
- When the pump is removed from the original packaging, place it in the pump module.
- Connect the grounding elements as described in the mounting instructions Art. no. 7001-0137.
- Connect the pre-installed suction line to the vacuum pump inlet at the suction-side small flange connection located at the top of the condensate catchpot).
- Connect a conduit that is suitable for removing the extracted vapors from the pump module, onto the
 pressure-side connection of the vacuum pump (hose olive on the top-back of the emission condenser).
- Guide the end of the conduit into an exhaust air system, which is explosion-proof constructed in consideration of any possible residual solvent contents. The operator must check if an explosive atmosphere may be present at the pump exit or at the exhaust waste vapor condenser. For this purpose, use a calculation of the solvent's partial pressure at the set-up coolant temperature of the exhaust waste vapor condenser and compare it to the explosion limits of the pumped solvent. The exhaust solvent concentration should be minimized by selecting the most appropriate condensation temperature for the solvent at the refrigeration plant that can be connected to the exhaust waste vapor condenser. The pumped-out gases at the pump exit or the exhaust waste vapor condenser must be removed in a controlled manner and according to applicable security regulations. If there is any possibility that an explosive mixture could still exist, the exhaust must be removed through antistatic conduits and disposed of according to the valid regulations of explosion protection.
- Establish the electrical connection at the pump's connector box. This must be carried out according to the original user manual of the pump manufacturer and to EN 60079-0, observing the zone that has been defined by the operator for the installation site of the pump. Equipotential bonding between the pump housing and the housing of the vacuum drying oven must be assured by the connected equipment grounding conductors of both units.

Inappropriate execution of the pump connection can lead to the risk of explosion.





Danger of ignition and explosion by inappropriate pump connection . Serious injury or death from burns and / or explosion pressure.

- It is obligatory to follow the instructions of the pump manufacturer regarding correct connection and commissioning.
- Observe the safety advice as in chap. 1.7.

Extracted vapors or the occasionally used inert gas can endanger health and / or have a corrosive effect on the oven and pump.



Danger of damage to health by release of extracted vapors.

Corrosion on the chamber and the pump. Damage to health.

- Remove the extracted vapors and/or inert gas via a suitable conduit from the pump module into e.g., a fume extractor facility.
- Directly connect the conduit to the corresponding pump outlets.



You can connect a laboratory cooling system to the emission condenser of the vacuum pump VP4.



To operate the chemical membrane pumps VP4 (MZ2C EX) please refer to the enclosed pump manufacturer's operating manual.



Confirm that the vacuum source is designed for a gas inlet temperature corresponding to the used drying temperature, or take appropriate measures to cool down the extracted vapor before its entry into the vacuum source.

The ATEX Directive 2014/34/EU compliant vacuum pump offered by BINDER is designed for a gas inlet temperature of 40 °C / 104 °F max. Do NOT exceed this temperature. If the gas inlet temperature is too high and then becomes even warmer by compression in the pump, the resulting temperature (of the gas-solvent mixture inside the pump) could exceed the solvent's temperature class and auto-ignition temperature.

The maximum permissible ambient temperature of the vacuum pump supplied by BINDER is 40 °C / 104 °F.

6.5.4 Note on the use of a flame arrester

A flame arrester is not mandatory for VDL applications (TRBS 2152-4:2012). A pump designed for Zone 1 is equipped with a temperature sensor on the bearing which, in the event of a fault, causes the pump to shut down immediately.

In general: In case of a risk of ignition before or after the vacuum pump, the operator must provide suitable flame arresters in accordance with EN 12874. The suitability (chemical resistance, sufficient flow and safety against clogging) must be ensured before commissioning.

6.5.5 ATEX connection kit for vacuum pump VP4 (option)

Connection kit for VP4 (Art. no. 8012-0621) consists of:

- Straining ring DN10/16 (3 pc.)
- Universal centering ring DN10/16 (3 pc.)
- Transition piece, adapter DN 16-10/8 (2 pc.)
- Vacuum hose 10/8, 2 m / 78.7 in
- Union nut M14 (2 pc.)
- Elbow DN 10/10



For mounting the VDL connection kit for VP4, please refer to the mounting instructions Art. no. 7001-0152 supplied with the connection kit.

6.6 Connecting inert gas supply

When operating the VDL vacuum drying oven with inert gas, correctly follow the technical ventilation measures, as described in the DGUV guidelines 213-850 on safe working in laboratories, issued by the employers' liability insurance association (for Germany

When operating with inert gas, the chamber is supplied with an oxygen displacing gas, e.g., N_2 . Inert gases in high concentrations are hazardous to health. They are colorless and almost odorless and therefore practically imperceptible. Inhalation of inert gases can cause drowsiness up to respiratory arrest. When the O_2 content of the air decreases below 18%, there is risk of death from lack of oxygen. Any gas that might escape has to be led out via good room ventilation or a suitable exhaust system.



via a pressure reducer. Screw the enclosed adapter with hose olive on the thread (4) at the chamber rear. Set the pressure reducer to a pressure slightly above ambient pressure. Ensure that the pressure reducer will certainly open. Do not alter this setting in order to avoid perturbation inside the oven and release of big quantities of inert gas after flooding the VDL.



6.7 Mounting the tilt protection holders

For chambers placed on the optional pump module it is recommended to install the supplied tilt protection.

Scope of delivery of tilt protection kit (Art.no. 8009-0870):

- 2 screws
- 2 tilt protection holders

Preparing the tilt protection holders

• Depending on the desired wall distance, you can bend the tilt protection holders accordingly.



Figure 17: Variable length of the tilt protection holder depending on the bend

Installation on the chamber

- Plug the two tilt protection holders each with the tab into the mounting holes and push them upward over the rear panel. The screw holes in the rear wall and in the tilt protection holders must align.
- Fix the tilt protection holders each with one of the supplied screws on the chamber rear wall.

Wall mounting

• Then fix both tilt protection holders on the wall, each with 2 screws Ø 6mm suitable for the wall (B)

6.8 Achieving equipotential bonding / Grounding concept

For systems in potentially explosive areas, equipotential bonding acc. to IEC 60079-14 is required. All electrically conductive parts must be connected to the equipotential bonding system. Connections to the equipotential bonding system must be secured against automatic loosening.

Grounding, i.e. achieving equipotential bonding is required as solvent vapors may be present during loading and / or unloading. Also when removing the filled condensate catchpot from the pump solvents may accidentally be spilled. Therefore, the accessible surface of the installation and loading area must be conductive, there must be technical ventilation, and all equipment (VDL / pump module / vacuum pumpmust be connected to the conductive surface or to each other according to the grounding concept. The personal protective equipment (PPE) of the operating personnel must be implemented ESD protected.



Installation without pump module

Installation with pump module

Figure 18: Possibilities of grounding (schematic representation)

- **VDL** Vacuum drying oven
- M Pump module
- **S** Walkable installation and operating surface with conductive surface
- P Vacuum pump
- A Equipotential bonding between the VDL and the conductive surface of the installation and loading area via grounding cable
- B Equipotential bonding between the VDL and the pump module via connecting plate
- C Equipotential bonding between the vacuum pump and the pump module via grounding cable
- D Equipotential bonding between the pump module and the conductive surface of the installation and loading area via grounding cable
- **E** Equipotential bonding between the condensate collecting tray and the pump module via screws





How to achieve equipotential bonding when installing the VDL with a pump module is described in detail in the mounting instructions for the pump module (Art. No. 7001-0137) supplied with the pump module.

Achieving equipotential bonding on the VDL

Equipotential bonding must always be made via external grounding connections, so that no potential can be introduced in the event of a short circuit. Following the installation of the VDL and having implemented all the measures described to achieve equipotential bonding, we recommend performing a protective conductor measurement before commissioning.

	The VDL provides a threaded bushing for grounding on the bottom left of the rear panel. In state of delivery the screw together with the washer and spring washer is screwed on the threaded bushing. Unscrew the screw.
	Threaded bushing after unscrewing
00	Washer, spring washer, screw
	Put the washer, the ring cable lug of the grounding cable and the spring washer in this order onto the screw. OR Put the spring washer, the ring cable lug of the grounding cable, and the washer directly onto the housing (recommended because this creates minimum resistance)
	Screw on the screw into threaded bushing. Connected grounding cable

Figure 19: Mounting the grounding cable on the VDL





6.9 Electrical connection

The chambers are supplied ready for connection. They come with a fixed power connection cable of at least 2000 mm / 78.74 *in* in length and a shockproof plug.

Model	Power plug of the power cable	Nominal voltage ± 10% at the indicated power frequency	Current type	Chamber fuse
VDL 23	Grounded plug	230 V at 50 Hz 230 V at 60 Hz	1N~	2 x 6,3 A
VDL 56	Grounded plug	230 V at 50 Hz 230 V at 60 Hz	1N~	2 x 8 A
VDL 115	Grounded plug	230 V at 50 Hz 230 V at 60 Hz	1N~	2 x 10 A
VDL 23-UL	NEMA 5-15P	100-120 V at 60 Hz	1N~	10 A
VDL 56-UL	NEMA 5-20P	100-120 V at 60 Hz	1N~	2 x 16 A
VDL 115-UL	NEMA 5-20P	100-120 V at 60 Hz	1N~	2 x 20 A

The domestic socket must also provide a protective conductor. Make sure that the connection of the
protective conductor of the domestic installations to the chamber's protective conductor meets the latest technology. The protective conductors of the socket and plug must be compatible!



Electrical hazard due to lack of a protective conductor.

Deadly electric shock.

Make sure that the power plug and power socket match and that the protective electrical conductors of the chamber and domestic installation are securely connected.

DANGER

• Prior to connection and start-up, check the power supply voltage. Compare the values to the specified data located on the chamber's type plate (left chamber side, bottom right-hand, see chap. 1.6).




NOTICE

Danger of incorrect power supply voltage due to improper connection. Damage to the equipment.

- > Check the power supply voltage before connection and start-up.
- Compare the power supply voltage with the data indicated on the type plate.
- When connecting, please observe the regulations specified by the local electricity supply company as well as the VDE directives (for Germany). We recommend the use of a residual current circuit breaker.



- \oslash Do NOT operate the chamber if the power cable is damaged.
- Pollution degree (acc. to IEC 61010-1): 2
- Over-voltage category (acc. to IEC 61010-1): II

See also electrical data (chap. 28.3).

To completely separate the chamber from the power supply, you must disconnect the power plug. Install the chamber in a way that the power plug is easily accessible and can be easily pulled in case of danger. A customer's emergency stop switch or a comparable power disconnector can also be used.

The chamber plug (power plug) is unprotected because it must be disconnected in case of an emergency to completely separate the chamber from the power supply. therefore the electrical connection must be established outside a zone..



7. Explosion safety tests before commissioning

This chapter provides instructions for the user to ensure the safety of the system and to meet applicable regulations. Proper operation is only ensured after the test has been carried out and any necessary measures implemented.

Follow the provisions on testing explosion protection according to country-specific regulations (for Germany in particular TRBS 1201 Part 1; this substantiates the requirements of the Industrial Safety Regulation (BetrSichV) 2015) within the scope of its application.

7.1 Scope of the functional test

The test represents the entirety of all work equipment relevant to explosion protection. This includes the vacuum drying oven with all safety, control, and regulation devices, related work equipment such as pumps or other vacuum systems, pump module, extraction devices, and ventilation systems, gas warning devices, inerting devices including connection elements as well as the installation area with effective devices for equipotential bonding and any other building components that may be relevant to explosion protection (non-exhaustive list).

- Before commissioning and after changes requiring review, perform a comprehensive inspection of the system in its entirety.
- Systems must be checked in their entirety at least every 6 years.
- Tests can also be carried out by an approved monitoring body or by personnel qualified for testing. Observe relevant regulations for the qualification requirement.
- Devices, protective systems, safety, control and regulating devices according to Directive 2014/34/EU, connection devices, and interactions with other parts of the system must continue to be checked at least every three years. Tests of ventilation systems, gas warning and inerting devices must be performed at least once per year in the future.
- It may be possible to skip recurring tests, e.g. of devices, protective systems, etc., as well as ventilation systems, gas warning and inerting devices, if a **maintenance plan** is provided. The full inspection of the entire system remains unaffected.

7.2 Explosion protection plan

The explosion protection plan to be created by the operator represents the entirety of the technical and organizational measures for explosion protection determined and specified on the basis of the risk assessment. In accordance with ATEX Operational Directive 1999/92/EC, these measures serve

- to prevent the formation of or to limit explosive atmospheres or to limit hazardous explosive mixtures
- to avoid the combustion of explosive atmospheres
- to limit the spread of an explosion and to minimize its effects on personnel in order to ensure the health and safety of employees

The explosion protection document serves to document the results of the risk assessment in accordance with § 6 Para. 9 GefStoffV (for Germany).

The explosion protection document serves to document the results of the risk assessment in accordance with § 6 Para. 9 GefStoffV (for Germany).

7.3 Objective of testing

Determine the suitability and functionality of safety-related measures. When testing the explosion safety of the system, evaluate the explosion protection plan and compare the target state derived from it with the actual state of the system (according to available test records):

- Assess the completeness and plausibility of safety-related documents (such as the explosion protection document, installation plans, zone plans, safety-related figures)
- Determine whether the system has been set up in accordance with national regulation (GefStoffV for Germany) and is safe for use with regard to explosion protection
- Technical measures are suitable and functional for explosion protection,
- Technical organizational measures necessary for explosion protection are suitable
- The deadline for the next recurring test was correctly set in accordance with national regulations (in accordance with § 3 Para. 6 BetrSichV for Germany).

Performing tests

The tests can be divided into the verification of the documentation and a technical examination.

7.4 Testing before initial commissioning

Proceed according to country-specific regulations (for Germany in particular: TRBS 1201 Part 1; BetrSichV).

Before the initial commissioning of the Ex system, perform the explosion safety test. It serves to determine the explosion safety of the system, including the work equipment and the working environment.

The test represents a comprehensive consideration of the explosion safety of the Ex system with regard to the protection of employees and other persons in the hazard area, including all functional units relevant to explosion protection and their interactions. The test of explosion safety is based on the explosion protection plan from the employer in accordance with the specifications in the explosion protection document and its implementation in the Ex system. Equivalent test results according to other legal regulations can be considered. It is also permissible to refer to tests that have already been carried out.

7.4.1 Scope of the test

7.4.1.1 Testing the plausibility of the explosion protection plan and measures

Verification of the traceability and plausibility of the explosion protection plan given in the explosion protection document and the measures derived from this in consideration of underlying constraints.

The test does not apply to systems for which this test has already been carried out in the course of a permit or approval process.

7.4.1.2 Verifying the implementation of measures

Verification of the measures described in the explosion protection document with regard to their implementation includes a holistic examination of the technical and organizational measures in accordance with the specifications of the explosion protection document. Typical test aspects (examples):



- Suitability and functionality of technical ventilation systems, gas warning systems, inerting devices, devices, protective systems, or control or regulating devices in the sense of Directive 2014/34/EU as well as explosive devices in the sense of TRGS 725
- Suitability and implementation of the measures determined on the basis of the risk assessment
- Suitability, functionality, and installation of work equipment and related connection devices that are not devices, protective systems, or safety, control, or regulating devices in the sense of Directive 2014/34/EU, but are relevant for explosion protection
- Suitability of other work equipment, such as ladders, containers, tools, for use in hazardous areas
- Suitability and functionality of other equipment and building components related to explosion protection (e.g. lightning protection systems, conductivity of floors and linings)
- Suitability of the personal protective equipment(PPE (e.g., the electrostatic discharge capacity of work shoes or gloves)
- The existence and legibility of the labels for potentially explosive areas in which measures to avoid ignition sources are required
- The existence and suitability of the organizational measures required for explosion protection
- The implementation of measures relevant to explosion protection from official requirements
- Certificates proving the correct installation of system parts, provided that their correct installation cannot or only partially be ascertained during the technical inspection, e.g. flame-arresting fittings or limit switches

7.4.1.3 Checking the deadlines for the recurring tests

When doing so, assess whether the system can be operated safely until the next specified recurring test.

7.4.1.4 Verifying the maintenance plan

When doing so, assess whether the maintenance plan is suitable for maintaining the safety of the Ex system until the next recurring test. The maintenance plan can also be used to test the technical protective measures for explosion protection of the explosive system. It can also be part of an integrated management system.

- **Definition of responsibilities** for the maintenance plan, definition of maintenance and inspection content, e.g. when creating work plans, processing the maintenance and inspection content, e.g. in the form of work plans, the assessment of deviations from the target state, and any necessary repairs.
- Determination of maintenance and inspection measures and deadlines for devices, protective systems, safety, control and regulating devices as well as their connections and interactions, technical ventilation systems, gas warning devices and inerting devices and MSR devices for explosion protection
- Comprehensible description of the required maintenance measures and deadlines e.g. in the form of work plans, work equipment of comparable design can be summarized.
- Implementation of the maintenance plan: Implementation of maintenance and inspection in accordance with the defined maintenance plan, notification of completion of the implementation of maintenance and inspection, documentation of identified repair needs and implementation of the repairs. Necessary maintenance measures must be carried out immediately. Maintenance work must be carried out by qualified specialist personnel who have sufficient experience in the maintenance of Ex systems based on the maintenance plan. The maintenance plan and the implementation of maintenance measures must be clearly documented.

7.4.2 Tests of technical ventilation systems, gas warning devices, inerting devices, devices, protective systems or safety, control or regulating devices, and other technical devices for explosion protection

Test content that has been checked and documented as part of conformity assessment procedures do not need to be checked again. Verify the plausibility and completeness of documents.

The following points must generally be verified:

- Technical ventilation systems, gas warning devices, inerting devices with regard to their suitability, their functionality, their interconnections, their installation conditions, their proper condition, and their installation / assembly
- Devices, protective systems, or safety, control, or regulating devices within the meaning of Directive 2014/34/EU on explosion protection with regard to their proper condition, their suitability, their interconnections, their installation conditions, and their installation / assembly
- Safety, control, or regulating devices with relevance for explosion protection, which can also be located outside the potentially explosive atmospheres, to determine whether ventilation systems, gas warning devices, inerting devices ensure the proper exclusion of ignition sources and functionality.
- Calibration of the Pt 100 controller sensor and, if required, subsequent adjustment is to be made before commissioning the chamber as well as part of the annual maintenance. The procedure is described in the Service manual (customer version).
- Ex devices in the sense of TRGS 725, whether they ensure the necessary functional reliability of the measures.
- Connection elements and other technical devices (such as lightning protection, requirements for floors) with regard to their condition, their interconnections, and their installation / assembly for explosion safety (e.g. type of installation, insulation resistance of electrical cables and lines)
- Take into account the significant interactions of devices, protective systems, safety, control, or regulating devices and their connecting elements – with each other and with other system parts. This includes, for example, testing the equipotential bonding, the involvement of pipes in equipotential bonding, overvoltage protection, and lightning protection, alignment of units (e.g. pump-coupling-motor).

7.5 Inspection after changes requiring review

There is a need for a change requiring review if the explosive safety of the explosive system is affected by the change. Changes requiring review are evaluated in accordance with applicable national regulations (for Germany in particular: TRBS 1123). Checks after a change requiring review may be limited to the changes made. Verify whether the system in the potentially explosive area has been changed in accordance with this regulation and is working properly. See the requirements in Chap. 7.4.

7.6 Recurring tests for the explosive safety of the system

Objective of testing: The recurring tests serve to maintain the explosive safety of the Ex system. Among other things, the actual state of the system is compared with the target state (according to the explosion protection document and available test records).

8. Functional overview and menu structure of the controller

The available controller functions depend on the current authorization (chap.12). Unless noted otherwise, the figure in this manual show the functional range, which is available for the user with "Admin" authorization level

The MB2 chamber controller controls following parameters inside the chamber:

- Temperature in °C or °F
- Pressure in mbar

You can enter the desired set point values in fixed value operation mode directly on the display surface or via the setpoint menu. For program operation the controller offers programming week and time programs. In addition there is a timer program available (stopwatch function).

The controller offers various notifications and alarm messages with visual and audible indication and remote alarms via e-mail, an event list (trace file) and the graphical display of the measuring values in the in der chart recorder view. The MB2 program controller permits programming temperature and pressure cycles, and specifying special controller functions for each program section. You can enter values or programs directly at the controller or use the APT-COM[™] 4 Multi Management Software (option) specially developed by BINDER.

				Operating mode
Fixed value			▼ 🛁 14:03:49 🔻	
		Setpoint	Actual value	
Temperature	°C	40.0	40.1 🖛	— Temperature values
Pressure	mbar	1100	1024 🖛	— Pressure values
				 Actual values Set-point values
		(j		Functional icons

Figure 20: Normal display of the MB2 program controller (sample values)



8.1 Operating functions in normal display



Figure 21: Operating functions of the MB2 controller in normal display (example values)



8.2 Display views: Normal display, program display, chart-recorder display



Press the Change view icon to toggle between normal display, program display and chartrecorder display.

Press the Normal display icon to return from program display and chart recorder display back to Normal display.



Normal display (actual values / setpoint values)

Program display (example: time program)

8.3 MB2 controller icons overview

Navigation icons in Normal display

lcon	Signification	Function
	Main menu	Access from Normal display to the main menu
	Alarm	Access from Normal display to the list of active alarms
	Event list	Access from Normal display to the event list
	Setpoint setting	Access from Normal display to the setpoint entry menu: setpoint entry for Fixed value operation, turning on/off temperature and/or pressure control, safety controller settings
	Program start	Start a previously entered time or week program, continue a paused time program
	Program pause	Pause a running time program
	Program cancelling	Cancel a running time or week program
í	Information	Information on program operation, setpoints, actual values, and the safety controller
()	Normal display	Return from program display or chart recorder display to Normal display
\mathbf{S}	Change view	Toggle between Normal display, program display, and chart recorder display

Functional icons in individual menus

lcon	Signification	Function
₽	Back	Return from each menu to Normal display
Ô	Update	Update the event list and alarm messages
\bigcirc	Confirm	Take over the entries and exit the menu / continue menu se- quence.
⊗	Close	Exit the menu / cancel menu sequence. Entries are not taken over. When terminating a menu sequence, an information win- dow appears, which must be confirmed.
۲	Reset alarm	Acknowledge the alarm and mute the buzzer.
	Change keyboard	Change between uppercase and lower case characters, digits and special characters
	Edit	Edit settings of time and week programs

lcon	Signification	Function	
	Show legend	Show legend	
	Hide legend	Hide legend	
C	History display	Pause chart recorder and change to history display. Data recording continues.	
A?	Curve selection	Go to "Curve selection" submenu in the history display	
	Search	Go to "Search" submenu in the history display to select the required instant	
	Zoom	Go to "Zoom" submenu in the history display to select the zoom factor	
•	Show scroll buttons	Show scroll buttons in the history display to scroll to an instant	
3	Hide scroll buttons	Hide scroll buttons in the history display to scroll to an instant	

Functional icons in the chart recorder display

Information icons referring to chamber conditions

lcon	Text information	Condition
Ċ	"Standby"	Chamber is in Standby mode
<u>}}}</u>	"Heating active"	Chamber is heating up
赵	"All valves are closed"	All valves are closed
GAS AIR	"GAS/AIR"	Ventilation via regular connection "GAS/AIR" (4)
GAS AIR2	"GAS/AIR 2"	Ventilation via optional connection "GAS/AIR2" (5) Regular connection "GAS/AIR" (4) deactivated.
©t	"Press.thresh. not reached"	Pressure threshold of 100 mbar not reached

Information icon for data processing

lcon	Information
	Waiting icon: Data processing is running. Remaining time to touch the display when calibrating the touchscreen.

8.4 MB2 controller operating modes

The MB2 program controller operates in the following operating modes:

• Fixed value operating mode

The controller operates as a fixed-point controller, i.e., set-points for temperature and pressure can be defined, which are then maintained until the next manual change (chap. 10.1.1).

• Timer program operation

Stopwatch function: during an entered duration the controller constantly equilibrates to the setpoints entered in Fixed value operation mode.

• Time program operation

An entered time program for temperature and pressure is running. The controller offers 25 program memory places with 100 program sections each. The total number of program sections of all programs is unlimited

• Week program operation

An entered week program for temperature and pressure is running. The controller offers 5 program memory places with 100 switching points each. The switching points can be distributed over all days of the week.

8.4.1 MB2 controller menu structure



Use the **navigation icons** in the screen footer in Normal display to access the desired controller functions.

The available functions depend on the current **authorization level** "Service", "Admin" or "User" (chap. 12.1. This is selected either during login or can be available without password protection.

	Main n The "S	Main menu: program settings, further information, "Service" submenu. The "Settings" submenu allows general configuration of the controller.		
٢	List of	List of active alarms		
	Access	chap. 13.5		
¢)	Setpoint entry for Fixed value operation, Standby mode, turning on/off temperature and/or pressure control, safety controller settings			
Start/ pa program week pr		Start/ pause/ cancel an already entered, respectively a running time program or start / cancel an already entered, respectively a running week program	chap. 18.1, 18.2, 19.1	

Unless noted otherwise, the figures show the functional range, which is available for the user with "Admin" authorization level.

8.4.2 Main menu

The main menu provides access to the general configuration of the controller as well as to program entry and the user administration. Additionally there are support functions like a contact page or the display calibration depending on the available angle.

	Press the <i>Main menu</i> icon to access the main menu from Normal Display.
1	Press the Back icon to return from each setting menu to Normal Display.

The main menu provides the following functions and submenus.

Main menu			
Luser	^	User management: login and logout, pass- word management	chap. 12.1
Device info		Chamber information	chap. 13.8
🗳 Settings	=	"Settings" submenu (not visible for user with "User" authorization level)	chap. 13
Programs		"Programs" submenu (not visible for user with "User" authorization level)	chap. 18 und 19
🛠 Service		"Service" submenu	chap. 8.4.4
Contact		BINDER Service contact page	chap. 13.6
Calibrate touchscreen	\checkmark	Calibrating the touch screen	chap. 13.4.2
•		Back to Normal Display	

"Settings" submenu

- Settings of many general controller functions and network settings (chap. 13).
- Available only for users with "Service" and "Admin" authorization level

"Service" submenu

- Access to service data, controller reset to factory settings (chap. 8.4.4)
- Available only for users with "Service" and "Admin" authorization level. Full functional range only for BINDER Service (users with "Service" authorization level).

"Programs" submenu

- Access to the controller's program functions (chap. 17, 18, 19)
- Available only for users with "Service" and "Admin" authorization level.

8.4.3 "Settings" submenu

The "Settings" submenu is available for users with "Service" or "Admin" authorization level. It serves to enter date and time, select the language for the controller menus and the desired temperature unit and to configure the controller's communication functions.

Path: *Main menu* > *Settings*

Main	Main Settings			
i	🛱 Chamber	^	Setting the temperature unit, menu language	chap. 13.1,
R	Date and time		Setting date and time	chap. 13.2
⊷ P⁄r	Display	≡	Setting the display brightness, continuous opera- tion and screen saver	chap. 13.4
%	Measurement chart		Settings for the measurement chart: storage inter- val, storage values, minimum and maximum val- ues	chap. 22.2
٩	& Various		Setting the tolerance range and delay time for tolerance range alarm	chap. 15
Ŗø	Serial interfaces		(not used)	
%	💭 Ethernet	=	Entry of the MAC address and IP address	chap. 20.1
0	Web server		Password protection for web server access	chap. 20.2
-	email	V	Configuration of the e-mail server, assignment of e-mail addresses	chap. 20.3
\odot	Ð	v	Back to main menu	

8.4.4 "Service" submenu

The "Service" submenu is available for users with "Service" or "Admin" authorization level. When loggedin with "Admin" authorization level the user will find information to tell the BINDER Service in service case.

Path: Main menu > Service

Main Service		
Service data	Serial number of the chamber, setup version of the controller software	chap. 13.8
1 Σ Counter	No function	
ST code	Information for BINDER Service	
Figure Factory settings	Reset to factory settings	
*		
0		
	Back to main menu	

(view with "Admin" authorization level)

8.5 Principle of controller entries

In the selection and entry menus there are icons displayed in the footers which you can use to take over the entry or cancel it.

Display	a 10:29:56
Brightness	100
Wait time for screen saver	300 s
Activate continuous operation	Yes 🔺
Begin continuous operation	No
End continuous operation	Yes
0	
(\mathbf{X})	$\mathbf{\otimes}$

Temperature					
					40.00
	+0.00	00+2	20.00		
	7	8	9		
	4	5	6		
	1	2	3		
	0	±		с	

Selection menu (example)

Entry menu (example)

After completing the settings there are the following possibilities:

\bigcirc	Press the Confirm icon to take over the entries and exit the menu or continue the menu se- quence.
\mathbf{X}	Press the Close icon to exit the menu or cancel the menu sequence without taking over the en- tries.
\bigcirc	When terminating a menu sequence, an information window appears, which must be confirmed.

8.6 **Performance during and after power failures**

During a power failure, all controller functions are shut down.

If there is a vacuum and ventilation is required during the duration of the power failure, this is possible via the emergency ventilation (chap. 9.10.3).

After the power returns, all functions return to the same status the chamber had before power failure.

All settings and set point values remain in the memory during power failure.

- If the Standby mode had been activated prior to the power failure, the chamber remains off after the power returns. To operate it you must sign in with a higher authorization level and deactivate the standby mode.
- If the Standby mode had been deactivated prior to the power failure, operation continues after the power returns with previously entered parameters. If the pressure reaches or falls below the required pressure threshold of 100 mbar, the heater turns on depending on the setpoint.

After the power returns, the controller continues to function in the original **operating mode** it was in previously before the power failure occurred:

• Performance after power failure in **Fixed value operation mode**

All functions return to the same status the chamber had before power failure. The set-points are immediately resumed.

• Performance after power failure during Timer operation

The set-points which had been active at the moment of program start are resumed. Program run continues.

• Performance after power failure during Time program operation

The program is resumed at the point where the interruption occurred with the latest set-points reached during the program run.

• Performance after power failure during Week program operation

The week program continues with the values corresponding to the current time.

Power failure and power return are noted in the Event list (chap. 13.5).

If during power failure an **alarm** has occurred (e.g., tolerance range, safety controller), confirm the alarm. See chap. 16.3.

9. Start up and performing the drying process

With regard to operating the vacuum drying oven VDL and to the installation location, please observe the relevant national regulations (for Germany in particular: DGUV guidelines 213-850 on safe working in laboratories, issued by the employers' liability insurance association; Industrial Safety Regulation (Be-trSichV); Ordinance on Hazardous Substances (GefStoffV); Technical Regulations on Industrial Safety and Health (TRBS 1201 Part 1).

Note: Warming chambers may release odors in the first few days after commissioning. This is not a quality defect. To reduce odors quickly we recommend heating up the chamber to its nominal temperature for one day and in a well-ventilated location.

|--|

9.1 Requirements for safe commissioning

Prior to turning on the chamber, the following points must certainly be met:

- Installation of the chamber (chap. 6) performed in compliance with the installation guidelines and ambient conditions (chap. 5)
- Connection for compressed air or inert gas for sweeping the electrical installation area and controller housing
- Vacuum supply connected (chap. 6.5)
- If required: Inert gas connection established (chap. 6.6)
- Equipotential bonding established(chap. 6.8)
- Observing all safety instructions
- Upon initial commissioning: Test before initial commissioning performed and passed (Chap. 7.4)
- Upon recommissioning after maintenance / repairs / changes requiring review: Test performed and passed (Chap. 7.5)
- Technical ventilation activated
- Power connection established (chap. 6.9).

9.2 Setting the pressure regulator for sweeping with compressed air / inert gas

After opening the pressure regulator on the chamber rear (turn clockwise), the area for electrical equipment of the oven and the controller housing will be swept. Compressed air or inert gas is used and then released into the surrounding atmosphere independent of the oven's operating state.

Compressed air sweeping must be in operation for at least 10 minutes before turning on the chamber. It remains in operation during the entire use of the chamber (loading, drying, removal of the material to be dried), with an overpressure of at least 25 Pa (recommendation: 40 Pa). After terminating the drying procedure and turning off the chamber it is recommended to continue sweeping for approx. 10 minutes.

On the chamber front there is an analog pressure display (manometer) to show the existing overpressure.



Figure 22: Pressure regulator for compressed air sweeping on the chamber rear, top right



Figure 23: analog pressure display (manometer) for compressed air sweeping on the chamber front

Sweeping before starting up the chamber:

- Open the USB cover on the controller housing (triangle instrument box)
- Turn the pressure regulator until the end stop to the lock nuts (turn clockwise).
- Recommended time for sweeping with maximum overpressure: 10 minutes. This flushes 5 times the volume of the electrical installation area and controller housing
- Close the USB cover on the controller housing (triangle instrument box)
- Now the pressure regulator can be turned back (turn counterclockwise) until there is an overpressure of at least 25 Pa (recommendation: 40 Pa).

Sweeping during chamber operation:

- Set the pressure on the pressure regulator in a way that the manometer shows at least 25 Pa overpressure. Recommended value: 40 Pa.
- Check the display frequently during chamber operation. In all operating states, the value on the manometer must indicate > 25 Pa.
- The USB cover on the controller housing must be closed.

Sweeping after completion of chamber operation (recommended):

- You can stop sweeping 10 minutes after turning off the chamber: Close the pressure regulator to (turn counterclockwise).
- Check on the manometer that there is no longer any overpressure.

Regarding use of the USB connection during chamber operation please observe the instructions given in chap. 21.1.

9.3 Overview of the drying process

Required measures for operation with solvent-containing substances, which may be able to form an explosive mixture with air:

Starting situation	
• The vacuum drying oven and additional equipment have been set up and installed in accord- ance with the instructions in this manual, the instructions of the operator and the relevant regulations. Equipotential bonding according to the grounding concept is ensured	
 The auto-ignition temperature of the solvent has been determined from its safety specifica- tions In the case of solvent mixtures, use the lowest auto-ignition temperature. 	
• All users have been trained and are familiar with the safety plan and the required measures.	
The vacuum source is connected and ready for operation	
Sweeping the area for electrical equipment and the controller housing (triangle instrument l	oox)
 Open the USB cover on the controller housing and turn the pressure regulator on the cham- ber rear until the end stop to the lock nuts for sweeping the electrical installation space and controller housing 	
• Sweep the area for electrical equipment and the controller housing at maximum overpressure with compressed air or inert gas for at least 10 minutes	
• Close the USB cover on the controller housing and adjust the pressure regulator by checking the manometer so that there is at least 25 Pa overpressure (recommendation: 40 Pa).	
Loading and starting the drying process	
Make sure that the technical ventilation is activated	
 Make sure that equipotential bonding has been established according to the grounding con- cept 	
 Make sure that the sweeping time of 10 minutes for the electrical installation area and con- troller housing have been observed 	
• Make sure that the compressed air or inert gas supply for sweeping the electrical installation area and controller housing is still open. Check the excess pressure of at least 25 Pa on the manometer (recommendation: 40 Pa).	
In case of Standby mode turn on the vacuum drying oven on the controller	
Set the desired temperature setpoint on the controller.	
 Set the safety controller to a suitable value. Recommended setting: safety controller mode: Limit, safety controller value approx. 5 °C above the temperature set-point 	
Make sure that the user's equipment is ESD protected.Place the material to be dried in the chamber.	
 Set the pressure set-point on the controller. Heating will start only when a vacuum corresponding to the pressure threshold of 100 mbar) is reached. 	



After completing the drying process or when cancelling the drying process When the pressure drops to the pressure set-point, the drying process is finished. If the drying mo (chap. 11.6) is activated, a corresponding message is displayed.	onitoring
 Make sure that the technical ventilation is activated Make sure that equipotential bonding has been established according to the grounding concept 	
For ventilation, set the pressure set-point to atmospheric pressure	
 Switch the vacuum drying oven on the controller to standby mode (not completely de- energized) 	
Make sure that the user's equipment is ESD protected.Remove the drying material	
• Continue sweeping the electrical installation area and controller housing with an overpres- sure of at least 25 Pa (recommendation: 40 Pa) for at least 10 minutes (recommended). Check the excess pressure on the manometer. Only then shut off the compressed air or inert gas supply	
For emptying the pump	
Make sure that the pump is turned off.	
 Make sure that the technical ventilation is activated Make sure that equipotential bonding has been established according to the grounding concept 	
Make sure that the user's equipment is ESD protected.Remove the full condensate catchpot of the pump	
Before starting a new drying process	
 In case of a new solvent with a different auto-ignition temperature: Determine the auto-ignition temperature of the solvent from its safety specifications. In the case of solvent mixtures, use the lowest auto-ignition temperature 	
 Make sure that the technical ventilation is activated Make sure that equipotential bonding has been established according to the grounding concept 	
Sweep the area for electrical equipment and the controller housing with compressed air or inert gas at maximum overpressure for at least 10 minutes	
 Turn on the chamber and check the settings (drying temperature, pressure set-point and safety controller setting) 	
• Now you can load the chamber and start the new drying process. Follow all safety measures	

9.4 Sweeping the area for electrical equipment and controller housing (triangular instrument box)

To sweep the area for electrical equipment and controller housing, activate the customer's compressed air or inert gas supply.

9.4.1 Sweeping before starting up the chamber

Before turning on the VDL it is mandatory to sweep the area for electrical equipment and controller housing with compressed air or inert gas for at maximum overpressure for at least 10 minutes.

- Open the USB cover on the controller housing
- Turn the pressure regulator until the end stop to the lock nuts (turn clockwise).
- Recommended time for sweeping 15min. This flushes 5 times the volume of the electrical installation area and controller housing
- Close the USB cover on the controller housing.
- Now the pressure regulator can be turned back (turn counterclockwise) until there is an overpressure of at least 25 Pa (recommendation: 40 Pa).

9.4.2 Sweeping during chamber operation

Sweeping the area for electrical equipment and controller housing must take place with an overpressure of at least 25 Pa (recommendation: 40 Pa) during the entire operation of the vacuum drying oven. Also after termination or cancellation of the drying process continued sweeping for at least 10 minutes is recommended.

EX	Explosion hazard by solvent-containing air penetrating and concentration in the electrical area of the chamber.
	Serious injury or death from burns and / or explosion pressure.
	Before turning on the chamber sweep the area for electrical equipment and controller housing with compressed air or inert gas at maximum overpressure for at least 10 minutes.
	Make sure that sweeping the area for electrical equipment and controller housing with an overpressure of at least 25 Pa (recommendation: 40 Pa) takes place during the en- tire operation.

9.5 Condition after establishing the power connection

Only trained personnel with key-authorization may work on the VDL vacuum drying oven.

Prior to establishing the power connection, the following points must certainly be met:

- Installation of the chamber (chap. 6) performed in compliance with the installation guidelines and ambient conditions (chap. 5)
- Vacuum supply connected (chap. 6.5)
- If required: Inert gas connection established (chap. 6.6)
- Equipotential bonding established (Chap. 6.8)

- Upon initial commissioning: Test before initial commissioning performed and passed (chap. 7)
- Technical ventilation is activated
- 10 minutes sweeping the area for electrical equipment and controller housing

Establish the power connection: connect the power plug (chap. 6.9). Connect the power supply only when needed, and disconnect it when the chamber is not in use for an extended period.

After establishing power supply the pilot lamp in the controller housing shows readiness for operation.

The authorization level is "User". To be able to use the entire functionality of the controller, log in with the desired authorization level.

All parameters, set-points and settings remain the same as before turning off.

- If the Standby mode had been activated prior to the power failure, the chamber remains off after the power returns. To operate it you must sign in with a higher authorization level and deactivate the standby mode.
- If the Standby mode had been deactivated prior to the power failure, operation continues after the power returns with previously entered parameters. If the pressure reaches or falls below the required pressure threshold of 100 mbar, the heater turns on depending on the setpoint

9.6 Standby mode Turning on and off the vacuum drying oven

Before turning on the chamber, the following points must surely be met:

- Equipotential bonding established (Chap. 6.8)
- Technical ventilation is activated
- 10 minutes sweeping the area for electrical equipment and the controller housing

Activate the chamber only as required. Switch the chamber to standby mode when it is not in use.

In standby mode no solvents may remain inside the chamber!

Before turning off the chamber (activating standby mode), completely remove all solvents from the chamber and its surroundings.



All settings and target values remain saved in standby mode.

If a program is running, it will be canceled by activating the standby mode

In Standby mode, the heating is off, and all valves are closed. Heating control and pressure control are off.

To completely separate the chamber from the power supply, you must disconnect the power plug.

For decommissioning observe the guidelines in chap. 27.2.

Required authorization: "Admin".



Press the Setpoint setting icon to access the "Setpoint" setting menu from Normal display...

Path: Setpoint > Fixed value operation setpoints > Functions on/off

In this menu you can activate and deactivate the Standby mode .

Activating the Standby mode (turning off the chamber):

Functions on/off	a 14:15:06
Standby	^
GAS/AIR 2	
Close all valves]
] –
	V
(\mathbf{X})	\odot

"Functions on/off" menu

Mark the checkbox of the function "Standby" to activate it and press the *Confirm* icon.

In the "Setpoints" menu press again the *Confirm* icon. The controller changes to Normal display.



When the function "Standby" is activated, the "Standby" icon is displayed in the screen header in Normal display. Press the flash icon next to the information icon to display the corresponding text information "Standby" (information messages, chap. 16.1).

When the controller display is dark in standby mode, press on the touchscreen to activate it for 10 seconds.

Deactivating the Standby mode (turning on the chamber

To deactivate the "Standby" function, unmark the checkbox.

9.7 Controller settings upon start up

Depending on the functions activated in the controller, various settings can be requested directly after turning on the chamber.

Then you should assign a password for the operating level (chap. 12).

The window "Language selection" enables the **language selection**, in case that it's activated in the "Start-up" menu. Afterwards occurs a request of the **time zone** and the **temperature unit**.

Language selection	Start-up		
German	Temperature unit	Degrees Celsius	•
English	Time zone	UTC+1h (CET)	•
	Daylight saving time switch	Automatic	-
	▼ Start of daylight saving time		
	▼ End of daylight saving time		
	Language query after restart	Yes	•
	\sim		C
$\mathbf{\otimes}$	(\mathbf{X})		$\mathbf{\overline{C}}$

The controller will function in the **operating mode**, which was active before the last shut-down. It controls temperature and pressure in fixed value operating mode to the last entered values and in the program mode to the set points achieved beforehand.



Locked operation



Provided that the user administration has been activated by the assignment of passwords for the different authorization types, the **controller operation** is first locked after turning on the unit, recognizable by the closed lock icon in the header.

In the locked view the controller provides all display functions. No setting functions are available.

The setpoints are shaded (light grey) in normal display. Changing them by direct entry in the fixed value operating mode is not possible. The functional icons for setpoint entry and program start in the footer are without function.

After turning on the unit, user log-in is required to operate the controller (chap. 12.2).

Operation without user log-in / without password-protection

If the password function has been deactivated, after turning on the unit without user log-in there are those controller functions available, which correspond to the highest authorization level without a password protection. There is no lock icon in the header.

9.8 Loading

Without technical ventilation the chamber must not be loaded with material containing solvents.

The chamber cannot be loaded when turned off / in standby mode .

Before loading the material to be loaded, note:

When loading the chamber also in the context of intended use, an explosive mixture may form in the working space. Therefore, a safety area of at least. 1 m in front of the oven must be considered.

- Ensure equipotential bonding. The accessible installation and operating surface of the equipment must be conductive. This installation and operating surface must be connected with the vacuum drying oven according to the grounding plan (Chap. 6.8).
- The personal protective equipment (PPE) of the operating personnel must be implemented ESD protected. This applies also to gloves.
- Activate the technical ventilation (extraction):

The operator shall provide active ventilation (technical ventilation according to country-specific regulations (TRBS 2152 Part 2 for Germany) prior to commissioning of the chamber. It must include the entire installation area of the vacuum drying oven. Loading must take place under technical ventilation in the safety area in front of the oven. Introduce only those solvents for which the auto-ignition temperature and the maximum drying temperature (safety temperature) have been determined and setting on the safety controller has been performed.

BINDER

 Acc. to IEC 60079-0, only substances with an auto-ignition temperature above 200 °C / 392 °F may be introduced into the chamber. This chamber is NOT suitable for drying substances with an autoignition temperature below 200 °C.



If the auto-ignition temperature of a solvent contained in the drying material is exceeded during the drying process, there is an immediate risk of fire and explosion. Make sure that the auto-ignition temperature of a solvent contained will NEVER be reached.

Fire and explosion hazard when exceeding the auto-ignition temperature of the solvent.
Serious injury or death from burns and / or explosion pressure.
Take the auto-ignition temperature from the safety specifications of the solvent. In the case of solvent mixtures, use the lowest auto-ignition temperature.
Correctly set the maximum drying temperature (safety temperature) on the temperature safety device according to the information panel "Temperature setting".
Introduce measures to prevent mixing up the material to be dried.
Before starting a new drying process with a different auto-ignition temperature, check the auto-ignition temperature with the safety specifications of the solvent.

If, during loading material containing solvents falls down, it is possible that the solvent or solvent vapors will spread outside the loading area, e.g. to the side of or below the chamber. The chamber must be disconnected from the power immediately (pull out the power plug or operate e.g., a customer's emergency stop switch).

The chamber is not to be installed and operated in potentially explosive areas.



9.9 Evacuation

Starting situation: The vacuum pump / vacuum system is connected and ready for operation.

Preparation:

- Make sure that the "Manual ventilation" plug (7) for emergency ventilation case of a power failure, which is located on the chamber rear, is closed
- Make sure that the pressure control is activated.
- Turn on the vacuum pump. The pump shall continue running during the entire drying procedure.
- Set the desired pressure set-point on the controller (chap. 10).
- · Monitor the internal pressure on the controller display

As long as there is a vacuum, never try to open the oven by force.

9.10 Breaking the vacuum (flooding)

9.10.1 Ventilation after completing the drying procedure (flooding with ambient air or inert gas)

The duration of the drying procedure can be determined via the pressure display on the controller. When the decreasing pressure reaches the set-point value, the drying process is completed. If the drying monitoring (chap. 11.6) is activated, a corresponding message is displayed.

To break the vacuum (ventilation) after completing the drying procedure, set the desired pressure setpoint to atmospheric pressure (chap. 10). The ventilation valve opens, and ambient air or inert gas flow into the inner chamber.

Regularly the universal connection for inert gas / ambient air "GAS/AIR" (4) is used for ventilation.

Chambers can be equipped as an option with an additional universal connection for inert gas / ambient air "GAS/AIR2" (5), which can be used alternatively. To do this, the controller function "GAS/AIR 2" serves to close the valve of the standard connection "GAS/AIR" (4). Then the valve of the optional connection "GAS/AIR 2" (5) is used for ventilation (chap. 11.2). This allows convenient switching when both connections are used differently (e.g., for inert gas and ambient air).

Ambient air is sucked in through the universal connection for inert gas / ambient air (4) or (5). The ambient air is introduced into the lower part of the rear panel of the inner chamber and is evenly distributed in the inner chamber. This supply of ambient air by under-flooding prevents turbulence of pulverized drying material.

Following ventilation, remove the loading material.

If no further drying process is to be carried out, switch the chamber to standby mode on the controller or pull the mains plug to switch off the chamber completely.

9.10.2 Operation with inert gas

When operating the VDL vacuum drying oven with inert gas, correctly follow the technical ventilation measures, as described in the DGUV guidelines 213-850 on safe working in laboratories, issued by the employers' liability insurance association (for Germany).

During operation with inert gas, the chamber is supplied with an oxygen displacing gas (e.g. N_2). Inert gases in high concentrations are hazardous to health. They are colorless and almost odorless and therefore practically imperceptible. Inhalation of inert gases can cause drowsiness up to respiratory arrest. When the O_2 content of the air decreases below 18%, there is risk of death from lack of oxygen. Any gas that might escape has to be led out via good room ventilation or a suitable exhaust system.



Install a pressure reducer for inert gas operation. Set the pressure reducer to a pressure slightly above ambient pressure. Ensure that the pressure reducer will open. Do not change this setting in order to avoid perturbation inside the oven and release of big quantities of inert gas after flooding the VDL.

Following evacuation, an inert gas, e.g., nitrogen, is led into the inner chamber via the connection "GAS/AIR" (4) or the optional connection "GAS/AIR 2" (5) until pressure compensation with the atmosphere occurs. Depending on the individual application, you can perform a second evacuation and repeat the inert gas flooding.

When the inert gas fine dosing valve is open, a maximum of approx. $0.6 \text{ m}^3/\text{h}$ gas flows into the inner chamber. The introduction of inert gas by under-flooding in the lower region of the inner chamber rear wall and the extraction at the inner chamber ceiling allow an effective inert gas flushing.

9.10.3 Ventilation / breaking the vacuum in case of a power failure

The emergency ventilation is intended for the case of a completed drying process

To be able to open the chamber in case of a power failure, remove the "Manual ventilation" plug (7) for emergency ventilation, which is located on the chamber rear.



As long as there is a vacuum, never try to open the oven by force.



Make sure that the drying procedure is complete before breaking the vacuum. Otherwise, you should wait for the power to return to continue the drying procedure.





Explosion hazard through the formation of an explosive atmosphere in the presence of hot surfaces.

Serious injury or death from burns and / or explosion pressure.

 \varnothing Do NOT remove the "Manual ventilation" plug, as long as the drying process is still running.

9.10.4 Ventilation before completing the drying procedure (flooding with ambient air or inert gas)

If possible, avoid terminating the drying process. If it is nevertheless to be done, it is essential to observe the following instructions!

Safety during the drying process: The vacuum during drying prevents the presence of an explosive atmosphere in the interior of the chamber. At the start of the drying process, the heater is therefore only released at a pressure of 100 mbar. In addition, the maximum temperature is limited so that, with correct load, there is no risk of ignition from hot surfaces.

Error: If incorrect loading with an inadmissible solvent (auto-ignition temperature <200 ° C) has occurred, proceed as follows

- Disconnect the power plug and turn off the pump.
- Let the chamber cool down to room temperature.
- Do NOT remove the "Manual ventilation" plug.
- Only ventilate when the interior temperature has cooled to room temperature. Only then open the door.

Hazard when opening the door after ventilation: After incorrect loading, open the door only when the inner temperature has sunk to ambient temperature.



Prior to a termination of a not completed drying process make sure that the auto-ignition temperatureof the solvent has been determined correctly, and that the drying temperature reached far below this. In case of doubt, do not interrupt the drying process!

Proceeding to terminate the drying process:

- Set the temperature set-point to approx. ambient temperature
- · the chamber cool down to ambient temperature
- Set the pressure set-point to approx. atmospheric pressure



9.11 Unloading the loading material



Do not unload the loading material without technical ventilation.

Note the following points before unloading the loading material:

When unloading the loading material also in the context of intended use, an explosive mixture may form in the working space. Therefore, a safety area of min. 1 m in front of the oven must be considered.



- Activate Standby mode on the controller before opening the door.
- Ensure equipotential bonding: The accessible installation and operating area in front of the equipment must be conductive. This installation and operating area must be connected to the vacuum drying over en and other equipment according to the grounding plan (chap. 6.8).
- Activate the technical ventilation (extraction):

The operator shall provide active extraction (technical ventilation according to country-specific regulations – TRBS 2152 Part 2 for Germany) prior to commissioning the oven. Extraction must include the entire installation area of the vacuum drying oven. Unloading the loading material must take place in the safety area in front of the oven with technical ventilation.

- The personal protective equipment (PPE) of the operating personnel must be implemented ESDprotected.
- Sweep the area for electrical equipment at least 10 minutes with compressed air or inert gas.

9.12 Removing the full condensate catchpot of the pump



Do not remove the full condensate catchpot of the pump without technical ventilation

Note the following points before removing the condensate catchpot:

When removing the condensate catchpot spilling of the solvent may occur.

• Ensure equipotential bonding:

The accessible installation and operation area of the equipment must be conductive. This area and the vacuum pump must be connected with the vacuum drying oven according to the grounding plan (Chap. 6.8).

• Activate the technical ventilation (extraction):

The operator shall provide active extraction (technical ventilation according to country-specific regulations – TRBS 2152 Part 2 for Germany) prior to manipulating the condensate catchpot of the pump. Extraction must include the entire installation area of the VDL and the vacuum pump, especially the area of the catchpot (when removing it) and the exhaust air of the vacuum pump. Removing the full condensate catchpot must take place under technical ventilation.

• Use ESD protected personal protective equipment:

The personal protective equipment (PPE) of the operating personnel must be implemented ESD protected. This includes also gloves.

9.13 **Preparing a new drying process**

Before starting a new drying process with a different auto-ignition temperature, determine the autoignition temperature of the solvent according to its safety data sheet. In the case of solvent mixtures, use the lowest auto-ignition temperature.

Check all settings (drying temperature, pressure set-point and safety controller setting). If appropriate, make sure that the new temperature set-point and safety controller value are entered on the controller.



With each change of the temperature set-point, observe the safety controller setting.

10. Set-point entry

	Setting ranges	Control ranges
Temperature	0.0 °C / 32 °F up to 110 °C / 230 °F	10 °C / <i>18 °F</i> above ambient temperature up to 110 °C / <i>230 °F</i>
Pressure	0 mbar up to 1100 mbar	0 mbar up to 1100 mbar



After starting the drying procedure, the heater is activated only when the pressure reaches or falls below the required pressure threshold of 100 mbar.

Solvents and resulting vapors can ignite at excessive drying temperatures.



In Fixed value operating mode you can enter a temperature set-point, a pressure set-point, and the switching-state of special controller functions.

All settings made in Fixed value operating mode remain valid until the next manual change. They are saved also when turning off the chamber or in case of toggling to Program Mode.



The values entered in Fixed value mode become valid again after the end of a program and will then be targeted and equilibrated.

When operating without a vacuum by setting "Pressure control off" (chap. 11.5), the pressure tolerance range function is automatically deactivated.

10.1.1 Set-point entry through the "Setpoints" menu



Press the Setpoint setting icon to access the "Setpoint" setting menu from Normal display.

Setpoints	a 14:04:25
 Fixed-value operation 	setpoints
Temperature	+50.000 °C
Pressure	+14.000 mbar
Functions on/off	00000000000000
▼ Control on/off	
 Safety controller 	
-	
(\mathbf{X})	

"Setpoints" menu.

Select "Fixed value operation setpoints" to access the individual parameters.

• Select the field "Temperature" and enter the desired temperature setpoint.

Confirm entry with *Confirm* icon.

• Select the field "Pressure" and enter the desired pressure setpoint.

Confirm entry with *Confirm* icon.

When entering a value outside the setting range, the message: "Value outside of limits! (Min: xxx, Max: xxx)" appears (xxx is a wildcard for the limits of the respective parameter). Press the **Confirm** icon and repeat the entry with a correct value.

After completing the settings, press the *Confirm* icon to take over the entries and exit the menu, **or** press the *Close* icon to exit the menu without taking over the entries.

With set-point type "**Limit**", adapt the safety controller (chap. 14.2) always when you changed the temperature set-point. Set the safety controller set-point by approx. 5 °C above the controller temperature set-point. Recommended setting: Set-point type "**Limit**" with safety controller set-point 5 °C.



As long as the pressure threshold of 100 mbar has not yet been reached, the icon "Pressure threshold not reached" in the screen header in Normal display. Press the flash icon next to the information icon to access the corresponding text information "Pressure threshold not reached" (Information messages, chap. 16.1)

10.1.2 Direct setpoint entry via Normal display

Alternatively you can also enter the setpoints directly via Normal display.

Fixed value		GAS AIR	⇔a 14:06:39 ▼
		Setpoint	Actual value
Temperature	°C	50.0	50.0
Pressure	mbar	14	14
		\square	

Normal display. Select the setpoint you want to change.

			AIR •	∞1 4:07:13
				50.00
+0.00	00+1	10.00		
7	8	9		
4	5	6		
1	2	3		
0	±		с	
	+0.00 7 4 1	+0.0000+1 7 8 4 5 1 2 0 ±	+0.0000+110.00 7 8 9 4 5 6 1 2 3 0 ± .	+0.0000+110.00 7 8 9 4 5 6 1 2 3 0 ± . C

Example: "Temperature" entry menu. Enter the desired setpoint and confirm entry with *Confirm* icon.

11. Setting special controller functions

You can set the following functions via the controller menu:

- Activate / deactivate the Standby mode (chap. 9.6)
- Use the optional connection "GAS/AIR2" (10) for ventilation (chap. 11.2)
- Close all existing fine dosing valves (chap. 11.3)
- Turning on / off temperature control (chap. 11.4)
- Turning on / off pressure control (chap. 11.5)
- Starting / terminating the drying monitoring (chap. 11.6)

11.1 Menu structure

(5

11.1.1 "Functions on/off" menu

This chapter describes the setting with operating mode Fixed value operation. Settings for program operation are described in chap. 18.7.3 (time programs) and chap. 19.6.5 (week programs).

In the "Functions on/off" menu you can define the switching state of three controller functions.

Press the **Setpoint setting** icon to access the "Setpoint" setting menu from Normal display.

Path: Setpoint > Fixed value operation setpoints > Functions on/off

- Function " Standby" (chap. 9.6)
- Function "GAS/AIR 2" (chap. 11.2)
- Function "Close all valves" (chap. 11.3)

Setpoints	a 14:16:04	ł
▲ Fixed-value operation	setpoints	
Temperature	+40.000 °C	
Pressure	+1100.0 mbar	
Functions on/off	00000000000100	
\bigotimes	6	Ø

"Setpoints" menu.

Select the field "Functions on/off".

"Functions on/off" entry menu.

Mark / unmark the checkbox to activate / deactivate the desired function and press the **Con***firm* icon

The functions are displayed from right to left. Activated function: switching status "1" (On) Deactivated function: switching status "0" (Off)

Example:

11.1.2 "Control on/off" menu

More functions are available via the "Control on/off" menu.

Press the *Setpoint setting* icon to access the "Setpoint" setting menu from Normal display..

Path: Setpoint > Control on/off

- Function "Temperature" (temperature control, chap. 11.4)
- Function "Pressure" (pressure control, chap. 11.5)

Setpoints		a 12:58:39
 Fixed-value operation setperation 	pints	
▲ Control on/off		
Temperature	\checkmark	
Pressure	\checkmark	
▼ Safety controller		
2		•
(\mathbf{X})		\bigcirc

"Setpoints" menu. Select the field "Control on/off". Mark / unmark the checkbox to activate / deactivate the desired function and press the *Confirm* icon

11.2 Using the optional universal connection "GAS/AIR 2" for ventilation

Regularly the universal connection for inert gas / ambient air "GAS/AIR" (4) is used for ventilation.

The "GAS/AIR 2" function serves to close the valve of the standard connection "GAS/AIR" (4) and activate the valve of the optional universal connection "GAS/AIR 2" (5), which is then used for ventilation

This allows convenient switching when both connections are used differently (e.g., for inert gas and ambient air).



If you activate the "GAS/AIR 2" function on a chamber, which is NOT equipped with the optional universal connection for inert gas / ambient air "GAS/AIR 2" (5), ventilation is no longer possible!



(سل	Press the Setpoint setting icon to access the	"Setpoint" setting menu from No	ormal display
-			

Path: Setpoint > Fixed value operation setpoints > Functions on/off

Functions on/off		a 14:13:21
Standby		^
GAS/AIR 2	\checkmark	
Close all valves		_
		=
		\vee
\bigotimes		
$\mathbf{\circ}$		${f igstyle}$

"Functions on/off" menu.

Mark the checkbox of the function "GAS/AIR 2" to activate it and press the *Confirm* icon.

In the "Setpoints" menu press again the *Confirm* icon. The controller changes to Normal display.



11.3 Close all valves

Close all existing fine dosing valves



Press the Setpoint setting icon to access the "Setpoint" setting menu from Normal display...

Path: Setpoint > Fixed value operation setpoints > Functions on/off

Functions on/off		a 14:14:03
Standby		^
GAS/AIR 2		
Close all valves	\checkmark	_
		=
5330		
		\vee
\bigotimes	F==1	\bigotimes

"Functions on/off" menu.

Mark the checkbox of the function "Close all valves" to activate it and press the **Confirm** icon.

In the "Setpoints" menu press again the *Confirm* icon. The controller changes to Normal display.



When the function "Close all valves" is activated, the "All valves closed" icon is displayed in the screen header in Normal display. Press the flash icon next to the information icon to display the corresponding text information "All valves are closed" (information messages, chap. 16.1)



11.4 Activating / deactivating temperature control

Press the Setpoint setting icon to access the "Setpoint" setting menu from Normal display..

Path: Setpoint > Control on/off

Setpoints	6 13:10:57
▼ Fixed-value operation setpoints	
Control on/off	
Temperature	
Pressure V	
\mathbf{X}	\bigcirc

"Setpoints" menu.

Select the field "Control on/off" (example: deactivated temperature control).

Mark / unmark the "Temperature" checkbox to activate / deactivate temperature control and press the *Confirm* icon.

- Checkbox marked: temperature control active
- Checkbox unmarked: temperature control deactivated

The actual temperature value continues to be displayed in Normal display:

Fixed value		GAS AIR	🖨 10:13:57 🔻
		Setpoint	Actual value
Temperature	°C		41.0
Pressure	mbar	1100	1024
	⑤ ●	í	

Normal display with deactivated temperature control.

11.5 Activating / deactivating pressure control

When operating the chamber without a vacuum connection, you can deactivate pressure control with the to avoid alarms of the pressure system. No pressure tolerance range alarms and no pressure alarm will be emitted.

Evacuation and ventilation via the controller are then no longer possible. The chamber is ventilated.

Press the **Setpoint setting** icon to access the "Setpoint" setting menu from Normal display.

Path: Setpoint > Control on/off

Setpoints	a 13:10:32
✓ Fixed-value operation setpoints	
▲ Control on/off	
Temperature	
Pressure	
- Safety controller	
	\sim
(\mathbf{X})	\bigotimes

"Setpoints" menu.

Select the field "Control on/off" (example: deactivated pressure control).

Mark / unmark the "Pressure" checkbox to activate / deactivate pressure control and press the **Confirm** icon

- Checkbox marked: pressure control active
- · Checkbox unmarked: pressure control deactivated

 Fixed value

 ⁶⁴⁵ - 10:14:55 Setpoint Actual value

 Temperature

 °C
 40.0
 40.6
 Pressure
 mbar
 --- 1024

 (i)
 (i)

The actual pressure value continues to be displayed in Normal display:

Normal display with deactivated pressure control.

11.6 Drying monitoring



Figure 24: Schematic timing of the drying process and drying monitoring

Procedure:

• Enter the temperature set-point.

The previously entered pressure setpoint is not used with this function. It remains saved.

The drying monitoring uses a fixed minimum pressure setpoint.

• Start the drying monitoring: the vacuum pump is activated, the evacuation valve opens.

Starting from ambient pressure, the pressure starts to decrease. \bigcirc

- Depending on the vapor pressure of the solvent, a plateau phase is then reached ② during which the solvent vaporizes. The pressure remains almost constant.
- After the solvent is completely evaporated, drying is complete. ③ The pressure starts to decrease again

Without drying monitoring the pressure would now continue to decrease 4, until the maximum final vacuum is reached. 5

• The drying monitoring recognizes this second pressure drop. It turns off the pressure control. The chamber will then be ventilated automatically. (6)

Prior to starting a new drying process, the pressure control must be activated again (chap. 11.4).

Notes:

If the drying monitoring is aborted during phase ① or ②, the controller will take the current actual pressure value as the pressure setpoint. This overwrites the previously entered pressure setpoint. It can be changed manually at any time.

In processes with low temperatures < 40 $^{\circ}$ C or thermally poorly coupled items to be dried (e.g. drying of powders), the drying monitoring may incorrectly identify the relevant parameters. In this case, please check the process result and, if necessary, use a process not including this program for such processes.


In Normal display press the **Program start** icon to access the "Program start" menu.

Program start	a 10:17:27		
Program type	Time program 💌		
Program	Drying monitoring		
Start section			
Program duration			
Program start	2019/09/23 10:17:23		
Program end	2019/09/27 13:17:23		
Program info	Before start: set the correct temperatur setpoint in manual mode		
$\mathbf{\hat{x}}$			

 (\blacktriangleright)

"Program start" menu with the selected Drying monitoring program.

- In the field "Program" select the setting "Drying monitoring" program.
- Select the field "Program start" and enter the desired program start time in the "Program start" entry menu. Press the *Confirm* icon. The program delay time until program start begins. The program end is calculated automatically.

After completing the settings, press the *Confirm* icon to take over the entries and exit the menu. The program starts running.

If instead you press the *Close* icon to exit the menu without taking over the entries, the program will not start.



Normal display. Information on the bottom of the screen indicates the currently running program and the time already passed. The grey bar shows how much time of the whole time is elapsed.

12. Authorization levels and password protection

We recommend that you also assign a password to the "User" authorization level so that no unauthorized person can use the chamber.

12.1 User management, authorization levels and password protection

The available functions depend on the current authorization level "Master", "Service", "Admin" or "User". The authorization levels are hierarchical: Every authorization includes all functions of the next lower level.

"Master" authorization level

- Highest authorization level, only for developers
- Extensive authorization for controller operation and configuration, outputs/inputs, alarm settings, parameter sets and operating ring display
- All passwords can be changed in the "log out" submenu (chap. 12.3).

"Service" authorization level

- Authorization level only for BINDER service
- Extensive authorization for controller operation and configuration, access to service data
- The passwords for "Service", "Admin" and "User" authorization levels can be changed in the "log out" submenu (chap. 12.3).

"Admin" authorization level

- Expert authorization level, for the administrator
- Authorization for controller configuration and network settings and for operating those controller functions required for operating the chamber. Restricted access to service data.
- Password (factory setting): "2".
- The passwords for "Admin" and "User" authorization levels can be changed in the "log out" submenu (chap. 12.3).

"User" authorization level

- Standard authorization level for the chamber operator
- Authorization for operating the controller functions required for operating the chamber.
- No authorization for controller configuration and network settings. The "Settings" and "Service" submenus of the main menu are not available.
- Password (factory setting): "1"
- The password for the "User" authorization level can be changed in the "log out" submenu (chap. 12.3).

As soon as a password has been assigned for an authorization level, the access to this level and the related controller functions are only available after log-in with the appropriate password.

If for an authorization level no password is assigned, the related controller functions of this level are available for every user without login.

If passwords have been assigned for all authorization levels, access to the controller functions is locked without login.

F

Operation after user login

At user login, the authorization level is selected and confirmed by entering the respective password.

Following user login, controller operation is available, recognizable by the open-lock icon in the header. The available controller functions correspond to the user's authorization level.



Password protection activated for all levels: operation without user login is locked

If passwords have been assigned for all authorization levels, the controller is locked without registration of a user.

As long as no user is registered, controller operation is locked, recognizable at the closed-lock icon in the header. This requires that the user management has been activated by the assignment of passwords for the individual authorization levels.



Password protection for at least one level deactivated: operation without user login is possible

If passwords have not been assigned for all authorization levels, after turning on the chamber there are those controller functions available, which correspond to the highest authorization level without password protection.

No lock icon is shown in the display header.

User login is neither required nor possible.

To activate the password protection and user login, perform new password assignment (chap. 12.5.3).



Information window

To check the authorization level of the user currently logged-in, select in Normal display the arrow far right in the display header.

Fixed value			▼ 🛁 14:19:52 ▼
		Setpoint	Actual value
Temperature	°C	40.0	40.0

The information window shows date and time, the controller's free memory space and under "Authorization" the authorization level of the current user.

If passwords have been assigned for all authorization levels, a user without login (password entry) has no authorization. There are only viewing functions available.

Fixed value	•	•
2016/05/24	I 4:32:10 ■	
Authorization:	Free storage: 98%	

Display when all authorization levels are password protected and no user has logged in: No authorization level is displayed.

If passwords have been assigned only for some of the authorization levels, a user without login (password entry) has access to the functions of the highest authorization level without password protection.

Fixed value	▼ 2
Tuesday, 2016/05/24	🖾 14:29:26
Authorization: Admin	Free storage: 98%

Display when only some of the authorization levels are password protected (example: no protection for the "User" and "Admin" levels) and no user has logged in:

The user's effective authorization (due to lack of password protection) is shown.

Example: user with "Admin" authorization.

If passwords have been assigned for some or all of the authorization levels, user login (password entry) provides the authorization for the corresponding password-protected level.

Fixed value	-	•
Tuesday, 2016/05/24	🕲 14:29:26	
Authorization: Admin	Free storage: 98%	

Display when at least some of the authorization levels are password protected and a user has logged in. The user's authorization (by password entry) is shown. Example: user with "Admin" authorization.

BINDER

12.2 Log in

Path: Main menu > User > Log in



After completing the settings, press the *Confirm* icon to take over the entries and exit the menu, **or** press the *Close* icon to exit the menu without taking over the entries.

		Main	User		Fixed value value	:56:36
		*	🖨 Log in		User level	
\frown		i	Password		Master	
		P/	Activation code		Service	_
		3/2			Admin	
Controller with deactivated		% ©			-	
password	r			ŗ		
		9	•		\otimes	\bigcirc

12.3 Log out

Path: *Main menu > User > Log out*



12.4 User change

If the password function has been deactivated (chap.12.5.2) this function is not available.

Path: *Main menu > User > User change*



12.5 Password assignment and password change

This function is not available for a user logged-in with "User" authorization.

12.5.1 Password change

A logged-in user can change the passwords of his current level and of the next lower level(s).

Example: A user with "Admin" authorization can change the passwords for the "Admin" and "User" authorization levels.



Path: Main menu > User > Password

Selection of the authorization level (example: view with "Admin" authorization)

Enter desired password. If desired, press the *Change keyboard* icon to access other entry windows.



In the "Keyboard switch" window you can select different keyboards to enter uppercase and lowercase letters, digits, and special characters. All types of characters can be combined within one single password.

Fixed value	▼ a 07:54:08
Keyboard switch	
ABCDEFGHIJKLMNOPQRSTUVWXYZ	
abcdefghijklmnopqrstuvwxyz	
0123456789	
#!?;:+-*%=,.0/	
(\mathbf{x})	

Example: access the digit entry window

To confirm the entry, press the Confirm icon.

-ixed value				• 09:14:32
Confirm password				
•				
	6			
	7	8	9	
	4	5	6	
	1	2	3	
		0		
(\mathbf{X})				

Fixed value		▼ 🔂 07:54:2
Password		
0		
0 1	2 3 4 5 6	7 8 9
•	0	
\bigotimes		(

Entry of digits

Repeat the password entry for confirmation (sample picture). For each character of the password, the required keyboard appears automatically. Then press the *Confirm* icon.

12.5.2 Deleting the password for an individual authorization level

A user logged-in with "Service" or "Admin" authorization can delete the passwords of his current level and of the next lower level(s). To do this no password is entered during a password change.

Path: Main menu > User > Password



Select the authorization level for which the password shall be deleted.

Fixed value				- → 08:52:15
Confirm password				
•				
	w	Y	z	
	Р	Q	R	
	G	н	Ν	
	,	٩	$\langle \times$	
\bigotimes				\bigcirc

Do NOT enter anything in the "Confirm password" screen. Press the *Confirm* icon.

Do NOT enter anything in the "Password" screen. Press the **Confirm** icon.

The password is deleted.

12.5.3 New password assignment for "service" or "admin" authorization level when the password function was deactivated

If the password protection for an authorization level has been deactivated, i.e., no password is assigned, no login for this level is possible. Therefore access to this authorization level is available without login.

If the password for the "Service" or "Admin" authorization has been deleted (chap. 12.5.2), a new password can be assigned for the current level and the next lower level(s) without user login.

Example: The password for the "Admin" authorization level was deleted, therefore every user without login has full access to the functions of the "Admin" authorization level. If access to this level shall become password protected again, the user can assign a new password for the "Admin" authorization level with the "Password" function.



Path: Main menu > User > Password

Select the authorization level, for which you want to assign a password.

(Example: "Admin" authorization)

Enter the desired password. If desired, press the *Change keyboard* icon to access other entry windows.

To confirm the entry, press the *Confirm* icon.

Repeat the password entry for confirmation. For each character of the password, the required keyboard appears automatically. Then press the *Confirm* icon.



12.6 Activation code

Certain functions of the controller can be unlocked with a previously generated activation code.

The activation code enables access to functions available only in the "Service" authorization level by users without a "Service" authorization. Such functions include e.g., adjustment or extended configurations.

The activation code is available in authorization levels.

Path: Main menu > User> Activation code

Controller with logged- in user	Main menu User User Device info Settings PV Programs Service Contact	Main User Image: I	
Activation code	ед 09:37:10 ▼	Activation code	32
Expiration date			
01.01.1984 00:00:00	Adjustment Configuration	0 1 2 3 4 5 6 7 8 9 A B C D E F	
User	Parameterization	t C	
	Service		
Ð	Parameter sets	8	

Activation code menu. Select the first of the four entry fields. Activation code entry window.

Enter the first four characters of the activation code and press the *Confirm* icon.

 Activation code
 AAAA
 AAAA
 AAAA
 AAAA
 AAAA
 OK

 Expiration date
 Rights
 OI.01.1984 | 00:00:00
 Adjustment
 Oconfiguration

 User
 Parameterization
 Service
 Parameter sets

"Activation code" menu with entered code (sample view). Press **OK** to take over the entry

Select the next of the four entry fields and proceed accordingly until the entire code has been entered.

The available functions are indicated by marked checkboxes.

Example: Extended configurations available.

	Adjustment
~	Configuration
	Parameterization
	Service
	Parameter sets

Under "Expiration date" the date of expiry of the code is displayed.

13. General controller settings and information

Most of the general settings can be accessed in the "Settings" submenu, which is available for users with "Service" or "Admin" authorization level. It serves to enter date and time, select the language for the controller menus and the desired temperature unit and to configure the controller's communication functions.

13.1 Selecting the controller's menu language

The MB2 program controller communicates by a menu guide using real words in German, English, French, Spanish, and Italian.

Chamber		a 14:24:38
Chamber name	VDL 115 (E3.1)	
Language	English	•
Language query after restart	German	~
Temperature unit	English	=
Audible alarm	French	
	Spanish	\mathbf{v}

Path: Main menu > Settings	>	Chamber
----------------------------	---	---------

Chamber name V	
	DL 115 (E3.1)
Language E	nglish 👻
Language query after restart	es 🔺
Temperature unit N	0
Audible alarm	20

"Chamber" submenu. Select the desired language. "Chamber" submenu.

Select if there shall be a language query after restarting the chamber and press the **Confirm** icon.

Return to Normal display with the **Back** icon to take over the entries.

13.2 Setting date and time

Following start-up of the chamber after language selection:

Start-up		
Temperature unit	Degrees Celsius 🔹	
Time zone	UTC+1h (CET) 🔹	1
Daylight saving time switch	Automatic 🔹	L
 Start of daylight saving time 		
 End of daylight saving time 		J
Language query after restart	Yes 👻	
\bigotimes	6	
$\mathbf{\otimes}$	(\mathcal{O}

Select the time zone and configure the daylight saving time switch.

Or later:

Path: Main menu > Settings > Date and time



"Date and time" submenu.

Select the field "Date / time".



"Date and time" submenu.

In the field "Daylight saving time switch" select the desired setting "Automatic" or "Inactive".

Date and time		a 10:11:15
Date / time	2016/05/25 09:58:35	
Daylight saving time switch	Automatic	•
Time zone	UTC+1h (CET)	•
 Start of daylight saving time 		
Month	March	-
Weekday/day	Sunday	-
Day of the month	Last	-
Change time	02:00:00	
 End of daylight saying time 		

"Date and time" submenu.

Select the desired start of the daylight saving time.



"Date / time" entry menu.

Enter date and time and press the *Confirm* icon.



"Date and time" submenu.

Select the desired time zone and press the *Confirm* icon.

Date and time	٩	a 10:11:39
Date / time	2016/05/25 09:58:35	
Daylight saving time switch	Automatic	•
Time zone	UTC+1h (CET)	-
▼ Start of daylight saving time		
 End of daylight saving time 		
Month	October	-
Weekday/day	Sunday	-
Day of the month	Last	-
Change time	03:00:00	

"Date and time" submenu.

Select the desired end of the daylight saving time and press the *Confirm* icon.

After completing the settings, press the *Confirm* icon to take over the entries and exit the menu, **or** press the *Close* icon to exit the menu without taking over the entries.

13.3 Selecting the temperature unit

Following start-up of the chamber:

Start-up	
Temperature unit	Degrees Celsius 👻
Time zone	UTC+1h (CET) 🔹
Daylight saving time switch	Automatic 🔹
 Start of daylight saving time 	
 End of daylight saving time 	
Language query after restart	Yes 🔻
\otimes	\bigotimes

Or later:

Path: *Main menu > Settings > Chamber*

Chamber	•a 14:28:12
Chamber name	VDL 115 (E3.1)
Language	English 👻
Language query after restart	Yes 💌
Temperature unit	Degrees Celsius
Audible alarm	Degrees Celsius
	Degrees Fahrenheit
\bigotimes	$\mathbf{\Im}$

Select the desired temperature unit and press the *Confirm* icon.

Change of the temperature unit between °C and °F.

If the unit is changed, all values are converted accordingly

Pr A	C = degree Celsius	0°C ≈ 31°F	Conversion:
50	F= degree Fahrenheit	100 °C = 212°F	[value in °F] = [value in °C] * 1,8 + 32

13.4 Display configuration

13.4.1 Adapting the display parameters

This function serves to configure parameters like display brightness and operating times.

Path: Main menu > Settings > Display > Display

Brightness 100 Wait time for screen saver 300 s Activate continuous operation Yes	
Wait time for screen saver 300 s Activate continuous operation Yes	
Activate continuous operation Yes	
	•
Begin continuous operation 06:00:00	
End continuous operation 20:00:00	

"Display" submenu.



• Select the field "Brightness".

Move the grey slide to the left or right to define the brightness of the display

- left = darker (minimum value: 0)
- right = brighter (maximum value: 100)

Press the *Confirm* icon.

Display		a 10:24:48
Brightness	1	
	100	
		Ш
\mathbf{X}		$\mathbf{\overline{\mathbf{A}}}$

- Select the field "Wait time for screen saver" and enter the desired waiting time for the screen saver in seconds. Setting range: 10 sec up to 32767 sec. During the waiting time the display is off. Confirm entry with *Confirm* icon.
- In the field "Activate continuous operation" select the desired setting "Yes" or "No".

wait unie for screen saver	500 5	
Activate continuous operation	Yes	-
Begin continuous operation	No	
End continuous operation	Yes	

- Select the field "Begin continuous operation" (possible only if continuous operation is activated) and enter the time with the arrow keys. Confirm entry with *Confirm* icon.
- Select the field "End continuous operation. (only possible if continuous operation is activated) and enter the time with the arrow keys. Confirm entry with **Confirm** icon.

After completing the settings, press the **Confirm** icon to take over the entries and exit the menu, **or** press the **Close** icon to exit the menu without taking over the entries.

13.4.2 Touchscreen calibration

This function serves to optimize the display for the user's individual angular perspective.

Path: Main menu > Calibrate touchscreen

Fixed value			▼ 🖬 14:03:49 👻	Mair	n menu	
		Setpoint	Actual value	i	Device info	\wedge
Temperature	°C	40.0	40.1	-	Device into	
Pressure	mbar	1100	1024	¢	Settings	
				₽ ¢	Programs	
				*	Service	≡
				0	Contact	
				÷	Calibrate touchscreen	\mathbf{v}
	۵ 🕃 🗎	(j		6)	

Normal display.

Select "Calibrate touchscreen" and follow the instructions on the display.

You need to touch all four corners of the touchscreen to calibrate it. Appropriate boxes appear successively in each corner.



(Ê)

 $\mathbf{\Omega}$

The waiting icon shows how much time there is left to touch the currently activated box. If the box is not touched withing this period, calibration is aborted and the display changes to Normal display.

After completing the calibration, i.e., touching all four boxes, the display changes to Normal display.

13.5 Event list

The "Event list" displays status information and errors of the current day. It enables to view the last 100 events or defective conditions of the chamber.

Press the *Event list* icon to access the event list from Normal display.

Event list		•] 1	3:18:52
2016/06/07	09:09:53	Login Service (Touch)	^
2016/06/07	09:09:53	Automatic log out Admin	
2016/06/07	07:47:25	Login Admin (Touch)	
2016/06/07	07:46:15	Automatic log out Admin	_
2016/06/07	07:46:15	Power on	Event I
2016/06/06	16:08:09	Power off	
2016/06/06	10:50:25	Login Admin (Touch)	
2016/06/06	10:49:44	Automatic log out Admin	
2016/06/06	10:49:44	Power on	V
•			(O)

Press the **Update** icon to update the event list.

Attention: Following a modification of the language setting (chap. 13.1) or the storage interval of the chart recorder (chap. 22.2) the Event list is cleared.

13.6 Service contact page

Path: Main menu > Contact





13.7 Current operating parameters

 (\mathbf{i})

Press the Information icon to access the "Info" menu from Normal display.

Info	a 14:06:17
 Program operation 	
▼ Setpoints	
✓ Actual values	
✓ Safety controller	
	(

"Info" menu. Select the desired information.

- Select "Program operation" to see information on a currently running program.
- Select "Setpoints" to see information on the entered setpoints and operation lines.
- Select "Actual values" to see information on the current actual values.
- Select "Safety controller" to see information on the safety controller status.

13.8 Technical chamber information

Path: *Main menu > Device info*

Main	Device info		
*	General	Chamber name and setup	
i	V1.X Versions	Versions of CPU, I/O module and safety con- troller	for BINDER Service
¢	In-/Outputs	Information on digital and analog inputs and outputs and phase angle outputs	for BINDER Service
₽¢⁄	Modbus inputs	Information on modbus analog and digital inputs	for BINDER Service
%	Ethernet	Information on Ethernet connection, MAC address display	chap. 20.1
0			
•	•	Back to main menu	

14. Temperature safety devices

14.1 Safety temperature limiter (TL) class 2

The safety temperature limiter (TL) serves to protect the vacuum drying oven, its environment and loading material against exceeding the permitted temperature. It has a fixed switching threshold and prevents exceeding the maximum surface temperature of the inner chamber of 160 °C in the event of a fault.. If this temperature is exceeded, the heater turns off. The TL protects the VDL vacuum drying oven, its environment and the loading material against impermissible excess temperatures and prevents exceeding the maximum drying temperature in case of a fault.

The safety temperature limiter (TL) provides mechanical temperature monitoring through an expansion tank. If the permissible temperature is exceeded, the heating is switched off via a relay and an additional self-holding circuit is activated, which is only reset when the power plug is removed and reconnected. This prevents the heating from being automatically switched on again via the relay. When the TL is triggered, an alarm message is displayed on the controller. An annual function check by the operator is recommended, for this a controller test routine is provided (chap. 16.5).

The safety temperature limiter (TL) provides ignition source monitoring. For further information of its function as part of the manufacturer's safety plan, please refer to chap. 3.1.

14.2 Overtemperature safety controller class 2

The chambers are regularly equipped with an electronic overtemperature safety controller (temperature safety device class 2 – temperature limiter) acc. to DIN 12880:2007). The safety controller protects the chamber, its environment and the charging material against exceeding the maximum permissible temperature. The safety device class 2 is electrically independent of the temperature controller and turns off the chamber permanently.

In the event of a fault in the temperature controller, the safety controller turns off the vacuum drying oven permanently, i.e. until manual alarm reset. This condition (state of alarm) is indicated visually and additionally with an audible alert if the buzzer is enabled (chap. 16.4). You can turn off the buzzer with the **OK** *button* / **Confirm** icon. The alarm persists until the chamber cools down below the configured safety controller value.

Please observe the DGUV guidelines 213-850 on safe working in laboratories, issued by the employers' liability insurance association (for Germany).

(A)

Check the setting regularly and adjust it following changes of the set-point or charge.

The temperature safety device only activates after the set-point has been reached once.

14.2.1 Safety controller mode

You can set the **safety controller mode** to "Limit" or "Offset".

• Limit: Limit value, absolute maximum permitted temperature value

This setting offers high safety as a defined temperature limit will not be exceeded. It is important to adapt the safety controller value after each modification of the temperature set-point. Otherwise, the limit could be too high to ensure efficient protection, or, in the opposite case, it could prevent the controller from reaching an entered set-point outside the limit range.

⁽K)

• **Offset:** Offset value, maximum overtemperature above any active temperature set point. The resulting maximum temperature changes internally and automatically with every temperature set-point change.

This setting is recommended for program operation. It is important to check the safety controller setpoint and safety controller mode occasionally, as it does not offer a fix, independent limit temperature value, which would never be exceeded.

Example:

Desired temperature value: 40 °C, desired safety controller value: 45 °C.

Possible settings for this example:

Temperature set point	Safety controller mode	Safety controller value
40 °C	Limit	Limit value 45 °C
40 C	Offset	Offset value 5 °C

Recommended setting: Safety controller mode "Limit", safety controller value by approx. 5 °C above the temperature set-point.

14.2.2 Setting the safety controller

	Press the Setpoint settin	ng icon to acce	ess the "Setpoint" setting menu from Normal display.
Setpoint Fixed Contro Safety	s -value operation setpoints ol on/off y controller	a 13:40:51	"Setpoints" menu. Select the field "Safety controller" to access the settings.
۲		\bigotimes	

 In the field "Mode" select the desired setting "Limit" or "Offset".

 Safety controller 		
Mode	Limit	-
Limit	Limit	
Offset	Offset	

 Select the corresponding field "Limit" or "Offset" according to the selected mode and enter the desired safety controller setpoint. Confirm entry with *Confirm* icon.



After completing the settings, press the *Confirm* icon to take over the entries and exit the menu, **or** press the *Close* icon to exit the menu without taking over the entries.

14.2.3 Message and measures in the state of alarm

The state of alarm is indicated visually and additionally with an audible alert if the buzzer is enabled (chap. 16.4).

The alarm remains active until it is acknowledged on the controller and the inner temperature falls below the set safety controller setpoint. Then the heating is released again.

Safety controller		GAS AIR	09:33:13
		Setpoint	Actual value
Temperature	°C	40.0	43.4
Pressure	mbar	100	100
		í	

Ac	tive alarms			a 09:33:33
18 1	2019/08/09	09:32:45	Safety controller	
(6			Ô
5				9

Normal display with safety controller alarm. Press the *Alarm* icon

List of active alarms. Press the **Reset alarm** icon.

14.2.4 Function check

Check the safety controller at appropriate intervals for its functionality. It is recommended that the authorized operating personnel should perform such a check, e.g., before starting a longer work procedure.

15. Tolerance range settings

In this menu you can define for temperature and pressure the deviation between the actual value and setpoint, which that shall cause a tolerance range alarm. The entered value defines the limit of permitted deviations from the set-point (exceeding and falling below). Reaching this limit triggers tolerance alarm.

In addition you can specify delay times for these alarms.

This function only activates after the set-point has been reached once.

15.1 Setting the alarm delay times and the tolerance ranges

Path: *Main menu > Settings > Various*

Various	4	14:01:18
Temp. alarm delay	+10.000 Min.	^
Temperature range	+2.0000 °C	
Press. alarm delay	+10.000 Min.	_
Pressure Range	+20.000 mbar	=
Test temp. limiter	+0.0000 -	
		V
		v
(\mathbf{X})		\bigcirc

Submenu "Various".

- Select the field "**Temp. alarm delay**" and enter the time in minutes, after which the temperature range alarm shall be triggered. Setting range: 1 min to 120 min. Confirm entry with *Confirm* icon.
- Select the field "**Temperature range**" and enter the desired value for the temperature range. Setting range: 1,0 °C to 10,0 °C. Confirm entry with *Confirm* icon.
- Select the field "**Press. alarm delay**" and enter the time in minutes, after which the pressure range alarm shall be triggered. Setting range: 1 min to 120 min. Confirm entry with **Confirm** icon.
- Select the field "**Pressure range**" and enter the desired value for the pressure range. Setting range: 10 mbar to 200 mbar. Confirm entry with **Confirm** icon.

For testing the safety temperature limiter (TB) see chap. 16.5.

After completing the settings, press the *Confirm* icon to take over the entries and exit the menu, **or** press the *Close* icon to exit the menu without taking over the entries.

15.1.1 Alarm condition

If there are actual values outside the tolerance range the following information icons for the corresponding parameter are displayed:

lcon	Signification	Information
1	"Temperature range"	The current actual temperature value is outside the tolerance range
0	"Pressure range"	The current actual pressure value is outside the tolerance range

If the condition persists, an alarm is triggered after the configured interval ("range alarm delay"). It is visually indicated in Normal display. If the alarm buzzer is activated (chap. 16.4) there is an audible alert. The alarm is shown in the list of active alarms (chap. 16.3).

16. Notification and alarm functions

16.1 Information messages

Information messages are indicated by **information icons** displayed in the screen header in Normal display.

An information icon serves as an indication of a certain condition.

If this condition persists, in some cases an alarm will be triggered after a fix or configurable interval. As long as the condition persists, the information icon therefore continues to be displayed also in state of alarm. If during alarm the conditions ends, e.g., if during a tolerance range alarm the actual value returns to within the tolerance range, the information icon disappears, whereas the alarm will continue until manual acknowledgement.

Press the flash icon next to the information icon to access the corresponding text information.

Fixe	ed value	Gas ⊜t ▲ 🖬 11:39:42 🔻
©t	Pressure threshold not reached	\smile
GAS AIR	GAS/AIR	
	GAS/AIR 2	
	All valves are closed	
	Heating active	
	Standby	

Normal display showing the text information.

The currently valid information texts are highlighted in black (example: "Pressure threshold not reached" and "GAS/AIR")

Information messages overview:

Condition	Information icon	Text information	Start after condition occurred
Deactivated temperature control		Temperature setpoint value display shows " – – – – "	immediately
Deactivated pressure control		Pressure setpoint value display shows " – – – – "	immediately
Pressure threshold of 100 mbar not reached	©t	"Pressure threshold not reached"	immediately
Ventilation via regular connection "GAS/AIR" (4)	GAS AIR	"GAS/AIR"	immediately
Ventilation via optional connection "GAS/AIR 2" (5). Regular connection "GAS/AIR" (4) deactivated.	GAS AIR2	"GAS/AIR 2"	immediately



Condition	Information icon	Text information	Start after condition occurred
All valves are closed	函	"All valves are closed"	immediately
Chamber is heating up	<u> 222</u>	"Heating active"	immediately
Standby mode activated	Ċ	"Standby"	immediately

Information messages are not shown in the event list.

16.2 Alarm messages

Alarm messages overview:

Condition	Alarm message	Start after condition occurred
The current actual temperature value is outside the tolerance range (chap. 15)	"Temperature range"	after configurable time (chap. 15.1) Factory setting: 10 minutes
The current actual pressure value is outside the tolerance range (chap. 15)	"Pressure range"	after configurable time (chap. 15.1) Factory setting: 10 minutes
Safety temperature limiter (TL) has turned off the heater	"Overtemperature"	immediately
Exceeded setpoint of the safety con- troller class 2	"Safety controller"	immediately
Inner chamber temperature sensor defective. Heater turns off.	Actual temperature value display shows e.g. " " or "<-<-< " or ">->->"	immediately
Heater temperature sensor defective. Heater turns off.	"Heater temp.sensor"	immediately
Pressure sensor defective	Actual pressure value display shows e.g. " " or "<-<-< " or ">->->"	immediately
Failure of temperature sensor for object temperature (option)	Object pressure value dis- play shows e.g. " " or "<-<-< " or ">->->"	immediately

Alarm messages are displayed in the list of active alarms until acknowledging them. They are also shown in the event list.



State of alarm

- 1. Visual indications in Normal display: alarm message, screen header flashing in red color
- 2. Audible alert, if the buzzer is enabled (chap. 16.4).



Normal display in state of alarm (example).

- (a) Screen header flashing in red color and showing the alarm message
- (b) *Alarm* icon on the bottom of the screen: change to the list of active alarms and alarm acknowledgement

16.3 Resetting an alarm

afety controller		GAS AIR	- 🛁 09:33:13 -
		Setpoint	Actual value
Temperature	°C	40.0	43.4
Pressure	mbar	100	100
		(i	
Normal disr	play in state o	f alarm (e	xample)

Press the *Alarm* icon.

List of active alarms. Press the **Reset alarm** icon.

Pressing the *Reset alarm* icon mutes the buzzer for all active alarms. The icon then disappears.

• Acknowledging while the alarm condition persists: Only the buzzer turns off. The visual alarm indication remains on the controller display. The alarm remains in the list of active alarms.

When the alarm condition has ended, the visual alarm indication is automatically cleared. The alarm is then no longer in the list of active alarms.

• Acknowledging after the alarm condition has ended: The buzzer and the visual alarm indication are reset together. The alarm is then no longer in the list of active alarms.

16.4 Activating / deactivating the audible alarm (buzzer)

Chamber	ංචු	14:33:04
Chamber name	VD 115 (E3)	
Language	English	•
Language query after restart	Yes	•
Temperature unit	Degrees Celsius	•
Audible alarm	Off	•
	Off	
	On	

Path: *Main menu* > Settings > Chamber

"Chamber" submenu (example).

In the field "Audible alarm" select the desired setting "off" or "on" and press the *Confirm* icon.

16.5 Test alarm of the safety temperature limiter (TL)

The safety temperature limiter (TL) provides temperature monitoring with a fixed switching threshold. It is an essential element of the manufacturer's safety plan to prevent ignition and explosions (chap. 3.1). Therefore, an annual function check by the operator is recommended. To do this, you can use the controller test routine described following.

For chambers equipped with a single safety temperature limiter (TL), this is tested with the setting "1". For chambers with 2 TB, the test is run twice, first with the setting "1" and then again with the setting "2".

Chambers with one TL	Chambers with two TL
VDL 23	VDL 56
VDL 23-UL	VDL 56-UL
VDL 115	VDL 115-UL

Path: *Main menu > Settings > Various*

Various	- 	14:01:18
Temp. alarm delay	+10.000 Min.	^
Temperature range	+2.0000 °C	
Press. alarm delay	+10.000 Min.	
Pressure Range	+20.000 mbar	=
Test temp. limiter	+0.0000 -	
0		~
(\mathbf{X})		\bigcirc

Submenu "Various".





 Various
 14:13:51

 Temp. alarm delay
 +10.000 Min.

 Temperature range
 +2.0000 °C

 Press. alarm delay
 +10.000 Min.

 Pressure Range
 +20.000 mbar

 Test temp. limiter
 +1.0000

 V
 V

"Test temp. limiter" setting menu.

To activate the test alarm for the first TL, enter "1" and press the *Confirm* icon..

Test temperature limit	er	aas ©t	- 🛁 14:14:28 👻
		Setpoint	Actual value
Temperature	°C	40.0	40.0
Pressure	mbar	1100	1024
🗎 🏟 🗎	(5)	(i	

Normal display in state of alarm (sample values)

The alarm message "Test temperature limiter" Screen header flashes in red color. if the buzzer is enabled there is an audible alert. Press the *Alarm* icon.

Submenu "Various" with activated test alarm "1".

Press the *Confirm* icon and go back to Normal display.

Ac	tive alarms			a 14:14:54
1	2020/04/02	14:14:13	Test temperature limiter	
e	2			6
C	2			U

List of active alarms. Press the **Reset alarm** icon.

To deactivate the test alarm, go back to the "Test temp. limiter" setting menu and set the value to "0" (test alarm deactivated).

Then pull out the power plug, let the chamber cool down for 20 minutes and then plug it in again.

For the chambers with a single safety temperature limiter (TL), the test is completed here.

For the chambers with two safety temperature limiters (TL), carry out another test for the second TL. To do this, enter "2" in the "Test temp. limiter" setting menu to activate the test alarm for the second TL and press the *Confirm* icon. Then proceed as described above.

17. Timer program (stopwatch function)

During an entered duration the controller constantly equilibrates to the setpoints entered in Fixed value operation mode (temperature, pressure, configuration of the special controller functions). This duration can be entered as a "Timer program". During the program runtime, any setpoint changes do not become effective; the controller equilibrates to the values which were active during program start.

Solvents and forming vapors can ignite if the drying temperature is too high



17.1 Starting a timer program

►

In Normal display press the **Program start** icon to access the "Program start" menu.

Program start	a 07:37:40	
Program type	Timer program	
Program	Time program	
Start section	Week program	
Program duration	Timer program	
Program start	2016/06/03 07:34:10	"Program start" menu
Program end	2016/06/03 07:34:10	
Program info	Programmhinweis	
\bigotimes		$\mathbf{\mathfrak{I}}$

- In the field "Program type" select "Timer program".
- Select the field "Program duration" and enter the desired program duration. Press the Confirm icon.
- Select the field "Program start" and enter the desired start time of the program in the "Program start" entry menu. Press the *Confirm* icon. The program delay time until program start begins.

Program	Timerprogramm	Program runtime 00:00:40
		i 🔊

Normal display.

Information on the bottom of the screen indicates the currently running program and the time already passed. The grey bar shows how much time of the whole time is elapsed.

17.1.1 Performance during program delay time

During the configured program delay time until program start, the controller equilibrates to the current setpoints of Fixed value operation mode. Modifications of these setpoints are possible but become effective only after the timer program is finished. When the configured moment for program start is reached, the program delay time ends and the program starts running. The controller equilibrates to the values which had been active during program start.

17.2 Stopping a running timer program

17.2.1 Pausing a running timer program

The program is paused. The program runtime stops running down, the time display flashes.

There are the following options:

lacksquare	Press the Program start icon to continue the program
	Press the <i>Cancelling</i> icon to cancel the program

17.2.2 Cancelling a running timer program

Press the *Program cancelling* icon to cancel the program.

A confirmation prompt is displayed. Press the *Confirm* icon to confirm that the program shall really be cancelled.

After confirming the message the controller changes to Fixed value operation mode. Temperature and humidity will then equilibrate to the setpoints of Fixed value operation mode.

17.3 Performance after the end of the program

Program end	
Device changes to fixed value operation mode.	
	\oslash

After the end of the program the message "Device changes to fixed value operation mode" appears on the screen.

Press the Confirm icon.

After confirming the message the controller changes to Fixed value operation mode. Temperature and humidity will then equilibrate to the setpoints of Fixed value operation mode.

18. Time programs

The MB2 program controller permits programming time programs with real-time reference. It offers 25 program memory positions with up to 100 program sections each.

For each program section you can enter a temperature set-point, a pressure set-point, section duration, type of temperature and pressure transition (ramp or step), the switching states of the special controller functions and the tolerance ranges.

F

 (\blacktriangleright)

Before starting the program, check the set-points entered in fixed value mode. After the end of the program, the set-points will equilibrate to these values

Solvents and forming vapors can ignite if the drying temperature is too high.



Programming remains saved in case of a power failure or after turning off the unit.

Path: *Main menu > Programs> Time program*

18.1 Starting an existing time program

In Normal display press the **Program start** icon to access the "Program start" menu.

Program start	a 10:17:27
Program type	Time program 🔹
Program	Drying monitoring -
Start section	
Program duration	
Program start	2019/09/23 10:17:23
Program end	2019/09/27 13:17:23
Program info	Before start: set the correct temperatur setpoint in manual mode
\bigotimes	

"Program start" menu

- In the field "Program type" select the setting "Time program".
- In the field "Program" select the desired program.
- Select the field "Program start" and enter the desired program start time in the "Program start" entry menu. Press the *Confirm* icon. The program delay time until program start begins.

The program end is adapted automatically depending on the entered program duration.



After completing the settings, press the *Confirm* icon to take over the entries and exit the menu. The program starts running.

If instead you press the *Close* icon to exit the menu without taking over the entries, the program will not start.



Normal display. Information on the bottom of the screen indicates the currently running program and the time already passed. The grey bar shows how much time of the whole time is elapsed. If program duration has been set to infinite, the grey bar is not displayed.

Heating takes place only when a vacuum according to the pressure threshold of 100 mbar is reached. Only then start the program or set a tolerance range for the first program section.

18.1.1 Performance during program delay time

During the configured program delay time until program start, the controller equilibrates to the current setpoints of Fixed value operation mode. Modifications of these setpoints are effective. When the configured moment for program start is reached, the program delay time ends and the program starts running.

18.2 Stopping a running time program

18.2.1 Pausing a running time program

(II) Pi	Press the Program pause icon to interrupt the program
------------------	--

The program is paused. The program runtime stops running down, the time display flashes.

There are the following options:

\bigcirc	Press the Program start icon to continue the program	
	Press the <i>Cancelling</i> icon to cancel the program	

18.2.2 Cancelling a running time program

|--|

Press the *Program cancelling* icon to cancel the program.

A confirmation prompt is displayed. Press the **Confirm** icon to confirm that the program shall really be cancelled.

After confirming the message, the controller changes to Fixed value operation mode. Temperature and humidity will then equilibrate to the setpoints of Fixed value operation mode.

18.3 Performance after the end of the program

Program end	
Device changes to fixed value operation mode.	
	\bigcirc

After the end of the program the message "Device changes to fixed value operation mode" appears on the screen.

Press the *Confirm* icon.

As long as the message has not been confirmed, the setpoint of the last program section remains effective. Program the last section as desired. If e.g. temperature and pressure control shall turn off, activate the corresponding controller functions (chap. 11.4, 11.5).

After confirming the message the controller changes to Fixed value operation mode. Temperature and humidity will then equilibrate to the setpoints of Fixed value operation mode.

18.4 Creating a new time program

Path: Main menu > Programs > Time program

Time program al 10:54		a 10:54:49
No.	Program name	
2	< empty >	^
3	< empty >	
4	< empty >	=
5	< empty >	
6	< empty >	
7	< empty >	
8	< empty >	
9	< empty >	
10	< empty >	
11	< empty >	~

"Time program" menu: overview of the existing programs. Select an empty program place.

		a 10:15:13
	Program name	
	Program info	
2		
	\bigotimes	\bigcirc

Enter the program name and, if desired, additional program information in the corresponding fields.

Press the Confirm icon.

The program view opens (chap. 18.5).

18.5 Program editor: program management

Path: Main menu > Programs > Time program

Time program 📾 10:14:37		a 10:14:37
No.	Program name	
1	program 1	~
2	program 2	
3	program 3	=
4	< empty >	
5	< empty >	
6	< empty >	
7	< empty >	
8	< empty >	
9	< empty >	
10	< empty >	\checkmark
		\bigotimes

"Time program" menu:

overview of the existing programs.

Select an existing program (example: program 3) or create a new program (chap. 18.4).

The program view opens.

Prog	gram 1 - Time	e program		a 10:56:29	
No.	Duration [hh:mm:ss]	Temperature [°C]	Pressure [mbar]	 	
1	00:00:01	220.00	1100.0	 	
					2
\mathbf{x})	[
$ \mathbf{O} $	/		Ð	\bullet	'

Program view (example: program 3).

If a new program has been created, there is just one program section.

There are the following options:

- Select a program section to open the section editor (chap. 18.6)
- Press the *Edit* icon to open the program editor



program 1 - Time program	a 20:45:57
Edit program	
Change program name	
Copy program	
Delete program	
Create new section	
\bigotimes	\bigcirc

Program editor: "Edit program" menu

Select the desired function and press the *Confirm* icon.

The program editor offers following options:

- Change the program name
- Copy program
- Replace program: Replacing an new or an existing program with the copied program. This menu point
 is visible only after a program has been copied.
- Delete program
- Create new section

a 20:45:57
00 LL 10
-

To add a new section, select "Create new section" and press the *Confirm* icon. The program view opens.

Prog	gram 1 - Time	e program		a 10:57:	30
No.	Duration [hh:mm:ss]	Temperature [°C]	Pressure [mbar]	 	
1	00:00:01	220.00	1100.0	 	
2	00:00:01	220.00	1100.0	 	
X)	(X		\bigcirc

Program view.

A new section is always added at the very bottom (example: section 2).

18.5.1 Deleting a time program

Path: *Main menu > Programs > Time program*

In the "Time program" menu select the program to be deleted. The program view opens.

In the **program view** press the *Edit* icon to open the program editor



In the **program editor** select "Delete program" and press the *Confirm* icon. The program is deleted. The controller returns to the program view.

18.6 Section editor: section management

Path: Main menu > Programs > Time program

Select the desired program.

Prop	gram 1 - Time	e program			a 10:57:30	Program 1 - Section number	r 1 😼 11:3	9:5
No.	Duration [hh:mm:ss]	Temperature [°C]	Pressure [mbar]			Duration	00:00:01	
1	00:00:01	220.00	1100.0	***	***	Course	Ramp 🕕	•
2	00:00:01	220.00	1100.0			Functions on/off	0000000000000000	
						Number of repetitions	0	
						Start section for repetition	1	
						Temperature	+220.00	
						Tolerance band min.	+0.0000	
						Tolerance band max.	+0.0000	
						Pressure	+1100.0	
X)	(e		\bigcirc	\otimes	²	6
Pro	gram vie	ew.				Section view (exa	mple: section 1).	
Select the desired program section			There are the follo	wing options:				
exa	ample: s	section 1)			 Select a parameter to enter or modify 		

program 3 - Section number 1

Section editor: "Edit section" menu Select the desired function and press the *Confirm* icon.

the according value (chap. 18.7)Press the *Edit* icon to open the program

editor

The section editor offers following options:

- Copy section
- Replace section: Replacing an existing section with the copied section. This menu point is visible only after a section has been copied.
- Insert section: Adding the copied section. This menu point is visible only after a section has been copied.
- Delete section
- Add new section

11:39:57

18.6.1 Add a new program section

program 1 - Section number 1	41 23:22:19
Edit section	
Copy section	
Delete section	
Create new section	
×	\odot

Section editor: "Edit section" menu.

Program 1 - Section number 1

Select "Create new section" and press the *Confirm* icon.

Then select whether to insert the new section before or after the current section.

program 3 - Section number 1	a 11:03:30
Add new section	
before current section	
after current section	

Press the Confirm icon. The new section opens.

18.6.2 Copy and insert or replace a program section

Prog	gram 1 - Time	program		a 10:57:3	30
No.	Duration [hh:mm:ss]	Temperature [°C]	Pressure [mbar]	 	J
1	00:00:01	220.00	1100.0	 	
2	00:00:01	220.00	1100.0	 	
\mathbf{x})	(

Program view.

Select the program section to be copied (example: section 1)

program 1 - Section number 1	a 20:59:08
Edit section	
Copy section	
Delete section	
Create new section	
$\mathbf{\hat{x}}$	\bigcirc
<u>&</u>	\bullet

Duration 00:00:01 Course Ramp • Functions on/off 0 Number of repetitions = Start section for repetition +220.00 Temperature Tolerance band min. +0.0000 Tolerance band max +0.0000 Pressure +1100.0 V \otimes \checkmark

Section view (example: section 1). Press the *Edit* icon to open the section editor.

Program 1 - Section number 1	a	11:39:57
Duration	00:00:01	^
Course	Ramp	•
Functions on/off	0000000000000000	
Number of repetitions	0	_
Start section for repetition	1	=
Temperature	+220.00	
Tolerance band min.	+0.0000	
Tolerance band max.	+0.0000	
Pressure	+1100.0	V

Section editor: "Edit section" menu

Select "Copy section" and press the *Confirm* icon.

The current section (example: section 1) is copied. The controller returns to the section view.

Section view (example: section 1).

Press the *Close* icon to change to the program view, if you want to select another section to be replaced or before or after which the copied section shall be inserted...

a 11:39:57

Λ

=

6

•

or

Duration

Course

Functions on/off Number of repetitions

Temperature

Pressure

X

Tolerance band min. Tolerance band max.

Start section for repetition

Program 1 - Section number 1

Press the *Edit* icon to open the section editor if you want the current section to be replaced or the copied section to be inserted before or after it

00:00:01

Ramp

0

1

+220.00 +0.0000

+0.0000

+1100.0

Pro	gram 1 - Time	program		a 10:57:30
No.	Duration [hh:mm:ss]	Temperature [°C]	Pressure [mbar]	
1	00:00:01	220.00	1100.0	
2	00:00:01	220.00	1100.0	

Program view.

Select the section to be replaced or before or after which the copied section shall be inserted (example: section 2) and press the **Con**firm icon.

Program 1 - Section number 1	a 11:48:00
Edit section	
Copy section	
Replace section	
Insert section	
Delete section	
Create new section	
\otimes	\bigotimes

Section editor: "Edit section" menu

18.6.3 Deleting a program section

In the program view select the program section to be deleted. The section view opens.

In the section view press the Edit icon to open the section editor



In the **section editor** select "Delete section" and press the **Confirm** icon. The section is deleted. The controller returns to the section view.

Press the *Edit* icon to open the section editor

Section view (example: section 1).

Select "Replace section" to replace the selected section with the copied section

or

Select "Insert section" to additionally add the copied section.

In this case select whether to insert it before or after the selected section.

Insert section
before current section
after current section

Press the *Confirm* icon
18.7 Value entry for a program section

Path: Main menu > Programs > Time program

Select the desired program and section.

The section view gives access to all parameters of a program section. You can enter or modify the values.

Program 1 - Section number 1		🛁 11:39:57		Program name and section number
Duration	00:00:01		^	Section duration
Course	Ramp	•		Type of setpoint transition: ramp or step
Functions on/off	000000000000000000000000000000000000000			Special controller function
Number of repetitions	0		_	
Start section for repetition	1		=	Repeating one or several sections within a program
Temperature	+220.00			Temperature setpoint
Tolerance band min.	+0.0000			
Tolerance band max.	+0.0000			Temperature tolerance range: minimum and maximum
Pressure	+1100.0			Pressure setpoint
Tolerance band min.	+0.0000			
Tolerance band max.	+0.0000		v	Pressure tolerance range: minimum and maximum
\mathbf{x}		6	2	
0			9	

The setting and control ranges for the individual parameters are the same as for "Fixed value" operating mode.

18.7.1 Section duration

program 3 - Secti	on number 1					a 10:58:07	7
Duration			00:0	00:0)1		^
program 3 - Secti	on number 2					🖨 11:14:1	9
Duration							
\odot							
	Δ		۸		Λ		
	00	:	00]:	01		
	\vee		\mathbf{v}		$\mathbf{\vee}$		
		(hł	:mm:	ss)			
						(2
×.						6	0

Section view (partial view). Select the field "Duration" indicating the time.

"Duration" entry menu.

Enter the desired section duration with the arrow keys and press the *Confirm* icon.

Setting range: 0 up to 99 hours 59 min 59 sec.

18.7.2 Set-point ramp and set-point step

You can define the type of temperature and pressure transitions for each individual program section.

"Ramp" mode: Gradual changes of temperature and pressure

The set-point of a given program section functions as the section's start temperature. During the section's duration, the set-point gradually passes to the set-point of the subsequent program section. The actual value follows the continually changing set-point.

If the last program section is in "ramp" mode and the setpoint shall change within this section, then you must program an additional section (with the shortest possible section duration) to provide the target temperature of the last program section. Otherwise, the setpoint would remain constant during the section's duration.

Programming in the "ramp" mode allows all kinds of temperature and humidity transitions:

• Gradual changes of temperature and pressure

The setpoint changes its value gradually during the entered section duration. The actual value follows the continually moving set-point at any time.

• Program sections with constant temperature and pressure

The setpoints (initial values) of two subsequent program sections are identical; so the temperature and pressure remain constant during the entire duration of the first program section.

• Sudden changes of temperature and pressure

Steps can be programmed in ramp mode as temperature or humidity changes (ramps) that occur during a very short interval. If the duration of this transitional program section is very short (minimum entry 1 sec), the temperature or humidity change will proceed rapidly within the minimum amount of time.

"Step" mode: Sudden changes of temperature and pressure

The set-point of any program section functions as the section's target value. At the start of the program section, the unit heats up and evacuates / ventilates the chamber with the maximum speed to reach the entered value; and then it holds it for the remaining section time. Therefore the set-point temperature remains constant for the section's duration. These changes occur rapidly within the minimum amount of time (minimum entry: 1 second).

Programming in the "step" mode allows only two kinds of temperature and pressure transitions:

- Programming gradual changes of temperature and humidity (ramps) is impossible in the "step" mode
- Program sections with constant temperature and pressure

The setpoints (target values) of two subsequent program sections are identical; so the temperature and pressure remain constant during the entire duration of the first program section.

• Sudden changes of temperature and pressure

The entered setpoint of the section is reached as fast as possible and then held constant for the remaining section duration.

Selecting the setting "Ramp" or "Step"

program 3 - Section number	2	a 11:17:48
Duration	00:05:00	^
Course	Ramp	_
Functions on/off	Ramp	
Number of repetitions	Step	=

Section view (partial view). In the field "Course" select the desired setting "Ramp" or "Step".





"Ramp" and "Step" mode example (representation of a temperature course)



Section No.	Duration [hh:mm:ss]	Temperature [°C]	Pressure mbar]	Ramp or Step
1	00:10:00	40.0	XXXX	Step
2	00:20:00	60.0	XXXX	Step
3	00:10:00	80.0	XXXX	Step
4	00:20:00	40.0	XXXX	Step
5	00:10:00	40.0	XXXX	Ramp
6	00:30:00	80.0	XXXX	Ramp
7	00:30:00	80.0	XXXX	Ramp
8	00:00:01	20.0	XXXX	Ramp

18.7.3 Special controller functions

In the "Functions on/off" menu you can define the switching state of three controller functions.

- Function "Standby" (chap. 9.6) •
- Function "GAS/AIR 2" (chap. 11.2)
- Function "Close all valves" (chap. 11.3)



Section view.

Select the field "Functions on/off".

Functions on/off		a 14:15:06
Standby	✓	^
GAS/AIR 2		
Close all valves		_
		=

•••		
		V
\odot		0
$\mathbf{\otimes}$		$\mathbf{\otimes}$

"Functions on/off" entry menu.

Mark / unmark the checkbox of the desired function to activate / deactivate it and press the **Confirm** icon.

The controller returns to the section view.

Program 1 - Section number 1	ଲ 11	1:43:37
Functions on/off	000000000000000000000000000000000000000	^
Number of repetitions	0	
Start section for repetition	1	
Temperature	+220.00	
Tolerance band min.	+0.0000	
Tolerance band max.	+0.0000	-
Pressure	+1100.0	
Tolerance band min.	+0.0000	
Tolerance band max.	+0.0000	V

Section view indicating the controller functions.

18.7.4 Setpoint entry

- Select the field "Temperature" and enter the desired temperature setpoint.
 Setting range: 0.0 °C up to 110.0 °C
 Confirm entry with *Confirm* icon. The controller returns to the section view.
- Select the field "Pressure" and enter the desired pressure setpoint.

Setting range: 0 mbar up to 1100 mbar

Confirm entry with *Confirm* icon. The controller returns to the section view.

18.7.5 Tolerance range

You can specify a temperature and pressure program tolerance range for each program section with different values for the tolerance minimum and maximum. When the actual value exceeds the given threshold, the program is interrupted. This is indicated on the display (see below). When the actual temperature is situated again within the entered tolerance limits, the program automatically continues. Therefore, the duration of the program may be extended due to the programming of tolerances.

ł	Programming of tolerances may extend program duration.

An entry of "-99999" for the tolerance minimum means "minus infinite" and an entry of "999999" for the tolerance maximum means "plus infinite". Entry of these values will never lead to program interruption. The entry of "0" for the tolerance minimum and/or maximum deactivates the respective tolerance function.

When requesting rapid value transitions, we recommend not programming tolerance values in order to enable the maximum heating-up speed.

Program 1 - Section number 1	-	11:39:57
Duration	00:00:01	^
Course	Ramp	•
Functions on/off	00000000000000000	
Number of repetitions	0	_
Start section for repetition	1	
Temperature	+220.00	
Tolerance band min.	+0.0000	
Tolerance band max.	+0.0000	
Pressure	+1100.0	V
⊗ (\bigcirc

Section view, showing the temperature tolerance range

- Select the field "Tolerance band min" and enter the desired lower tolerance band value. Setting range: -99999 to 99999. Confirm entry with **Confirm** icon. The controller returns to the section view.
- Select the field "Tolerance band max" and enter the desired upper tolerance band value. Setting range: -99999 to 99999. Confirm entry with *Confirm* icon. The controller returns to the section view.

Set the tolerance ranges for other parameters accordingly, if desired.

If one of the actual values (temperature and/or pressure) is outside the program tolerance range the whole program course is interrupted. During this program interruption time the controller equilibrates to the set-points of the current section.

The screen header indicates "Program pause (tolerance band)". The program runtime indication flashes and does not proceed any further.

When the temperature or pressure values are back within the entered program tolerance range, the program continues automatically.

18.7.6 Repeating one or several sections within a time program

You can repeat several subsequent sections together. It is not possible to define the start section the same time also as the target section, therefore you cannot repeat a single individual section.

Enter the desired number of repetitions in the field "Number of repetitions" and the number of the section to start the repetition cycle with in the field "Start section for repetition" To have sections repeated infinitely, enter the number of repetitions as "-1".

The selected sections are repeated as many times as selected. Then the program continues.

Duration	00.00.01	
	00.00.01	~
Course	Ramp	•
Functions on/off	000000000000000	
Number of repetitions	0	
Start section for repetition	1	=
Temperature	+220.00	
Tolerance band min.	+0.0000	
Tolerance band max.	+0.0000	
Pressure	+1100.0	V

Section view, showing the repetition function

- Select the field "Number of repetitions" and enter the desired number of repetitions. Setting range: 1 to 99, and -1 for infinite. Confirm entry with *Confirm* icon. The controller returns to the section view.
- Select the field "Start section for repetition" and enter the section number, at which the repetition should start. Setting range: 1 up to the section before the currently selected section. Confirm entry with *Confirm* icon. The controller returns to the section view.

program3 - Section number 1	a 18:23:1			
Duration	00:30:00	^		
Course	Ramp	•		
Functions on/off	000000000000000000000000000000000000000			
Number of repetitions	0			
Start section for repetition	1			
Temperature	+70.000			
Tolerance band min.	+0.0000			
Tolerance band max.	+0.0000			
Pressure	+120.00	V		
⊗ ($\mathbf{\tilde{c}}$			

18.7.7 Saving the time program

Section view (sample values).

After the all desired values of the program section have been configured, press the **Con-***firm* icon to take over the programming.

The controller changes to the program view.

No. Duration [hh:mm:ss] Temperature [°C] Pressure [mbar] 1 00:30:00 70.000 120.00 2 00:15:00 75.000 120.00 3 01:00:00 75.000 100.00	prog	gram3 - Time	program		a 18:20):5
1 00:30:00 70.000 120.00 2 00:15:00 75.000 120.00 3 01:00:00 75.000 100.00	No.	Duration [hh:mm:ss]	Temperature [°C]	Pressure [mbar]	 	
2 00:15:00 75.000 120.00 3 01:00:00 75.000 100.00	1	00:30:00	70.000	120.00	 	
3 01:00:00 75.000 100.00	2	00:15:00	75.000	120.00	 	
	3	01:00:00	75.000	100.00	 	

Program view (sample program).

Press the *Confirm* icon to take over the programming.

The controller changes to the Normal display.

To save the programming it is absolutely required to press the Confirm icon. Otherwise all settings will be lost! There is no confirmation prompt!

19. Week programs

The MB2 program controller permits programming week programs with real-time reference. It offers 5 week program places in total with up to 100 shift points for each week program.

Path: *Main menu > Programs> Week program*

For each program section you can enter the moment in time, the temperature set-point, the pressure setpoint, and the switching states of the special controller functions.



Before starting the program, check the set-points entered in fixed value mode. After the end of the program, the set-points will equilibrate to these values.

Solvents and forming vapors can ignite if the drying temperature is too high



19.1 Starting an existing week program

) In Normal display press the **Program start** icon to access the "Program start" menu.

Program start	a 08:	07:19	
Program type	Time program	•	
Program	program 1	•	
Start section	1		
Program duration			
Program start	2016/06/03 08:04:24		"Pr
Program end	2016/06/06 23:04:24		
Program info			
$(\mathbf{\hat{x}})$		\bigcirc	

Program start" menu.

- In the field "Program type" select the setting "Week program".
- In the field "Program" select the desired program.
- There are no further settings available in the "Program start" menu for week programs, as they are needed only for time programs.

After completing the settings, press the *Confirm* icon to take over the entries and exit the menu. The program starts running.

If instead you press the *Close* icon to exit the menu without taking over the entries, the program will not start.

After starting the week program, the previously entered week program setpoints are active and will be equilibrated according to the current time.

Program	n pi	rogram	n 1				
)				(i)	^	\mathbf{S}

Information on the bottom of the screen indicates the currently running program.

19.2 Cancelling a running week program

(
Press the *Program cancelling* icon to cancel the program.

A confirmation prompt is displayed. Press the *Confirm* icon to confirm that the program shall really be cancelled.

After confirming the message the controller changes to Fixed value operation mode. Temperature and humidity will then equilibrate to the setpoints of Fixed value operation mode.

19.3 Creating a new week program

Path: Main menu > Programs > Week program

Wee	k program	a 15:34:32		
No.	Program name			Program nar
26	program 1			
27	program 2			
28	< empty >			Program info
29	< empty >		\Box	
30	< empty >			-
				Course
		\bigcirc		\mathbf{X}

"Week program" menu: overview of the existing programs. Select an empty program place.



Program view.

For the first section no weekday is specified. Therefore the section is first marked in red and cannot be saved.



Enter the program name and, if desired, additional program information in the corresponding fields.

Select the set-point course "Ramp" or "Step" (chap. 19.6.1).

Press the *Confirm* icon. The program view opens.



Error message when attempting to save the program

To enter the values, select the program section which is marked in red. You will have access to the **Section view** where you can enter the values of the selected section (chap. 19.6).

19.4 Program editor: program management

Path: Main menu > Programs > Week program

No. Pro	ogram name	
26 pro	ogram 1	
	grann	
27 pro	ogram 2	
28 < e	empty >	
29 < e	empty >	
30 < e	empty >	

"Week program" menu: overview of the existing programs.

Select an existing program (example: program 1).

program 1 - Week program	a 15:43:30
Edit program	
Change program name	
Copy program	
Delete program	
Create new section	
\otimes	\bigotimes



Program view (example: program 1).

If a new program has been created, there is just one program section.

There are the following options:

- Select a program section to open the section editor (chap. 19.5)
- Press the *Edit* icon to open the program editor

Program editor: "Edit program" menu. Select the desired function and press the *Confirm* icon.

The program editor offers following options:

- Change program name. This menu also offers to configure the ramp / step mode setting (chap. 19.6.1).
- Copy program
- Replace program: Replacing an new or an existing program with the copied program. This menu point is visible only after a section has been copied.
- Delete program
- Create new section



program 1 - Week program 🖨 15:43:30	1	progra	am1 - Weel	<program< th=""><th></th><th></th><th>a 12:11:1</th><th>2</th></program<>			a 12:11:1	2
Edit program	1	No.	Weekday	Time [hh:mm:ss]	Temperature [°C]	Pressure [mbar]		
Change program name		1	Monday	08:00:00	60.000	100.00		
Copy program Delete program Create new section	⇒	2	No day	00:00:01	220.00	1100.0		
8	(\bigotimes			Ø			\bigcirc

To add a new section, select "Create new section" and press the *Confirm* icon. The program view opens.

Program view.

With a new section no weekday is specified. Therefore the section is first marked in red and cannot be saved.

A new section is always added at the very bottom (example: section 3). When the section start is specified the sections are automatically arranged in the correct chronological order.

19.4.1 Deleting a week program

Path: *Main menu > Programs > Week program*

In the "Week program" menu select the program to be deleted. The program view opens.

In the **program view** press the *Edit* icon to open the program editor



In the **program editor** select "Delete program" and press the **Confirm** icon. The program is deleted. The controller returns to the program view.

19.5 Section editor: section management

Path: Main menu > Programs > Week program

Select the desired program.

program1 - Week program	a 12:13:10	program1 - Section number 2	a 12:12:31
No. Weekday Time Temperature Pressu [hh:mm:ss] [°C] [mbar	re	Weekday Monday	•
1 Monday 08:00:00 60.000 100.00		Time 14:00:00	Û
2 Monday 14:00:00 40.000 500.00) (Temperature +40.000	
		Pressure +500.00	
		Functions on/off 00000000	0000000
Program view. Select the desired program section (example: section 2)	⊘ on	 Section view (example: section Section view (example: section There are the following option Select a parameter to end Select a parameter to end Press the <i>Edit</i> icon to option 	on 2). hs: hter or modify ap. 19.6) pen the program
		editor	
program 1 - Section number 1	a 23:22:19		
Edit section			
Copy section			
Delete section			
Create new section		Section editor: "Edit section" menu	l
		Select the desired function and pro	ess the Confirm icon.
\otimes	\odot		

The section editor offers following options:

- Copy section
- Replace section: Replacing an existing section with the copied section. This menu point is visible only after a section has been copied.
- Insert section: Adding the copied section. This menu point is visible only after a section has been copied.
- Delete section
- Create new section

19.5.1 Add a new program section

program 1 - Section number 1	a 23:22:19	prog	gram1 - Week	program			a 12:11:1	2
Edit section		No.	Weekday	Time [hh:mm:ss]	Temperature [°C]	Pressure [mbar]		
Copy section		1	Monday	08:00:00	60.000	100.00		
Delete section		2	No day	00:00:01	220.00	1100.0		
Create new section		$ \rightarrow $						
\bigotimes	\bigcirc)					
`		6	/		\odot			\bullet

Section editor: "Edit section" menu.

Select "Create new section" and press the *Confirm* icon.

Program view.

With a new section no weekday is specified. Therefore the section is first marked in red and cannot be saved.

A new section is always added at the very bottom (example: section 3). When the section start is specified the sections are automatically arranged in the correct chronological order.

19.5.2 Copy and insert or replace a program section

program 1 - Section number 1	a 20:59:08	program1 - Week program 🛁 12:13	:10
Edit section		No. Weekday Time Temperature Pressure [hh:mm:ss] [°C] [mbar]	
Copy section		1 Monday 08:00:00 60.000 100.00	
		2 Monday 14:00:00 40.000 500.00	
Delete section			
Create new section			
\otimes	\bigcirc	\otimes	\bigcirc
Section editor: "Edit section" menu		Program view	

Select "Copy section" and press the *Confirm* icon.

The current section (example: section 1) is copied.

The controller returns to the program view.

Select the section to be replaced or before or after which the copied section shall be inserted (example: section 2).

Press the Confirm icon

The controller returns to the section editor



program 1 - Section number 1	a 21:00:40
Edit section	
Copy section	
Replace section	
Insert section	
Delete section	
Create new section	
\bigotimes	\bigotimes

Select "Replace section" to replace the selected section with the copied section

or

Select "Insert section" to additionally add the copied section.

Press the Confirm icon.

If you selected "Insert section" the sections are automatically arranged in the correct chronological order.

Section editor: "Edit section" menu

19.5.3 Deleting a program section

In the program view select the program section to be deleted. The section view opens.



In the section view press the *Edit* icon to open the section editor

In the **section editor** select "Delete section" and press the **Confirm** icon. The section is deleted. The controller returns to the section view.

19.6 Value entry for a program section in the Section view

Path: Main menu > Programs > Week program

Select the desired program and section.

19.6.1 Set-point ramp and set-point step modes

The explanation of the settings "Ramp" or "Step" is given in chap. 18.7.2.

You can define the type of temperature and pressure transitions for the entire week program.

Select the desired program and press the *Edit* icon to open the program editor. In the program editor select the "Change program name" function and press the *Confirm* icon.

		a 15:36:29
Program name		
Program info	Ramp	
	Step	
Course	Ramp	
\bigotimes		\bigotimes

"Change program name" menu.

In the field "Course" select the desired setting "Ramp" or "Step" and press the *Confirm* icon.

19.6.2 Weekday

eekday Monday •	•
00:00:01	
emperature +220.00	
+1100.0	
Inctions on/off 00000000000000000000000000000000000	

In the field "Weekday" select the desired weekday.

Sunday	^
Monday	≡
Tuesday	
Wednesday	$\mathbf{\vee}$
Thursday	^
Thursday Friday	^
Thursday Friday Saturday	^ ≡

With "Daily" selected, this section will run every day at the same time.

Section view.

19.6.3 Start time



Section view. Select the field "Moment".

19.6.4 Setpoint entry

program1 - Section number 1	a 12:09:47
Weekday	Monday 👻
Time	08:00:00
Temperature	+60.000
Pressure	+100.00
Functions on/off	000000000000000000000000000000000000000
\bigotimes (

Section view.

Moment						
\odot						
	^		^		٨	
	12	:	30	:	30	
	V		v		\mathbf{v}	
		(hh	:mm:	ss)		

Entry menu "Moment".

Select with the arrow keys the desired start moment of the section and press the *Confirm* icon.

• Select the field "Temperature" and enter the desired temperature setpoint.

Setting range: 0.0 °C up to 110.0 °C

Confirm entry with **Confirm** icon. The controller returns to the section view.

• Select the field "Pressure" and enter the desired pressure setpoint.

Setting range: 0 mbar up to 1100 mbar

Confirm entry with *Confirm* icon. The controller returns to the section view.

19.6.5 Special controller functions

program1 - Section number 1	á	12:09:47
Weekday	Monday	-
Time	08:00:00	
Temperature	+60.000	
Pressure	+100.00	
Functions on/off	00000000000000000	
\mathbf{X}	۶)	

In the **"Functions on/off"** menu you can define the switching state of three controller functions.

- Function "Standby" (chap. 9.6)
- Function "GAS/AIR 2" (chap. 11.2)
- Function "Close all valves" (chap. 11.3)

For details please refer to chap. 18.7.3.

Section view.

After the all desired values of the program section have been configured, press the *Confirm* icon. The controller changes to the program view

20. Network and communication

For the network and communication settings at least the "Admin" authorization level is required.

20.1 Ethernet

20.1.1 Configuration

Path: Main menu > Settings > Ethernet



"Ethernet" submenu.



 In the field "IP address assignment" select the desired setting "Automatic (DHCP)" or "Manual".

With selection "Manual" you can enter the IPaddress, the subnet mask and the standard gateway manually.

IP address assignment	Automatic (DHCP)	<u> </u>
IP address	Manual	
Subnet mask	Automatic (DHCP)	
ID address assignment	Manual	
in address assignment	Manual	
IP address assignment	Manual 223.223.223.1	•
IP address assignment IP address Subnet mask	223.223.223.1 255.255.255.0	-

- · Select "DNS device name" and enter the DNS device name. Confirm entry with Confirm icon.
- In the field "DNS server address" select the desired setting "Automatic" or "Manual".

With selection "Manual" you can enter the DNS server address manually.

Standard gateway	Manual	
DNS device name	Automatic	
DNS server address	Automatic	
DNS server address	Automatic	
DNS server address	Manual	•

After completing the settings, press the *Confirm* icon to take over the entries and exit the menu, **or** press the *Close* icon to exit the menu without taking over the entries.

20.1.2 Display of MAC address

Path: Main menu > Device info > Ethernet

Ethernet	• 🖬 13	3:49:56
Ethernet	Yes	\wedge
MAC address	00-0C-D8-09-E3-3F	
IP address	192.168.14.87	
Subnet mask	255.255.255.0	
Standard gateway	192.168.14.1	=
DNS server	192.168.10.5	
DNS device name	MAC000CD809E33F- TYP703596	
Test were		V
•		

"Ethernet" submenu (example).

20.2 Web server

This controller menu serves to configure the web server. Then you can enter the chamber's IP-address in the Internet. The IP address is available via *Chamber information > Ethernet*. The BINDER web server opens. Enter the user name and password which have been assigned for the web server in the controller menu. This enables online access to the controller display, to see e.g., the event list or error messages. In this view no settings can be changed.

Path: Main menu > Settings > Web server

Web server	🖬 11:08:32
Password active	Yes 💌
User name	admin
Password	1234
Automatic log out after	0 Min
\bigcirc	

"Webserver" submenu.

 In the field "Password active" select the desired setting "Yes" or "No".

Password active	Yes	
User name	No	
Password	Yes	

- Select the field "User name" and enter the desired user name. Confirm entry with Confirm icon.
- Select the field "Password" and enter the desired password. Confirm entry with the Confirm icon.
- Select the field "Automatic log out after" and enter the time in minutes after which the webserver shall log out automatically. Setting range: 0 min to 65535 min. Confirm entry with *Confirm* icon.

After completing the settings, press the **Confirm** icon to take over the entries and exit the menu, **or** press the **Close** icon to exit the menu without taking over the entries.

20.3 E-Mail

As soon as an alarm was triggered, an e-mail is sent to the configured e-mail address.

Path: Main menu > Settings > Email

E-mail address entry:

email	a 11:28:45
Email address	
Email address	
Email address	
۲	\bigotimes

"Email" submenu.

Select the desired e-mail address field and enter the e-mail address. You can use the *Keyboard change* icon for entry. Confirm entry with *Confirm* icon.

E-mail server settings:

email	an 03:	40:17
Email address 1		^
Email address 2		
Email address 3		
 Email server 		
Authentication	None	• =
Email user name	Username	
Email password	Password	
SMTP mail server URL	smtp.example.net	
SMTP port number	25	
	chamber@example.net	

"Email" submenu. Select the field "Email server" to access the settings

• In the field "Authentication" select the desired setting "None" or "SMTP" auth".

With the setting "SMTP auth", you can enter a password under "Email password".

Authentication	None	
Email user name	None	
Email password	SMTP auth	
SMTP mail server URL	192.168.10.45	

- Select the field "Email user name" and enter the desired user name. Confirm entry with *Confirm* icon.
- Select the field "SMTP mail server URL" and enter the SMPT mail server URL. Confirm entry with *Confirm* icon.
- Select the field "SMTP port number" and enter the desired port number. Standard setting: "25". Confirm entry with *Confirm* icon.
- Select the field "Email sender" and enter the desired Email sender. Confirm entry with Confirm icon.

After completing the settings, press the *Confirm* icon to take over the entries and exit the menu, **or** press the *Close* icon to exit the menu without taking over the entries.

21. USB menu: Data transfer via USB interface

21.1 Using the USB connection during chamber operation

- Turn the pressure regulator to the end stop of the lock nuts (turn clockwise). The manometer then shows maximum pressure.
- Open the USB cover on the controller housing (triangle instrument box)
- Observe the display of the manometer: The overpressure must not drop below 25 Pa (recommendation: 40 Pa).
- Connect the USB stick.

If the USB stick shall remain on the chamber for a longer time, the pressure can be reset to an overpressure of at least 25 Pa (recommendation: 40 Pa) on the pressure regulator.

- Remove the USB stick when it is no longer needed
- Close the USB cover on the controller housing (triangle instrument box)
- Now the pressure regulator can be turned back (turn counterclockwise) until there is an overpressure of at least 25 Pa (recommendation: 40 Pa)..



The USB port is located in the controller housing (triangle instrument box).

When you insert a USB-stick, the "USB" menu opens.

Depending on the user's authorization level, different functions (highlighted in black) are available for the logged-in user.

USB menu	
Log-out USB stick	^
Export new chart recorder data (*.DAT)	
Export all chart recorder data (*.DAT)	
Export all chart recorder data (*.csv)	=
Import configuration and programs	
Export configuration and programs	
Import programs	
Export service data	
Software update	~
	\bigcirc

USB menu				
Log-out USB stick	^			
Export new chart recorder data (*.DAT)				
Export all chart recorder data (*.DAT)				
Export all chart recorder data (*.csv)	=			
Import configuration and programs				
Export configuration and programs	=			
Import programs				
Export service data				
Software update	\checkmark			
	\bigcirc			

Available functions with "User" authorization level

Available functions with "Admin" authorization level

Function	Explanation	
Log-out USB stick	Log-out USB stick bevor pulling it	
Export new chart recorder data (*.DAT)	Export chart recorder data, which have been added since last export, in .dat format	
Export all chart recorder data (*.DAT)	Export all chart recorder data in .dat format	
Export all chart recorder data (*.csv)	Export all chart recorder data in .csv format	
Import configuration and programs	Import configuration and timer / time / week programs	
Export configuration and programs	Export configuration and timer / time / week programs	
Import programs	Import timer / time / week programs	
Export service data	Export service data	
Software update	Controller firmware update	

22. Chart recorder display

This view offers graphic representation of the measurement course. Data representation imitates a chart recorder and allows recalling any set of measured data at any point of time taken from the recorded period.

22.1 Views

Press the *Change view* icon to access the pen recorder display.

22.1.1 Show and hide legend



Press the **Show legend** icon to display the legend on the right side of the display



22.1.2 History display



History display

Press the *History display* icon to change to the history display.



Then further icons appear:

History display with legend shown.

The chart recorder is paused. Data recording continues in the background.

Move the central red line by tapping and holding to the desired position.

The legend at the right side shows the values of the current line position.

History display: Curve selection

J	?
~	~

Curve selection

Press the *Curve selection* icon to access the "Curve selection" submenu.

19/07/29 14:01:00	1:1	
R1 Temperature		"Curve selection" submenu. Select the curves to be displayed by checking the
fi2 Pressure		checkbox of the corresponding parameter. Press the Confirm icon
\otimes	\oslash	

History display: Search the required instant

	Search
--	--------

Press the Search icon to access the "Search" submenu.



"Search" submenu.

Select the required instant by entering its date and time and press the *Confirm* icon

History display: Zoom function

\bigcirc	
\mathbf{S}	

Zoom

Press the Zoom icon to access the "Zoom" submenu.



History display: Show and hide scroll buttons to scroll to an instant

(Show scroll buttons	Hide scroll buttons	
----------	---------------------	---------------------	--

Press the **Show scroll buttons** icon to access the "Page selection" submenu.



"Page selection" submenu.

Scroll buttons are shown on the left and on the right. Use them to move along the timeline.

22.2 Setting the parameters

This menu allows setting the storage interval, the type of values to be shown and the scaling of the temperature and humidity charts.

Path: Main menu > Settings > Measurement chart

Measurement chart	a 16:23:39
Storage interval	60 s
Storage values	Current values -
n. temperature °C	+0.0000 °C
√la×. temperature °C	+300.00 °C
/lin. pressure mbar	+0.0000 mbar
Max. pressure mbar	+1600.0 mbar

"Measurement chart" submenu.

• Select the field "Storage interval" and enter the desired storage interval. Confirm entry with *Confirm* icon.

The available presentation depends on the pre-selected storage rate. Factory setting: 60 seconds. This means the higher the storage rate, the more precisely but shorter the data representation will be.

• In the field "Storage values" select the desired value type to be displayed.

Storage Interval	60 S	
Storage values	Current values	•
Min. temperature °C	Mean values	
Max. temperature °C	Current values	
Min. pressure mbar	Min. value	
Max. pressure mbar	Max. value	

 For scaling the representation select the desired minimum and maximum temperature or pressure value and enter the desired values. Temperature display range: 0 °C up to 300 °C. Pressure display range: 0 mbar up to 1600 mbar. Confirm each entry with *Confirm* icon.

Setting the storage rate or rescaling (minimum and/or maximum) will clear the measured-value memory and the event list.

NOTICE
Danger of information loss when setting the storage rate or rescaling.
 Change the storage rate or scaling ONLY if the previously registered data is no longer needed.

After completing the settings, press the *Confirm* icon to take over the entries and exit the menu, **or** press the *Close* icon to exit the menu without taking over the entries.

23. Reference measurements

23.1 Checking the temperature in the inner chamber

The controller display was adjusted in the factory to the temperature in the center of the usable volume (chap. 28.1). The sensor probe of the reference measuring device was connected tightly to an expansion rack positioned in the middle of the chamber.

23.1.1 Checking the controller display

- Conduct the reference sensor into the inner chamber through the measuring port (12). The port must be largely vacuum tight to enable a typical operation vacuum for the calibration. For a high vacuum, use a measuring access port. Usually, a silicone plug with a hole for the sensor wire is sufficient.
- Fix the sensor to the center of an expansion rack in the middle of the useable volume with adhesive aluminum tape or thermal conductive paste to ensure sufficient thermal conductivity.
- Perform the measurement in a thermally stable condition with 3 expansion racks and empty oven.
- Equilibrating time: at least 12 hours.

23.1.2 Checking the spatial temperature exactitude

- Fix at least 9 sensor probes on 3 racks with adhesive aluminum tape or thermal conductive paste to ensure sufficient thermal conductivity
- The distance of the sensor probes to all inner chamber walls must be at least 10% of the corresponding inner chamber dimension (see DIN 12880:2007).
- Perform the measurement in a thermally stable condition with 3 expansion racks and empty oven.
- Response time: at least 12 hours.



Do NOT use the temperature probe of the reference measurement device without any contact to the expansion rack, i.e., do NOT measure vacuum values!



In case the temperature probe is a thermo element, mount it so it is electrically insulated from the rack.

If you note an excessive divergence between the controller and reference temperatures, please contact BINDER Service to calibrate the temperature controller.

24. Options

24.1 APT-COM[™] 4 Multi Management software (option)

The chamber is regularly equipped with an Ethernet interface (2) that can connect the BINDER APT-COM[™] 4 Multi Management Software.

The MAC Address is indicated in the "Device info" controller menu (chap. 20.1.2).

The actual temperature and pressure values are given at adjustable intervals. Programming can be performed graphically via PC.

Up to 100 chambers can be cross-linked. For further information please refer to the APT-COM[™] 4 operating manual.

24.2 Analog outputs for temperature and pressure (option)

With this option, the camber is equipped with analog outputs 4-20 mA for temperature and pressure. These outputs allow transmitting data to external data registration systems or devices.

The connection cable is firmly connected to the connection "Analog output" (3b) located in the VDL rear connection panel. The connection is realized as a 9-poles SUB-D socket as follows:



ANALOG OUTPUT 4-20 mA DC PIN 1: Temperature + PIN 2: Temperature – PIN 4: Pressure + PIN 5: Pressure – Temperature range: 0 °C to +110 °C Pressure range: 0 mbar to 1100 mbar A suitable plug is enclosed.

Figure 25: Pin configuration of the SUB-D socket "Analog output" (8) for the analog outputs option

24.3 Measuring access port for vacuum, 9 poles (option)

The measuring access port allows creating electrical connections for low voltages or sensors between the exterior and interior of the VDL vacuum drying oven. A 9 poles plug for the outside is included



Figure 26: Measuring connection (12) with measuring access port and supplied plug

Connections at the measuring access port

- At the inner side of the measuring access port you can solder up to 9 cables. The inside connections
 must be insulated against each other and against ground. Use 300 °C / 572 °F solder.
- The 9 contacts are conducted outside via the measuring access port. You can use them to connect a device via the delivered plug.

Maximum load capacity of the switching contacts: 42 V AC/DC - 2A

Electrical hazard due to exceeding the load capacity of the switching contacts and connection socket. Deadly electric show					
	\varnothing Do NOT exceed the maximum switching load of 42 AC/DC – 2Amp.				
	 Do NOT connect any devices with a higher load capacity. Insulate the inside connections against each other and against ground. Use 300 °C / 572 °F solder. 				

24.4 Object temperature display with flexible Pt 100 temperature sensor (option)

The object temperature display permits recording the object temperature directly on or in the drying material. This enables the determination of the actual temperature of the charging material during the whole process. The object temperature is measured via a flexible Pt100 sensor inside the inner chamber and can be viewed on the controller display. The sensor needs to be in thermally conducting contact with the charging material. It can be plunged into humid charging material up to the length of its protecting tube.

The connection cable is firmly connected to the connection "Object temperature input" (3a) located in the VDL rear connection panel. The connection is realized as a 9-poles SUB-D socket



Figure 27: SUB-D socket to connect the optional Pt 100 in the rear connection panel of the chamber

24.4.1 Connection of the object temperature sensor

- Insert the Pt 100 temperature sensor from the rear through the measuring connection (12) into the inner chamber.
- The 3 contacts of the Pt 100 sensor are conducted outside via a measuring access port. From there, establish the connection to the 9-poles SUB-D socket "Object temperature input" of the connection (3a). For reasons of explosion protection, this electrical connection to the inner chamber is conducted via a triple internal safety barrier with a conducting-state voltage of 1.6 Volt maximum against ground.
- Connect the supplied cable to the measuring access port and into SUB-D-socket of the connection (3a).





Figure 28: Measuring connection (12) with measuring access port

Technical data of the Pt 100 sensor:

- Three-wire technique
- Class B (DIN EN 60751)
- Temperature range up to 320 °C / 608 °F
- Stainless steel protective tube, length 45 mm / 1.77 in, stainless steel material no. 1.4501

24.4.2 Display on the MB2 controller

Fixed value		<u></u>	▪ •€ 09:05:00 ▼
		Setpoint	Actual value
Temperature	°C	40.0	40.1
Pressure	mbar	1100	1024
Obj. Temp.	°C		10.6
	🕢 🕟	Ĵ	

Normal display with object temperature display (sample values)

The object temperature data are put out together with the data of the temperature controller to the chamber's interface and can be documented by the APT-COM[™] 4 Multi Management Software (option, chap. 24.1) developed by BINDER.

25. Cleaning and decontamination

Clean the chamber after each use to avoid potential corrosion damage by ingredients of the charging material.

25.1 Safety instructions on cleaning and decontamination

During cleaning and decontamination, no explosive atmosphere may be present in the installation area of the chamber and inside the chamber.



Prior to renewed startup, allow the chamber to completely dry after all cleaning and decontamination measures.



Avoid electrostatic charges.



Explosion hazard due to electrostatic charge when rubbing with a dry cloth. Serious injury or death from burns and / or explosion pressure.

Use only damp cloth when wiping the device. You may use water and the specified cleaning agents.

DANGER

 \varnothing NEVER wipe the device with a dry cloth.



25.2 Cleaning

Disconnect the oven from the power supply before cleaning. Disconnect the power plug.

	The interior of the chamber must be kept clean. Thoroughly remove any residues of the charg- ing material
--	--

Wipe the surfaces with a moistened towel. In addition, you can use the following cleaning agents:

Exterior surfaces,	Standard commercial cleaning detergents free from acid or halides.
inner chamber,	Alcohol based solutions.
door gaskets	We recommend using the neutral cleaning agent Art. No. 1002-0016.
Expansion racks,	Standard commercial cleaning detergents free from acid or halides, no salt solution or chlorinated solvents.
rack holders	We recommend using the neutral cleaning agent Art. No. 1002-0016.
Controller housing (tri-	Standard commercial cleaning detergents free from acid or halides.
angular instrument box)	We recommend using the neutral cleaning agent Art. No. 1002-0016.
Zinc coated hinge parts rear chamber wall	Standard commercial cleaning detergents free from acid or halides. Do NOT use a neutral cleaning agent on zinc coated surfaces.

Do not use cleaning agents that may cause a hazard due to reaction with components of the device or the charging material. If there is doubt regarding the suitability of cleaning products, please contact BINDER service.

We recommend using the neutral cleaning agent Art. No. Art. 1002-0016 for a thorough cleaning. Any corrosive damage that may arise following use of other cleaning agents is excluded from

liability by BINDER GmbH. Any corrosive damage caused by a lack of cleaning, is excluded from liability by BINDER GmbH.



NOTICE

Danger of corrosion by using unsuitable cleaners. Damage to the chamber.

- $\ensuremath{\varnothing}$ Do NOT use acidic or chlorine cleaning detergents.
- $\varnothing\,$ Do NOT use a neutral cleaning agent on other kind of surfaces e.g., the zinc coated hinge parts or the rear chamber wall.

F)
S	

For surface protection, perform cleaning as quickly as possible. After cleaning completely remove cleaning agents from the surfaces with a moistened towel. Let the chamber dry.

Soapsuds may contain chlorides and must therefore NOT be used for cleaning.



With every cleaning method, always use adequate personal safety controls.

Following cleaning, leave the chamber door open or remove the access port plugs.



The neutral cleaning agent may cause health problems in contact with skin and if ingested. Follow the operating instructions and safety hints labeled on the bottle of the neutral cleaning agent.

Recommended precautions: To protect the eyes use sealed protective goggles. Suitable protective gloves with full contact: butyl or nitrile rubber, penetration time >480 minutes.



25.3 Decontamination / chemical disinfection

The operator must ensure that proper decontamination is performed in case a contamination of the chamber by hazardous substances has occurred.

Disconnect the chamber from the power supply prior to chemical decontamination. Disconnect the power plug.

Do not use decontamination agents that may cause a hazard due to reaction with components of the device or the charging material. If there is doubt regarding the suitability of cleaning products, please contact BINDER service.

You can use the following disinfectants:

Inner chamber	ber Standard commercial surface disinfectants free from acid or halides.	
	Alcohol based solutions.	
	We recommend using the disinfectant spray Art. No. 1002-0022.	



With every decontamination / disinfection method, always use adequate personal safety controls.

In case of contamination of the interior by biologically or chemically hazardous material, proceed as follows:

Remove the vacuum expansion racks and removable rack holders and spray the inner chamber with an appropriate disinfectant.

If desired you can sterilize the vacuum expansion racks and removable rack holders in a sterilizer or autoclave. Before start-up, the chamber must be absolutely dry and ventilated, as explosive gases may form during the decontamination process.



In case of eye contact, the disinfectant spray may cause eye damage due to chemical burns. Follow the operating instructions and safety hints labeled on the bottle of the disinfectant spray.

Recommended precautions: To protect the eyes use sealed protective goggles.





After using the disinfectant spray, allow the chamber to dry thoroughly, and aerate it sufficient-

26. Maintenance and service, troubleshooting, repair, testing



26.1 General information, personnel qualifications

• Maintenance

Please refer to chap. 26.3

• Simple troubleshooting

Chap. 26.2. describes troubleshooting by operating personnel. It does not require technical intervention into the chamber, nor disassembly of chamber parts

For personnel requirements please refer to chap. 1.1

• Detailed troubleshooting

If errors cannot be identified with simple troubleshooting, further troubleshooting must be performed by BINDER Service or by BINDER qualified service partners or technicians, in accordance with the description in the VDL Service Manual.

For personnel requirements please refer to the Service Manual.

• Repair

Repair of the chamber can be performed by BINDER Service or by BINDER qualified service partners or technicians, in accordance with the description in the VDL Service Manual.

After maintenance, the chamber must be **<u>tested</u>** prior to resuming operation. An electrical test and an explosion protection test are required.

• Electrical testing

To prevent the risk of electrical shock from the electrical equipment of the chamber, an annual repeat inspection as well as a test prior to initial startup and prior to resuming operation after maintenance or repair, are required. This test must meet the requirements of the competent public authorities. We recommend testing under DIN VDE 0701-0702:2008 in accordance with the details in the Service Manual.

For personnel requirements please refer to the Service Manual.

• Test for explosion protection

Testing before initial commissioning and before restarting after maintenance or repair as well as repeat tests according to the explosion protection concept created by the operator is required.

Observe the relevant legal regulations for the qualification of the examiner. In Germany, the explosion protection test may only be carried out by a **qualified person recognized by a state authority** or by the **manufacturer** (BINDER Service.

26.2 Simple troubleshooting



Defects and shortcomings can compromise the operational safety of the chamber and can lead to risks and damage to equipment and persons. If there are is a technical fault or shortcoming, take the chamber out of operation and inform BINDER Service. If you are not sure whether there is a technical fault, proceed according to the following list. If you cannot clearly identify an error or there is a technical fault, please contact BINDER Service.



Only qualified service personnel authorized by BINDER must perform repair. Repaired chambers must comply with the BINDER quality standards and pass the required tests.



Fault description	Possible cause	Required measures	
General	-	-	
	No power supply.	Check connection to power supply.	
Chamber permanently turned	Wrong voltage.	Check power supply for voltage of 115V or 230V.	
01.	Chamber fuse has responded.	Check chamber fuse.	
	Controller defective.	Contact BINDER Service.	
Heating			
	Pressure threshold of 100 mbar	Wait until pressure threshold is reached and heater released.	
		Select suitable pressure setpoint.	
Chamber doesn't heat up.	Chamber door not properly closed.	Completely close chamber door.	
	Door gasket defective.	Replace door gasket,	
	Pt 100 sensor defective.		
	Heating element defective.	Contact BINDER service.	
	Semiconductor relay defective		
Chamber doesn't heat up. Alarm message "safety control- ler" on the controller display	Safety controller has responded: Inner chamber temperature has reached the safety controller value. Safety controller value set too low or temperature set-point too high, or error in the heating system.	Let the chamber cool down. Acknowledge the alarm on the controller. Check the settings of the temperature setpoint and safety controller value. If appropriate, select suitable safety controller value (chap. 14.2).	
	Safety controller defective.	Contact BINDER service.	
Chamber doesn't heat up. Alarm message "Overtempera- ture" on the controller display	Safety temperature limiter (TL) has turned off the heater. Cham- ber defective.	Let the chamber cool down. Acknowledge the alarm on the controller and restart the chamber (reconnect power plug). If the error repeats, turn off the chamber and contact BINDER service.	
Set-point temperature is not	Chamber door not properly closed.	Completely close chamber door.	
reached after specified time.	Door gasket defective.	Replace door gasket,	
	Controller not adjusted.	Calibrate and adjust controller.	
	Controller defective.	Contact BINDER service	
Chamber heating permanently,	Pt 100 sensor defective.		
set-point not maintained.	Semiconductor relay defective		
	Controller not adjusted.	Calibrate and adjust controller.	
Deviations from the indicated heating-up times.	Oven fully loaded.	Charge the oven less or consider longer heating-up times.	
Deviations from the temperature set-point in equilibrated state.	Invalid calibration	Use the delivered expansion racks only. Do NOT change between aluminum and stainless steel racks	
Wrong temperature value	Reference temperature sensor has insufficient contact to expan- sion rack.	Fix the reference temperature sen- sor with thermal conductive paste or adhesive aluminum tape.	
measured during calibration	Leakage current when using a thermo element not electrically isolated.	Mount a thermo element electrically isolated from the rack.	



Fault description	Possible cause	Required measures
Vacuum		·
	Door gasket defective.	Replace door gasket,
	Safety glass panel defective.	Replace safety glass panel.
Vacuum not held.	Gaskets of small flange connec- tions (universal eccentric ring) defective.	Replace gaskets of small flange connections.
	Inner tube connection leaky.	Contact BINDER Service.
Controller		
No chamber function (dark display).	Chamber is in standby mode.	Deactivate standby mode (chap. 9.6).
	Menu functions not available with current authorization level.	Log in with the required higher au- thorization.
Menu functions not available.		Log in with the required higher au- thorization. or contact BINDER ser- vice to obtain an activation code (chap. 12.6).
No access to controller	Incorrect password.	Contact BINDER service.
	Temperature control is turned off	Turn on temperature control (chap. 11.4).
Controller does not equilibrate to	Pressure control is turned off.	Turn on pressure control (chap. 11.5).
entered setpoints.	Set-points were entered in Fixed value operation mode. Controller is in program opera- tion mode.	Change to Fixed value operation mode.
Pressure alarm when operating without a vacuum connection.	Pressure control turned on.	Turn off pressure control (chap. 11.5).
Acknowledging the alarm does not cancel the alarm state.	Cause of alarm persists.	Remove cause of alarm. If the alarm state continues, contact BINDER service.
Alarm message: or <-<-< or >->->	Sensor rupture between sensor and controller or Pt 100 sensor defective.	Contact BINDER service.
	Short-circuit.	Change the stars as rate or easily r
cleared in Chart recorder func- tion, information lost.	scaling (minimum and/or maxi- mum) (chap. 22.2).	ONLY if the previously registered data are no longer required.
Program does not run correctly after starting it.	Pressure threshold of 100 mbar not reached. No heater	Wait until pressure threshold is reached and heater released. Start program after this or set suitable tolerance limits.
		If appropriate, select suitable pres- sure setpoint.
Controller does not equilibrate to program set-points.	Controller is not in program operation mode, or program delay time is running.	Start the program again. If appropri- ate, wait for the program delay time.



Fault description	Possible cause	Required measures			
Controller (continued)					
Program duration longer than programmed.	Tolerances have been pro- grammed.	For rapid transition phases, do NOT program tolerance limits in order to permit maximum heating, evacuat- ing, or ventilation speed.			
Program keeps the last program setpoint constant while in setting "ramp".	Program line with setting "ramp" is incomplete.	When programming with setting "ramp", define the end value of the desired cycle by adding an addition- al section with a section time of at least one second.			
Ramp temperature transitions are only realized as steps.	Setting "step" has been se- lected.	Select setting "ramp".			

26.3 Maintenance, Service

26.3.1 Safety instructions on maintenance work





Electrical hazard during live maintenance work. Deadly electric shock.

> Disconnect the chamber before conducting maintenance work. Pull the power plug.

DANGER

- \oslash Do NOT remove the rear panel of the chamber.
- Make sure that general maintenance work will be conducted by licensed electricians with additional skills in explosion protection (ATEX) or experts authorized by BINDER.




The warranty becomes void if maintenance work is conducted by non-authorized personnel.



Replace the door gasket only when cold. Otherwise, the door gasket may become damaged.

26.3.2 Maintenance intervals

Ensure regular maintenance work is performed at least once a year and that the legal requirements are met regarding the qualifications of service personnel, scope of testing and documentation.

Calibration of the Pt 100 controller sensor and, if required, subsequent adjustment shall be performed annually during maintenance. The procedure is described in the Service manual (customer version).

An extended test of the safety temperature limiter (TL) as described in the Service manual shall be performed annually during maintenance.

Maintenance of the pump or vacuum system must be performed regularly as specified by the manufacturer. When using the VP4 pump provided by BINDER, note the information given by the pump manufacturer.

The technical ventilation (extraction) in the installation area of the chamber must also be monitored in accordance with relevant standards and regulations(for Germany: TRBS2152 Part 2).

Regular maintenance of the pump must also be carried out.

26.4 Service Reminder

After 8760 operating hours or two years the following message appears:

Notification		
	Maintenance due!	
-		
		\bigcirc

After confirmation with the **Confirm** icon, the message window will pop up again every two weeks until it is reset by BINDER Service.

26.4.1 BINDER Service contact data

We recommend taking out a maintenance agreement. Please consult BINDER Service.

BINDER telephone hotline: +49 (0) 7462 2005 555 BINDER fax hotline: +49 (0) 7462 2005 93555 **BINDER** e-mail hotline: service@binder-world.com BINDER service hotline USA: +1 866 885 9794 or +1 631 224 4340 x3 (toll-free in the USA) BINDER service hotline Asia Pacific: +852 390 705 04 or +852 390 705 03 BINDER service hotline Russia and CIS +7 495 988 15 16 **BINDER** Internet website http://www.binder-world.com **BINDER** address BINDER GmbH, post office box 102, D-78502 Tuttlingen

International customers, please contact your local BINDER distributor.

26.5 Sending the chamber back to BINDER GmbH

If you return a BINDER product to us for repair or any other reason, we will only accept the product upon presentation of an **authorization number** (RMA number) that has previously been issued to you. An authorization number will be issued after receiving your complaint either in writing or by telephone **prior** to your sending the BINDER product back to us. The authorization number will be issued following receipt of the information below:

- BINDER product type and serial number
- Date of purchase
- Name and address of the dealer from which you bought the BINDER product
- Exact description of the defect or fault
- Complete address, contact person and availability of that person
- Exact location of the BINDER product in your facility
- A contamination clearance certificate (chap. 32) must be faxed in advance

The authorization number must be applied to the packaging in such a way that it can be easily recognized or be recorded clearly in the delivery documents.

For security reasons we cannot accept a chamber delivery if it does not carry an authorization number.

Return address:

BINDER GmbH Abteilung Service Gänsäcker 16 78502 Tuttlingen Germany

27. Disposal

27.1 Disposal of the transport packing

Packing element	Material	Disposal
Straps to fix packing on pallet	Plastic	Plastic recycling
Wooden transport box (option)	Non-wood (compressed match- wood, IPPC standard)	Wood recycling
with metal screws	Metal	Metal recycling
Pallet	Solid wood (IPPC standard)	Wood recycling
with foamed plastic stuffing	PE foam	Plastic recycling
Shipping box	Cardboard	Paper recycling
with metal clamps	Metal	Metal recycling
Top cover	Cardboard	Paper recycling
Edge protection	Styropor [®] or PE foam	Plastic recycling
Protection of doors	PE foam	Plastic recycling
Bag for operating manual	PE foil	Plastic recycling
Insulating air cushion foil (packing of optional accessories)	PE foil	Plastic recycling

If recycling is not possible, all packing parts can also be disposed of with normal waste.

27.2 Decommissioning

- Disconnect the oven from the power supply. Disconnect the power plug.
- Turn off the inert gas supply.

Through the open inert gas connection, inert gas can enter the vacuum drying oven and escape into the ambient air.



- Turn off the vacuum pump. Ventilate the chamber as described in chap. 9.10.1.
- Remove the vacuum connection (chap. 6.5).
- Remove the inert gas connection and the pressure reducer (chap. 6.6).
- Temporal decommissioning: See indications for appropriate storage, chap. 4.3.

Final decommissioning: Dispose of the chamber as described in chap. 27.3 to 27.5.

27.3 Disposal of the chamber in the Federal Republic of Germany

According to Annex I of Directive 2012/19/EU of the European Parliament and of the Council on waste electrical and electronic equipment (WEEE), BINDER devices are classified as "monitoring and control instruments" (category 9) only intended for professional use". They must not be disposed of at public collecting points.

The chambers bear the symbol for the marking of electrical and electronic equipment manufactured / placed on the market in the EC after 13 August 2005 and be disposed of in separate collection according to Directive 2012/19/EU on waste electrical and electronic equipment (WEEE) and German national law for electrical and electronic equipment (Elektro- und Elektronikgerätegesetz, ElektroG). WEEE marking: crossed-out wheeled bin with solid bar under. A significant part of the materials must be recycled in order to protect the environment.



At the end of the device's service life, have the chamber disposed of according to the German national law for electrical and electronic equipment (Elektro- und Elektronikgerätegesetz, ElektroG from 20 October 2015, BGBI. I p. 1739) or contact BINDER service who will organize taking back and disposal of the chamber according to the German national law for electrical and electronic equipment (Elektro- und Elektronikgerätegesetz, ElektroG from 20 October 2015, BGBI. I p. 1739).





Certified companies disassemble waste (used) BINDER equipment in primary substances for recycling according to Directive 2012/19/EU. The devices must be free from toxic, infectious or radioactive substances in order to eliminate any health hazards to the employees of the recycling companies.

Prior to handing the chamber over to a recycling company, it is the user's responsibility that it is free from toxic, infectious or radioactive substances.
Prior to disposal, clean all introduced or residual toxic substances from the chamber.
Prior to disposal, disinfect the chamber from all sources of infection. Be aware that sources of infection may also be located outside the inner chamber.
If you cannot safely remove all toxic substances and sources of infection from the chamber, dispose of it as "special" waste according to national law.
Fill out the contamination clearance certificate (chap. 32) and enclose it with the chamber.



Danger of intoxication and infection through contamination of the chamber with toxic, infectious or radioactive substances.

Damages to health.

- Ø NEVER take a chamber contaminated with toxic substances or sources of infection for recycling according to Directive 2012/19/EU.
- Prior to disposal, remove all toxic substances and sources of infection from the chamber.
- A chamber from which all toxic substances or sources of infection cannot be safely removed must be considered as "special" waste according to national law. Dispose of it accordingly.

27.4 Disposal of the chamber in the member states of the EU except for the Federal Republic of Germany

According to Annex I of Directive 2012/19/EU of the European Parliament and of the Council on waste electrical and electronic equipment (WEEE), BINDER devices are classified as "monitoring and control instruments" (category 9) only intended for professional use". They must not be disposed of at public collecting points.

The chambers bear the symbol for the marking of electrical and electronic equipment manufactured / placed on the market in the EC after 13 August 2005 and be disposed of in separate collection according to the Directive 2012/19/EU on waste electrical and electronic equipment (WEEE). WEEE marking: crossed-out wheeled bin with solid bar under.



At the end of the device's service life, notify the distributor who sold you the device, who will take back and dispose of the chamber according to the Directive 2012/19/EU on waste electrical and electronic equipment (WEEE).



15 -224	NOTICE
S.C.E	Danger of violation against existing law if not disposed of properly. Alteration of the environment.
	arnothing Do NOT dispose of BINDER devices at public collecting points.
	Have the device disposed of professionally at a recycling company that is certified ac- cording to conversion of the Directive 2012/19/EU into national law. or
	Instruct the distributor who sold you the device to dispose of it. The agreements apply that were agreed with the distributor when purchasing the chamber (e.g. his general terms of payment and delivery).
	If your distributor is not able to take back and dispose of the chamber, please contact BINDER service.

Certified companies disassemble waste (used) BINDER equipment in primary substances for recycling according to Directive 2012/19/EU. The devices must be free from toxic, infectious or radioactive substances in order to eliminate any health hazards to the employees of the recycling companies.

Prior to handing the chamber over to a recycling company, it is the user's responsibility that it is free from toxic, infectious or radioactive substances.

- Prior to disposal, clean all introduced or residual toxic substances from the chamber.
- Prior to disposal, disinfect the chamber from all sources of infection. Be aware that sources of infection may also be located outside the inner chamber.
- If you cannot safely remove all sources of infection and toxic substances from the chamber, dispose of it as "special" waste according to national law.
- Fill out the contamination clearance certificate (chap. 32) and enclose it with the chamber.



27.5 Disposal of the chamber in non-member states of the EU



NOTICE

Danger of violation against existing law if not disposed of properly. Alteration of the environment.

- For final decommissioning and disposal of the vacuum drying oven, please contact BINDER Service.
 - Follow the statutory regulations for appropriate, environmentally friendly disposal.

The main board of the vacuum drying oven in the controller housing (triangular instrument box) includes a lithium cell. Please dispose of it according to national regulations.

28. Technical description

28.1 Factory calibration and adjustment

This chamber was calibrated and adjusted in the factory. Calibration and adjustment were performed using standardized test instructions, according to the QM DIN EN ISO 9001 system applied by BINDER (certified since December 1996 by TÜV CERT). All test equipment used is subject to the administration of measurement and test equipment that is also a constituent part of the BINDER QM DIN EN ISO 9001 systems. They are controlled and calibrated to a DKD-Standard at regular intervals.

Factory adjustment was done in the center of the usable volume and under vacuum conditions. The sensor is fixed in the middle of the expansion rack in a way ensuring good thermal conductivity (heat conduction). Measuring is performed in equilibrated state.



28.2 Over current protection

The chambers are protected by one or two miniature fuses against over current, accessible from the outside. The miniature fuses are located at the rear of the chamber next to the power cable connection. Each fuse holder is equipped with a fuse clip 5mm x 20 mm (cUL version 6,3x32 mm). A fuse may be replaced only with a substitute of the same ratings. Refer to the technical data of the respective device type.

28.3 VDL / VDL-UL technical data

Chamber size		23	56	115
External dimensions				
Vacuum drying oven				
Width, net	mm / inch	520 / 20.47	637 / 25.10	742 / 29.21
Height, gross (including feet)	mm / inch	720 / 28.35	837 / 32.95	964 / 37.95
Depth, net	mm / inch	490 / 19.29	540 / 21.26	660 / 25.98
Depth, gross (including controller, door handle, connections, pressure regulator)	mm / inch	632 / 24.88	680 / 26.77	801 / 31.54
Window width	mm / inch	265 / 10.43	380 / 14.96	486 / 19.13
Window height	mm / inch	265 / 10.43	380 / 14.96	486 / 19.13
Pump module (option)				
Width, net	mm / inch	523 / 20.59	638 / 25.12	743 / 29.25
Height, net	mm / inch	705 / 27.76	705 / 27.76	705 / 27.76
Depth, net	mm / inch	491 / <i>19.</i> 33	539 / 21.22	659 / 25.94
Depth, gross (including door handle, connec- tions)	mm / inch	546.5 / 21.52	594.5 / 23.41	714.5 / 28.13

Chamber size			23	56	115	
External dimensions						
Chamber with optional pump module						
Width, net		mm / inch	523 / 20.59	637 / 25.10	742 / 29.21	
Height, net			mm / inch	1425 / 56.10	1542 / 60.71	1669 / 65.71
Depth, net			mm / inch	491 / 19.33	540 / 21.26	660 / 25.98
Depth, gross (including controller, door handle, connections, pressure regulator)		mm / inch	632 / 24.88	680 / 26.77	801 / <i>31.54</i>	
Wall clearances		•				
Wall clearance, rear (minimum)		mm / inch	100 / 3.94	100 / 3.94	100 / 3.94	
Wall clearance, side (minin	num)		mm / inch	70 / 2.76	70 / 2.76	70 / 2.76
Internal dimensions				ſ		[
Width			mm / inch	285 / 11.22	400 / 15.75	506 / 19.92
Height			mm / inch	285 / 11.22	400 / 15.75	506 / 19.92
Depth			mm / inch	295 / 11.61	343 / 13.50	460 / 18.11
Interior volume			/ cu.ft.	24 / 0.85	55 / 1.94	119 / 4.20
Racks	()				0	0
Number of expansion racks	s (aluminum), seri	es		2	2	2
Number of expansion racks	s (aluminum), max	(.	mm Linch	4	5	0
	S		mm / inch	224 x 290	02 / 2.44 240 x 220	00 / 2.00
Usable space per rack (wic	tth x depth)			9.21 x 11.02	13.74 x 12.60	455 x 440 17.91 x 17.32
Permissible load per rack			Kg / Ibs	20 / 44	20 / 44	20 / 44
Permissible total load			Kg / Ibs	50 / 110	60 / 132	70 / 154
Weight						
Weight (empty) K		Kg / Ibs	72 / 159	104 / 229	158 / 348	
Temperature data						
Temperature range	degrees above ro temperature	om	°C / °F	9 / 16.2	9 / 16.2	9 / 16.2
	up to		°C / °F	110 / 230	110 / 230	110 / 230
Temperature fluctuation at	100 °C / 212 °F		± K	0,1	0,1	0.1
Temperature uniformity (va at 100 °C / 212 °F	ariation)		± K	1,0	1,5	2,9
Heating up time to 100 °C	/ 212 °F		Min	150	140	170
Vacuum data		n		1		
Vacuum connection with sr	mall flange	DN	mm / <i>inch</i>	16	16	16
Measuring access port with	n small flange	DN	mm / inch	16	16	16
Inert gas connection with flow-limiter Adapter with hose olive \varnothing r		mm / <i>inch</i>	8	8	8	
Vacuum range (adjustable) mt		oar / <i>inHg</i>	10 to 1100	10 to 1100	10 to 1100	
Leak rate bar		/h/ <i>inHg/h</i>	1x10 ⁻² / 0.295	1x10 ⁻² / 0.295	1x10 ⁻² / 0.295	
Ex Classification						
Ex-Classification of the entire chamber according to ATEX Directive 2014/34/EU		Æx>	II 2/3/- G IIB T	3 Gb/Gc/- X		
Electrical data (model ver	sions VDL023-230	DV, V	/DL056-230)V, VDL115-23	0V)	
Protection type according t controller housing	o EN 60529 - MB2	2	IP	20	20	20
Protection type, VDL gener	ral (type plate)		IP	20	20	20

Chamber size		23	56	115	
Electrical data (model versions VDL023-230V, VDL056-230)V, VDL115-23	0V) (continued)		
Nominal voltage	at 50 Hz power frequency	V	200-230	200-230	200-230
(+/-10%)	at 60 Hz power frequency	V	200-230	200-230	200-230
Current type	·		1N~	1N~	1N~
Nominal power		kW	0,90	1,40	1,60
Nominal current		Α	3,9	6,1	7,0
Chamber fuse 5 x 2	0 mm / 250V / time-lag T	Α	2 x 6,3	2 x 8	2 x 10
Power plug			Grounded plug		
Over-voltage catego	ory acc. to IEC 61010-1		II	II	II
Pollution degree acc	c. to IEC 61010-1		2	2	2
Different electrical data for VD-UL constructed for th (model versions VDL023UL-120V, VDL056UL-120V, VD		d for the US 20V, VDL11	SA and Canad 5UL-120V)	а	
Nominal voltage	at 50 Hz power frequency	V	100-120	100-120	100-120
(+/-10%)	at 60 Hz power frequency	V	100-120	100-120	100-120
Nominal current	·	Α	7,5	11,7	13,4
Chamber fuse 5 x 2	0 mm / 250V / time-lag T	Α	10	2 x 16	
Chamber fuse 6.3 x 32 mm / 250V / time-lag T		Α			2 x 20
Power plug		NEMA	5-15P	5-20P	5-20P
Environment-specific data					
VDL noise level (me	an value)	dB (A)	40	40	40
Energy consumption at 100 °C / 212 °F		Wh/h	140	180	230

All technical data is specified for unloaded chambers with standard equipment (with aluminum racks) at an ambient temperature of +22 °C +/- 3 °C / 71.6 °F +/- 5.4 °F and a power supply voltage fluctuation of +/- 10 %. Technical data is determined in accordance to BINDER Factory Standard Part 2:2015 and DIN 12880:2007.

All indications are average values, typical for chambers produced in series. We reserve the right to change technical specifications at any time.

28.4 Equipment and options (extract)

To operate the VDL vacuum drying oven, use only original BINDER accessories or accessories / components from third-party suppliers authorized by BINDER. The user is responsible for any risk arising from using unauthorized accessories.

Regular equipment

Microprocessor display program controller MB2 with touch screen

Ethernet interface for computer communication

USB interface

Safety controller (safety device class 2 according to DIN 12880:2007)

Universal connection for inert gas / ambient air "GAS/AIR", adapter with 8 mm hose olive, with finedosing valve for inert gas / ambient air

Pressure regulator (rear) for sweeping with compressed air

Analog pressure display (manometer) for sweeping with compressed air

Pressure switch for heating release at 100 mbar

Measuring connection (DN 16), rear

2 vacuum expansion racks

Safety glass panel

Options / accessories			
Expansion racks , aluminum or stainless steel 1.4571			
Lockable door			
Analog outputs 4-20 mA for temperature and pressure			
Measuring access port for vacuum, 9 poles (DN 16) for measuring connection	on (DN 16), re	ear	
Additional universal connection for inert gas / ambient air "GAS/AIR 2", adap with fine-dosing valve for inert gas / ambient air	oter with 8 mr	n hose olive,	
Additional universal access port 40 mm			
FKM door gasket (temperature resistant up to 150 °C / 302 °F			
Object temperature display with flexible Pt 100 temperature sensor			
APT-COM™ 4 Multi Management Software for logging and display of temperature data and networking up to 100 chambers with PC			
ATEX connection kit for VP4 vacuum pump with various small flange parts			
Pump module			
Chemical membrane pump VP4 with separator and emission condenser			
Ready to connect: Suction power	m³/h	1,9	
End vacuum	mbar	12	
Electrical connection (50-60 Hz)	V	120 / 230	
Factory calibration certificate		÷	
Extension to factory calibration certificate (additional value)			
Calibration certificate of object temperature display			
Calibration certificate of pressure display			
Extension to factory calibration certificate (additional value) of pressure display			
Qualification folder			
Evaporating dish, small or large			
Stable table on wheels with castors and locking brakes			

28.5 Accessories and spare parts (extract)

BINDER GmbH is responsible for the safety features of the chamber only, provided skilled electricians or qualified personnel authorized by BINDER perform all maintenance and repair, and if components relating to chamber safety are replaced in the event of failure with original spare parts. The user is responsible for any risks arising from using unauthorized accessories/components.

Failure to follow these instructions can result in loss of explosion protection.

Chamber size	23	56	115
Description	Art. no.		
Expansion rack, aluminum	8009-1031	8009-1030	8009-1029
Expansion rack, stainless steel	8009-1093	8009-1092	8009-1091
Exchange of aluminum expansion racks for stainless steel, calibration included	8012-1955	8012-1956	8012-1957
Silicon door gasket, temperature-resistant up to 200 °C / 392°F	6005-0290	6005-0291	6005-0292
FKM door gasket, temperature-resistant up to 150 °C / 302 °F, acid-resistant, silicon free	8012-0502	8012-0501	8012-0500



Chamber size	23	56	115
Description	Art. no.		
Chamber fuse 5 x 20 mm / 250V / time lag T for VDL 230 V	5006-0092	5006-0093	5006-0079
Chamber fuse 5 x 20 mm / 250V / time lag T for VDL 23- UL, VD 56-UL	5006-0079	5006-0103	
Chamber fuse 6,3 x 32 mm / 250V / time lag T for VDL 115-UL			5006-0030
Safety glass panel	6012-0012	6012-0013	6012-0014
Rack holder	6004-0230	6004-0229	6004-0211
Pump module	8012-1948	8012-1949	8012-1950

Description	Art. no.
Accessory kit, consisting of:	8009-0070
Copper seal ring	6005-0056
Hose olive	6009-0064
Universal centering ring	6009-0048
Straining ring	6009-0009
Blind flange	6009-0010
Door handle, complete	6002-0541
Stable table on wheels with castors and locking brakes	9051-0018
Evaporating dish, small	4022-0125
Evaporating dish, large	4022-0126
Vacuum pump VP 4 (230V)	5013-0049
Vacuum pump VP 4 (120V)	5013-0118
Connection kit for vacuum pump VP4	8012-0621
Neutral cleaning agent, 1 kg	1002-0016

Validation service	Art. No.
Qualification folder IQ-OQ (printed version)	7007-0001
Qualification folder IQ-OQ (digital version)	7057-0001
Qualification folder IQ-OQ-PQ (printed version)	7007-0005
Qualification folder IQ-OQ-PQ (digital version)	7057-0005
Execution of IQ-OQ	DL420300
Execution of IQ-OQ-PQ	DL440500

Calibration service	Art. no.
Calibration of temperature including certificate (1 measuring point)	8012-1145
Spatial temperature measurement including certificate (9 measuring points)	8012-0916
Spatial temperature measurement including certificate (15 measuring points)	8012-0919
Calibration of pressure including certificate	8012-0440

For information on components not listed here, please contact BINDER Service.

28.6 Dimensions

28.6.1 VDL 23



(Dimensions in mm)



28.6.2 VDL 56





28.6.3 VDL 115





29. Index

Activation code 119 Ambient temperature 54 Analog output 171 Analog outputs 46 Area classification 25, 46, 49 Audible alarm 134 Auto-ignition temperature 18, 19, 22, 25, 26, 33, 34, 35, 38, 39, 64, 65, 67, 90, 91, 96, 99, 100, 101, 136, 138, 152 Cleaning 174 Commissioning 74, 75 Condensate catchpot 18, 27, 40, 53, 91, 100 Connection kit 62, 68, 191, 192 Corrosion 55, 64, 67 Domestic vacuum system 62 Drying monitoring 108 Drying monitoring 91 Dust 15, 19, 26, 52, 96 Emergency ventilation 46, 50, 87, 97, 98 Equipotential bonding 26, 39, 41, 54, 70, 71, 95 Equipotential bonding 90 ESD 20, 27, 32, 33, 40, 54, 70, 72, 90, 95, 100 Ethernet 37, 46, 171, 190 Ex classification 13, 37 Exothermal reactions 26 Expansion rack 191 Expansion racks 38, 55, 56, 175, 176, 189, 191 Explosion group 19, 26 Explosion hazard 8, 15, 16, 17, 18, 19, 21, 52, 53, 55, 59, 61, 63, 64, 65, 66, 73, 96, 97, 98, 99, 101, 136, 138, 152 Explosion protection document 32, 74, 75 Explosion protection plan 14, 32, 33, 74, 75 Explosion protection symbol 10, 13 Extraction 18, 27, 40, 52, 53, 95, 100, 182 Fire extinguisher 54 Flame arrester 67 Foreseeable misuse 34 Foreseeable Misuse 27 Fuse 188

Gas group 19, 26 Gas inlet temperature 18, 64, 65, 67 GAS/AIR 46, 97, 104, 190, 191 Gloves 27, 33, 40, 76, 95, 100 Grounding concept 16, 70, 90 Grounding plan 26, 39, 41, 95 Heater release 39 Heating release 13, 190 Ignition source monitoring 38, 126 Inert gas 21, 22, 59, 60, 65, 67, 68, 97, 98, 104, 185 Inert gas connection 68 Instrument box 44, 165 Intended use 25 interface 190 Interface 37, 44, 46, 171, 173 Labels 12 Lightning protection device 55 Loading area 20, 40, 53, 54, 96, 97 Maintenance 35, 181, 182 Manual ventilation 46, 50, 97, 98 Measuring access port 171 Measuring connection 44, 171, 172, 190 Medical devices 26 Object temperature display 46, 172, 173 Object temperature input 172 Operating instructions 28, 33, 34 Overheating 15 Password protection 95, 110 Personal protective equipment 27, 32, 33, 54, 70, 72, 95, 100 Personal protective equipment 20 Plug 46, 50, 97, 98 PPE 20, 27, 33, 54, 70, 72, 76, 95, 100 Pressure threshold 90 Pump module 21, 39, 40, 49, 50, 52, 54, 60, 62, 64, 65, 66, 67, 70, 71, 74, 188, 191, 192 Rack holder 192 Rack holders 55 Residual risks 29, 34



Risk assessment 32 safety alert symbol 10 Safety controller 22, 35, 41, 87, 90, 100, 125, 127, 179, 190 Safety glass panel 41, 192 Safety glass window 43 Safety pressure monitoring 39 Safety temperature 96 SOP 34 Stacking 52 Standard Operating Procedures 34 Standby 90, 93, 95, 103, 148 Technical ventilation 16, 18, 21, 22, 27, 40, 48, 51, 52, 53, 62, 76, 77, 88, 90, 93, 95, 100, 182

Temperature class 13, 18, 19, 25, 37, 64, 65, 67

Termination of the drying process 34, 99 Tests 75, 77 tolerance range 87 Tolerance range 130 Transport 51 TRGS 725 76, 77 Type plate 13, 25, 27, 37, 41, 72 Unpacking 50 USB 37, 44, 165, 190 Vacuum connection 46, 62 Vacuum pump 17, 49, 52, 54, 62, 63, 64, 65, 66, 67, 70, 74, 192 Vacuum supply 17 Zone 15, 17, 21, 25, 27, 46, 52, 62, 65, 66, 67

Zone classification 46

30. Certificates and declarations of conformity

30.1 EU Declaration of Conformity

	BINDER
	Best conditions for your succe
EU-Konformitätserklärung / EU UE / Declaración de conformid соответствия EU	J Declaration of Conformity / Déclaration de conformité lad UE / Dichiarazione di conformità UE / Декларация
Hersteller / Manufacturer / Fabricant / Fab- ricante / Fabricante / Производитель	BINDER GmbH
Anschrift / Address / Adresse / Dirección / Endereço / Адрес	Im Mittleren Ösch 5, 78532 Tuttlingen, Germany
Produkt / Product / Produit / Producto / Pro- dotto / Продукт	Vakuumtrockenschränke für entflammbare Lösungsmittel Vacuum drying ovens for flammable solvents Etuves de séchage à vide pour les solvants inflammables Estufas de secado al vacío para disolventes inflamables Stufe a vuoto per solventi infiammabili Вакуумные сушильные шкафы для воспламеняющихся растворителей
Typenbezeichnung / Type / Type / Tipo / Tipo / Тип	VDL 23, VDL 56, VDL 115 (E3.1)
Art. No. / Art. no. / Réf. / Art. № / Art. n. / №	9630-0009, 9630-0010, 9630-0011,
арт.	9630-0013, 9630-0014, 9630-0015
dans le Journal officiel de l'Union européenn La máquina descrita arriba cumple con las s de la Unión Europea): Le macchine sopra descritte sono conforme	e): iguientes directivas de la CE/UE (publicados en el Diario ofici alle seguenti direttive CE/UE (secondo la pubblicazione nella
Gazzetta ufficiale della Commissione europe Машина, указанная выше, полностью соот (опубликованным в Официальном журнал	за): ветствует следующим регламентам EC/EU іе Европейского Содружества):
 2006/42/EC Maschinenrichtlinie 2006/42/EG / Machinen tiva 2006/42/CE (Máquinas) / Direttiva mac 	ry directive 2006/42/EC / Directive Machines 2006/42/EC / Direc chine 2006/42/CE / Директива о машинах 2006/42/EC
2014/34/EU ATEX-Richtlinie 2014/34/EU / ATEX Directive 2014/34/EU / Directive ATEX 2014/34/UE / Directiva ATEX 2014/34/LE / Directiva ATEX 94/9/UE / Директира ATEX 2014/34/EU	
 2014/30/EU EMV-Richtlinie 2014/30/EU / EMC Directive 2014/30/EU / Directive CEM 2014/30/UE / Directiva CEM 2014/30/UE / Directiva EMC 2014/30/UE / Директива ЭМС 2014/30/FU 	
 2011/65/EU RoHS-Richtlinie 2011/65/EU / RoHS Dir RoHS 2011/65/UE / Direttiva RoHS 2011. 	rective 2011/65/EU / Directive RoHS 2011/65/UE / Directive
	1/3







Explosionsschutz / Explosion protection / Protection contre les explosions / Protección contra explosiones / Protezione contro le esplosioni / Взрывозащита

- EN 1127-1:2011
- EN 60079-2:2014
- EN 60079-11:2012
- EN ISO 80079-36:2016
- EN ISO 80079-37:2016

Die Ex-Klassifikation des Gesamtgerätes (Baugruppe) nach ATEX Richtlinie 2014/34/EU ist :

The Ex classification of the entire unit (assembly) according to ATEX Directive 2014/34/EU is :

La classification Ex de l'appareil entier (assemblage) selon la Directive 2014/34/UE ATEX est :

La clasificación Ex del dispositivo completo (ensamblaje) según la Directiva 2014/34/UE es:

La classificazione Ex dello spazio interno dell'intero apparecchio (assemblaggio) secondo la direttiva ATEX 2014/34/UE è:

Классификация Ex внутренней всей камеры (сборка) в соответствии с Директивой ATEX 2014/34/EU

(Ex) II 2/3/- G IIB T3 Gb/Gc/- X

Die Temperaturklasse des Gerätes nach EN 60079-0 ist T3. The temperature class of the entire unit acc. to EN 60079-0 is T3. La classe de température de l'appareil entier selon EN 60079-0 est T3. La classe de temperatura del dispositivo completo es T3. La classe di temperatura dell'intero apparecchio secondo EN 60079-0 è T3. Класс температурной защиты всей камеры в соответствии с EN 60079-0 – T3.

78532 Tuttlingen, 25.03.2020 BINDER GmbH

Minder

P. M. Binder Geschäftsführender Gesellschafter Managing Director Directeur général Director general Direttore Generale Директор

J/Bollaender Leiter F & E Director R & D Chef de service R&D Responsable I & D Direttore R & D Глава департамента R&D 3 / 3

BINDER GmbH Postfach 102 D-78502 Tuttlingen Anschrift: BINDER GmbH im Mittleren Ösch 5 D-78532 Tuttlingen Kontakt: Telefon: +49 (0) 74 62 / 20 05 - 0 | Telefax: +49 (0) 74 62 / 20 05 - 10 | Intro@binder-world.com Geschäftsführung: Dipl-Ing. Peter M. Binder | Amtsgenicht Stuttgart, HRB 727150 | Sitz der Gesellschaft: Tuttlingen Bankverbindung: Kreissparkasse Tuttlingen Konto-Nr: 2266 BILZ: 643 500 70 | IBAN-Code: DE05643 500700 000002266 | SWIFT-Code: SOLA DE S1TUT S-Account 2202 611 55 | IBAN-Code: DE7464350070 0220 261155 | SWIFT-Code: SOLA DE S1TUT Deutsche Bank Tuttlingen Konto-Nr: 2 138 709 BLZ: 653 700 75 | IBAN-Code: DE56653 70075 0213870900 | SWIFT-Code: DEUT DE SS603 Altgeräte-Entsorgung gemäß WEEE-Reg.-Nr. DE 37004983

31. Product registration



32. Contamination clearance certificate

32.1 For chambers located outside USA and Canada

Declaration regarding safety and health

Erklärung zur Sicherheit und gesundheitlichen Unbedenklichkeit

The German Ordinance on Hazardous Substances (GefStofV), and the regulations regarding safety at the workplace, require that this form be filled out for all products that are returned to us, so that the safety and the health of our employees can be guaranteed.

Die Sicherheit und Gesundheit unserer Mitarbeiter, die Gefahrstoffverordnung GefStofV und die Vorschriften zur Sicherheit am Arbeitsplatz machen es erforderlich, dass dieses Formblatt für alle Produkte, die an uns zurückgeschickt wird.



 A completely filled out form must be transmitted via Fax (+49 (0) 7462 2005 93555) or by letter in advance, so that this information is available before the equipment/component part arrives. A second copy of this form must accompany the equipment/component part. In addition, the carrier should be notified.

Eine vollständig ausgefüllte Kopie dieses Formblattes soll per Telefax (Nr. +49 (0) 7462 2005 93555) oder Brief vorab an uns gesandt werden, so dass die Information vorliegt, bevor das Gerät/Bauteil eintrifft. Eine weitere Kopie soll dem Gerät/Bauteil beigefügt sein. Ggf. ist auch die Spedition zu informieren.

• Incomplete information or non-conformity with this procedure will inevitably lead to substantial delays in processing. Please understand the reason for this measure, which lies outside our area of influence, and will help us to speed up this procedure.

Unvollständige Angaben oder Nichteinhalten dieses Ablaufs führen zwangsläufig zu beträchtlichen Verzögerungen in der Abwicklung. Bitte haben Sie Verständnis für Maßnahmen, die außerhalb unserer Einflussmöglichkeiten liegen und helfen Sie mit, den Ablauf beschleunigen.

Please print and fill out this form completely.

Bitte unbedingt vollständig ausfüllen!

1.	Unit/ component part / type: / Gerät / Bauteil / Typ:
2.	Serial No. / Serien-Nr.:
3.	Details about utilized substances / biological substances / Einzelheiten über die eingesetzten Substanzen/biologische Materialien:
3.1	Designations / Bezeichnungen:
a)	
b)	
c)	
3.2	Safety measures required for handling these substances / Vorsichtsmaßnahmen beim Umgang mit diesen Stoffen:
a)	
b)	
c)	



3.3	Measures to be taken in case of skin contact or release into the atmosphere / Maßnahmen
a)	
b)	
c)	
d)	
3.4	Other important information that must be taken into account / Weitere zu beachtende und wichtige Informationen:
a)	
b)	
c)	
4.	Declaration on the risk of these substances (please checkmark the applicable items) / Erklärung zur Gefährlichkeit der Stoffe (bitte Zutreffendes ankreuzen) :
□ 4.1	For non toxic, non radioactive, biologically harmless materials / für nicht giftige, nicht radioak- tive, biologisch ungefährliche Stoffe:
We her Gerät/B	reby guarantee that the above-mentioned unit / component part / Wir versichern, dass o.g.
Has sons	not been exposed to or contains any toxic or otherwise hazardous substances / weder giftige noch tige gefährliche Stoffe enthält oder solche anhaften.
That evtl.	eventually generated reaction products are non-toxic and also do not represent a hazard / auch entstandene Reaktionsprodukte weder giftig sind noch sonst eine Gefährdung darstellen.
Ever entfe	ntual residues of hazardous substances have been removed / evtl. Rückstände von Gefahrstoffen ernt wurden.
□ 4.2 We her	For toxic, radioactive, biologically harmful or hazardous substances, or any other hazard- ous materials / für giftige, radioaktive, biologisch bedenkliche bzw. gefährliche Stoffe oder anderweitig gefährliche Stoffe.
The mer garc sind	hazardous substances, which have come into contact with the above-mentioned equip- t/component part, have been completely listed under item 3.1 and that all information in this re- l is complete / die gefährlichen Stoffe, die mit dem o.g. Gerät/Bauteil in Kontakt kamen, in 3.1 aufgelistet und alle Angaben vollständig sind.
□ That dioa	the unit /component part has not been in contact with radioactivity / das Gerät/Bauteil nicht mit Ra- ktivität in Berührung kam
5.	Kind of transport / transporter / Transportweg/Spediteur:
Transp	ort by (means and name of transport company, etc.) Versendung durch (Name Spediteur o.ä.)
Date of	dispatch to BINDER GmbH / Tag der Absendung an BINDER GmbH:



We hereby declare that the following measures have been taken / Wir erklären, dass folgende Maßnahmen getroffen wurden:
Hazardous substances were removed from the unit including component parts, so that no hazard ex- ists for any person in the handling or repair of these items / das Gerät/Bauteil wurde von Gefahrstoffen be- freit, so dass bei Handhabung/Reparaturen für die betreffenden Person keinerlei Gefährdung besteht
The unit was securely packaged and properly identified / das Gerät wurde sicher verpackt und vollständig gekennzeichnet.
Information about the hazardousness of the shipment (if required) has been provided to the trans- porter / der Spediteur wurde (falls vorgeschrieben) über die Gefährlichkeit der Sendung informiert.
We hereby commit ourselves and guarantee that we will indemnify BINDER GmbH for all damages that are a consequence of incomplete or incorrect information provided by us, and that we will exempt BINDER GmbH from eventual damage claims by third parties./ Wir versichern, dass wir gegenüber BINDER für jeden Schaden, der durch unvollständige und unrichtige Angaben entsteht, haften und BINDER gegen eventuell entstehende Schadenansprüche Dritter freistellen.
We are aware that, in accordance with Article 823 of the German Civil Code (BGB), we are directly liable with regard to third parties, in this instance especially the employees of BINDER GmbH, who have been entrusted with the handling / repair of the unit / component. / Es ist uns bekannt, dass wir gegenüber Dritten – hier insbesondere mit der Handhabung/Reparatur des Geräts/des Bauteils betraute Mitarbeiter der Firma BINDER - gemäß §823 BGB direkt haften
Name:
Position/Title:
Date / Datum:
Signature / Unterschrift:
Company stamp / Firmenstempel:

Equipment that is returned to the factory for repair must be accompanied by a completely filled out contamination clearance certificate. For service and maintenance on site, such a contamination clearance certificate must be submitted to the service technician before the start of any work. No repair or maintenance of the equipment is possible, without a properly filled out contamination clearance certificate.

32.2 For chambers located in USA and Canada

Product Return Authorization Request

Please complete this form and the Customer Decontamination Declaration (next 2 pages) and attach the required pictures. E-mail to: IDL_SalesOrderProcessing_USA@binder-world.com

After we have received and reviewed the complete information we will decide on the issue of a RMA number. Please be aware that size specifications, voltage specifications as well as performance specifications are available on the internet at <u>www.binder-world.us</u> at any time.

	Please fill:	
Reason for return request	O Duplicate order	
	O Duplicate shipment	
	O Demo	Page one completed by sales
	O Power Plug / Voltage	115V / 230 V / 208 V / 240V
	O Size does not fit space	
	O Transport Damage	Shock watch tripped? (pictures)
	O Other (specify below)	
Is there a replacement PO?	O Yes O No	
If yes -> PO #		
If yes -> Date PO placed		
Purchase order number		
BINDER model number		
BINDER serial number		
Date unit was received		
Was the unit unboxed?	O Yes O No	
Was the unit plugged in?	O Yes O No	
Was the unit in operation?	O Yes O No	
Pictures of unit attached?	O Yes O No	Pictures have to be attached!
Pictures of Packaging at- tached?	O Yes O No	

Take notice of shipping laws and regulations.

	Customer Contact Information	Distributor Contact Information
Name		
Company		
Address		
Phone		
E-mail		

Customer (End User) Decontamination Declaration

Health and Hazard Safety declaration

To protect the health of our employees and the safety at the workplace, we require that this form is completed by the user for all products and parts that are returned to us. (Distributors or Service Organizations cannot sign this form)

NO RMA number will be issued without a completed form. Products or parts returned to our NY warehouse without a RMA number will be refused at the dock.

A second copy of the completed form must be attached to the outside of the shipping box.

1.	Unit/ component part / type:
2.	Serial No.
3.	List any exposure to hazardous liquids, gasses or substances and radioactive material
3.1 (if ther	List with MSDS sheets attached where available or needed e is not enough space available below, please attach a page):
a)	
b)	
3.2	Safety measures required for handling the list under 3.1
a)	
b)	
c)	
3.3	Measures to be taken in case of skin contact or release into the atmosphere:
a)	
b)	
c)	
d)	
3.4	Other important information that must be considered:
a)	
b)	
c)	



4. Declar	ation of Decontamination		
For toxic, radi hazardous ma	oactive, biologically and chemically harmful or hazardous substances, or any other iterials.		
4.1 Any hazar componer complete.	 We hereby guarantee that 4.1 Any hazardous substances, which have come into contact with the above-mentioned equipment / component part, have been completely listed under item 3.1 and that all information in this regard is complete 		
4.2 That the u4.3 Any Haza for a perse	 2 That the unit /component part has not been in contact with radioactivity 3 Any Hazardous substances were removed from the unit / component part, so that no hazard exists for a persons in the shipping, handling or repair of these returned unit 		
4.4 The unit w outside of laration.	4 The unit was securely packaged in the original undamaged packaging and properly identified on the outside of the packaging material with the unit designation, the RMA number and a copy of this dec- laration.		
4.5 Shipping I	aws and regulations have not been violated.		
I hereby comm consequence and hold harm	nit and guarantee that we will indemnify BINDER Inc. for all damages that are a of incomplete or incorrect information provided by us, and that we will indemnify nless BINDER Inc. from eventual damage claims by third parties.		
Name: _			
Position: _			
Company: _			
Address: _			
Phone #:			
Email:			
Date: _			
Signature: _			

Equipment returned to the NY warehouse for repair must be accompanied by a completed customer decontamination declaration. For service and maintenance works on site, such a customer decontamination declaration must be submitted to the service technician before the start of work. No repair or maintenance of the equipment is possible without a completed form.