

# Inspired by temperature

Betriebsanleitung · Operation manual · Manual de instrucciones · Manuel d'utilisation · Manuale de d'uso

・ 사용 설명서・ Manual de instruções ・ Инструкция по эксплуатации ・ Kullanım talimatı ・ 操作说明书・

Betriebsan instruccion · 사용 설명

по эксплуа Betriebsan Minichiller® OLÉ Unichiller® OLÉ

Manual de ale de d'uso нструкция **逆明书** Manual de ale de d'uso

・ 사용 설명서・ Manual de instruções ・ Инструкция по эксплуатации ・ Kullanım talimatı ・ 操作说明书

This documentation does not contain a device-specific technical appendix.

You can request the full operating instructions from info@huber-online.com. Please give the model designation and serial number of your temperature control unit in your e-mail.





**OPERATION MANUAL** 

# Minichiller® OLÉ Unichiller® OLÉ



# Minichiller® Unichiller®

## OLÉ

This operation manual is a translation of the original operation manual.

Also for models with heater.

## **VALID FOR:**

## **DESKTOP**


Minichiller® 280 OLÉ Minichiller® 300 OLÉ Minichiller® 500 OLÉ Minichiller® 600 OLÉ Minichiller® 900 OLÉ Unichiller® 007 OLÉ Unichiller® 01x OLÉ Unichiller® 02x OLÉ

Abbreviations used in model names: Without = with air cooling, P = stronger pump, w = with water cooler, -H = with heater



## OPERATION MANUAL

The control panel: Displays and keys





## **Table of contents**

V1.3.0en/22.01.19//1.0.0

1	Introduction 1	2
1.1	Details on the declaration of conformity1	<b>12</b>
1.2	Safety 1	<b>.2</b>
1.2.1	Symbols used for Safety Instructions1	L2
1.2.2	Representation of safety identifiers1	L3
1.2.3	Proper operation1	L3
1.2.4	Reasonably foreseeable misuse1	L4
1.3	Responsible bodies and operators – Obligations and requirements 1	
1.3.1	Obligations of the responsible body1	
1.3.1.1	Proper disposal of resources and consumables1	
1.3.1.2	Temperature control unit with natural refrigerants (NR)	
1.3.1.3	Temperature control units with fluorinated greenhouse gases/refrigerant	
1.3.2	Requirements for operators1	
1.3.3	Obligations of the operators1	
1.4	General information	
1.4.1	Description of workstation1	
1.4.2	Safety devices to DIN 128761	
1.4.2.1	Mechanical overtemperature protection1	
1.4.2.2	Low level protection1	
1.4.3	Further protective devices1	
1.4.3.1	Power interruption1	
1.5	Exemplary illustrations of the cooling variants	
1.5.1	Air cooling2	
1.5.2	Water cooling2	
1.5.3	Consequence of inadequate energy dissipation2	
2	Commissioning 2	2
2.1	In-plant transport	2
2.1.1	Lifting and transporting the temperature control unit2	
2.1.1.1	Temperature control unit with lifting eyes	
2.1.1.2	Temperature control unit without lifting eyes	
2.1.2	Positioning the temperature control unit2	
2.1.2.1	Temperature control unit with casters	
2.1.2.2	Temperature control unit without casters	
2.2	Unpacking	
2.3	Ambient conditions	
2.3.1	EMC-specific notes2	
2.4	Installation conditions	
2.5	Recommended temperature control and cooling water hoses	
2.6	Wrench sizes and torques2	
2.7	Temperature control units with water cooling	
2.8	Preparations for operation	
2.8.1	Unscrewing/activating the leveling feet (if any)2	
2.8.2	Opening/closing the bypass valve2	
2.8.3	Enable / Disable silent operation (optional)2	
2.8.4	Installing collecting container2	
2.9	Connecting externally closed application	



OPERA	TION MA	ANUAL

2.9.1	Connecting an externally closed application	
2.10	Connecting to the power supply	
2.10.1	Connection using socket with protective earth (PE)	30
2.10.2	Connection via hard wiring	31
3	Function description	32
3.1	Function description of the temperature control unit	32
3.1.1	General functions	
3.1.2	Other functions	
3.2	Information on the thermal fluids	32
3.3	To be noted when planning the test	33
3.4	Display and control instruments	
3.4.1	Display	
3.4.2	Control instruments	
3.4.2.1	Arrow keys	
3.4.2.2	SET key	
3.4.2.3	ESC key	
3.4.2.4	Start/Stop key	
3.4.3	Adjusting settings	
3.4.5 <b>3.5</b>	Menu function	
3.6	Functional examples	
3.6.1	Selecting a language	
3.6.2		
	Setting the setpoint	
3.6.3	Changing the Auto-Start function	38
4	Setup mode	39
4.1	Setup mode	39
4.1.1	Turning on the temperature control unit	39
4.1.2	Turning off the temperature control unit	39
4.1.3	Setting the overtemperature (OT) protection	39
4.1.3.1	General information on the overtemperature protection	39
4.1.3.2	Setting the overtemperature protection	40
4.1.4	Testing the overtemperature protection for functionality	40
4.2	Filling, venting, degassing and draining	41
4.2.1	Filling and venting externally closed application	41
4.2.1.1	Filling and venting with >Sight glass< [23]	42
4.2.1.2	Filling and venting with >Level indicator and drain< [38]	
4.2.2	Draining externally closed applications	
4.2.2.1	Draining with >Sight glass< [23]	
4.2.2.2	Draining with >Level indicator and drain< [38]	
5	Normal operation	46
5.1	Automatic operation	46
5.1.1	Temperature control	
5.1.1.1	Starting the temperature control process	
5.1.1.2	Ending the temperature control process	
J.1.1.2		40
6	Interfaces and data communication	47
6.1	Controller interfaces	
6.1.1	USB-2.0 interface	
6.1.1.1	USB-2.0 interface, device	
6.1.2	RS232 jack	47
6.2	Interfaces on the temperature control unit (optional)	47



## OPERATION MANUAL

6.2.1	RS232 jack	.48
6.2.2	Connection jack for Pt100 process display sensor	.48
6.2.3	Jack ECS (External Control Signal) standby	.48
6.2.4	Connector POKO (floating contact) alarm	.49
6.3	Data communication	. 50
6.3.1	LAI commands	.50
6.3.1.1	Command "V" (Verify)	.51
6.3.1.2	Command "L" (Limit)	.51
6.3.1.3	Command "G" (General)	.52
6.3.2	PP commands	.53
7	Service/maintenance	55
7.1	Displays in the event of faults	. 55
7.2	Maintenance	56
7.2.1	Function check and visual inspection	.56
7.2.2	Replacing temperature control or coolant hoses	.57
7.2.2.1	Replacing temperature control hoses	.57
7.2.2.2	Replacing coolant hoses	.57
7.2.3	Clean liquefier fins (air-cooled temperature control unit)	.58
7.2.4	Clean hat-type strainer (dirt trap) (water-cooled temperature control unit)	.59
7.3	Thermal fluid inspection, replacement and circuit cleaning	. 59
7.3.1	Thermal fluid replacement	.60
7.3.1.1	Externally closed application	.60
7.3.2	Rinsing the thermal fluid circuit	.60
7.3.2.1	Rinsing a thermofluid circuit with >Sight glass< [23]	.61
7.3.2.2	Rinsing the thermofluid circuit with >Level indicator and drain< [38]	
7.4	Cleaning the surfaces	62
7.5	Inspect the mechanical seal	63
7.6	Plug contacts	
7.7	Decontamination/repairs	63
8	Shutting down	64
8.1	Safety instructions and basic principles	64
8.2	Switch-off	64
8.3	Draining the cooling water	65
8.3.1	Draining process	.65
8.4	Packing	65
8.5	Shipping	65
8.6	Disposal	66
8.7	Phone number and company address	67
8.7.1	Telephone number: Customer Support	.67
8.7.2	Telephone number: Sales	.67
8.7.3	Email address: Customer Support	.67
8.7.4	Service/return address	
8.8	Certificate of Compliance	67
9	Annex	68



OPERATION MANUAL



## **Foreword**

Dear Customer,

Thank you for choosing a temperature control unit from Peter Huber Kältemaschinenbau AG. You have made a good choice. Thank you for your trust.

Please read the operation manual carefully before putting the unit into operation. Strictly follow all notes and safety instructions.

Follow the operation manual with regard to transport, start-up, operation, maintenance, repair, storage and disposal of the temperature control unit.

We fully warrant the temperature control unit for the specified normal operation.

The models listed on page 5 are referred to in this operation manual as temperature control units and Peter Huber Kältemaschinenbau AG as Huber company or Huber.

Liability for errors and misprints excluded.

The following trademarks and the Huber logo are registered trademarks of Peter Huber Kältemaschinenbau AG in Germany and/or other countries worldwide: BFT®, CC®, CC-Pilot®, Com.G@te®, Compatible Control®, CoolNet®, DC®, E-grade®, Grande Fleur®, KISS®, Minichiller®, Ministat®, MP®, MPC®, Peter Huber Minichiller®, Petite Fleur®, Pilot ONE®, RotaCool®, Rotostat®, SpyControl®, SpyLight®, Tango®, TC®, UC®, Unical®, Unichiller®, Unipump®, Unistat®, Unistat-Pilot®, Unistat Tango®, Variostat®, Web.G@te®. The following trademarks are registered in Germany to DWS Synthesetechnik: DW-Therm®, DW-Therm HT®



## 1 Introduction

## 1.1 Details on the declaration of conformity

The equipment complies with the basic health and safety requirements of the European Directives listed below:

- Machinery Directive
- Low Voltage Directive
- EMC Directive

## 1.2 Safety

## 1.2.1 Symbols used for Safety Instructions

Safety instructions are marked by the below combinations of pictograms and signal words. The signal word describes the classification of the residual risk when disregarding the operation manual.



Denotes an immediate hazardous situation that will result in death or serious injuries.



Denotes a general hazardous situation that may result in death or serious injuries.



Denotes a hazardous situation that can result in injury.


NOTE

Denotes a situation that can result in property material damage.

**INFORMATION** 

Denotes important notes and usable hints.

Safety information and procedure



The safety information in this operation manual is designed to protect the responsible body, the operator and the equipment from damage. Safety instructions appear at the beginning of each chapter and before instructions. First inform yourself about any residual risks due to misuse before you start an operation.



Chapter 1 OPERATION MANUAL

## 1.2.2 Representation of safety identifiers

The following pictograms are used as safety identifiers. The table gives an overview of the safety identifier used here.

#### Overview

w	Identifier	Description
	Mandatory sign	
		- Observe the instructions
	Warning sign	
- General warning sign - observe the instructions		
	A	- Warning of electrical voltage
		- Warning of hot surface
		- Warning of flammable substances

## 1.2.3 Proper operation



## Operating the temperature control unit in a potentially explosive area DEATH THROUGH EXPLOSION

> Do NOT install or start up the temperature control unit within an ATEX zone.



## Improper use

## SERIOUS INJURY AND PROPERTY DAMAGE

- Store the operation manual where it is easy to access in close proximity to the temperature control unit.
- > Only adequately qualified operators may work with the temperature control unit.
- Operators must be trained before handling the temperature control unit.
- > Check that the operators have read and understood the operation manual.
- > Define precise responsibilities of the operators.
- Personal protective equipment must be provided to the operators.
- ➤ Be sure to follow the responsible body's safety rules to protect life and limb and to limit damages!

## NOTE

## Modifications to the temperature control unit by third-parties

## DAMAGE TO THE TEMPERATURE CONTROL UNIT

- > Do not allow third parties to make technical modifications to the temperature control unit.
- > The EU declaration of conformity becomes invalid if any modifications are made to the temperature control unit without the approval of Huber.
- > Only specialists trained by Huber may carry out modifications, repairs or maintenance work.
- > The following must be observed without fail:
- Only use the temperature control unit in a fault-free condition!
- ➤ Have the start-up and repairs carried out by specialists only!
- Do not ignore, bypass, dismantle or disconnect any safety devices!

The temperature control unit must not be used for any purposes other than temperature control in accordance with the operation manual.

The temperature control unit is manufactured for industrial use. The temperature control unit maintains the temperature of certain applications, including glass or metal reactors or other expedient items in laboratories and industry. Flow-through coolers and calibration baths must be used only in combination with Huber temperature control units. Thermal fluids suitable for the overall system are used. The chilling and heating capacity is provisioned at the pump connections or - where present - in the tempering bath. The technical specification of the temperature control unit is given in the data sheet (from page 68 in section »Annex«). The temperature control unit must be installed, configured and operated according to the handling instructions in this operating manual. Failure to comply with the operation manual is deemed improper use. The temperature control unit conforms to state-of-the-art technology and the recognized safety regulations. Safety devices are built into your temperature control unit.

## 1.2.4 Reasonably foreseeable misuse

Use with medical devices (e.g. in Vitro diagnostic procedure) or for direct foodstuff temperature control is **NOT** permissible.

The temperature control unit must **NOT** be used for any purposes other than temperature control in accordance with the operation manual.

The manufacturer accepts **NO** liability for damage caused by **technical modifications** to the temperature control unit, **improper handling** or use of the temperature control unit if the operation manual is **not observed**.

# 1.3 Responsible bodies and operators – Obligations and requirements

## 1.3.1 Obligations of the responsible body

The operation manual is to be stored where it is easy to access in close proximity to the temperature control unit. Only adequately qualified operators (e.g. chemists, CTA, physicists etc.) are permitted to work with the temperature control unit. Operators must be trained before handling the temperature control unit. Check that the operators have read and understood the operation manual. Define precise responsibilities of the operators. Personal protective equipment must be provided to the operators.

- The responsible body must install a condensation water / thermal fluid drip tray below the temperature control unit.
- The responsible body must check whether national regulations require the mandatory installation
  of a drain tray for the installation area of the temperature control unit/the entire system.
- Our temperature control unit complies with all applicable safety standards.
- Your system, which uses our temperature control unit, must be as safe.
- The responsible body must design the system to ensure it is safe.
- Huber is not responsible for the safety of your system. The responsible body is responsible for the safety of the system.
- Although the temperature control unit provided by Huber meets all the applicable safety standards, integration into a system may give rise to hazards that are characteristic of the other system's design and beyond the control of Huber.
- It is the responsibility of the system integrator to ensure that the overall system, into which this
  temperature control unit is integrated, is safe.
- The >Mains isolator< [36] (if present) may be provided with a facility to lock the main isolator in the off position to facilitate safe system installation and maintenance of the temperature control unit. It is the responsibility of the responsible body to develop any lock-out/tag-out procedure in accordance with local regulations (e.g. CFR 1910.147 for the US).</p>
- Only valid for water-cooled temperature control units: The responsible body must ensure that the
  cooling water supply and drain pipes are laid frost-protected. The cooling water temperature
  must not fall below 3 °C. The cooling water supply must be heated if the ambient temperature is
  below 3 °C.



Chapter 1 OPERATION MANUAL

## 1.3.1.1 Proper disposal of resources and consumables

Do comply with all national disposal regulations applicable for you. Contact your local waste management company for any questions concerning disposal.

#### Overview

,	Material / Aids	Disposal / Cleaning
	Packing material	Keep the packaging material for future use (e.g. transport).
	Thermal fluid	Please refer to the safety data sheet of the thermal fluid used for information on its proper disposal.  Use the original thermal fluid container when disposing it.
		Clean the filling accessories for reuse. Make sure that the materials and cleaning agents used are properly disposed of.
	Aids such as towels, cleaning cloths	Tools used to take up spilled thermal fluid must be disposed of in the same fashion as the thermal fluid itself.  Tools used for cleaning must be disposed of depending on the cleaning agent used.
stainless steel cleaning agents, sensitive-fabrics proper disposal.		Please refer to the safety data sheet of the cleaning agent used for information on its proper disposal.  Use the original containers when disposing of large quantities of cleaning agents.
	Consumables such as air filter mats, temperature control hoses	Please refer to the safety data sheet of the consumables used for information on their proper disposal.

#### 1.3.1.2 Temperature control unit with natural refrigerants (NR)



#### Over 8 g refrigerant per m3 room air

#### **DEATH OR SERIOUS INJURY DUE TO EXPLOSION**

- Observe the rating plate (amount of natural refrigerant contained) and the room size (maximum room concentration of natural refrigerant in case of leakage) when installing the temperature control unit.
- Over 8 g refrigerant per m³ room air: A gas warning sensor must be fitted and functioning.
- The gas warning sensor must be calibrated and maintained at regular intervals (between 6 and 12 months).
- ➤ The temperature control unit is not approved for operation in an ATEX zone.

Huber products with natural refrigerants work with numerous proven, safe and highly-sustainable technologies. The relevant standards and regulations for temperature control units with natural refrigerants contain a number of stipulations, the importance of complying with which is set out below. Also observe on page 13 the section **»Proper operation«**.

Huber temperature control units are constructed to be permanently sealed and are carefully checked for leak tightness. Temperature control units with more than 150 g natural refrigerant are equipped with an additional gas warning sensor. To find out whether your temperature control unit is equipped with a gas warning sensor, refer to the data sheet from page 68 in section »Annex«.

The fill quantity of your temperature control unit is stated on the data sheet (from page 68 in section **»Annex«**) or on the rating plate on the rear of the temperature control unit. Observe page 24, section **»Ambient conditions«** and page 25, section **»Installation conditions«**.

Classifying the application field

Class of application field	Application field	Example of the installation location	Max. quantity of refrigerant		Max. permissible quantity above ground level (GL)
А	General	Publicly accessible area in a public building		AND	1.5 kg
В	Monitored	Laboratories		٩	2.5 kg
С	Access only for authorized persons	Production equipment	ambient air		10.0 kg
Temperature control units with more than 1 kg refrigerant must not be installed below ground level (GL).					

#### Temperature control units with up to 150 g natural refrigerant

- The temperature control unit has been constructed to the requirements of EU and EFTA countries.
- Use the table as guidance for classifying the application field. Respect the max. refrigerant quantity stated therein.

#### Temperature control units WITH pre-installed gas warning sensor and > 150 g natural refrigerant

- The temperature control unit has been constructed to the requirements of EU and EFTA countries
- Use the table as guidance for classifying the application field. Respect the max. refrigerant quantity or the permissible highest quantity above ground level (GL) stated therein.
- Ventilation with optional supply and exhaust air connection: Use the temperature control unit's supply and exhaust air connection to connect it to the building's exhaust system (see wiring diagram from page 68 in Section »Annex«). First, remove the cover to the air inlet connection; an air filter mat is installed behind it. This air filter mat must be checked / replaced at regular intervals so that the air flowing into the temperature control unit is not reduced (see page 56, Section »Function check and visual inspection«). Connect the building's exhaust system with the temperature control unit's exhaust air port. The cover of the supply air port mustnot be removed if the exhaust system provided in a building is not used.
- The mounting plate for mounting a gas warning sensor is located inside the temperature control unit in the vicinity of the >Cable entry gas warning sensor<[100].
- For the position of the >Cable entry gas warning sensor< [100], please refer to the wiring diagram from page 68 in Section »Annex«.
- Additional information on the pre-installed gas detection sensor:
  - The built-in gas detection sensor enables a safety shutdown at 20% of the lower explosive limit via a power disconnect relay that is to be installed by the responsible body. The temperature control unit is thus switched off early and safely in case of fault.
  - A 24 V DC external power supply must be available for the pre-installed gas warning sensor. The alarm output of the gas warning sensor uses a 4 20 mA signal. Please refer to the data sheet of the gas warning sensor for further technical information. A separate processing unit is available as an accessory for the control of the power disconnect relay. The processing unit provides a potential-free switching contact and simultaneously supplies power to and analyzes the gas warning sensor. Both variants require the responsible body to provide the necessary dimensioning and installation. Please refer to the data sheet of the gas warning sensor for the technical installation information. The alarm of the gas detection system can be connected to the responsible body's alarm control unit. The responsible body is responsible for this and other measures.
  - The responsible body is responsible for the calibration of the gas detection sensor prior to initial operation and the observance of calibration and maintenance intervals specified in the operating manual. We recommend to set calibration and maintenance intervals between 6 and 12 months if no information is provided. For increased safety requirements, shorter intervals can be specified. On request, we will recommend a specialist company to carry out calibration and maintenance.



Chapter 1 OPERATION MANUAL

Temperature control units WITHOUT pre-installed gas warning sensor and > 150 g natural refrigerant



#### Over 8 g refrigerant per m3 room air

#### **DEATH OR SERIOUS INJURY DUE TO EXPLOSION**

- Observe the rating plate (amount of natural refrigerant contained) and the room size (maximum room concentration of natural refrigerant in case of leakage) when installing the temperature control unit.
- > Over 8 g refrigerant per m³ room air: A gas warning sensor must be fitted and functioning.
- > The gas warning sensor must be calibrated and maintained at regular intervals (between 6 and 12 months).
- > The temperature control unit is not approved for operation in an ATEX zone.
- The temperature control unit has been constructed to the requirements of EU and EFTA countries.
- Use the table as guidance for classifying the application field. Respect the max. refrigerant quantity or the permissible highest quantity above ground level (GL) stated therein.
- Ventilation with optional supply and exhaust air connection: Use the temperature control unit's supply and exhaust air connection to connect it to the building's exhaust system (see wiring diagram from page 68 in Section »Annex«). First, remove the cover to the air inlet connection; an air filter mat is installed behind it. This air filter mat must be checked / replaced at regular intervals so that the air flowing into the temperature control unit is not reduced (see page 56, Section »Function check and visual inspection«). Connect the building's exhaust system with the temperature control unit's exhaust air port. The cover of the supply air port mustnot be removed if the exhaust system provided in a building is not used.
- NO gas warning sensor is installed in this temperature control unit! Make sure that the installation site of the temperature control unit is sufficiently protected in the event of malfunction.
   These include:
  - Installation of a gas warning sensor for the building (room monitoring).
  - Permanent ventilation of the temperature control unit and/or the installation site.
  - All-pole disconnection in the event of malfunction of the temperature control unit.

#### 1.3.1.3 Temperature control units with fluorinated greenhouse gases/refrigerants

**F gases regulation (EC) No. 517/2014** of April 16, 2014, on fluorinated greenhouse gases, and repealing Regulation (EC) No. 842/2006.

These regulations deal with all systems that contain fluorinated refrigerants. The substances dealt with in Directive (EC) No. 1005/2009 of the European Parliament and of the Council of 16 September 2009 that deplete the ozone layer are excluded (CFC/HCFC).

The directive regulates the reduction of the emission, utilization, recovery, and destruction of certain fluorinated greenhouse gases. It also regulates the identification and disposal of products and devices that contain these gases. Since July 4, 2007, responsible bodies must check their stationary refrigeration systems for leaks at regular intervals, and have any leaks eliminated immediately.

Directive (EC) No. 303/2008 contains stipulations on the training and certification of companies and personnel that are permitted to execute the specified activities.

#### Obligations of the responsible bodies:

- Directive (EC) No. 842/2006 already imposed a number of obligations upon responsible bodies regarding certain fluorinated greenhouse gases. The new Ordinance on Fluorinated Greenhouse Gases upholds these to a large extent. Some duties are added while others are designed differently by this new ordinance. Please refer to the text of this ordinance for a complete overview of the individual responsibilities of responsible bodies.
- General obligation to reduce emissions.
- Only certified companies may maintain, repair or decommission refrigeration systems. The responsible bodies must verify that these companies are certified.
- Regular leak tests of stationary refrigeration systems by certified personnel (such as Huber service engineers). The required test interval is based on the refrigerant filling capacity and the type of refrigerant, converted to CO<sub>2</sub>2 equivalent.
- Responsibility of responsible bodies operating a plant to recover F-gases by certified personnel.

- Obligatory documentation requirement in the refrigeration system's operation manual, specifying type and volume of refrigerant used or recovered. The responsible body must keep the records for at least 5 years after their creation and present it to the responsible authority upon request.
- Temperature control units with natural refrigerants (NR) are exempt from this Directive.
- Please refer to the data sheet or name plate of your temperature control unit for the quantity and type of refrigerant.
- Additional information about the definition of the inspection interval can be found on our website.

## 1.3.2 Requirements for operators

Work on the temperature control unit is reserved for appropriately qualified specialists, who have been assigned and trained by the responsible body to do so. Operators must be at least 18 years old. Under 18-year olds may operate the temperature control unit only under the supervision of a qualified specialist. The operator is responsible vis-a-vis third-parties in the work area.

## 1.3.3 Obligations of the operators

Carefully read the operation manual before operating the temperature control unit. Please observe the safety instructions. When operating the temperature control unit, wear appropriate personal protective equipment (e.g. safety goggles, protective gloves, non-slip shoes).

## 1.4 General information

## 1.4.1 Description of workstation

The workstation is located at the control panel in front of the temperature control unit. The workstation is determined by the customer's connected peripheries. Accordingly, it must be designed safe by the responsible body. The workstation design also depends on the applicable requirements of the German occupational health and safety regulations [BetrSichV] and the risk analysis for the workstation.

## 1.4.2 Safety devices to DIN 12876

The rating of your temperature control unit is stated on the data sheet in the appendix.

Rating of laboratory thermostats and laboratory baths

Classification	Temperature control medium	Technical requirements	Identification <sup>d)</sup>
I	Non-combustible a)	Overheat protection c)	NFL
II	Combustible b)	Adjustable overheat protection	FL
III	Combustible b)	Adjustable overtemperature protection and additional low-level protection	FL

a) Usually water; other fluids only if non-combustible even within the temperature range of an individual fault.

- Temperature control units with heating correspond to class number III/FL. These temperature
  control units are characterized by an "H" in the device name.
- Temperature control units without heating correspond to class number I/NFL.

<sup>&</sup>lt;sup>b)</sup> The temperature control media must have a combustion point of  $\geq$  65 °C.


c) The overheat protection can, for instance, can be realized using a suitable fill level sensor or a suitable temperature limiter.

d) Optional at the choice of the manufacturer.



Chapter 1 OPERATION MANUAL

Overview of the temperature thresholds



#### 1.4.2.1 Mechanical overtemperature protection

Only temperature control units with a heater are fitted with a mechanical overtemperature protection. Set the overtemperature protection as described on page 39 in section "Setting the overtemperature (OT) protection".

#### 1.4.2.2 Low level protection

**Minichiller with heater:** A mechanical float is used for level monitoring. A floating body, which is guided in a device, floats on the surface of the thermal fluid. Depending on the level of the thermal fluid, the float device signals the electronics a **state of good** (in case of sufficient filling) or a **state of bad** (in case of insufficient filling). The functionality of the float is checked at regular intervals during continuous operation.

**Unichiller with heater:** The low level protection operates via a pressure sensor in the thermal fluid circuit. The pump and the thermal fluid provide the required pressure at the pressure sensor. Air in the system (fill level too low, inadequately vented) prevents the pressure from reaching the value specified at the pressure sensor. Temperature control and circulation are interrupted.

## 1.4.3 Further protective devices

## **INFORMATION**

Emergency strategy – isolate the power supply!

To determine the type of switch or switch combination your temperature control unit is equipped with, please refer to the connection sketch starting on page 68 in the section **»Annex«**.

Temperature control units with >Mains isolator< [36] (red/yellow or gray): Turn the >Mains isolator< [36] to the "0" position!

Temperature control units with >Mains isolator [36] (red/yellow) and additional >Appliance switch< [37] (gray): Turn the >Mains isolator< [36] to the "0" position! Then turn the >Appliance switch< [37] to the "0" position!

Temperature control units with >Mains isolator< [36] (gray) and >Emergency stop switch< [70] (red/yellow): Press the >Emergency stop switch< [70]. Then turn the >Mains isolator< [36] to the "0" position!

Temperature control units with >Mains switch< [37]: Power supply via socket: Disconnect the temperature control unit from the power supply. Then turn the >Mains isolator< [37] to the "0" position! Power supply via hard wiring: Disconnect the power supply by means of the building's circuit breaker. Then turn the >Mains isolator< [37] to the "0" position!

**Temperature control units without a switch or inside a protective housing:** Connection via socket: Disconnect the temperature control unit from the power supply. Connection via hard wiring: Disconnect the power supply by means of the building's circuit breaker.

#### 1.4.3.1 Power interruption

Following a power outage (or when switching on the temperature control unit), this function can be used to determine how the temperature control unit is supposed to respond.

#### Auto-Start function is turned off

The temperature control is started only by manual input when the temperature control unit is turned on.

## Auto-Start function is turned on


The temperature control unit is set to the same state it was in before the power outage. For example, before the power outage: Thermoregulation is off; after power outage: Thermoregulation is off. If temperature control is active during a power outage, the process will automatically continue after the power outage.

Further information can be found on page 38 in section »Changing the Auto-Start function«.


## 1.5 Exemplary illustrations of the cooling variants

## 1.5.1 Air cooling

Example: Air cooling




Air inlet



## 1.5.2 Water cooling


Example: Water cooling





Chapter 1 OPERATION MANUAL

Water connection



## 1.5.3 Consequence of inadequate energy dissipation

## Room air/cooling water

Consequences of, for instance, contamination of the liquefier fins, inadequate clearance between temperature control unit to wall/bath wall, room air/cooling water too warm, cooling water differential pressure too low, suction strainer contamination: The refrigerant in the coolant circuit can no longer fully discharge the admitted energy to the room air/cooling water. Thus there is not sufficient liquefied refrigerant available, the condensation temperature and the energy consumption to rise.

## **Coolant circuit**

Consequences of inadequate refrigerant quantity/rising condensation temperature: Not all the cooling capacity from the coolant circuit is available at the evaporator. This means reduced energy transmission from the thermal fluid circuit.

## Thermal fluid circuit

Consequence of inadequate energy dissipation from the thermal fluid: The thermal fluid can only dissipate the energy from your application to a limited extent.

#### **Application**

Consequences of inadequate energy dissipation from the application: The energy created (exothermic) in the application can no longer be fully dissipated.

## Temperature control unit

An electronically-controlled expansion valve is used in the temperature control unit to optimize the power adjustment. The expansion valve always provisions the maximum possible cooling capacity within the permissible ambient temperature range. The temperature control unit switches off when the upper range is reached (maximum permissible ambient temperature).

V1.3.0en/22.01.19//1.0.0



## 2 Commissioning

## 2.1 In-plant transport



Temperature control unit is not transported / moved according to the specifications in this operation manual

#### **DEATH OR SERIOUS INJURY DUE TO CRUSHING**

- > Always transport / move the temperature control unit according to the specifications in this operation manual.
- Wear personal protective equipment during transport.
- Always work with the specified number of persons when moving the temperature control unit on casters (if any).
- If the temperature control unit is equipped with casters and parking brakes:
  2 parking brakes are always freely accessible when moving the temperature control unit. Activate the 2 parking brakes in an emergency!
  If only one parking brake is activated on the casters in an emergency:
  The temperature control unit is not stopped but rotates around the axis of the caster with the

#### NOTE

# Temperature control unit transported in a horizontal position DAMAGE TO THE COMPRESSOR

- > Only transport the temperature control unit in an upright position.
- If available, use the lugs on the top side of the temperature control unit for transportation.
- Use an industrial truck for transport.

activated parking brake!

- The casters on the temperature control unit are not suitable for transport. The casters are symmetrically loaded with 25% of the total mass of the temperature control unit.
- Remove the packing material (e.g. the palette) only at the place of installation.
- Protect the temperature control unit from transport damage.
- Do not transport the temperature control unit alone and without aids.
- Check the load bearing capacity of the transportation route and the place of installation.
- The parking brakes must be activated at the casters (if any) and/or the leveling feet (if any) must be unscrewed/activated before the temperature control unit is put into operation (see page 28, section »Unscrewing/activating the leveling feet (if any)«).

## 2.1.1 Lifting and transporting the temperature control unit

## 2.1.1.1 Temperature control unit with lifting eyes

## NOTE

# The temperature control unit is raised at the lifting eyes without load handling attachments DAMAGE TO THE TEMPERATURE CONTROL UNIT

- > Always use load handling attachments when lifting and transporting the temperature control unit
- The lifting eyes are only designed for a load without inclination (0°).
- The load handling attachment used must be adequately dimensioned. Take the dimensions and weight of the temperature control unit into account.
- Do not lift and transport the temperature control unit at the lifting eyes alone and without aids.
- Lift and transport the temperature control unit at the lifting eyes only with a crane or an industrial truck.
- The crane or industrial truck must have a lifting force equal to or greater than the weight of the temperature control unit. See the data sheet (from page 68 in section »Annex«) for the weight of the temperature control unit.

Minichiller® OLÉ, Unichiller® OLÉ



Chapter 2 OPERATION MANUAL

#### 2.1.1.2 Temperature control unit without lifting eyes

- Do not lift and transport the temperature control unit alone and without aids.
- Lift and transport the temperature control unit only with an industrial truck.
- The industrial truck must have a lifting force equal to or greater than the weight of the temperature control unit. See the data sheet (from page 68 in section »Annex«) for the weight of the temperature control unit.

## 2.1.2 Positioning the temperature control unit

#### 2.1.2.1 Temperature control unit with casters

- Do not use the casters for transportation to the place of installation. Observe page 22, section
   »Lifting and transporting the temperature control unit« for the transport to the place of installation.
- Use the rollers only for positioning at the place of installation.
- Only ever move the temperature control unit on casters if the surface is level, without a gradient, non-slip and stable.
- Do not move the temperature control unit alone.
- At least 2 persons are required to move the temperature control unit on casters. At least 5 persons are required to move the temperature control unit on casters if the total weight of the temperature control unit is over 1.5 tons.
- The parking brakes must be activated at the casters and/or the leveling feet (if any) must be unscrewed/activated before the temperature control unit is put into operation (see page 28, section »Unscrewing/activating the leveling feet (if any)«).

#### 2.1.2.2 Temperature control unit without casters

- An industrial truck must be used for positioning the temperature control unit.
- Do not move the temperature control unit alone.
- At least 2 persons are required to move the temperature control unit.
- The industrial truck must have a lifting force equal to or greater than the weight of the temperature control unit. See the data sheet (from page 68 in section »Annex«) for the weight of the temperature control unit.
- The leveling feet (if any) must be unscrewed/activated before the temperature control unit is put into operation (see page 28, section »Unscrewing/activating the leveling feet (if any)«).

## 2.2 Unpacking



#### Starting up a damaged temperature control unit

## MORTAL DANGER FROM ELECTRIC SHOCK

- > Do not operate a damaged temperature control unit.
- Please contact the Customer Support. The telephone number can be found on page 67, section »Phone number and company address«.

## **PROCEDURE**

- Check for damage to the packaging. Damage can indicate property damage to the temperature control unit.
- Check for any transport damage when unpacking the temperature control unit.
- Always contact your forwarding agent regarding the settlement of claims.
- Follow the instructions on page 15, section **»Proper disposal of resources and consumables«** for the disposal of packaging material.



## 2.3 Ambient conditions



## Unsuitable ambient conditions/unsuitable installation

#### SERIOUS INJURY DUE TO CRUSHING

Comply with the requirements under sections »Ambient conditions« and »Installation conditions«.

## **INFORMATION**

Make sure there is adequate fresh air available at the site for the circulation pump and the compressors. The warm exhaust air must be able to escape upwards unhindered.

#### Free-standing model


For the connection data, see the data sheet (from page 68 in Section »Annex«).

Use of the temperature control unit is permitted only under normal ambient conditions in accordance with DIN EN 61010-1:2011:

- Use only indoors. The illuminance must be at least 300 lx.
- Installation altitude up to 2000 meters above sea level .
- Maintain wall and ceiling clearance for adequate air exchange (dissipation of waste heat, supply
  of fresh air for the temperature control unit and work area). Ensure adequate floor clearance for
  air-cooled temperature control units. Do not operate this temperature control unit from within
  the box or with an inadequately dimensioned bath. This inhibits the exchange of air.
- Ambient temperature values are provided on the technical data sheet; compliance with the ambient conditions is mandatory, to ensure trouble-free operation.
- Relative humidity up to 32 °C max. 80% and decreasing linearly to 50% up to 40 °C.
- Short distance to supply connections.
- The temperature control unit must not be installed so as to hinder or prevent access to the isolator (to the power supply).
- Magnitude of the power supply fluctuations: see data sheet from page 68 in section »Annex«.
- Transient surges, as would normally occur in the power supply system
- Installation Class 3
- Applicable degree of soiling: 2.
- Surge category II.

Observe page 20 of section <code>»Exemplary</code> illustrations of the cooling variants«.


#### Wall clearances



24



Chapter 2 OPERATION MANUAL



## 2.3.1 EMC-specific notes

These devices are suitable for the operation in "industrial electromagnetic environments". It meets the "immunity requirements" of the currently applicable EN61326-1, which are required for this environment.

It also meets the "interference emission requirements" for this environment. It is a **Group 1** and **Class A** unit according to the currently applicable **EN55011**.

**Group 1** specifies that high frequency (HF) is only used for the function of a device. **Class A** specifies the interference emission limits to be observed.

## 2.4 Installation conditions



Temperature control unit is connected to the power supply line
DEATH FROM ELECTRICAL SHOCK BY DAMAGE TO THE POWER CABLE.

> Do not put temperature control unit on power cable.



Operating the temperature control unit fitted with castors without brakes activated CRUSHING OF LIMBS

- > Activate brakes on the wheels.
- Allow the temperature control unit to acclimate for about 2 hours when changing from a cold to a warm environment (or vice versa). Do not turn on the temperature control unit before!
- Install upright, stable and without tilt.
- Use a non-combustible, sealed subsurface.
- Keep environment clean: Prevent slip and trip hazards.
- Wheels must be locked after the installation, if installed!
- Spilled/leaked thermofluid must be disposed of immediately and properly. Follow the instructions
  on page 15, section »Proper disposal of resources and consumables« for the disposal of thermofluid and material.
- Observe the floor load bearing capacity for large units.
- Observe the ambient conditions.

## 2.5 Recommended temperature control and cooling water hoses



## Use of unsuitable/defective hoses and/or hose connections

#### **INJURIES**

- > Thermal fluid
- Use appropriate hoses and/or hose connections.
- Check periodically for leaks and the quality of the hose and hose connections and take suitable measures (replace) as required.
- Isolate and protect temperature control hoses against contact/mechanical load.
- Cooling water
- Reinforced hoses must be used to satisfy tougher safety requirements.
- Shut off the cooling water supply to the temperature control unit even for shorter downtimes (e.g. overnight).



#### Hot or cold thermal fluid and surfaces

#### RURNS TO LIMBS

- Avoid direct contact with the thermal fluids or the surfaces.
- > Wear your personnel protective equipment (e.g. temperature-resistant safety gloves, safety goggles, safety footwear).

To connect applications, use only temperature control hoses that are compatible with the thermal fluid used. When selecting temperature control hoses, also pay attention to the temperature range in which the hoses are to be used.

- We recommend you use only temperature-insulated temperature control hoses with your temperature control unit. The responsible body is responsible for the insulation of connection valves.
- We exclusively recommend reinforced hoses for connecting to the cooling water supply. Cooling
  water and insulated temperature control hoses can be found in the Huber catalogue under Accessories.

## 2.6 Wrench sizes and torques

Note the wrench sizes that result for the pump connection on the temperature control unit. The following table lists the pump connections and the resulting wrench sizes, and torque values. A leak test must always be performed, and the connections tightened if necessary. The values of the maximum torque (see table) must **not** be exceeded.

Overview wrench sizes and torques

v b	Connection	Sleeve nut wrench size	Connector wrench size	Recommended torques in Nm	Maximum torques in Nm
S	M16x1	19	17	20	24
	M24x1.5	27	27	47	56
	M20:4 F	36	32	79	93
	M30x1.5	36	36	79	93
	M38x1.5	46	46	130	153
	G-thread (flat- sealing)	Adapt the torque to the material of the flat seal used. First hand-tighten the temperature control hose.  When using adapters, do not overtighten the G-thread on the pump connection when connecting a temperature control hose. When connecting a temperature control hose to the adapter piece, secure the G thread against overwinding.		p connection when ature control hose to	

Chapter 2



## 2.7 Temperature control units with water cooling

## **MARNING**

Open electrical wires below the temperature control unit if the temperature falls below the dew point.

#### DEATH FROM ELECTRICAL SHOCK BY WATER ENTRY INTO THE ELECTRIC LINES.

- ➤ A temperature below the dew point may result in condensation in the temperature control unit and at the cooling water connections. The condensation is caused by high humidity at the cooling water-bearing components. The condensation exists the temperature control unit at the hottom
- Electrical lines directly below the temperature control unit must be protected against liquid ingress.



## Use of unsuitable/defective hoses and/or hose connections

#### **INJURIES**

- > Thermal fluid
- Use appropriate hoses and/or hose connections.
- Check periodically for leaks and the quality of the hose and hose connections and take suitable measures (replace) as required.
- > Isolate and protect temperature control hoses against contact/mechanical load.
- Cooling water
- Reinforced hoses must be used to satisfy tougher safety requirements.
- Shut off the cooling water supply to the temperature control unit even for shorter downtimes (e.g. overnight).

#### NOTE

#### No protection against corrosion

#### DAMAGE TO THE TEMPERATURE CONTROL UNIT

- > The addition of anti-corrosion agents is mandatory if salts (chlorides, bromide) have been added to the water circuit.
- > Ensure that the materials used in the cooling water circuit are resistant with respect to the cooling water. See the data sheet from page 68 in section »Annex« for information on the materials used.
- Take suitable measures to maintain the warranty conditions.
- For information about water quality, see www.huber-online.com.

## NOTE

#### Usage of un-filtered river/sea or ocean water as cooling water


## DAMAGE TO THE TEMPERATURE CONTROL UNIT

- ➤ Un-filtered river or sea water is not suitable for use as cooling water due to its contaminants.
- Use drinking water or filtered river or sea water for cooling.
- > Sea water must not be used for water cooling.
- For information about water quality, see www.huber-online.com.

## **INFORMATION**

To minimize cooling water consumption, Huber temperature control units with water cooling are equipped with a cooling water regulator. It limits the flow of cooling water to the amount required by the current load situation. If only a low cooling capacity is requested, only a small amount of cooling water is consumed. It cannot be ruled out that cooling water flows when the machine is switched off. Shut off the cooling water supply to the temperature control unit even for shorter downtimes (e.g. overnight).

Installing a suction strainer (table-top models only)



Connection diagram



#### Preparing the temperature control unit with water cooling:

#### **INFORMATION**

The responsible body must ensure that the cooling water supply and drain pipes are laid frost-protected. The cooling water temperature must not fall below 3 °C. At ambient temperatures below 3 °C, the cooling water supply must be heated.

The minimum pressure differential in the cooling water circuit and the recommended cooling water inlet temperature can be found on the data sheet (from page 68 in the section »Annex«).

The illustration "connection diagram" can be found on page 68 in section "Annex".

## **PROCEDURE**

- ➤ Close (if fitted) the >Cooling water drain< [15].
- ➤ Connect the >Cooling water outlet< [14] to the water return flow. A seal must be used.
- Insert the suction strainer (dirt trap) into the **>Cooling water return<** [13].
- Connect the >Cooling water inlet< [13] to the water supply.</p>

## NOTE

## Leaking cooling water connections

## DAMAGE BY ROOM FLOODING

- > Slowly open the building-side shut-off valves of the cooling water supply and return line.
- If water leaks from the cooling water connections: shut off the cooling water supply and return line immediately.
- Provide leakproof cooling water connections.
- Open the shut-off valves in the water line on the temperature control unit and on the building side.
- Check the connections for leaks.

## 2.8 Preparations for operation

## 2.8.1 Unscrewing/activating the leveling feet (if any)



# The leveling feet are not unscrewed/activated before switching on the temperature control unit DEATH OR SERIOUS INJURY DUE TO CRUSHING

- > The parking brakes must be activated at the casters (if any) and/or the leveling feet must be unscrewed/activated before the temperature control unit is put into operation.
- The temperature control unit may move if the parking brakes of the casters (if any) are not activated and/or the leveling feet are not unscrewed/activated.

Always unscrew/activate the leveling feet before switching on the temperature control unit. Uneven floors can be compensated by adjusting these leveling feet.

## **PROCEDURE**

- Verify that the parking brakes of the casters (if any) have been activated.
- Unscrew the leveling feet.
- > Compensate uneven floors by adjusting these leveling feet, if necessary. Use a spirit level to horizontally align the temperature control unit.
- Tighten the lock screws on the leveling feet after aligning the temperature control unit. This prevents the leveling feet from changing their height during operation.

huber

Chapter 2 OPERATION MANUAL


## 2.8.2 Opening/closing the bypass valve

Some temperature control units are fitted with an adjustable bypass to protect fragile applications (e.g. a glass apparatus). To find out whether your temperature control unit is equipped with an adjustable bypass, refer to the "Wiring diagram" from page 68 in Section "Annex".

The **>Bypass valve**< [62] is located on top of the temperature control unit. The set pressure is displayed on the display (see page 34 Section **»Display«**). The **>Bypass valve**< [62] must be fully open before the circulation starts:

- at the initial filling of the machine;
- when switching to another thermal fluid;
- when switching to another application.

Opening and closing the bypass valve



## **INFORMATION**

#### Opening the bypass valve:

Open the valve by turning it counterclockwise (turn 90° left as far as it will go).

#### Closing the bypass valve:


Close the valve by turning it clockwise (turn 90° right as far as it will go).

## **PROCEDURE**

- > Check whether the >Bypass valve< [62] is open.
- ➤ Open the >Bypass valve< [62] by turning it counterclockwise (turn 90° left as far as it will go).

## 2.8.3 Enable / Disable silent operation (optional)

Enable / Disable silent operation



Activating silent operation on the temperature control unit reduces the noise level by decreasing the pumping capacity. For the exact position of the button **>Change pump speed< [114]** please refer to the "Wiring diagram" from page 68 in Section **»Annex«**.

## **PROCEDURE**

- > To activate silent operation, press the button >Change pump speed< [114] on the temperature control unit. The pumping capacity and the noise level are reduced.
- ➤ To deactivate silent operation, re-press the button >Change pump speed< [114] on the temperature control unit. The pumping capacity and the noise level are increased.
- Select the silent operation mode by activation and deactivation.

## 2.8.4 Installing collecting container

## **PROCEDURE**

- Install a suitable hose at the **>overflow<** [12] on the temperature control unit. It must be compatible with the thermal fluid and the temperature.
- > Put the other end of the hose in a suitable collecting container.



## 2.9 Connecting externally closed application

The illustration "connection diagram" can be found on page 68 in section "Annex".


## 2.9.1 Connecting an externally closed application

## NOTE

# Overpressure in the application (e.g. > 0.5 bar (g) with glass apparatus) MATERIAL DAMAGE TO THE APPLICATION

- > Provide an overpressure protective device to prevent damage to the application.
- Do not install valves/quick-release couplings in the feed/discharge lines from the temperature control unit to the application and from the application to the temperature control unit.
- ➤ If valves/quick-release couplings are required:
- > Install burst disks on the application itself (at the feed and discharge lines).
- > Install a bypass upstream of the valves/quick-release couplings for the application.
- Matching accessories (e.g. bypasses to reduce pressure) can be found in the Huber catalog.

Example: Connecting an externally closed application



To enable your application to be operated correctly and eliminate air bubbles from the system, you must ensure that the **>Circulation flow<** [1] connection from the temperature control unit is attached to the lower connection point of the application and the **>Circulation return<** [2] into the temperature control unit is attached to the higher connection point of the application.

## **PROCEDURE**

- Remove the screw plugs from the >Circulation flow< [1] and >Circulation return< [2] connections</p>
- Then connect your application to the temperature control unit using suitable thermal fluid hoses. The corresponding wrench sizes can be found in the table on page 26 in section »Wrench sizes and torques«.
- > Check the connections for leaks.

## 2.10 Connecting to the power supply

#### **INFORMATION**

Based on local circumstances, it may be that you need to use an alternative power cable instead of the supplied original power cable. Do not use a power cable that is longer than **3 m** to be able to disconnect the temperature control unit at any time from the mains. Have the mains cable only replaced by a qualified electrician.

## 2.10.1 Connection using socket with protective earth (PE)



Connecting to a power socket without protective earth (PE)
MORTAL DANGER FROM ELECTRIC SHOCK

> Always connect the temperature control unit to safety sockets (PE).



## Damaged power cable/power cable connection

## MORTAL DANGER FROM ELECTRIC SHOCK

- > Do not start up the temperature control unit.
- Isolate the temperature control unit from the power supply.
- Have the power supply cable/power supply connection replaced and inspected by an electrician
- Do not use a power cable that is longer than 3 m.

huber

Chapter 2 OPERATION MANUAL

## NOTE

#### Incorrect power supply connection

#### DAMAGE TO THE TEMPERATURE CONTROL UNIT

> Your building's existing power supply voltage and frequency must match the data provided on the rating plate of the temperature control unit.

## **INFORMATION**

In case of uncertainties about an existing protective earth (PE), have the connection inspected by an electrician.

## 2.10.2 Connection via hard wiring



# Connection/adjustment to the power supply not carried out by an electrician MORTAL DANGER FROM ELECTRIC SHOCK

> Have the connection/adjustment to the power supply carried out by an electrician.



## Damaged power cable/power cable connection

#### MORTAL DANGER FROM ELECTRIC SHOCK

- Do not start up the temperature control unit.
- Isolate the temperature control unit from the power supply.
- Have the power supply cable/power supply connection replaced and inspected by an electrician.
- > Do not use a power cable that is longer than **3 m**.

## NOTE

#### Incorrect power supply connection

## DAMAGE TO THE TEMPERATURE CONTROL UNIT

Your building's existing power supply voltage and frequency must match the data provided on the rating plate of the temperature control unit.



## **3** Function description

## 3.1 Function description of the temperature control unit

## 3.1.1 General functions

Circulating coolers are temperature control units, which are mainly used to dissipate process heat as well as a cost effective alternative to cooling water (drinking water).

Due to **powerful refrigeration engineering**, **short cooling rates** can be achieved.

## 3.1.2 Other functions

A pump ensures the thermal fluid is circulated. The following data are displayed on the **display with OLED technology** depending on the model and options: Temperature of the internal and external temperature sensor, setpoint, pressure and flow rate. Use the membrane keyboard to enter the controller settings.

The temperature control unit can easily be integrated in many laboratory automation systems using the standardly existing RS232 and USB interfaces on the controller and the optional ECS and POKO interfaces.

An external Pt100 sensor can be connected via the optional **Pt100 process display sensor port**. The temperature measured is displayed on the display.

Temperature control units with a heater have an **overtemperature protection to DIN EN 61010-2-010 that is independent** of the control circuit.

## 3.2 Information on the thermal fluids



# Non-compliance with the safety data sheet for the thermal fluid to be used INJURIES

- Risk of injury to the eyes, skin, respiratory tract.
- > The safety data sheet for the thermal fluid to be used must be read prior to using it and its content must be respected.
- Observe the local regulations/work instructions.
- Wear your personal protective equipment (e.g. temperature-resistant safety gloves, safety goggles, safety footwear).
- Danger of slipping because floor and work area are contaminated. Clean the work station and follow the instructions for the disposal of thermal fluid and material on page 15 in Section »Proper disposal of resources and consumables«.

## NOTE

# Non-compliance with the compatibility between the thermal fluid and your temperature control unit MATERIAL DAMAGE

- Observe the classification of your temperature control unit according to DIN 12876.
- ➤ Ensure the following materials are resistant with respect to the thermal fluid: Stainless steel 1.4301/1.4401 (V2A), copper, nickel, FKM, red bronze/brass, silver solder and plastic.
- The maximum viscosity of the thermal fluid must not exceed 50 mm²/s at the lowest working temperature!
- ➤ The maximum density of the thermal fluid may not exceed 1 kg/dm³!

Minichiller® OLÉ, Unichiller® OLÉ



Chapter 3 OPERATION MANU

Thermal fluid: Water

Designation	Specification
Calcium carbonate per liter	≤ 1.5 mmol/l; corresponds to a water hardness of: ≤ 8.4 °dH (soft)
PH value	between 6.0 and 8.5
Ultrapure water, distillates	Add 0.1 g of sodium carbonate (Na <sub>2</sub> CO <sub>3</sub> ) per liter
Not approved water	Distilled, deionized, demineralized, chloric, ferruginous, ammoniacal, or contaminated river water or sea water
Volume circulated (at least)	3 l/min.
Thermal fluid: Water without ethyl	ene glycol
Use	≥ +3 °C
Thermal fluid: Water-ethylene glyc	ol mixture
Use	<+3 °C
Thermal fluid composition	The mixture's temperature must be 10 K below the permissible min. temperature. For the permissible temperature range, refer to the datasheet from page 68 in Section <b>»Annex«</b> .

## 3.3 To be noted when planning the test

#### **INFORMATION**

Also observe page 13 in section »Proper operation«.

The focus is on your application. Bear in mind that system performance is influenced by heat transfer, temperature, thermal fluid viscosity, volume flow, and flow speed.

- Make sure that the electrical connection is adequately dimensioned.
- The installation location of the temperature control unit should be selected so as to ensure adequate fresh air, even with water-cooled chillers.
- The maximum forward flow pressure of a temperature control unit must be taken into account in case of pressure-sensitive applications, such as glass reactors.
- Avoid a cross-section reduction or shut-off in the thermal fluid circuit. Take corresponding
  measures to limit the pressure in the system; see data sheet from page 68 in section »Annex«
  and the data sheet for your glass apparatus.
- Check whether it is necessary to use an external bypass for temperature control units without pressure limitation.
- To prevent the danger of overpressure in the system, the thermal fluid must always be brought to room temperature before turning off. This will prevent damage to the temperature control unit or the application. Any isolating valves must remain open (pressure equalization).
- Select the thermal fluid to be used in such a way that it not only permits the minimum and maximum working temperature but is also suitable with regard to combustion point, boiling point, and viscosity. In addition, the thermal fluid must be compatible with all the materials in your system.
- Avoid bending the temperature control and cooling water hoses (if required). Use suitable angle
  pieces and lay the hose connections with a large radius. Take the minimum bending radius from
  the data sheet of the temperature control hoses used.
- The selected hose connections must be resistant to the thermal fluid, the working temperatures and the permitted maximum pressure.
- Check the hoses at regular intervals for any material fatigue (e.g. cracks, leaks).
- Keep the temperature control hoses as short as possible.
  - The inside diameters of the temperature control hoses must always be adapted to the pump connections.
  - The viscosity of the thermal fluid determines the pressure drop and affects the temperature control results, particularly at low operating temperatures.
  - Too small connectors and couplers and valves can generate significant flow resistance.
     Your application will therefore be slower to reach its design temperature.
- Basically, you should only use the thermal fluid recommended by the manufacturer and only within the usable temperature and pressure range.


- The application should be roughly below or at the same level of the temperature control unit if the thermoregulation is close to the boiling temperature of the thermal fluid.
- Fill the temperature control unit slowly, carefully and steadily. Wear the necessary personal protective equipment, such as goggles, heat-proof and chemical-resistant gloves, etc.
- The temperature control circuit must be vented after filling and setting all required parameters.
   This is required to ensure trouble-free operation of the temperature control unit and hence your application.

#### **INFORMATION**

For water-cooled temperature control units, please take the cooling water temperature necessary for perfect operation and the required differential pressure from the data sheet from page 68 onward in the Section »Annex«.


## 3.4 Display and control instruments

The control panel: Displays and keys




## 3.4.1 Display

Home screen: Temperature control is active



Home screen: Temperature control is inactive or an error message is displayed





Chapter 3 OPERATION MANUAL

Home screen: Explanation of the display

Designation	Description
Temperature limit for setpoint	Display of the setpoint limit. You can set the setpoint only within this range. You can change this limit in the menu item "Protection Options" and then "Setpoint Minimum" and "Setpoint Maximum". Do take the thermal fluid used and the material to be tempered into account when changing these settings. See also on page 37, section »Menu function«.
Flow sensor / pressure sensor (optional, depending on model)	Display for the measured values of the built-in flow or pressure sensor.  This feature is optional depending on the model and is not available in KISS controllers and other temperature control units.  Use the menu item "Sensor Configuration" under "Flow Sensor / Pressure Sensor Display" to change the display or to turn it on and off. See also on page 37, section "Menu function".
Heater	This symbol is displayed when the temperature control unit heats the thermal fluid. (Only for temperature control units with heating)
Cooling system	This symbol is displayed when the temperature control unit cools down the thermal fluid.
Pump	The symbol is displayed when the pump in the temperature control unit runs.
Current internal temperature	Display of the current thermal fluid temperature. The temperature is measured and controlled by the internal temperature sensor.
Pt100 sensor (optional)	Displays the measured value of the external Pt100 process display sensor. This display requires that:  1) the temperature control unit is equipped with a Pt100 port,  2) a Pt100 process display sensor has been attached,  3) the Pt100 process display sensor was placed in the application.  You can turn on and off the display in the menu item "Sensor Configuration" under "Display external Pt100 sensor" only if the corresponding interface has been installed. See also on page 37, section "Menu function".
Adjusted setpoint	Displays the setpoint set.
Info text or error message	Displays an info text or error message.

## 3.4.2 Control instruments

## 3.4.2.1 Arrow keys



Use the **>Arrow keys<** [B] to enter values ( $\bigcirc$  (+) or  $\bigcirc$  (-)), to select a menu item ( $\bigcirc$  (arrow left) or  $\bigcirc$  (arrow right)) or to select a different menu item ( $\bigcirc$  (up) or  $\bigcirc$  (down)). Pressing an arrow key for an extended period changes a value faster. Pressing both **>Arrow keys<** [B] simultaneously calls up the main menu.

## 3.4.2.2 SET key



Pressing the **>SET key<** [C] on the home screen switches directly to the screen where you can enter the setpoint temperature. It allows you to quickly modify the setpoint temperature. The **>SET key<** [C] is also used to get to a selected menu item or to confirm changes.

## 3.4.2.3 ESC key



Pressing the **>ESC key<** [D] cancels changes / entries. The display changes to the previous screen without saving a change / entry. Pressing the **>ESC key<** [D] brings you back to the previous screen, all the way to the home screen. Press the **>ESC key<** [D] to acknowledged the alarm sound of an error.


## 3.4.2.4 Start/Stop key




Start or stop the thermoregulation by pressing the >Start/Stop button< [E].

## 3.4.3 Adjusting settings

Exemplary setting of a numerical value



Exemplary setting by text selection



There are two ways to adjust settings:

#### **Numerical settings:**

Use the **>Arrow keys**< [B] ( $\triangle$  (+) or  $\bigcirc$  (-)) and confirm an entry by pressing the **>SET key**< [C]. Pressing an arrow key for an extended period changes a value faster.

## Text selection:

Select the text via the **>Arrow keys<** [B] ( $\bigcirc$  (up) or  $\bigcirc$  (down)) and confirm your entry by pressing the **>SET key<** [C].


Minichiller® OLÉ, Unichiller® OLÉ



Chapter 3 OPERATION MANUAL

# 3.5 Menu function

Main menu



Pressing both **>Arrow keys<** [B] simultaneously calls up the main menu. Some menu items cannot be selected depending on the configuration of the temperature control unit.

Overview of the menu items

Display	Description	KISS	OLÉ			
Setpoint 1	Sets the setpoint. Use the >Arrow keys< [B] to change the setpoint.					
Adjusting brightness	Adjusting the brightness of the OLED display.  Use the <b>&gt;Arrow keys</b> B to change the brightness.	X	X			
G_¥	This menu item makes available:.					
<b>6</b> ^	1) Adjustment of the internal sensor (input options: Offset (K))	Х	Х			
Canaca	2) Adjustment of the external sensor (input options: Offset (K))	0	0			
Sensor	3) Temperature unit (choose between "Celsius" and "Fahrenheit")	X	X			
configura- tion	4) Mode (choose between "Internal temperature control", "Venting" and "Circulation"  5) Display of external Pt100 sensor – (activating the display of an external Pt100	X O	X O			
	process display sensor) 6) Flow sensor / pressure sensor display – (activating the display of the optional flow sensor / pressure sensor)	_	М			
	This menu item makes available:					
	1) RS232 1 (setting of "Baud rate" and "Mode" (HuberBus))	Х	X			
Interfaces	2) RS232 2 (setting of "Baud rate" and "Mode" (HuberBus))	X	0			
interraces	3) USB device (setting of "Baud rate" and "Mode" (HuberBus))  Only the Huber service engineer is allowed to use the "STBus" mode.  4) Floating contact (selection of "Off", "Alarm" and "Unipump/PCS")	Х	Х			
	5. External control signal (selection between "Off", "Setpoint2" and "Standby")	_	О			
		-	0			
<b>A</b>	This menu item makes available:.					
<u>^\</u>	1) Setpoint2 (to input the second setpoint)	_	0			
Dueteetien	2) Setpoint minimum (to input the lower limit of the adjustable setpoint)	X	X			
Protection	3) Setpoint maximum (to input the upper limit of the adjustable setpoint)	X	X			
Options	4) Power failure automatic (select between "Off" and "Automatic")	Х	Х			
<b>1</b> 9	This menu item makes available:	.,				
(EER Q	1) Heating output (only with temperature control units; setting in %	X	M			
System	Select Language (choose between "English" and "German")     Cooling bath (select between "Without cooling bath" (Off), "With cooling bath	X M	X			
Эузісііі	and common power supply" (On) and "With cooling bath and separate power supply" (On))	IVI	_			
	System Information (display different serial numbers (Serial Number) and version statuses)	Х	Х			
	5) Service menu (only for Huber service technicians. This submenu is password protected)	х	х			
	6) Factory settings (choose between "Continue" and "Cancel")	Х	Х			
X = standard, O = optional, M = model-dependent = not possible						

# 3.6 Functional examples

# 3.6.1 Selecting a language

# **PROCEDURE**

- > Press both >Arrow keys< [B] to invoke the main menu.
- ➤ Use the >Arrow keys< [B] to select the menu item "System".
- > Press the >SET key< [C] to confirm your selection.
- ➤ Use the >Arrow keys< [B] to select the submenu "Select Language".
- > Press the >**SET key**< [C] to confirm your selection.
- > Use the >Arrow keys< [B] to select the desired language.
- > Press the >SET key< [C] to confirm your selection.
- > Press the >ESC key< [D] twice to return to the home screen.

# 3.6.2 Setting the setpoint

# **PROCEDURE**

## Using the home screen to set the setpoint

- > Press the >SET key< [C].
- Vise the >Arrow keys< [B] (△ (+) or ¬ (-)) to set the new setpoint.</p>
  The longer you keep an arrow key pressed the faster the value changes.
- > Press the >SET key< [C] to confirm your input.

# 3.6.3 Changing the Auto-Start function

Following a power outage (or when switching on the temperature control unit), this function can be used to determine how the temperature control unit is supposed to respond.

#### Auto-Start function is turned off

The temperature control is started only by manual input when the temperature control unit is turned on.

#### Auto-Start function is turned on

The temperature control unit is set to the same state it was in before the power outage. For example, before the power outage: Thermoregulation is off; after power outage: Thermoregulation is off. If temperature control is active during a power outage, the process will automatically continue after the power outage.

# **PROCEDURE**

- Press both >Arrow keys< [B] to invoke the main menu.</p>
- ➤ Use the >Arrow keys< [B] to select the menu item "Protection Options".
- ➤ Press the >**SET key**< [C] to confirm your selection.
- ➤ Use the >Arrow keys< [B] to select the submenu "Power Failure Automatic".
- > Press the >SET key< [C] to confirm your selection.
- ➤ Use the **>Arrow keys<** [B] to select the desired setting.
- Press the >SET key< [C] to confirm your selection.</p>
- > Press the >ESC key< [D] twice to return to the home screen.



# 4 Setup mode

# 4.1 Setup mode



Moving the temperature control unit during operation
SERIOUS BURNS/FREEZING OF THE HOUSING PARTS/ESCAPING THERMAL FLUID

> Do not move temperature control units that are in operation.

# 4.1.1 Turning on the temperature control unit

# **PROCEDURE**

- The temperature control unit must be filled with thermal fluid before you turn it on via the >Mains switch< [37] (see on page 41 Section »Filling, venting, degassing and draining«). An error message appears on the display after a short time if the temperature control unit is switched on without thermal fluid. If this is the case, switch off the temperature control unit using the >Mains switch< [37] and fill it.
- > Switch on the temperature control unit using the >Mains switch< [37]. The float switch monitors the thermal fluid level. The float switch is automatically pressed down. The buoyancy of the float forces it upwards when thermal fluid is filled and thus the test is passed. The test may generate some sounds.
  - Circulation and thermoregulation are turned off.

# 4.1.2 Turning off the temperature control unit

# **PROCEDURE**

- > Warm the thermofluid to room temperature.
- > Stop the thermoregulation.
- > Switch off the temperature control unit using the >Mains switch< [37].

# 4.1.3 Setting the overtemperature (OT) protection




The overtemperature protection is set higher than the ignition temperature of the thermal fluid used MORTAL DANGER FROM FIRE

- The overtemperature protection must be correctly set to the thermal fluid you are using.
- Always observe the safety data sheet of the thermal fluid.
- > Set the cut-out value of the overtemperature protection at least 25 K below the combustion point of the thermal fluid.

#### 4.1.3.1 General information on the overtemperature protection

Example of a potentiometer at the temperature control unit



The overtemperature protection is installed only in temperature control units that have a heater. The flow temperature is monitored to ensure the safety of your system. It is set immediately after you have filled the system with thermal fluid.

Upon delivery, the cut-out value of the overtemperature protection is set to 40  $^{\circ}$ C. An alarm is triggered by the temperature control unit shortly after turning on the power if the temperature of the thermal fluid just filled is higher than the cut-out value set for the overtemperature protection. Set the overtemperature protection to the thermal fluid you are using. Please note: The printed scale can deviate by - 25 K from the set cut-out value.

#### 4.1.3.2 Setting the overtemperature protection

Setting the cut-out value



#### **INFORMATION**

You need a screwdriver (flat blade  $1.0 \times 5.5$ ) to set the cut-out value of the overtemperature protection.

# **PROCEDURE**

➤ Use a screwdriver to set the cut-off value on the potentiometer. The cut-out value must be set to match the thermal fluid you are using. It is not required to switch on the temperature control unit.

# 4.1.4 Testing the overtemperature protection for functionality



#### Overtemperature protection (OT) does not trip

#### MORTAL DANGER FROM FIRE

> Test the response of the device every month and after each change of the thermal fluid in order to assure proper functioning.

#### NOTE

The steps below are carried out without permanent monitoring of the temperature control unit DAMAGE TO AND IN THE VICINITY OF THE TEMPERATURE CONTROL UNIT

The following actions may only be carried out while constantly monitoring the temperature control unit and the application!

# **INFORMATION**

The overtemperature protection is installed only in temperature control units that have a heater. You need a sufficiently large-sized screwdriver to check the overtemperature protection for functionality.

Steps to test the correct functioning of the overtemperature protection:

# **PROCEDURE**

- > Note down the cut-out value of the overtemperature protection set on the potentiometer.
- > Switch on the temperature control unit.
- Enter a setpoint (room temperature). Further information can be found on page 38 in section »Setting the setpoint«.
- ➤ Press the >Start/Stop button<[E] to start temperature control.
- > Use a screwdriver to set the new cut-off value on the potentiometer. This shutdown value must be **below** the displayed internal temperature. The overtemperature protection is triggered.
- > Turn off the temperature control unit.
- Use a screwdriver to reset the cut-off value on the potentiometer to the original value.

#### **INFORMATION**

Immediately take the temperature control unit out of operation if the overtemperature protection is not triggered. Immediately contact Customer Support. The telephone number can be found on page 67, section **»Phone number and company address«**. Do not put the temperature control unit back into operation.



# 4.2 Filling, venting, degassing and draining

The illustration "connection diagram" can be found on page 68 in section »Annex«.

# **!** CAUTION

# Extremely hot / cold surfaces, connections and thermal fluids

#### **BURNS/FREEZING OF LIMBS**

- > Surfaces, connections and tempered thermal fluids can be extremely hot or cold depending on the operating mode.
- ➤ Avoid direct contact with surfaces, connections and thermal fluids!
- Wear your personnel protective equipment (e.g. temperature-resistant safety gloves, safety goggles).

#### NOTE

# During an active circulation, the thermal fluid circuit is shut off by shut-off valves

#### MATERIAL DAMAGE TO THE CIRCULATING PUMPS INSTALLED IN THE TEMPERATURE CONTROL UNIT

- > Do not close the thermal fluid circuit during an active circulation by means of shut-off valves.
- Warm the thermal fluid to room temperature before stopping the circulation.

# 4.2.1 Filling and venting externally closed application

# ! CAUTION

# Non-compliance with the safety data sheet for the thermal fluid to be used INJURIES

- Risk of injury to the eyes, skin, respiratory tract.
- > The safety data sheet for the thermal fluid to be used must be read prior to using it and its content must be respected.
- Observe the local regulations/work instructions.
- Wear your personal protective equipment (e.g. temperature-resistant safety gloves, safety goggles, safety footwear).
- Danger of slipping because floor and work area are contaminated. Clean the work station and follow the instructions for the disposal of thermal fluid and material on page 15 in Section »Proper disposal of resources and consumables«.

# NOTE

#### Semi-automatic venting

#### DAMAGE TO THE TEMPERATURE CONTROL UNIT

- ➤ An elevated tolerance time for the pressure drop can damage the pump if the thermal fluid level in the system is also too low.
- Constantly observe the thermal fluid level on the >Sight glass< [23] or the >Level indicator and drain< [38]. Fill up the thermal fluid during the venting phase so the thermal fluid level does not fall below the minimum mark in the >Sight glass< [23] or the >Level indicator and drain< [38].</p>

# NOTE

# The >Bypass valve< [62] (if any) is not adapted to the external application MATERIAL DAMAGE TO THE EXTERNAL APPLICATION

- ➤ A closed >Bypass valve< [62] can cause the pressure in the thermal fluid circuit to become too high for the external application used. It may cause the thermal fluid to overflow from the external application and/or damage the external application.
- ➤ Initial filling, switching to another thermal fluid or another external application: The >Bypass valve< [62] must be fully open before the circulation is started. As a result, the pressure in the thermal fluid circuit is at the lowest point.
- Note the pressure gauge when starting the circulation. The allowable pressure of your external application must not be exceeded.


# **INFORMATION**

Calculate whether the capacity of the **>Expansion vessel<** [18] can absorb the expansion volume during operation. Assume the following volumes for this calculation: [Minimum filling capacity of the temperature control unit] + [Volume of the thermal fluid hoses] + [Jacket volume of your application] + [10% / 100 K].

- During the fill process, ensure any necessary measures, such as earthing the tanks, funnels and other aids, have been taken.
- Fill to the lowest possible height.

#### 4.2.1.1 Filling and venting with >Sight glass< [23]

Fill levels in the >Sight glass< [23]



# **PROCEDURE**

- > At temperature control units with >bypass valve<[62], ensure that the valve is fully open.
- Check that a hose was installed at the >overflow<[12] (if installed).</p>
  The other end of the hose must be in a suitable collecting container. Excess thermal fluid will flow into this container when the temperature control unit is overfilled. Hose and container must be resistant to the thermal fluid and the temperature.
- ➤ Open the >Filling port<[17] manually.
- Using the filling accessories (funnel and/or beaker), fill suitable thermal fluid into the >Filling port<[17]. The thermal fluid flows into the temperature control unit and through the hose connection to the external application. The level shows in the >sight glass<[23]. When you clean the filling accessories, observe the instructions on page 15, section »Proper disposal of resources and consumables«.</p>
- Switch on the temperature control unit.
- > Set the setpoint to 20 °C. Further information can be found on page 38 in the section **»Setting** the setpoint«.
- Press the >Start/Stop button<[E] to start circulation.</p>
- > Refill thermal fluid as needed. Watch the level in the **>sight glass<[23]**. The filling/venting process is complete when the temperature control unit is filled sufficiently.

#### **INFORMATION**

If, with externally closed applications (reactors), the fluid level in the fill level display remains the same when the pump is running and when the pump has stopped, the application has been vented.

- At temperature control units with >bypass valve<[62], adjust the pressure in the thermal fluid circuit to the employed external application. For this purpose, use the >bypass valve<[62] and the manometer on the display.
- Press the >Start/Stop button<[E] to stop circulation.</p>
- > Turn off the temperature control unit.
- Check the level in the collecting container. Empty the container when necessary and dispose of its contents properly.
- Close the >Filling port<[17] manually.</p>
  The temperature control unit is now filled.

#### **INFORMATION**

**Venting** must be performed especially during commissioning and after changing the thermal fluid. This is the only way to ensure trouble-free operation.


Note that the volume expansion of the thermal fluid depends on the working temperature range you wish to work in. At the "lowest" working temperature, do not go beyond the **minimum** mark of the **>Sight glass<** [23] and at the "highest" working temperature there should be no overflow from the **>Expansion vessel<** [18]. In case of overfilling, drain the excess amount of thermal fluid (see page 44 in Section **»Draining with >Sight glass<** [23]«). Check if the thermal fluid can be reused. On page 15 observe Section **»Proper disposal of resources and consumables**«.

Minichiller® OLÉ, Unichiller® OLÉ V1.3.0en/22.01.19//1.0.0



#### 4.2.1.2 Filling and venting with >Level indicator and drain< [38]

>Level indicator and drain< [38]



# **PROCEDURE**

- Ensure that the hose of the >Level indicator and drain<[38] was not pulled out.
- ➤ Open the >Filling port<[17] manually.
- Using the filling accessories (funnel and/or beaker), fill suitable thermal fluid into the >Filling port<[17]. The thermal fluid flows into the temperature control unit and through the hose connection to the external application. Fill the temperature control unit up to 1 cm below the end of the hose of the >Level indicator and drain<[38]. When you clean the filling accessories, observe the instructions on page 15, section »Proper disposal of resources and consumables«.</p>
- Switch on the temperature control unit.
- Set the setpoint to 20 °C. Further information can be found on page 38 in the section »Setting the setpoint«.
- Press the >Start/Stop button<[E] to start circulation.</p>
- Refill thermal fluid as needed. Watch the level in the >Level indicator and drain<[38]. Ensure that the level never drops below the minimum level marking. The filling/venting process is complete when the temperature control unit is filled sufficiently.</p>

#### **INFORMATION**

If, with externally closed applications (reactors), the fluid level in the fill level display remains the same when the pump is running and when the pump has stopped, the application has been vented.

- > Stop the circulation by pressing the >Start/Stop button< [E].
- Manually close the >Filling port< [17].</p>
  The temperature control unit is now filled.

#### **INFORMATION**

**Venting** must be performed especially during commissioning and after changing the thermal fluid. This is the only way to ensure trouble-free operation.

Note that the volume expansion of the thermal fluid depends on the working temperature range you wish to work in. At the "lowest" working temperature, do not go beyond the **minimum** mark of the **>Level indicator and drain<** [38] and at the "highest" working temperature there should be no overflow at the **>Level indicator and drain<** [38]. Fill the temperature control unit up to about 1 cm below the hose end. In case of overfilling, drain the excess amount of thermal fluid (see page 45 in Section **»Draining with >Level indicator and drain<** [38]«). Check if the thermal fluid can be reused. On page 15 observe Section **»Proper disposal of resources and consumables**«.

# 4.2.2 Draining externally closed applications



#### Hot or very cold thermal fluid

#### SERIOUS BURNS/FREEZING OF LIMBS

- > Before draining, ensure that the thermal fluid has room temperature (20 °C).
- > If, at this temperature, the thermal fluid is too viscous to be drained: Control the temperature of the thermal fluid for a few minutes until the viscosity will allow drainage. Never control the temperature of the thermal fluid when the Drain is open.
- > Danger of burns when draining thermal fluids at temperatures above 20 °C.
- Wear your personal protective equipment when carrying out the drain operation.
- Only drain with a suitable draining hose and container. These must be resistant to the thermal fluid and the temperature.

#### 4.2.2.1 Draining with >Sight glass< [23]

# **PROCEDURE**

#### Temperature control units without >Emptying of residues< [10]

- > Have a suitable container ready to catch the thermal fluid.
- Remove the knurled screw at the >Drain< [8]. As soon as you have opened the knurled screw, the thermal fluid will flow from the external application over the temperature control unit and into the container. Check if the thermal fluid can be reused. On page 15 observe Section »Proper disposal of resources and consumables«.</p>
- Wait until the external application and the temperature control unit are empty.
- > Open the connection >Circulation flow< [1].
- > Open the connection >Circulation return< [2].
- Leave the temperature control unit open for a while to allow it to dry out and the residue to drain.
- Close the connection >Circulation flow< [1].</p>
- Close the connection >Circulation return< [2].</p>
- Re-fit the knurled screw to the >Drain< [8].</p>
  The temperature control unit is now drained.

# **PROCEDURE**

#### Temperature control units with >Emptying of residues< [10]

- > Have a suitable container ready to catch the thermal fluid.
- Remove the knurled screw at the >Drain< [8]. As soon as you have opened the knurled screw, the thermal fluid will flow from the external application over the temperature control unit and into the container. Check if the thermal fluid can be reused. On page 15 observe Section »Proper disposal of resources and consumables«.</p>
- Wait until no more thermal fluid flows from the >Drain< [8].
- Remove the knurled screw from the >Emptying of residues< [10]. The remaining thermal fluid will flow from the temperature control unit into the container as soon as you have opened the knurled screw. Check if the thermal fluid can be reused. On page 15 observe Section »Proper disposal of resources and consumables«.</p>
- > Wait until the temperature control unit is empty.
- Open the connection >Circulation flow< [1].</p>
- Open the connection >Circulation return< [2].</p>
- Leave the temperature control unit open for a while to allow it to dry out and the residue to drain.
- > Close the connection > Circulation flow < [1].
- Close the connection >Circulation return< [2].</p>
- Re-fit the knurled screw to the >Emptying of residues< [10].</p>
- Re-fit the knurled screw to the >Drain< [8].</p>
  The temperature control unit is now drained.



Chapter 4 OPERATION MANUAL

#### 4.2.2.2 Draining with >Level indicator and drain< [38]

# **PROCEDURE**

- > Have a suitable container ready to catch the thermal fluid.
- > Pull the hose from the >Level indicator and drain< [38]. As soon as you have pulled out the hose, the thermal fluid will flow from the external application over the temperature control unit and into the container. Check if the thermal fluid can be reused. On page 15 observe Section »Proper disposal of resources and consumables«.
- Wait until the external application and the temperature control unit are empty.
- > Open the connection >Circulation flow< [1].
- > Open the connection >Circulation return< [2].
- > Leave the temperature control unit open for a while to allow it to dry out and the residue to drain.
- > Close the connection > Circulation flow < [1].
- > Close the connection >Circulation return< [2].
- Reinsert the hose into the >Level indicator and drain< [38].</p>
  The temperature control unit is now drained.



# 5 Normal operation

# 5.1 Automatic operation



# Extremely hot / cold surfaces, connections and thermal fluids BURNS/FREEZING OF LIMBS

- > Surfaces, connections and tempered thermal fluids can be extremely hot or cold depending on the operating mode.
- ➤ Avoid direct contact with surfaces, connections and thermal fluids!
- Wear your personnel protective equipment (e.g. temperature-resistant safety gloves, safety goggles).

#### NOTE

# During an active circulation, the thermal fluid circuit is shut off by shut-off valves

# MATERIAL DAMAGE TO THE CIRCULATING PUMPS INSTALLED IN THE TEMPERATURE CONTROL LINIT

- > Do not close the thermal fluid circuit during an active circulation by means of shut-off valves.
- Warm the thermal fluid to room temperature before stopping the circulation.

# 5.1.1 Temperature control

#### 5.1.1.1 Starting the temperature control process

The temperature control process can be started after filling and complete venting.

# **PROCEDURE**

With the temperature control unit switched on and thermoregulation/circulation stopped, press the >Start/Stop button< [F].</li>
 Thermoregulation starts.

#### 5.1.1.2 Ending the temperature control process

# NOTE

When the temperature control unit is switched off, the thermal fluid temperature is higher/lower than room temperature

# DAMAGE TO THE TEMPERATURE CONTROL UNIT AND THE GLASS APPARATUS/APPLICATION

- > Bring the thermal fluid up to room temperature using the temperature control unit.
- > Do not close the shut-off valves in the thermal fluid circuit.

Thermoregulation can be terminated at any time. Thermoregulation and circulation are switched off immediately afterwards.

# **PROCEDURE**

 With the temperature control unit switched on and thermoregulation/circulation started, press the >Start/Stop button< [E].</li>
 Thermoregulation stops.



# 6 Interfaces and data communication

NOTE


The specifications of the interface used are not being met.

#### **PROPERTY DAMAGE**

> Only connect components that meet the specifications of the interface used.

# 6.1 Controller interfaces

Standard interfaces on the OLÉ controller



#### 6.1.1 USB-2.0 interface

#### **INFORMATION**

The interfaces used must meet the specifications of the generally accepted standards. The necessary drivers for the interface can be found at: www.ftdichip.com/Drivers/VCP.htm

#### 6.1.1.1 USB-2.0 interface, device



USB-2.0 connection (for Mini-B connector) for communicating with a computer.

# 6.1.2 RS232 jack



A PC, a SPS or a Process Control System (PCS) can be connected to this jack for remote control of the controller electronics. Before plugging in the cable, check the settings in the "Interfaces" category and adjust if necessary.

## **INFORMATION**

The interfaces used must meet the specifications of the generally accepted standards.

Pin assignment (front view)



Pin assignment

nt	Pin	Signal	Description
	2	RxD	Receive Data
	3	TxD	Transmit Data
	5	GND	Signal GND

# 6.2 Interfaces on the temperature control unit (optional)

## NOTE

Connecting to the interfaces at the temperature control unit during operation DAMAGE TO THE INTERFACES

- When devices in operation are connected with interfaces of the temperature control unit, interfaces may get damaged.
- > Before connecting, ensure the temperature control unit and the device to be connected are turned off.

For the exact position of the interfaces, please refer to the "wiring diagram" from page 68 in Section "Annex".

# 6.2.1 RS232 jack




A PC, a SPS or a Process Control System (PCS) can be connected to this jack for remote control of the controller electronics.



The interfaces used must meet the specifications of the generally accepted standards.

Pin assignment (front view)



#### Pin assignment

Pin	Signal	Description
2	RxD	Receive Data
3	TxD	Transmit Data
5	GND	Signal GND

# 6.2.2 Connection jack for Pt100 process display sensor




A temperature sensor located in the connected application (Pt100, 4-wire technology, Lemosa connector) is connected to the Pt100 port. It records and displays the external actual temperature.

# **INFORMATION**

Only use  ${\it shielded}$  sensor cables. We recommend the external Pt100 process sensor from the Huber accessories program.

Pin assignment (front view)



## Pin assignment

t	Pin	Signal	
	1	I+	Pt100
	2	U+	Pin 1: I+ Pin 4: I–
	3	U-	 Pin 2: U+
	4	I-	

# 6.2.3 Jack ECS (External Control Signal) standby

Enable signal ECS (external control signal) for starting/stopping the temperature control process.



Activation via a potential-free contact. Contacts 1 and 3 are internally bypassed. **ECS** is energized when E1 and E2 are connected by an external floating contact. Contact specification: min.  $0.1\,\text{A}$  / 24 V DC.

The functionality of the **ECS** is specified in the "Interfaces" menu item.

#### The following variants are offered:

- "Off": Switching the contacts open/closed or closed/open has no effect.
- "Setpoint2": An open contact causes a thermoregulation to its original "Setpoint1". A closed contact causes a thermoregulation to "Setpoint2".
- "Stand-by": The temperature control process starts when switching from an open to a closed contact. The temperature control process switches off when switching from a closed to an open contact.

Minichiller® OLÉ, Unichiller® OLÉ V1.3.0en/22.01.19//1.0.0



Chapter 6 OPERATION MANUAL

# **INFORMATION**

The interface is specified as a digital input. Do not apply voltage or current.

Pin assignment (front



Pin assignment

t	Pin	Signal
	1.3	E2
	2	E1

#### 6.2.4 Connector POKO (floating contact) alarm

Signal contact for external monitoring.



The floating contact (PoKo) signals the state of the temperature control unit via the contact positions. A closed normally open contact means readiness for operation. If a fault or an error occurs, the normally open contact is opened (this applies to the make contact between pin 1 and pin 2).

#### The following settings are offered:

- "Off":POKO is without function.
- "Alarm": The POKO relay becomes active (OK state) in this function only, if the temperature control unit is switched on and is in "Fault" mode.
- "Unipump/PCS": This POKO function and the enable contact of the pump guarantee that the external pump runs synchronously with the pump in the temperature control unit if an external pressure booster pump is used in your temperature control circuit / cooling water circuit, i.e. the POKO assumes the OK state as soon as the internal pump is started up.

PCS:The POKO is used to communicate the state of the temperature control unit to the process


POKO condition **ON** means the pump is running.

POKO condition OFF means the pump is not running, the temperature control unit is in stand-by mode.

#### **INFORMATION**

With the floating contact, use only sheathed lines! The interface is specified as a digital output.

Pin assignment (front view)



The connection is designed as a potential-free changeover contact.

Closing contact between pin 1 and pin 2.

Opening contact between pin 2 and pin 3.

Contact load: 1 A at 24 V DC.

Minichiller® OLÉ, Unichiller® OLÉ V1.3.0en/22.01.19//1.0.0

# 6.3 Data communication

The communication via the RS232 interface is a master-slave communication. The Master (e.g. PC or PLC) starts a communication and the slave (the temperature control unit) will only respond to a request.

#### **Transmission format:**

8 data bits, 1 stop bit, no parity, no handshake

These parameters are non-adjustable and cannot be changed! The baud rate can be set in a range from 9600 baud to 115200 baud.

#### Time response (timing):

The data flow of a command must not be interrupted. Pauses of more than 100 ms between the characters of a command result in the receiver aborting the incoming command. The temperature control unit will always send a response for a correctly received command. The next command can be sent once a complete response was received. The typical response time is less than 300 ms.

#### **INFORMATION**

You need the software "SpyControl" to transmit commands. The software can be downloaded from the download area of www.huber-online.com.

#### 6.3.1 LAI commands

There are 3 commands to communicate LAI commands to the temperature control unit:

- 1. "V" (Verify) to query the device ID,
- 2. "L" (limit) to guery the device limits,
- 3. "G" (General) to control and query the temperature control unit.

The send commands always begin with "[M01", answers always with "[S01", followed by the command qualifier "V" (Verify), "L" (Limits) or "G" (General). The next two bytes specify the length or the response of the command. A check sum is transmitted to increase data safety. The checksum is the 1 byte sum of all hex values from the start character to the last character before the checksum. It is appended to the end of the command or the response and then finished off with the end character CR ("\r", 0Dh).

Structure of a send command

Byte	Command	Response	Description
1 Byte	[	[	Start character, fix
2 Byte	М	С	Identification of the transmitter (M = Master, S = Slave)
3 bytes	0	0	Slave address, fix
4 bytes	1	1	Slave address, fix
5 bytes	V/L/G	V/L/G	Command qualifier (V = Verify, L = Limit, G = General)
6 bytes	0	1	Length of command / response (example)
7 bytes	7	4	Length of command / response (example)
n Bytes	х	х	If applicable, content; the number of bytes depends on the command
I-2 byte	С	С	Checksum (example)
I-1 byte	6	1	Checksum (example)
I byte	\r	\r	End-of-text character CR

Minichiller® OLÉ, Unichiller® OLÉ V1.3.0en/22.01.19//1.0.0



Chapter 6 OPEF

## 6.3.1.1 Command "V" (Verify)

This command is provided to check the presence of a slave and query its ID.

# Command structure "V" (Verify)

Byt	е	ASCII	Hex	Description
Ma	Master sends: [M01V07C6\r		C6\r	
1. B	yte	[	5Bh	Start character
2. E	yte	М	4Dh	Master ID
3. E	yte	0	30h	Slave address
4. B	yte	1	31h	Slave address
5. B	yte	V	56h	Command qualifier
6. B	yte	0	30h	Length of data field (0)
7. B	yte	7	37h	Length of data field (7)
8. E	yte	С	43h	Checksum
9. E	yte	6	36h	Checksum
10.	Byte	\r	0Dh	End character CR

The checksum is formed from bytes 1 to 7:

5Bh + 4Dh + 30h + 31h + 56h + 30h + 37h = 1C6h = 1 byte sum = C6h

The hex value C6h is appended as two ASCII characters "C" (43h) and "6" (36h).

The slave responds: [S01V14Huber ControlC1\r

The 13 bytes of the data set "Huber Control" plus the 7 bytes in front of the data set result in a data field length of 20 bytes = 14h bytes.

# 6.3.1.2 Command "L" (Limit)

This command is used to query the setpoint limits.

# Command structure "L" (Limit)

Byte	ASCII	Hex	Description	
Master se	Master sends: [M01L0F******1B\r			
The slave responds: [S01L17F4484E20F4484E2045\r				

A response always includes four limit values (starting from the eighth byte):

- 1. Lower setpoint limit (4 bytes),
- 2. upper setpoint limits (4 bytes),
- 3. lower working range limit (4 bytes),
- upper working range limit (4 bytes).

The working range limits are device-specific and cannot be changed. The lower setpoint limit can not be lower than the lower working range limit and the upper setpoint limit can not exceed the upper working range limit.

The two bytes before the last byte contain the checksum and the last byte of the response contains the end character (CR).

Each of the four values is expressed as a hex value. The values are signed, where 1 bit corresponds to 0.01 K. Thus a number range from 0000h to 7FFFh, i.e. from 0.00 °C to 327.67 C°, can be represented. Negative numbers are represented from FFFFh to 8000h, i.e. from -0.01 °C to -327.66 °C. Thus the four individual ASCII characters "F448" correspond to a 16-bit hex value of F448h and thus a temperature of -30 °C (also see on page 52 Section "Command "G" (General)«).

# 6.3.1.3 Command "G" (General)

This command transmits the most important temperatures and status information in a cycle. A modified setpoint is not stored in the permanent memory, i.e. this value is lost when switching off the machine.

Structure Command "G" (General)

Byte	ASCII	Hex	Description
Master se	Waster sends: [M01G0Dsatttppr		·
1. Byte	[	5Bh	Start character
2. Byte	М	4Dh	Master ID
3. Byte	0	30h	Slave address
4. Byte	1	31h	Slave address
5. Byte	G	47h	Command qualifier
6. Byte	0	30h	Length of the command: 0Dh = 13 bytes (number of bytes without
7. Byte	D	44h	checksum and end character)
8. Byte	s: C/I/O/*	43h / 49h / 4Fh / 2Ah	Temperature control mode  Meaning of the characters in the send string:  "C" (43h) = Circulation, switch circulation on;  "I" (49h) = Turn internal temperature control on;  "O" (4Fh) = Off, turn temperature control off;  "*" (2 Ah) = Do not change the current state.
9. Byte	a: 0/1/*	30h / 31h / 2Ah	Alarm acknowledgment Meaning of the characters in the send string: "0" (30h) = No alarm acknowledgment; "1" (31h) = Any pending alarm tone is acknowledged; "*" (2 Ah) = Do not change the current state.
10. Byte	t		Query or set the setpoint
11. Byte	t		Meaning of the characters in the send string: Setpoint with 16-bit resolution (2 bytes, thus 4 ASCII characters)
12. Byte	t	tttt /	"tttt" = 0000h (0.00 °C) to 7FFFh (327.67 °C) FFFFh (-0.01 °C) to 8000h (-327.68 °C)
13. Byte	t	****	0190h corresponds to +4 °C, (30h, 31h, 39h, 30h)  FE70h corresponds to -4 °C (46h, 45h, 37h, 30h)  "****" (2Ah, 2Ah, 2Ah) = no change to the setpoint, setpoint is only queried
14. Byte	р	Checksum	Checksum
15. Byte	р	Checksum	It is generated from bytes 1 to 13.
16. Byte	\r	0Dh	End character CR
The slave	responds: [S01	G15sattttiiiieee	eepp\r
1. Byte	[	5Bh	Start character
2. Byte	С	53h	Slave ID
3. Byte	0	30h	Slave address
4. Byte	1	31h	Slave address
5. Byte	G	47h	Command qualifier
6. Byte	1	31h	Length of response: 15h = 21 Bytes
7. Byte	5	35h	25.50. 5. 16990136. 251. 22 57665
8. Byte	s: C/I/O	43h / 49h / 4Fh	Temperature control mode  Meaning of the characters in the response string:  "C" (43h) = Circulation, circulation is on;  "I" (49h) = Internal temperature control is on;  "O" (4Fh) = Off, temperature control is off.

Minichiller® OLÉ, Unichiller® OLÉ V1.3.0en/22.01.19//1.0.0



Chapter 6 OPERATION MANUAL

Byte	ASCII	Hex	Description	
9. Byte	a: 0/1	30h / 31h	Alarm status Meaning of the characters in the response string: "0" (30h) = No alarm; "1" (31h) = Any number other than "0" is an alarm	
10. Byte	t		Query or set the setpoint	
11. Byte	t		Meaning of the characters in the send string: Setpoint with 16-bit resolution (2 bytes, thus 4 ASCII characters)	
12. Byte	t	tttt /	"tttt" = 0000h (0.00 °C) to 7FFFh (327.67 °C) FFFFh (-0.01 °C) to 8000h (-327.68 °C)	
13. Byte	t	****	0190h corresponds to +4 °C, (30h, 31h, 39h, 30h)  FE70h corresponds to -4 °C (46h, 45h, 37h, 30h)  "****" (2Ah, 2Ah, 2Ah) = no change to the setpoint, setpoint is only queried	
14. Byte	i			
15. Byte	i		Internal actual value	
16. Byte	i	iiii	Same format as setpoint	
17. Byte	i			
18. Byte	е			
19. Byte	е		External actual value	
20. Byte	е	eeee	Same format as setpoint, depends on device configuration	
21. Byte	е			
22. Byte	р	Checksum	Checksum	
23. Byte	р	Checksum	It is generated from bytes 1 to 21.	
24. Byte	\r	0Dh	End character CR	

# Example:

The temperature control mode and the alarm status should remain unchanged (each "\*") and a setpoint of -4.00 °C (FE70) is to be set.

The master sends: [M01G0D\*\*FE700A\r

The slave responds (for example): [S01G15O0FE7009A4C504E7\r

The temperature control unit is turned off ("O"), there is no alarm ("0"), the setpoint of -4.00 °C was set (FE70), the actual value is 24.68 °C (09A4), "C504" corresponds to -151.00 °C and indicates that no external temperature sensor is installed or connected.

# 6.3.2 PP commands

There is another set of commands to make the communication with the temperature control unit easy. The PP commands can be used, e.g. in conjunction with simple terminal programs. The calculation of a checksum has therefore been omitted and the commands kept very simple. Each command is terminated with Carriage Return ('\r', ODh) and Linefeed ('\n', OAh). There are read and write commands. Each correct command causes a response from the temperature control unit. Temperature and setpoint values are represented by a five-digit number, which corresponds to the temperature being expressed in hundredths of a degree (without decimal point).



Available read commands

Function	Master sends	Slave responds	Description
Read the set- point	SP?\r\n	SP +02500\r\n	The setpoint is set to 25.00 °C.
Read the inter- nal actual value	TI?\r\n	TI +02499\r\n	Currently, the internal actual value is 24.99 °C.
Read the exter-	TE?\r\n	TE +02499\r\n	Currently, the external actual value is 24.99 °C.
nal actual value		TE -15100\r\n	An external sensor is not connected or does not exist.
Read the tem-	CA?\r\n	CA +00000\r\n	Temperature control and circulation are inactive.
perature control mode		CA +00001\r\n	Temperature control and circulation are active.

Available write com-

Function	Master sends	Slave responds	Description
Setting the setpoint	SP@ -01234\r\n	SP -01234\r\n	The setpoint is set to -12.34 °C.
Starting the temperature control unit	CA@ 00001\r\n	CA +00001\r\n	The temperature control process is started.
Stopping the temperature control unit	CA@ 00000\r\n	CA +00000\r\n	The temperature control process is stopped.

Minichiller® OLÉ, Unichiller® OLÉ V1.3.0en/22.01.19//1.0.0



# **7** Service/maintenance

# 7.1 Displays in the event of faults

An alarm signal (xx Hz) is sounded in the event of a fault and the temperature control unit displays an alarm or warning message on the OLED display.

Overview	of
messag	es

Code	Cause	Effect, measure		
001	Overtemperature alarm The internal temperature is above the set value of the overtemperature protection. The overtemperature protection was triggered.	The internal temperature of the thermal fluid is in the upper allowable extreme range. The temperature control unit can be turned on again only when the temperature of the thermal fluid has returned to normal parameters. Check whether the thermal fluid used matches your required parameters if overtemperatures repeatedly shut down the unit.		
002	Tmax exceeded The internal temperature is above the set setpoint limit.	The internal temperature of the thermal fluid is above the setpoint limit set in the controller. Control continues.		
003	Tmin undercut The internal temperature is below the set setpoint limit.	The internal temperature of the thermal fluid is below the setpoint limit set in the controller. Control continues.		
004	Error float test	Check the thermal fluid level. KISS: Is the float blocked or sticky? Please contact Customer Support if the thermal fluid level is sufficient and the float of the KISS controller moves freely.		
005	Low-level alarm No enable signal, level alarm	Control is inactive. (Pump off, compressor off, heating off) Check the fill level of the thermal fluid. Restart impossible until the thermal fluid level is OK.		
006	Overpressure cutout triggered The pressure in the condenser is too high. The overpressure cutout (pressure switch) has triggered.	Temperature and pressure increase in the condenser. An overpressure cutout (pressure switch) is installed to protect the temperature control unit against excessive pressure.  Water cooling: a.) Is the cooling water supply correctly connected? b.) Is the suction strainer (dirt trap) clogged? c.) What is the cooling water temperature, the cooling water flow rate and the cooling water pressure?		
		Air cooling: a.) Is the heat exchanger or the grille dirty? b.) Does the fan turn if the cooling machine is switched on? If the fan does not turn: Contact Customer Support.		
009 011	Sensor F1 short Sensor F2 short Short-circuit at the internal temperature sensor F1 or at the external temperature sensor F2.	Control is inactive. (Pump off, compressor off, heating off) Check the sensor.		
010 012	Sensor F1 open Sensor F2 open The internal temperature sensor F1 or the external temperature sensor F2 is open.	Control is inactive. (Pump off, compressor off, heating off) Check the sensor.		
033	Error EPO (Flash)			
034	Error EP1 (EEPROM)			
035	Error EP2 (NVRAM)	Please contact Customer Support.		
036	Synchronization			

Code	Cause	Effect, measure
037	Parameters not equal	
038	Invalid status	
039	Error safety chip	
042	Pump protection activated The pump motor is overheated.	Check the ambient conditions. Check the viscosity of the thermal fluid. Turn the temperature control unit off and let it cool down.

# 7.2 Maintenance



# Cleaning/maintenance while the temperature control unit is operating MORTAL DANGER FROM ELECTRIC SHOCK

- > Stop an ongoing temperature control process.
- Turn off the temperature control unit.
- Also disconnect the temperature control unit from the power supply.

# NOTE

# Carrying out maintenance work not described in this operation manual DAMAGE TO THE TEMPERATURE CONTROL UNIT

- > For maintenance work not described in the operation manual, contact the Huber company.
- > Maintenance work not described in this operation manual is reserved for qualified specialists trained by Huber.
- > Only perform the following maintenance work on the temperature control unit yourself.

# 7.2.1 Function check and visual inspection

Inspection intervals

S	Cooling*	Description	Maintenance interval	Comment	Person re- sponsible
	A/W	Visually inspect hoses and hose connections	Prior to switching on the tempera- ture control unit	Exchange leaking hoses and hose connections prior to switching on the temperature control unit. See page 57, section »Replacing temperature control or coolant hoses«.	Operating company and/or operators
	A/W	Check the level in the collecting container at the >overflow< [12] (if installed)	Prior to switching on the tempera- ture control unit	Check the level in the collecting container. Empty as required. To dispose of thermal fluid, follow the instructions on page 15, section "Proper disposal of resources and consumables".	Responsible body and/or operators
	A/W	Inspection in ac- cordance with the F-Gas Directive	In accordance with the F-Gas Directive	See page 17, section »Temperature control units with fluorinated greenhouse ga- ses/refrigerants«	Operating company
	A/W	I inspect nower I on the tempera-		Do not start the temperature control unit if the power cable is damaged.	Qualified electrician (BGV A3)
	A	Clean air inlet grille	As required	Clean the perforated sheet of the temperature control unit with a damp cloth	Operating company
	A/W	Thermal fluid inspection	As required	_	Operating company and/or operators



Chapter 7 OPERATION MANUAL

Description	Maintenance interval	Comment	Person re- sponsible
Inspect the me- chanical seals	Monthly	See page 63, section »Inspect the mechanical seal«	Operating company and/or operators
Check liquefier fins	As required, after 3 months at the latest	See page 58, section »Clean lique- fier fins (air-cooled temperature control unit)«	Operating company and/or operators
Check suction strainer (dirt trap)	As required, after 3 months at the latest	See page 59, section »Clean hat- type strainer (dirt trap) (water- cooled temperature control unit)«	Operating company and/or operators
Overtemperature protection (OT) - functional check	Every month or after changing the thermal fluid	See page 39, section »Setting the overtemperature (OT) protection«	Operating company and/or operators
Inspect tempera- ture control unit for damage and stabil- ity	Every 12 months or after a change of location	-	Operating company and/or operators
Inspect cooling water quality	Every 12 months	Descale the cooling water circuit as required. Documentation on water quality available at: www.huber-online.com	Operating company and/or operators
	Inspect the mechanical seals  Check liquefier fins  Check suction strainer (dirt trap)  Overtemperature protection (OT) - functional check  Inspect temperature control unit for damage and stability  Inspect cooling	Inspect the mechanical seals  Check liquefier fins  Check suction strainer (dirt trap)  Overtemperature protection (OT) - functional check  Inspect temperature control unit for damage and stability  Inspect cooling  Inspect cooling  Inspect cooling  Inspect temperature protection (OT) - functional check  Inspect temperature control unit for damage and stability  Inspect cooling  Fivery 12 months	Inspect the mechanical seals  Monthly  See page 63, section »Inspect the mechanical seal«  As required, after 3 months at the latest  Check suction strainer (dirt trap)  As required, after 3 months at the latest  Check suction strainer (dirt trap)  As required, after 3 months at the latest  Check suction strainer (dirt trap)  As required, after 3 months at the latest  Check suction strainer (dirt trap)  Every month or after changing the thermal fluid  Inspect temperature control unit for damage and stability  Inspect cooling water quality  Every 12 months or after a change of location  Descale the cooling water circuit as required. Documentation on water quality available at:

# 7.2.2 Replacing temperature control or coolant hoses

Replace defective temperature control and/or coolant hoses **before** turning on the temperature control unit.

#### 7.2.2.1 Replacing temperature control hoses

# **PROCEDURE**

- Drain the temperature control unit as described on page 44 in section »Draining externally closed applications«.
- > Replace defective temperature control hoses. When disposing of them, observe page 15, section »Proper disposal of resources and consumables«.
- Reconnect your external application as described on page 30 in section »Connecting externally closed application«.
- Fill the temperature control unit with thermofluid as described on page 41 in section **»Filling and venting externally closed application«**.
- Vent the temperature control unit as described on page 41 in section »Filling and venting externally closed application«.
- > Restart the temperature control unit in normal mode.

## 7.2.2.2 Replacing coolant hoses

# **PROCEDURE**

- > Drain the cooling water as described on page 65 in section »Draining the cooling water«.
- Replace the defective coolant hoses. When disposing of them, observe page 15, section »Proper disposal of resources and consumables«.
- > Reconnect the temperature control unit to the building's cooling water supply. Proceed as described on page 27 in section **»Temperature control units with water cooling«**.
- Restart the temperature control unit in normal mode.

# 7.2.3 Clean liquefier fins (air-cooled temperature control unit)

# ! CAUTION

#### Manual cleaning

#### RISK OF BEING CUT ON THE LIQUEFIER FINS

- > Wear suitable cut-resistant gloves for cleaning work.
- Depending on the ambient conditions, use cleaning equipment such as vacuum cleaners and/or a hand brush/brush. Follow the local regulations when cleaning. Do not clean the liquefier fins in a clean room with items like a brush and do not use a vacuum cleaner without an extra-fine particle filter.

#### NOTE

#### Cleaning using pointed or sharp-edged tools

#### DAMAGE TO THE LIQUEFIER FINS

Clean the liquefier fins using suitable cleaning appliances.

#### **INFORMATION**

Make sure there is adequate ventilation (removal of waste heat, fresh air supply) for the temperature control unit, in case of air cooling, maintain wall clearance (see page 20, section »Exemplary illustrations of the cooling variants« and page 24, section »Ambient conditions«).

The liquefier fins must be cleaned (dust) from time to time as only then will the temperature control unit perform at its maximum cooling capacity.

Identify the position of the ventilation grille, usually located on the front. With some temperature control units, the ventilation grilles on the side wall, rear or on the underside (table units) of the temperature control unit.

# **PROCEDURE**

#### Ventilation grille on the front/rear or on a side wall

- > Turn off the temperature control unit.
- Disconnect the temperature control unit from the power supply.
- Remove the ventilation grille to create unhindered access to the liquefier fins.
- > Clean the liquefier fins using suitable cleaning appliances. Observe the local regulations and ambient conditions when selecting cleaning appliances.
- Make sure the liquefier fins are not damaged or deformed as this will impair the air flow.
- > Re-mount the ventilation grille after cleaning work.
- Connect the temperature control unit to the power supply.
- Turn on the temperature control unit.

# **PROCEDURE**

#### Ventilation grille on the underside (table-top units)

# NOTE

# Cleaning of liquefier fins at the underside when the temperature control unit is filled DAMAGE CAUSED BY THERMAL FLUID PENETRATING THE TEMPERATURE CONTROL UNIT

- Empty the temperature control unit before cleaning the liquefier fins at the underside of the temperature control unit.
- > Turn off the temperature control unit.
- Disconnect the temperature control unit from the power supply.
- > Drain the thermofluid from the temperature control unit. Additional information is provided on page 44 in the section »Draining externally closed applications«.
- > Tilt the temperature control unit to remove the grille (if available) in front of the liquefier fins.
- Clean the liquefier fins using suitable cleaning appliances. Observe the local regulations and ambient conditions when selecting cleaning appliances.
- Make sure the liquefier fins are not damaged or deformed as this will impair the air flow.
- > Re-mount the ventilation grille after cleaning work.
- Connect the temperature control unit to the power supply.
- Refill the temperature control unit with thermofluid. Additional information is provided on page 41 in the section »Filling and venting externally closed application«.

huber

Chapter 7 OPERATION MANUAL

# 7.2.4 Clean hat-type strainer (dirt trap) (water-cooled temperature control unit)

#### NOTE

#### Building side shut-off valves are not closed

#### DAMAGE BY ROOM FLOODING

- Close the building's shut-off valves in the cooling water supply and return lines.
- For table-top models, place a collection container below the >Cooling water drain< [15] (see connection diagram page 68, section »Annex«).</p>

#### **INFORMATION**

The strainer at the cooling water inlet must be inspected and cleaned on a regular basis, depending on water quality.

# **PROCEDURE**

#### Table-top models:

- > Turn off the temperature control unit.
- Disconnect the temperature control unit from the power supply.
- > Close the customer's shut-off valves in the cooling water supply and return lines.
- Place a collecting container below the **>Cooling water inlet<** [13].
- > Remove the cooling water supply line and take out the hat-type strainer for inspection and cleaning.
- Clean the suction strainer under running water.
- > Following inspection/cleaning, reinsert the hat-type strainer and fasten the cooling water supply line.
- Remove the collecting container from below the >Cooling water inlet< [13].</p>
- Open the customer's shut-off valves in the cooling water supply and return lines.
- Connect the temperature control unit to the power supply.
- > Turn on the temperature control unit.

# **PROCEDURE**

#### Free-standing models:

- > Turn off the temperature control unit.
- > Disconnect the temperature control unit from the power supply.
- Close the customer's shut-off valves in the cooling water supply and return lines.
- > Remove the panel around the **>Cooling water inlet<** [13] and **>Cooling water outlet<** [14]. Information: Located immediately behind the **>Cooling water inlet<** [13] is the dirt trap.
- Place a collecting container below the >Cooling water inlet< [13].</p>
- > Carefully detach the cover (hexagonal).
- > Remove and clean the metal strainer located below.
- Clean the metal strainer under running water.
- > Re-insert the metal strainer after cleaning work.
- > Carefully fasten the cover (hexagonal).
- > Remove the collecting container from below the >Cooling water inlet< [13].
- Re-mount the panel around the >Cooling water inlet< [13] and >Cooling water outlet< [14].
- Open the customer's shut-off valves in the cooling water supply and return lines.
- > Connect the temperature control unit to the power supply.
- > Turn on the temperature control unit.

# INFORMATION

We also provide service training. Please contact the Customer Support. The telephone number can be found on page 67, section **»Phone number and company address«**.

# 7.3 Thermal fluid inspection, replacement and circuit cleaning

The illustration "connection diagram" can be found on page 68 in section "Annex".

# **!** CAUTION

#### Extremely hot / cold surfaces, connections and thermal fluids

#### **BURNS/FREEZING OF LIMBS**

- > Surfaces, connections and tempered thermal fluids can be extremely hot or cold depending on the operating mode.
- Avoid direct contact with surfaces, connections and thermal fluids!
- Wear your personnel protective equipment (e.g. temperature-resistant safety gloves, safety goggles).

V1.3.0en/22.01.19//1.0.0

OPERATION MANUAL Chapter 7

#### NOTE

# During an active circulation, the thermal fluid circuit is shut off by shut-off valves MATERIAL DAMAGE TO THE CIRCULATING PUMPS INSTALLED IN THE TEMPERATURE CONTROL UNIT

- Do not close the thermal fluid circuit during an active circulation by means of shut-off valves.
- Warm the thermal fluid to room temperature before stopping the circulation.

#### 7.3.1 Thermal fluid replacement

#### NOTE

#### Mixing different thermofluids in a thermal fluid circuit

#### PROPERTY DAMAGE

- Do not mix different types of thermofluid (such as mineral oil, silicone oil, synthetic oil, water, etc.) in a thermofluid circuit.
- The thermal fluid circuit must be rinsed when changing from one type of thermal fluid to another. No residues of the previous type of thermal fluid may remain in the thermal fluid circuit.

#### 7.3.1.1 **Externally closed application**

To replace the thermal fluid, proceed as described from page 41 in Section »Filling and venting externally closed application«. The draining and filling operations are described in this section.

#### 7.3.2 Rinsing the thermal fluid circuit

# DANGER

# Setpoint and overtemperature protection are not adjusted to the thermofluid **MORTAL DANGER FROM FIRE**

- The cut-out value of the overtemperature protection must be adapted to the thermofluid. Set the cut-out value of the overtemperature protection 25 K below the combustion point of the
- The setpoint set during rinsing must be adjusted to the thermofluid used.



## Non-compliance with the safety data sheet for the thermal fluid to be used **INJURIES**

- Risk of injury to the eyes, skin, respiratory tract.
- The safety data sheet for the thermal fluid to be used must be read prior to using it and its content must be respected.
- Observe the local regulations/work instructions.
- Wear your personal protective equipment (e.g. temperature-resistant safety gloves, safety goggles, safety footwear).
- Danger of slipping because floor and work area are contaminated. Clean the work station and follow the instructions for the disposal of thermal fluid and material on page 15 in Section »Proper disposal of resources and consumables«.


#### NOTE

# Mixing different thermofluids in a thermal fluid circuit

#### PROPERTY DAMAGE

- Do not mix different types of thermofluid (such as mineral oil, silicone oil, synthetic oil, water, etc.) in a thermofluid circuit.
- The thermal fluid circuit must be rinsed when changing from one type of thermal fluid to another. No residues of the previous type of thermal fluid may remain in the thermal fluid circuit.

Example: Connecting a short circuit hose



The inner components of the temperature control unit must be dried out Need to avoid boiling retardation during future uses (e.g. use of a silicone oil at temperatures above about 100 °C).



huber

Chapter 7 OPERATION MANUAL

#### 7.3.2.1 Rinsing a thermofluid circuit with >Sight glass< [23]

# **PROCEDURE**

> Drain the temperature control unit as described on page 44 in section »Draining with >Sight glass< [23]«.

#### **INFORMATION**

Residual thermal fluid can remain in the pump chamber and the internal lines after draining. Leave the temperature control unit with open valves for a while.

- > Check the fill level in the collecting container. Follow the instructions on page 15, section »Proper disposal of resources and consumables« for the disposal of thermofluid.
- Re-fit the knurled screw to the >Emptying of residues< [10] (if present).</p>
- > Re-fit the knurled screw to the >Drain< [8].
- > Connect the >Circulation flow< [1] with the >Circulation return< [2] to the temperature control using a bypass hose.

#### INFORMATION

Perform the following steps without attaching a short circuit hose, if the application used by you (externally closed) is also dirty. In this case, leave your externally closed application connected to the temperature control unit. This rinses the temperature control unit and your application at the same time.

- > Fill the system (minimum fill level) with the thermal fluid you wish to use. The description can be found on page 42 in Section »Filling and venting with >Sight glass< [23]«.
- ➤ Vent the system as described on page 42 in Section »Filling and venting with >Sight glass< [23]«.
- Adjust the **setpoint** and the cut-out value of the **overtemperature protection** to the thermal fluid used. This procedure can be found on page 38 in Section **»Setting the setpoint**« and on page 39 in Section **»Setting the overtemperature (OT) protection**«.
- > Start the circulation. The length of rinsing depends on the level of soiling.
- > Stop the circulation.
- > Drain the thermal fluid from the system, using a suitable container (e.g. original canister, which is compatible with the thermal fluid). The description for draining can be found on page 44 in Section »Draining with >Sight glass< [23]«. Follow the instructions for the disposal of thermal fluid on page 15 in section »Proper disposal of resources and consumables«.
- Repeat the steps "Filling", "Venting", "Start/Stop circulation" and "Draining" until the drained thermal fluid remains clear.
- Remove the bypass hose.

#### **INFORMATION**

Leave an application connected, if you have simultaneously rinsed a used application (externally closed).

- Leave the >Drain< [8] and >Emptying of residues< [10] (if any) open for a while to allow the thermofluid to evaporate in the temperature control unit.
- Close the >Drain< [8] and >Emptying of residues< [10] (if any) once the thermofluid has evaporated.</p>
- Remove the collecting container. Follow the instructions on page 15, section »Proper disposal of resources and consumables« for the disposal of thermofluid.
- > Re-connect your application. (Only if you have rinsed the thermofluid circuit using a bypass hose.)
- Fill the temperature control unit with thermofluid as described on page 42 in section **»Filling and venting with >Sight glass< [23]**«.
- Vent the temperature control unit as described on page 42 in section »Filling and venting with >Sight glass< [23]«.</p>
- > Restart the temperature control unit in normal mode.

# 7.3.2.2 Rinsing the thermofluid circuit with >Level indicator and drain< [38]

# **PROCEDURE**

> Drain the temperature control unit as described on page 45 in section »Draining with >Level indicator and drain< [38]«.

#### **INFORMATION**

Residual thermal fluid can remain in the pump chamber and in the internal lines after draining. Therefore leave the temperature control unit open for a while.

- > Check the fill level in the collecting container. Follow the instructions on page 15, section \*Proper disposal of resources and consumables\* for the disposal of thermofluid.
- Reinsert the hose into the >Level indicator and drain< [38].</p>
- Connect the >Circulation flow< [1] with the >Circulation return< [2] to the temperature control using a bypass hose.</p>

#### **INFORMATION**

Perform the following steps without attaching a short circuit hose, if the application used by you (externally closed) is also dirty. In this case, leave your externally closed application connected to the temperature control unit. This rinses the temperature control unit and your application at the same time.

- > Fill the system (minimum fill level) with the thermal fluid you wish to use. The description can be found on page 43 in Section »Filling and venting with >Level indicator and drain< [38]«.
- Vent the system as described on page 43 in Section »Filling and venting with >Level indicator and drain< [38]«.</p>
- ➤ Adjust the **setpoint** and the cut-out value of the **overtemperature protection** to the thermal fluid used. This procedure can be found on page 38 in Section **»Setting the setpoint**« and on page 39 in Section **»Setting the overtemperature (OT) protection**«.
- > Start the circulation. The length of rinsing depends on the level of soiling.
- > Stop the circulation.
- > Drain the thermal fluid from the system, using a suitable container (e.g. original canister, which is compatible with the thermal fluid). The description for draining can be found on page 45 in Section »Draining with >Level indicator and drain< [38]«. Follow the instructions for the disposal of thermal fluid on page 15 in Section »Proper disposal of resources and consumables«.
- Repeat the steps "Filling", "Venting", "Start/Stop circulation" and "Draining" until the drained thermal fluid remains clear.
- Remove the bypass hose.

#### **INFORMATION**

Leave an application connected, if you have simultaneously rinsed a used application (externally closed).

- Leave the temperature control unit open for a longer while to allow the thermofluid remaining in the temperature control unit to evaporate.
- Reinsert the hose into the >Level indicator and drain< [38].</p>
- Remove the collecting container. Follow the instructions on page 15, section »Proper disposal of resources and consumables« for the disposal of thermofluid.
- Re-connect your application. (Only if you have rinsed the thermofluid circuit using a bypass hose.)
- > Fill the temperature control unit with thermofluid as described on page 43 in section »Filling and venting with >Level indicator and drain< [38]«.
- > Vent the temperature control unit as described on page 43 in section »Filling and venting with >Level indicator and drain< [38]«.
- Restart the temperature control unit in normal mode.

# 7.4 Cleaning the surfaces



# Extremely hot / cold surfaces, connections and thermal fluids

## **BURNS/FREEZING OF LIMBS**

- > Surfaces, connections and tempered thermal fluids can be extremely hot or cold depending on the operating mode.
- Avoid direct contact with surfaces, connections and thermal fluids!
- Wear your personnel protective equipment (e.g. temperature-resistant safety gloves, safety goggles).

#### NOTE

#### **Exposed plug contacts**

#### **DAMAGE CAUSED BY FLUID INGRESS**

- Protect unused plug contacts with the protective caps supplied.
- Clean surfaces only with a damp cloth.

A standard stainless steel cleaning agent is suitable for cleaning the stainless steel surfaces. Carefully clean painted surfaces (damp only) using a solution of sensitive-fabrics detergent. Follow the instructions on page 15, section **»Proper disposal of resources and consumables«** for the disposal of cleaning agents and material.



# 7.5 Inspect the mechanical seal

#### NOTE

No visual inspection of the mechanical seals

# MATERIAL DAMAGE IN THE TEMPERATURE CONTROL UNIT CAUSED BY LEAKING MECHANICAL SFALS

- Check the mechanical seals once a month.
- If case of leakage, stop the temperature control unit and contact Customer Support. The telephone number can be found on page 67, section »Phone number and company address«.

Expect drop formation at the mechanical seal when operating with thermal fluids that evaporate only very slowly, as mechanical seals are never absolutely tight. These drops must be removed if necessary (see page 56, section **»Function check and visual inspection«**). The tightness of the mechanical seal must be visually checked. In case of a leakage, more thermal fluid exits at the bottom of the temperature control unit. Follow the instructions on page 15, section **»Proper disposal of resources and consumables«** for the disposal of thermofluid.

# 7.6 Plug contacts

# NOTE

**Exposed plug contacts** 

#### DAMAGE CAUSED BY FLUID INGRESS

- Protect unused plug contacts with the protective caps supplied.
- Clean surfaces only with a damp cloth.

Protective caps are supplied for all plug contacts. Make sure that any plug contacts not required are protective with the caps.

# 7.7 Decontamination/repairs



Returning a not decontaminated temperature control unit for repair

# PHYSICAL INJURY AND PROPERTY DAMAGE CAUSED BY HAZARDOUS MATERIALS IN OR ON THE TEMPERATURE CONTROL UNIT

- > Carry out appropriate decontamination.
- > The decontamination process depends on the type and quantity of the materials used.
- > Consult the relevant safety data sheet.
- You will find a prepared return receipt at www.huber-online.com.

As the responsible body you are responsible for carrying out decontamination **before** third-party personnel come into contact with the temperature control unit / accessory. Decontamination must be carried out **before** the temperature control unit / accessory is returned for repair or inspection. Attach a clearly visible written notice stating that the temperature control unit / accessory has been decontaminated.

To simplify the process, we have prepared a form for you. This is available for download at www.huber-online.com.



# 8 Shutting down

# 8.1 Safety instructions and basic principles



Connection/adjustment to the power supply not carried out by an electrician and/or connection to a power socket without protective earth (PE)

#### MORTAL DANGER FROM ELECTRIC SHOCK

- ➤ Have the connection/adjustment to the power supply carried out by an electrician.
- Always connect the temperature control unit to safety sockets (PE).



#### Damaged power cable/power cable connection

#### MORTAL DANGER FROM ELECTRIC SHOCK

- Do not start up the temperature control unit.
- > Isolate the temperature control unit from the power supply.
- Have the power supply cable/power supply connection replaced and inspected by an electrician.
- Do not use a power cable that is longer than 3 m.



#### Risk of tipping due to unstable temperature control unit

#### SERIOUS INJURY AND PROPERTY DAMAGE

> Avoid risk of tipping due to unstable temperature control unit.



# Non-compliance with the safety data sheet for the thermal fluid to be used

#### **INJURIES**

- ➤ Risk of injury to the eyes, skin, respiratory tract.
- > The safety data sheet for the thermal fluid to be used must be read prior to using it and its content must be respected.
- > Observe the local regulations/work instructions.
- Wear your personal protective equipment (e.g. temperature-resistant safety gloves, safety goggles, safety footwear).
- Danger of slipping because floor and work area are contaminated. Clean the work station and follow the instructions for the disposal of thermal fluid and material on page 15 in Section »Proper disposal of resources and consumables«.



#### Hot or very cold thermal fluid

# **SERIOUS BURNS/FREEZING OF LIMBS**

- > Before draining, ensure that the thermal fluid has room temperature (20 °C).
- ➢ If, at this temperature, the thermal fluid is too viscous to be drained: Control the temperature of the thermal fluid for a few minutes until the viscosity will allow drainage. Never control the temperature of the thermal fluid when the Drain is open.
- Danger of burns when draining thermal fluids at temperatures above 20 °C.
- Wear your personal protective equipment when carrying out the drain operation.
- Only drain with a suitable draining hose and container. These must be resistant to the thermal fluid and the temperature.

# INFORMATION

All safety instructions are important and must be followed accordingly during working operations!

# 8.2 Switch-off

# **PROCEDURE**

- > Turn off the temperature control unit.
- Disconnect the temperature control unit from the power supply connection.

64



# 8.3 Draining the cooling water

#### **INFORMATION**

This section must be observed when using water-cooled temperature control units.

#### 8.3.1 Draining process



#### Pressurized cooling water connections

#### RISK OF INIURY

- Wear your personnel protective equipment (e.g. safety goggles).
- Carefully open the cooling water connection. Open slowly (1-2 signal edges) and drain the cooling water slowly.

## NOTE

#### The building's isolating valves are not closed

#### DAMAGE BY ROOM FLOODING

- Close the building's isolating valves in the cooling water supply and return lines.
- For table-top models, place a collection container below the >Cooling water outlet< [14] and/or >Cooling water drain< [15] (if any).</p>

# **PROCEDURE**

#### Temperature control units with >Cooling water drain< [15]

- > Close the building's isolating valves in the cooling water supply and return lines.
- Place a collecting container below the >Cooling water outlet< [14] and >Cooling water drain< [15].</p>
- Undo the screw cap on the >Cooling water drain< [15]. The cooling water will begin to drain out. Allow all the cooling water to drain out to prevent the risk of freezing during transport and storage!</p>

# **PROCEDURE**

#### Tempering without >Cooling water drain< [15]

- > Close the building's isolating valves in the cooling water supply and return lines.
- Place the collecting container below the >Cooling water outlet< [14].</p>
- > Open the >Cooling water outlet< [14]. The cooling water will begin to drain out. Allow all the cooling water to drain out to prevent the risk of freezing during transport and storage!

# 8.4 Packing

Use the original packaging wherever possible! Further information can be found on page 23 in section **»Unpacking«**.

# 8.5 Shipping

## NOTE

#### Temperature control unit transported in a horizontal position

#### DAMAGE TO THE COMPRESSOR

> Only transport the temperature control unit in an upright position.


# NOTE

# Temperature control unit transported incorrectly

# PROPERTY DAMAGE

- Do not transport by truck on the castors or feet.
- > Comply all requirements in this section to avoid damage to the temperature control unit.

Pallet with squared timber for freestanding units



Transport using the lugs, if fitted, on the top of the temperature control unit. Do not transport the temperature control unit alone and without aids.

- Always use the original packaging for transport.
- Always transport the temperature control unit upright on a pallet!
- Protect attachments from damage during transport!
- During transport, place the temperature control unit on squared timber to protect the castors/feet.
- Secure with tensioning belts/lashing straps rated for the weight concerned.
- Additionally secure (depending on model) with plastic film, cardboard and straps.

# 8.6 Disposal



# Uncontrolled or incorrect opening of the coolant circuit

# RISK OF INJURY AND ENVIRONMENTAL DAMAGE

- Work on the coolant circuit and disposal of the refrigerant must be carried out by approved refrigeration/air-conditioning system contractors.
- Also see page 17, section »Temperature control units with fluorinated greenhouse gases/refrigerants«.

#### NOTE

# Improper disposal

# **ENVIRONMENTAL DAMAGE**

- Spilled/leaked thermofluid must be disposed of immediately and properly. Follow the instructions on page 15, section »Proper disposal of resources and consumables« for the disposal of thermofluid and material.
- To avoid environmental damage, have "old" temperature control units disposed of exclusively by approved waste management companies (e.g. refrigeration and air conditioning companies).
- Also see page 17, section »Temperature control units with fluorinated greenhouse gases/refrigerants«.

Huber temperature control units and Huber accessories are made of high quality, recyclable materials. For example: Stainless steel 1.4301 / 1.4401 (V2A), copper, nickel, FKM, Perbunan, NBR, ceramic, carbon, Al-Oxid, red brass, brass, nickel-plated brass and silver solder. Proper recycling of the temperature control unit and accessories can actively help reduce CO<sub>2</sub> emissions in the production of these materials. Follow the laws and regulations of your jurisdiction when disposing material.

huber

Chapter 8 OPERATION MANUAL

# 8.7 Phone number and company address

# **INFORMATION**

Contact Customer Support **prior** to returning your temperature control unit. Have the serial number of your temperature control unit to hand. The serial number can be found on the rating plate on the temperature control unit.

# 8.7.1 Telephone number: Customer Support

Telephone: +49-781-9603-244

# 8.7.2 Telephone number: Sales

Telephone: +49-781-9603-123

# 8.7.3 Email address: Customer Support

Email: support@huber-online.com

# 8.7.4 Service/return address

Peter Huber Kältemaschinenbau AG Werner-von-Siemens-Straße 1 77656 Offenburg

# 8.8 Certificate of Compliance

Please read page 63, section »Decontamination/repairs«.



# 9 Annex

# Inspired by **temperature designed for you**

Peter Huber Kältemaschinenbau AG Werner-von-Siemens-Str. 1 77656 Offenburg / Germany

Telefon +49 (0)781 9603-0 Telefax +49 (0)781 57211

info@huber-online.com www.huber-online.com

Technischer Service: +49 (0)781 9603-244

-125°C ...+425°C

