

User manual for:

Manufacturer	Model
Tefcold	SE Range

Uploaded: Oct 2015

Interlevin Refrigeration Ltd
West Meadow Rise
Castle Donington
Derby
DE74 2HL

Sales: 01332 850090
Parts: 01332 850190
Service: 01332 850064
Email: trade.sales@interlevin.co.uk
Web: www.interlevin.co.uk

Model:

SE10-45, SE20-45, SE30-45, SE40-45



Brugsvejledning
Users manual

DK 5
UK 13

DK Indholdsfortegnelse

Vigtige instruktioner	3
Udpakning og opstilling	3
El-tilslutning	3
Opstart	3
Termostat	4
Afrimning	5
Lås	5
Vedligeholdelse	6
Service	6
Bortskaffelse	6
Parameter liste	11

UK Contents

Important safety instructions	7
Unpacking and installation	7
Electrical connection	7
Start-up of the cabinet	7
Thermostat	8
Defrosting	9
Lock	9
Maintenance and cleaning	10
Service	10
Disposal	10
Parameter list	11



Vigtige informationer

1. For at få det fulde udbytte af fryseren, bør De læse denne brugsvejledning igennem.
2. Det er brugers ansvar at anvende fryseren i henhold til instruktionerne.
3. Kontakt omgående forhandleren, såfremt der opstår fejl ved fryseren.
4. Fryseren bør anbringes i et tørt og tilstrækkeligt ventileret rum.
5. Fryseren bør ikke placeres i nærheden af varmekilder eller direkte sollys.
6. Bemærk at alle elektriske apparater kan medføre farer.
7. Opbevar ikke eksplosionsfarlige stoffer, f.eks. gas, benzin, æter og lignende.
8. Der er ikke brugt asbest eller CFC i konstruktionen.
9. Olien i kompressoren indeholder ikke PCB.

Udpakning og opstilling

Fryseren leveres emballeret, undersøg denne for skader inden udpakning.

El-tilslutning

Fryseren er beregnet for tilslutning til 220-240 V/50 Hz. Tilslutningen skal ske ved en stikkontakt, der bør være let tilgængelig.

Denne fryser skal ekstrabeskyttes ifølge stærkstrømsreglementet. Dette gælder også, selvom der er tale om udskiftning af en eksisterende fryser, der ikke har været ekstrabeskyttet. I bygninger opført før 1. april 1975 er ekstrabeskyttelsen i orden, hvis der er installeret HFI-afbryder, som beskytter den stikkontakt fryseren skal tilsluttes.

I begge disse tilfælde skal der, hvis stikkontakten er for trebenet stikprop, benyttes en trebenet stikprop, og lederen med grøn/gul isolation skal tilsluttes jordklemmen (mærket ⊕).

Hvis stikkontakten kun er for tobenet stikprop, benyttes en tobenet stikprop. Hvis brugeren selv monterer denne, skal lederen med grøn/gul isolation klippes af så tæt som muligt på det sted, hvor lederen går ind i stikproppen.

I alle andre tilfælde bør De lade en autoriseret el-installatør undersøge, hvordan De nemmest får ekstrabeskyttet fryseren. Hvis De ikke har ekstrabeskyttelse i bygningen i forvejen, anbefaler Elektricitetsrådet, at De lader el-installatøren opsætte en PFI- eller HPFI afbryder.

Opstart

Inden fryseren tages i brug, anbefales det at rengøre dette, se afsnit om vedligeholdelse.

Vigtigt !

Hvis fryseren har ligget ned under transport, vent 2 timer før opstart.

Termostat



Vis indstillet temperatur:



Tryk en gang på denne tast og display viser den indstillede temperatur, efter 5 sec. vender display tilbage til normal visning.

Indstil ny temperatur:



Tryk en denne tast i 3 sec. og display viser den indstillede temperatur.



Tryk på denne tast for at hæve den indstillede temperatur.



Tryk på denne tast for at sænke den indstillede temperatur.



Tryk på denne tast for at gemme den nye indstilling, display blinker med den nye værdi og vender derefter tilbage til normal visning.

Ændring af parametre:



+
Hold disse taster inde i 3 sek. for at få adgang til parameter-liste, display vil vise parameter-nummer. Gentag dette for at få adgang til alle parameterne.



Tryk på denne tast for at bladre op i parameterlisten.



Tryk på denne tast for at bladre ned i parameterlisten.



Tryk på denne tast for at vælge den parameter der skal ændres, display viser den aktuelle værdi. Brug pil-taster til at ændre og afslut med 'Set'.

Efter 15 sec. vil termostaten vende tilbage til normal visning.

Se parameter-oversigt fra side 11

Alarm koder:

P1 Blinkende i display, betyder at rum-føleren er defekt.

HA Blinkende i display, betyder at temperaturen er for høj.

LA Blinkende i display, betyder at temperaturen er for lav.

Afrimning


Det anbefales at fryseren afrimes hver 3 måned eller hvis rimlaget overskrider 5 mm.

Brug ALDRIG metal eller andre skarpe genstande til at skrabe de indvendige side da det kan skade fryseren.

1. Sluk fryseren.
2. Tøm fryseren.
3. Lad låget stå åbent.
4. Brug plastik-skraberen til at fjerne is fra inderbeholderen.
5. Fjern bundproppen og åben for afløb på fryserens bagside og placer en bakke under afløbet.
6. Rengør fryseren i mildt sæbevand og aftør grundigt.
7. Fryseren tilsluttes og er klar til brug.

Lås

Fryseren er forsynet med en lås i håndtaget.



Vedligeholdelse

Afbryd kølemøblet på stikkontakten.

Med passende mellemrum skal kølemøblet rengøres. Udvendig og indvendige rengøring foretages med svag sæbeopløsning og aftørres grundigt. Rustfrie overflader kan vedligeholdes med stålolie.

Rengøringsmidler må IKKE indeholde klor, klorforbindelser eller andre aggressive midler, da de kan forårsage tæring på overflader og på det indvendige kølesystem.

Ventilationsristen holdes bedst rent ved hjælp af en støvsuger og en stiv børste.

Der må ikke spules med vand ind i kompressorrummet, da der kan opstå kortslutninger og skader på de elektriske dele.

Service

Kølesystemet er et hermetisk lukket system og kræver ikke tilsyn, kun renholdelse.

Ved svigt i kølevirkningen, undersøg om årsagen er afbrydelse i stikkontakt eller sikringsgruppe.

Kan grunden til svigt ikke findes, må De henvende Dem til Deres leverandør. Ved al henvendelse bedes De oplyse skabets typenavn og serienummer. Disse oplysninger findes på typenummerskiltet placeret indvendigt i højre side.

Bortskaffelse

Når det udtjente kølemøbel skal bortskaffes, skal det ske på en miljømæssig forsvarlig måde. Vær opmærksom på reglerne for bortskaffelse. Der kan være særlige krav og betingelser, der skal overholdes.





Important safety instructions

1. To obtain full use of the cabinet, we recommend reading this instruction manual.
2. It is the user's responsibility to operate the appliance in accordance with the instructions given.
3. Contact your dealer immediately in case of any malfunctions.
4. Place the cabinet in a dry and ventilated place.
5. Keep the cabinet away from strongly heat-emitting sources and do not expose it to direct sunlight.
6. Always keep in mind that all electrical devices are sources of potential danger.
7. Do not store inflammable material such as thinner, gasoline etc. in the cabinet.
8. We declare that no asbestos nor any CFC are used in the construction.
9. The oil in the compressor does not contain PCB.

Unpacking and installation

Remove the wooden pallet and the packing. Stainless steel surfaces are supplied with a protection foil, which must be removed before installation

Electrical connecting

The cabinet operates on 230 V/50 Hz.

The wall socket should be easily accessible.

All earthing requirements stipulated by the local electricity authorities must be observed. The cabinet plug and wall socket should then give correct earthing. If in doubt, contact your local supplier or authorized electrician.

The flexible cord fitted to this appliance has three cores for use with a 3-pin 13-Amp or 3-pin 15-Amp plug. If a B.S. 1363 (13-Amp) fused plug is used, it should be fitted with a 13-Amp fuse.

The wires in this mains lead are coloured in accordance with the following code:
Green/Yellow: Earth, Blue: Neutral, Brown: Live.

The main electrical connections must be done by skilled electricians.

Start-up of the cabinet

Before use, we recommend that the cabinet is cleaned, see the section on maintenance and cleaning.

Important !

If the cabinet has been vertically placed during transport, please wait 2 hours before starting up the cabinet.

Thermostat



Display set temperature:



Press this key and the display will show the set temperature. Press the key again to return to normal reading.

Set new temperature:



Press this key for 3 sec. and the display shows the set temperature.



Press this key to increase the set temperature.



Press this key to lower the set temperature.



Press this key to save the new settings. The display will flash with the new value and will then return to normal reading.

Changing of parameters:



+

Press these keys continuously for 5 seconds to access the list of parameters. The display will show the number of the parameter and after 2 seconds the value.



Press this key to increase the value.



Press this key to lower the value.



Press this key to save the new settings. The display will flash with the new value and will then return to normal reading.

See table of parameters from page 11.

Alarm codes:

P1 Flashing in the display: indicates that the cabinet sensor is defective.
The cabinet will strive to keep the set temperature until it has been repaired.

HA Flashing in the display: indicates that the temperature is too high.

LA Flashing in the display: indicates that the temperature is too low.

Defrosting


We recommend defrosting the freezer every three month or if the layer of ice exceeds 5 mm.

Do never use metal or other sharp objects to scrape the internal sides as it can damage the freezer

1. Disconnect the freezer
2. Empty the freezer
3. Leave the freezer with the lid open
4. Use the plastic scraper to remove the ice from the inner liner
5. Remove the drain plug and open the drain on the back side of the freezer and place a tray under the drain
6. Clean the freezer with mild detergent and wipe thoroughly
7. Connect the freezer and it is ready for use.

Lock

The freezer is supplied with a lock in the handle



Maintenance and cleaning

Switch the freezer off at the socket.

The cabinet must be periodically cleaned. Clean the external and internal surfaces of the cabinet with a light soap solution and subsequently wipe dry. Stainless steel surfaces can be maintained using steel oil.

Do NOT use cleansers containing chlorine or other harsh cleansers, as these can damage the surfaces and the internal cooling system.

Clean the condenser and the compressor compartment using a vacuum cleaner and a stiff brush.

Do NOT hose the compressor compartment with water as this can cause short circuits and damage on the electrical parts.

Service

The cooling system is a hermetically sealed system and does not require supervision, only cleaning.

If the cabinet fails to cool, check if the reason is a power cut.

If you cannot locate the reason to the failure of the cabinet, please contact your supplier. Please inform model and serial number of the cabinet. You can find this information on the rating label which is placed inside the cabinet in the top right hand side.

Disposal

Disposal of the cabinet must take place in an environmentally correct way. Please note existing regulation on disposal. There may be special requirements and conditions which must be observed.



XR20C (SE-45 Series)

PAR.	DESCRIPTION	RANGE	DEFAULT	U.M.
Set	Set point	LS-US	-45	°C/°F
Hy	diFFerential. Relay compressor tripping differential. The compressor stops on reaching the Setpoint value, and restarts at temperature equal to the Setpoint plus the value of the differential.	0.1...25.0	2,0	°C/°F
LS	Lower SEt. Minimum possible setpoint value.	-55.0...HSE	-45	°C/°F
US	Higher SEt. Maximum possible setpoint value.	LSE...302	-5,0	°C/°F
Ot	CAlibration 1. Calibration 1. Positive or negative temperature value added to the value read by probe 1, based on "ot" parameter settings.	-9.9...9.9	0	°C/°F
P2P	Second probe presence: n=not present, y=present	n/y	N	flag
oE	CAlibration 2. Calibration 2. Positive or negative temperature value added to the value read by probe 2, based on "P2" parameter settings.	-9.9...9.9	0	°C/°F
odS	delay (at) On compressor. Delay time in activating the compressor relay after switch-on of instrument.	0...99	2	min
AC	Anti short cycle delay	0...50	5	Min
CON	On time (compressor). Compressor activation time in the event of faulty probe.	0...99	10	min
COF	OFF time (compressor). Compressor in disabled state time in the event of a faulty probe.	0...99	10	min
CF	Measurement units: °C=Celsius, °F=Fahrenheit	°C/°F	°C	°C/°F
rES	Resolution (only for °C): dE=decimal between -9.9 and 9,9; in=integer	dE-in	dE	flag
Lod	Default display: P1=thermostat probe, P2=evaporator probe, SP=Set point	P1,P2,SP	P1	flag
td	defrost type. Type of defrosting. El = electric defrost. in = reverse cycle defrost (hot gas)	EL/in	In	flag
dtE	Defrost termination temp.	-50...50	6	°C/°F
idF	defrost interval time. Interval between the start of two successive defrosting operations.	0...99	0	hours
MdF	Max length for defrost	0...99	0	min
dFd	Display during defrost: rt=real temp. it=start defrost temp., St=Set point, dF=label Df	Rt/it/SP/dF	St	flag
dAd	Max display delay after defrost	0...255	1	Min
dAF	Defrost delay after fast freezing	0...23	0	hours
ALc	Temperature alarm configuration: rE=relative to SET, Ab=absolute	rE/Ab	rE	Flag
ALU	Higher ALarm. Maximum temperature alarm. Temperature value. which if exceeded in an upward direction triggers the activation of the alarm signal.	AL...99	10	°C/°F
ALL	Lower ALarm. Minimum temperature alarm. Temperature value. which if exceeded in a downward direction, triggers the activation of the alarm signal.	-55...AU	-1	°C/°F
ALd	Temperature alarm delay	0...99	20	min
dAO	Exclusion of temperature alarm at startup.	0...23	1	hour
PbC	Kind of probe	Ptc/ntc	Ntc	flag