

## Operations Manual Item: C2000



**PLATEFUGE™**  
MICROPLATE MICROCENTRIFUGE

### Introduction:

Thank you for purchasing the PlateFuge™ MicroPlate Microcentrifuge. Please read this manual thoroughly prior to operating the instrument.

The PlateFuge is designed for low speed applications and quick spin downs of PCR plates and microtitre plates. An adapter carrier is also available for 0.2ml PCR strips and tubes.

### Installation:

Place the PlateFuge on a flat and level surface nearby an electrical outlet. It

should not be near a heat source or in direct sunlight.

### Operation:

- Attach the power cord and place the power switch into the on "I" position.
- Open the lid and load your samples into the included rotor. Always ensure a balanced load.

**NOTE:** The centrifuge should never be started with one plate or two plates that are not equally balanced. Additional information can be found in the following section of this manual, **"Loading the Rotor"**.

- Close the lid, the rotor quickly accelerates to the maximum speed of 2200 rpm. The plate carriers automatically swing out to a fully horizontal position, resulting in even spin downs that will be concentrated at the bottom of the plate wells.
- When the desired run time is completed, pull on the lid tab to open the lid, the rotor quickly brakes to a stop and the samples can be retrieved.



**NEVER Attempt:** to remove samples until the rotor has come to a complete stop.

### Specifications:

Speed: 2100 rpm / 400xg  
Capacity: 2 x PCR Plates (or microplates)  
192 x 0.2ml or 24 x PCR strips  
Dimensions: 9.2(W) x 10.2(D) x 7.75(H) in.  
23(W) x 26(D) x 19.7(H) cm  
Electrical: 120V or 230V, 50-60 Hz  
Max. Radius: 8.0cm

### Loading the Rotor:

To ensure safe operation and long life of the instrument, samples must always be loaded into the rotor in a balanced fashion.

Plates must always be loaded in the center of the carrier. When loading non-skirted plates, it is important to line up the wells of the plate with those shown on the plate carrier. Starting the centrifuge with the plates not properly centered will result in an unbalanced load and increased vibration.

### Example of properly balanced rotor:



### Example of improperly balanced rotor:



### Cleaning and Maintenance:

The centrifuge rotor can be removed for cleaning by using the included allen wrench to loosen the set screw. Once removed, the rotor can be cleaned

with isopropyl alcohol or can be sterilized in an autoclave at 121°C for 20 minutes.

**Service and Contact:**

In the event that service or technical support is required, please contact Benchmark Scientific by phone at 1-908-769-5555 or by email at [info@benchmarkscientific.com](mailto:info@benchmarkscientific.com).