

Operating Manual

APT.line™ VD

Vacuum Drying Ovens

with microprocessor program controller RD3

Model	Art. No.
VD 23 (E2.1)	9030-0029, 9130-0029
VD 23-UL (E2.1)	9030-0035, 9130-0035
VD 53 (E2.1)	9030-0030, 9130-0030
VD 53-UL (E2.1)	9030-0036, 9130-0036
VD 115 (E2.1)	9030-0031, 9130-0031
VD 115-UL (E2.1)	9030-0037, 9130-0037

BINDER GmbH

Address	Post office box 102 D-78502 Tuttlingen
Tel.	+49 7462 2005 0
Fax	+49 7462 2005 100
Internet	http://www.binder-world.com
E-mail	info@binder-world.com
Service Hotline	+49 7462 2005 555
Service Fax	+49 7462 2005 93 555
Service E-Mail	service@binder-world.com
Service Hotline USA	+1 866 885 9794 or +1 631 224 4340
Service Hotline Spain	+34 9492 677 23
Service Hotline Asia Pacific	+852 39070500 or +852 39070503
Service Hotline Russia and CIS	+7 495 98815 17

EC – Declaration of Conformity



EG – KONFORMITÄTSERKLÄRUNG EC - DECLARATION OF CONFORMITY CE - DECLARATION DE CONFORMITE

Anbieter / Supplier / Fournisseur: BINDER GmbH
Anschrift / Address / Adresse: Im Mittleren Ösch 5, D-78532 Tuttlingen
Produkt / Product / Produit: Vakuumtrockenschränke mit Programmregelung
Vacuum drying ovens with program control
Etuves de séchage à vide à régulation programmable
Typenbezeichnung / Type / Type: VD 23, VD 53, VD 115

**Die oben beschriebenen Produkte sind konform mit folgenden EG-Richtlinien:
The products described above are in conformity with the following EC guidelines:
Les produits décrits ci-dessus sont conformes aux directives CE suivantes:**

Niederspannungsrichtlinie 2006/95/EG	Richtlinie 2006/95/EG des Europäischen Parlaments und des Rates vom 12. Dezember 2006 zur Angleichung der Rechtsvorschriften der Mitgliedstaaten betreffend elektrische Betriebsmittel zur Verwendung innerhalb bestimmter Spannungsgrenzen
Low voltage directive 2006/95/EC	
Directive basse tension 2006/95/CE	Council Directive 2006/95/EC of 12 December 2006 on the harmonization of the laws of Member States relating to electrical equipment designed for use within certain voltage limits
	Directive 2006/95/CE du Parlement Européen et du Conseil du 12 décembre 2006 concernant le rapprochement des législations des États membres relatives au matériel électrique destiné à être employé dans certaines limites de tension
EMV-Richtlinie 2004/108/EG	Richtlinie 2004/108/EG des Europäischen Parlaments und des Rates vom 15. Dezember 2004 zur Angleichung der Rechtsvorschriften der Mitgliedstaaten über die elektromagnetische Verträglichkeit und zur Aufhebung der Richtlinie 89/336/EWG.
EMC Directive 2004/108/EC	
Directive CEM 2004/108/CE	Directive 2004/108/EC of the European Parliament and of the Council of 15 December 2004 on the approximation of the laws of the Member States relating to electromagnetic compatibility and repealing Directive 98/336/EEC.
	Directive 2004/108/CE du Parlement Européen et du Conseil du 15 décembre 2004 relative au rapprochement des législations des États membres concernant la compatibilité électromagnétique et abrogeant le directive 98/336/CEE.

**Die oben beschriebenen Produkte tragen entsprechend die Kennzeichnung CE.
The products described above, corresponding to this, bear the CE-mark.
Les produits décrits ci-dessus, en correspondance, portent l'indication CE.**

Die oben beschriebenen Produkte sind konform mit folgenden harmonisierten Normen:
The products described above are in conformity with the following harmonized standards:
Les produits décrits ci-dessus sont conformes aux normes harmonisées suivantes:

Sicherheit / safety / sécurité:

- | | |
|---------------------|--|
| EN 61010-1:2010 | <p>Sicherheitsbestimmungen für elektrische Mess-, Steuer-, Regel- und Laborgeräte – Teil 1: Allgemeine Anforderungen (DIN EN 61010-1:2002 + Berichtigung 1:2002 + Berichtigung 2:2004)</p> <p>Safety requirements for electrical equipment for measurement, control, and laboratory use – Part 1: General requirements (IEC 61010-1:2010, BS EN 61010-1:2010)</p> <p>Règles de sécurité pour appareils électriques de mesure, de régulation et de laboratoire – Partie 1: Prescriptions générales (CEI 61010-1:2010, NF EN 61010:2011)</p> |
| EN 61010-2-010:2003 | <p>Sicherheitsbestimmungen für elektrische Meß-, Steuer-, Regel- und Laborgeräte – Teil 2-010: Besondere Anforderungen an Laborgeräte für das Erhitzen von Stoffen (DIN EN 61010-2-010:2004)</p> <p>Safety requirements for electrical equipment for measurement, control, and laboratory use – Part 2-010: Particular requirements for laboratory equipment for the heating of materials (IEC 61010-2-10:2005, BS EN 61010-2-10:2003)</p> <p>Règles de sécurité pour appareils électriques de mesure, de régulation et de laboratoire – Partie 2-010 : Prescriptions particulières pour appareils de laboratoire utilisés pour l'échauffement des matières (CEI 61010-2-10:2003, NF EN 61010-2-10:2005)</p> |

EMV / EMC / CEM:

- | | |
|--|---|
| EN 61326-1:2006
+ Corr. 1:2008 + Corr. 2:2010 | <p>Elektrische Mess-, Steuer-, Regel- und Laborgeräte - EMV-Anforderungen - Teil 1: Allgemeine Anforderungen (DIN EN 61326-1:2006 + Berichtigung 1:2008 + Berichtigung 2:2011)</p> <p>Electrical equipment for measurement, control and laboratory use - EMC requirements - Part 1: General requirements (IEC 61326-1:2005 + Corr. 1:2008 + Corr. 2:2010, BS EN 61326-1:2006+ A1:2008)</p> <p>Matériel électrique de mesure, de commande et de laboratoire - Exigences relatives à la CEM - Partie 1: Exigences générales (CEI 61326-1:2005 + AC1:2008, NF EN 61326-1:2006 mod.)</p> |
| EN 61326-2-2:2006 | <p>Elektrische Mess-, Steuer-, Regel- und Laborgeräte – EMV-Anforderungen. Teil 2-2: Besondere Anforderungen - Prüfverordnung, Betriebsbedingungen und Leistungsmerkmale für ortsveränderliche Prüf-, Mess- und Überwachungsgeräte in Niederspannungs-Stromversorgungsnetzen. (DIN EN 61326-2-2:2006)</p> <p>Electrical equipment for measurement, control and laboratory use – EMC requirements. Part 2-2: Particular requirements - Test configurations, operational conditions and performance criteria for portable test, measuring and monitoring equipment used in low-voltage distribution systems. (IEC 61326-2-2:2005, BS EN 61326-2-2:2006)</p> <p>Matériel électrique de mesure, de commande et de laboratoire – Exigences relatives à la CEM. Partie 2-2: Exigences particulières - Configurations d'essai, conditions de fonctionnement et critères d'aptitude à la fonction des matériels portatifs d'essai, de mesure et de surveillance utilisés dans des systèmes de distribution basse tension. (CEI 61326-2-2:2005 + AC1:2007, NF EN 61326-2-2:2006)</p> |


D-78532 Tuttlingen, 03.08.2011

BINDER GmbH



P. M. Binder

Geschäftsführender Gesellschafter
Managing Director
Directeur général



Dr. H. von Both

Leiter F & E
Director R & D
Chef de service R&D

Product registration

Online Product Registration

Register your BINDER now!

www.binder-world.com/register

The registration is free and takes just a few seconds

Advantages:

- ▶ Short response times if service is needed
- ▶ Fair prices when relocating or installing equipment
- ▶ Calibration as required at no charge in case of recalls
- ▶ Free information on news, product upgrades and accessories

Easy registered in 3 steps:



1. List serial number here:

 -

2. Go online: www.binder-world.com/register

3. Register serial number

Contents

EC – Declaration of Conformity	2
Product registration	5
1. SAFETY	8
1.1 Legal considerations	8
1.2 Structure of the safety instructions	8
1.2.1 Signal word panel	8
1.2.2 Safety alert symbol	9
1.2.3 Pictograms	9
1.2.4 Word message panel structure	10
1.3 Localization / position of safety labels on the unit	10
1.4 Type plate	11
1.5 General safety instructions on installing and operating the vacuum drying oven	12
1.6 Intended use	14
2. DESCRIPTION OF THE EQUIPMENT	14
2.1 Overview of the equipment	15
2.2 VD 23 control panel	16
2.3 VD 53 / 115 control panel	16
2.4 Connections at the rear of the unit	17
3. COMPLETENESS OF DELIVERY, TRANSPORTATION, STORAGE, AND INSTALLATION	18
3.1 Unpacking, and checking equipment and completeness of delivery	18
3.2 Guidelines for safe lifting and transportation	19
3.3 Storage	19
3.4 Location of installation and ambient conditions	19
4. INSTALLATION AND CONNECTIONS	20
4.1 Vacuum expansion racks	20
4.2 Electrical connection	21
4.3 Vacuum connection	21
4.4 Inert gas connection	22
5. START UP	22
5.1 Settings at the RD3 program controller	22
5.2 General indications	24
6. FIXED VALUE ENTRY MODE	25
7. WEEK PROGRAM EDITOR	26
7.1 Program table template for Week program Editor	28
7.2 Programming example of the Week program editor	29
7.2.1 Desired time function	29
7.2.2 Proceeding overview	29
7.2.3 Proceeding in detail	30
8. PROGRAM EDITOR	35
8.1 Selecting between set-point ramp and set-point step	35
8.1.1 Programming with setting “Ramp” (default setting)	35
8.1.2 Programming with setting “step”	37
8.1.3 General notes on programming temperature transitions	38
8.2 Set-point entry for program operation	38
8.3 Program table template	41
8.4 Deleting a program section	42



9. PROGRAM START LEVEL.....	43
10. USER LEVEL	46
11. PERFORMANCE IN CASE OF FAILURES.....	52
11.1 Performance after power failure.....	52
11.2 Alarm messages	52
12. SAFETY DEVICE CLASS 2 (DIN 12880).....	52
13. REFERENCE MEASUREMENTS. CHECKING THE TEMPERATURE IN THE INNER CHAMBER	53
14. COMMISSIONING THE VACUUM	54
14.1 Evacuation	54
14.2 Breaking the vacuum (flooding)	55
14.3 Operation with inert gas	55
15. SWITCHING CONTACTS 24V DC VIA OPERATION LINES	55
16. OPTIONS.....	57
16.1 Connection kit VD (option)	57
16.2 Vacuum module empty (without pump) (option)	57
16.3 Vacuum module with chemical membrane pump VP 1.1 or VP 2.1 (option).....	59
16.4 Vacuum module with speed controlled chemical membrane pump VP 3.1 and vacuum controller (option)	61
16.5 Digital pressure display (option).....	63
16.6 Additional measuring channel for digital object temperature display with flexible Pt 100 temperature sensor (option)	63
16.7 Measuring access port vacuum 9 poles (option)	64
16.8 Communication software APT-COM™ 3 DataControlSystem (option)	65
16.9 Protocol printer (available via BINDER INDIVIDUAL customized solutions).....	65
17. MAINTENANCE, CLEANING, AND SERVICE	66
17.1 Maintenance intervals, service.....	66
17.2 Cleaning and decontamination	66
17.3 Sending the unit back to BINDER GmbH	67
18. DISPOSAL.....	68
18.1 Disposal of the transport packing	68
18.2 Decommissioning.....	68
18.3 Disposal of the unit in the Federal Republic of Germany	69
18.4 Disposal of the unit in the member states of the EC except for the Federal Republic of Germany .	70
18.5 Disposal of the unit in non-member states of the EC	71
19. TROUBLESHOOTING	72
20. TECHNICAL DESCRIPTION.....	73
20.1 Factory calibration and adjustment	73
20.2 VD technical Data	74
20.3 Equipment and Options	75
20.4 Spare parts.....	77
20.5 Dimensions VD 23	78
20.6 Dimensions VD 53	79
20.7 Dimensions VD 115	80
21. CONTAMINATION CLEARANCE CERTIFICATE	81

Dear customer,

For the correct operation of the program controlled vacuum drying oven VD, it is important that you read this operating manual completely and carefully and observe all instructions as indicated. Failure to read, understand and follow the instructions may result in personal injury. It can also lead to damage to the unit and/or poor equipment performance.

1. Safety

This operating manual is part of the components of delivery. Always keep it handy for reference. The device should only be operated by laboratory personnel especially trained for this purpose and familiar with all precautionary measures required for working in a laboratory. To avoid injuries and property damage observe the safety instructions of the operating manual.

	 WARNING
	<p>Failure to observe the safety instructions.</p> <p>Serious injuries and unit damage.</p> <ul style="list-style-type: none"> ➤ Observe the safety instructions in this operating manual. ➤ Carefully read the complete operating instructions of the VD vacuum drying oven.

1.1 Legal considerations

This operating manual is for informational purposes only. It contains information for installing, start-up, operation and maintenance of the product. Note: the contents and the product described are subject to change without notice.

Understanding and observing the instructions in this operating manual are prerequisites for hazard-free use and safety during operation and maintenance. In no event shall BINDER be held liable for any damages, direct or incidental arising out of or related to the use of this manual.

This operating manual cannot cover all conceivable applications. If you would like additional information, or if special problems arise that are not sufficiently addressed in this manual, please ask your dealer or contact us directly by phone at the number located on page one of this manual

Furthermore, we emphasize that the contents of this operating manual are not part of an earlier or existing agreement, description, or legal relationship, nor do they modify such a relationship. All obligations on the part of BINDER derive from the respective purchase contract, which also contains the entire and exclusively valid statement of warranty administration. The statements in this manual neither augment nor restrict the contractual warranty provisions.

Have repairs performed only by experts authorized by BINDER. Repaired units must comply with the quality standard specified by BINDER.

1.2 Structure of the safety instructions

In this operating manual, the following safety definitions and symbols indicate dangerous situations following the harmonization of ISO 3864-2 and ANSI Z535.6.

1.2.1 Signal word panel

Depending on the probability of serious consequences, potential dangers are identified with a signal word, the corresponding safety color, and if appropriate, the safety alert symbol.

 DANGER
<p>Indicates an imminently hazardous situation that, if not avoided, will result in death or serious (irreversible) injury.</p>



WARNING

Indicates a potentially hazardous situation which, if not avoided, could result in death or serious (irreversible) injury.



CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in moderate or minor (reversible) injury.

CAUTION

Indicates a potentially hazardous situation, which, if not avoided, may result in damage to the product and/or its functions or to property in its proximity.















1.2.2 Safety alert symbol






Use of the safety alert symbol indicates a **risk of injury**.

Observe all measures that are marked with the safety alert symbol in order to avoid death or injury.

1.2.3 Pictograms

Warning signs			
			
Electrical hazard	Hot surface	Explosive atmosphere	Stability hazard
			
Inhalation hazard	Pollution Hazard	Harmful substances	Biohazard
			
Lifting hazard			
Mandatory action signs			
			
Mandatory regulation	Read operating instructions	Disconnect the power plug	Lift with several persons
			
Environment protection			

Prohibition signs			
			
Do NOT touch	Do NOT spray with water		

	Information to be observed in order to ensure optimum function of the product.
---	--

1.2.4 Word message panel structure

Type / cause of hazard.



Possible consequences.

- Ø Instruction how to avoid the hazard: prohibition
- Instruction how to avoid the hazard: mandatory action

Observe all other notes and information not necessarily emphasized in the same way, in order to avoid disruptions that could result in direct or indirect injury or property damage.

1.3 Localization / position of safety labels on the unit

The following labels are located on the unit:

Pictograms (Warning signs)	Service label
 <p>Hot surface</p>	<div style="background-color: red; color: white; padding: 10px;"> <p>Service - Hotline</p> <p>International: + 49 (0) 7462 / 2005-555 USA Toll Free: + 1 866 885 9794 or: + 1 631 224 4340 Россия и СНГ: + 7 495 98815 17</p> <p>service@binder-world.com www.binder-world.com</p> <p></p> </div>





Figure 1: Position of labels on the unit

	Keep safety labels complete and legible.
---	--

Replace safety labels that are no longer legible. Contact BINDER Service for these replacements.

1.4 Type plate



Figure 2: Position of type plate

Nominal temperature	200 °C 392°F	0,80 kW 230 V 1 N ~ 3,5 A 50/60 Hz	
Enclosure protection	IP 20		
Temp. safety device	DIN 12880		
Class	2.0		
Art. No.	9030-0029	US PATS 4585923 / 5222612 / 5309981	
Project No.	---	5405194 / 5601143 / 5773287 / 6079403	








D 78532 Tuttlingen / Germany
Tel. + 49 (0) 7462/ 2005-0
Internet: www.binder-world.com



VD 23 Serial No. 00-00000
Made in Germany

Figure 3: Type plate (example of VD 23 regular unit)

Indications of the type plate		Information
BINDER		Manufacturer: BINDER GmbH
VD 23		Model VD 23
Serial No.	00-00000	Serial No. 00-00000
Nominal temperature	200 °C 392 °F	Nominal temperature
Enclosure protection	IP 20	IP type of protection 20 acc. to EN 60529
Temp. safety device	DIN 12880	Temperature safety device acc. to standard DIN 12880
Class	2.0	Temperature safety device, class 2
Art. No.	9030-0029	Art. No. 9030-0029
Project No.	---	(Special application acc. to project no.)
0,80 kW		Nominal power 0,80 kW
230 V 1 N ~		Nominal voltage 230 V ± 10%, single-phase unit
3,5 A		Nominal current 3,5 Amp
50/60 Hz		Power frequency 50/60 Hz


Symbol on the type plate	Information
	CE conformity marking
	Electrical and electronic equipment manufactured / placed on the market in the EC after 13 August 2005 and to be disposed of in a separate collection according to directive 2002/96/EC on waste electrical and electronic equipment (WEEE).
	VDE-GS certification mark
	The equipment is certified in the GOST R certification system of GOSTSTANDARD Russia.
 (VD-UL only)	The equipment is certified by Underwriters Laboratories Inc. [®] according to standards UL 61010A-1, UL 61010A-2-10, CSA C22.2 No. 1010.1-92, and CSA C22.2 No. 1010.2.010-94.

1.5 General safety instructions on installing and operating the vacuum drying oven

With regard to operating the vacuum drying oven VD and to the installation location, please observe the guideline BGI/GUV-I 850-0 on safe working in laboratories (formerly BGR/GUV-R 120 or ZH 1/119 laboratory guidelines issued by the employers' liability insurance association) (for Germany).

BINDER GmbH is only responsible for the safety features of the unit provided skilled electricians or qualified personnel authorized by BINDER perform all maintenance and repair, and if components relating to chamber safety are replaced in the event of failure with original spare parts.



To operate the unit, use only original BINDER accessories or accessories from third-party suppliers authorized by BINDER. The user is responsible for any risk caused by using unauthorized accessories.

	CAUTION
	Danger of overheating. Damage to the unit. <ul style="list-style-type: none"> ⊘ Do NOT install the oven in unventilated recesses. ➤ Ensure sufficient ventilation for dispersal of the heat.

Do not operate the vacuum drying oven VD in hazardous locations.

	 DANGER
	Explosion hazard. Danger of death. <ul style="list-style-type: none"> ⊘ Do NOT operate the unit in potentially explosive areas. ➤ KEEP explosive dust or air-solvent mixtures AWAY from the unit.

The vacuum drying oven VD is regularly equipped with a large-surface area safety valve. The window, manufactured in toughened safety glass, is elastic-mounted and serves as a safety valve in the event of explosion. The additional plastic panel provides splinter protection.



	<div style="background-color: red; color: white; padding: 5px; text-align: center;">  DANGER </div> <p>Explosion hazard. Danger of death.</p> <ul style="list-style-type: none"> Ø Do NOT introduce any substance into the oven which is combustible or explosive at working temperature. Ø NO explosive dust or air-solvent mixture in the inner chamber. Ø Do NOT use the vacuum drying oven for drying or heat treatments leading to release of combustible vapors able to form an explosive mixture with air.
---	--

Any solvent contained in the charging material must not be explosive or inflammable. I.e., irrespective of the solvent concentration in the steam room, NO explosive mixture with air must form. The drying temperature must lie below the flash point or below the sublimation point of the charging material. Familiarize yourself with the physical and chemical properties of the charging material, as well as the contained moisture constituent and its behavior with the addition of heat energy and changes in pressure.


Familiarize yourself with any potential health risks caused by the charging material, the contained moisture constituent or by reaction products that may arise during the drying process. Take adequate measures to exclude such risks prior to putting the vacuum drying oven into operation.

	<div style="background-color: red; color: white; padding: 5px; text-align: center;">  DANGER </div> <p>Electrical hazard. Danger of death.</p> <ul style="list-style-type: none"> Ø The oven must NOT become wet during operation or maintenance.
--	--

The vacuum drying ovens were produced in accordance with the relevant VDE regulations and were routinely tested in accordance to VDE 0411-1 (IEC 61010-1).

	<div style="background-color: yellow; padding: 5px; text-align: center;">  CAUTION </div> <p>The inner chamber will become hot during operation. Danger of burning.</p> <ul style="list-style-type: none"> Ø Do NOT touch the inner surfaces or the charging material during operation.
---	--

In the case of operation with inert gas, the unit is supplied with an oxygen-displacing gas (e.g. N₂). The gas emerging from the system must therefore be removed from the installation area by means of a suitable extraction system (see technical ventilation measures in the guideline BGI/GUV-I 850-0 on safe working in laboratories (formerly BGR/GUV-R 120 or ZH 1/119 laboratory guidelines issued by the employers' liability insurance association) (for Germany).

	<p>With use of a vacuum system or a vacuum pump, observe the permitted gas inlet temperature. Observe the safety instructions of the pump manufacturer.</p>
---	---

1.6 Intended use

The VD vacuum drying ovens are suitable for drying and heat treatment of solid or pulverized charging material, as well as bulk material, using the supply of heat under vacuum. The solvent content must not be explosive or flammable. A mixture of any component of the charging material with air must NOT be explosive. The drying temperature must lie below the flash point or below the sublimation point of the charging material.



Observing the instructions in this operating manual and conducting regular maintenance work (chap. 17) is part of the intended use.

2. Description of the equipment

Vacuum drying is used for special drying problems, for which conventional drying methods cannot offer a solution due to physical limitations.

All functions of the multifunctional program control can be set simply and conveniently via the easy to understand function keypad of the RD3 temperature program controller. This controller is equipped with touch function keys and a digital display and permits exact temperature setting and programming temperature cycles. The VD provides almost unlimited possibilities of adapting to individual customer requirements based upon extensive programming options and on the week program timer and real time clock of the controller.

The electro-polished inner chamber, the rack holder, and all of the unit's vacuum connections and valves are made of especially corrosion resistant stainless steel V4A (material no. 1.4571 in Germany). The housing is RAL 7035 powder-coated. All corners and edges are also completely coated. When operating the chamber at temperatures above 150 °C / 302°F, the impact of the oxygen in the air may cause discoloration of the metallic surfaces (yellowish-brown or blue) by natural oxidation processes. These colorations are harmless and will in no way impair the function or quality of the unit.

The vacuum drying ovens in the APT.line™ are jacket-heated. The APT.line™ preheating chamber technique ensures a completely homogeneous jacket temperature, ensuring uniform heat transfer into the inner chamber. The low-loss heat transfer to the material uses the patented aluminum vacuum expansion racks (or optionally available in stainless steel). The elastic-mounted safety glass window reliably compensates any overpressure or explosions that may occur. The additional polycarbonate panel ensures proven and effective splinter protection in the event of an implosion.

All VD units provide an inert gas connection and a measuring connection serving to connect a vacuum controller or a measuring access port.

The VD vacuum drying ovens are equipped as standard with a large-surface safety valve. The toughened safety glass window is elastic-mounted and in the event of explosion serves as a safety valve. The additional plastic panel provides splinter protection.

The VD vacuum drying oven is equipped with a serial interface RS 422 for computer communication, e.g. via the communication software APT-COM™ 3 DataControlSystem (option, chap.16.8). For further options, see chap. 20.3.

All installable items, such as racks and rack holders, can be easily removed. The completely smooth inner chamber with its rounded corners and internally welded seams is easy to clean.

The minimum working temperature of the vacuum drying oven is approx. 15 °C / 27 °F above room temperature. The maximum temperature is 200 °C / 392°F.

Vacuum pumps with a suction capacity of 1 m³/h to 30 m³/h are suitable for the VD vacuum drying oven. The permissible end vacuum is 10⁻² mbar / 0.0003 inHg.

2.1 Overview of the equipment




Figure 4: VD 23 with option vacuum module and chemical membrane pump

- (A) Control panel
- (B) Unit door
- (C) Elastic-mounted safety glass window
- (D) Vacuum module (option)
- (E) Chemical membrane pump (option)

2.2 VD 23 control panel




Figure 5: VD 23 control panel

- (1) On/off switch (main power switch)
- (2) Temperature safety device class 2
- (2a) Red alarm lamp of the safety device class 2
- (3) Manometer (pressure reading)
- (4) Aeration valve (inert gas or ambient air)
- (7) Program controller RD3
- (8) Vacuum shut-off valve

2.3 VD 53 / 115 control panel




Figure 6: VD 53/115 control panel

- (1) On/off switch (main power switch)
- (2) Temperature safety device class 2
- (2a) Red alarm lamp of the safety device class 2
- (3) Manometer (pressure reading)
- (5) Aeration valve (ambient air)
- (6) Fine dosing valve (inert gas)
- (7) Program controller RD3
- (8) Vacuum shut-off valve

2.4 Connections at the rear of the unit




Figure 7: Rear of VD

- (9) RS 422 serial interface for computer communication
- (10) Miniature fuse
- (11) Power connection line
- (12) Inert gas connection, adapter with hose olive \varnothing 8 mm / 0.31 in
(VD23: also simultaneous fresh air connection)
- (13) Vacuum connection with small flange DN16
- (14) DIN socket (option) for option "object temperature display"
- (15) DIN socket (operation line 2) (option) for option "program controlled venting"
- (16) DIN socket (operation line 1) (option) for option "vacuum module with pump"
- (17) Measuring connection with small flange DN16





3. Completeness of delivery, transportation, storage, and installation

3.1 Unpacking, and checking equipment and completeness of delivery

After unpacking, please check the unit and its optional accessories, if any, based on the delivery receipt for completeness and for transportation damage. Inform the carrier immediately if transportation damage has occurred.

The final tests of the manufacturer may have caused traces of the shelves on the inner surfaces. This has no impact on the function and performance of the unit.

Please remove any transportation protection devices and adhesives in/on the unit and on the doors and remove the operating manuals and accessory equipment.

  	<div style="background-color: yellow; text-align: center; padding: 5px;">  CAUTION </div> <p>Sliding or tilting of the unit.</p> <p>Damage to the unit.</p> <p>Risk of injury by lifting heavy loads.</p> <ul style="list-style-type: none"> Ø Do NOT lift or transport the unit using the door handle, the door or the lower housing. ➤ Lift units size 23 and 53 from the pallet at the four lower corners with the aid of 4 people. ➤ Lift units size 115 from the pallet with the aid of 6 people.
---	--

If you need to return the unit, please use the original packing and observe the guidelines for safe lifting and transportation (chap. 3.2).

For disposal of the transport packing, see chap. 18.1.

If you ordered the option “vacuum module with chemical membrane pump”, the pump will be delivered in a separate box and must be fitted into the module and connected at the place of installation (see chap. 16.3 and 16.4).





Note on second-hand units (Ex-Demo-Units):

Second-hand units are units that were used for a short time for tests or exhibitions. They are thoroughly tested before resale. BINDER ensures that the chamber is technically sound and will work flawlessly.

Second-hand units are marked with a sticker on the unit door. Please remove the sticker before commissioning the unit.

3.2 Guidelines for safe lifting and transportation

After operation, please observe the guidelines for temporarily decommissioning the unit (chap. 18.2).

  	<div style="background-color: yellow; text-align: center; padding: 5px;">  CAUTION </div> <p>Sliding or tilting of the unit.</p> <p>Damage to the unit.</p> <p>Risk of injury by lifting heavy loads.</p> <ul style="list-style-type: none"> ➤ Transport the unit in its original packaging only. ➤ For moving or shipping, secure the oven with transport straps. ⊘ Do NOT lift or transport the unit using the door, the handle, or the lower housing. ➤ Lift units size 23 and 53 at the four lower corners with the aid of 4 people. ➤ Lift units size 115 with the aid of 6 people.
---	--

- Permissible ambient temperature range during transport: -10 °C / 14°F to +60 °C / 140°F.

You can order transport packing for moving or shipping purposes from BINDER Service.

3.3 Storage


Intermediate storage of the unit in a closed and dry room. Observe the guidelines for temporary decommissioning (chap. 18.2).

- Permissible ambient temperature range during storage: -10 °C / 14°F to +60 °C / 140°F.
- Permissible ambient humidity: max. 70 % r.H., non-condensing


When after storage in a cold location you transfer the unit to its warmer installation site, condensation may form. Before start-up, wait at least one hour until the chamber has attained ambient temperature and is completely dry.

3.4 Location of installation and ambient conditions

Set up the VD vacuum drying oven on a flat, even, and non-flammable surface, free from vibration, in a well-ventilated, dry location. Align it using a spirit level. The site of installation must be capable of supporting the unit's weight (see technical data, chap. 20.2). The chambers are designed for setting up inside a building (indoor use).


	<div style="background-color: yellow; text-align: center; padding: 5px;"> CAUTION </div> <p>Danger of overheating.</p> <p>Damage to the unit.</p> <ul style="list-style-type: none"> ⊘ Do NOT set up units in non-ventilated recesses. ➤ Ensure sufficient ventilation for dispersal of the heat.
---	--

- Permissible ambient temperature range during operation: +18 °C / 64°F to +32 °C / 90°F.

	<p>The ambient temperature should not be substantially higher than the indicated ambient temperature of +25 °C / 77°F to which the specified technical data relate. Deviations from the indicated data are possible for other ambient conditions.</p>
---	---

- Permissible ambient humidity: 70 % r.H. max., non-condensing.
- Installation height: max. 2000 m / 6562 ft above sea level.

When placing several units of the same size side by side, maintain a minimum distance of 250 mm / 9.8 in between each unit. Wall distances: rear 100 mm / 3.9 in, sides 135 mm / 5.3 in. Spacing above and behind the unit of at least 100 mm / 3.9 in must also be maintained.

	CAUTION
	<p>Danger by stacking.</p> <p>Damage to the units.</p> <p>⊘ Do NOT place vacuum drying ovens on top of each other.</p>

To completely separate the unit from the power supply, you must disconnect the power plug. Install the unit in a way that the power plug is easily accessible and can be easily pulled in case of danger.

Do not install or operate the vacuum drying oven VD in potentially explosive areas.

	 DANGER
	<p>Explosion hazard.</p> <p>Danger of death.</p> <p>⊘ Do NOT operate the unit in potentially explosive areas.</p> <p>➤ KEEP explosive dust or air-solvent mixtures AWAY from the vicinity of the unit.</p>

For operation with inert gas, the unit is supplied with an oxygen-displacing gas, e.g. N₂. The gas emerging from the system must be removed from the installation area by means of a suitable extraction system (see technical ventilation measures in the guideline BGI/GUV-I 850-0 on safe working in laboratories (formerly BGR/GUV-R 120 or ZH 1/119 laboratory guidelines issued by the employers' liability insurance association) (for Germany).

The maximum permissible ambient temperature of the vacuum pumps delivered by BINDER is 40 °C / 104°F.

4. Installation and connections

4.1 Vacuum expansion racks

The low-loss heat transfer to the material occurs via the patented aluminum vacuum expansion racks (also available in stainless steel as an option). The strong tension causes the racks to fit tightly against the interior wall and their large-surface contact area ensures rapid and effective heat transfer.


The removable rack holders allow for easy positioning.


You can also remove the expansion racks for easy cleaning. Do not remove them too often in order to prevent wear.



Figure 8: Using the expansion racks


- Pushing the locking lever: The expansion rack is released and can be removed.
- Pulling the locking lever: The expansion rack is pressed against the inner chamber walls.

	<p>Following each new tightening of an expansion rack, check that the lateral parts of the rack fit closely over their whole surface to the inner chamber wall. This is necessary in order to ensure the specified temperature exactitude.</p>
---	--


	CAUTION
	<p>Invalid calibration.</p> <ul style="list-style-type: none"> ⊘ Do NOT change between aluminum and stainless steel racks ➤ Use the delivered expansion racks only

4.2 Electrical connection

- The VD vacuum drying oven comes with a fixed power connection cable that has a length of 1800 mm / 5.9 ft..
- **VD 23, VD 53, VD 115:**
Shockproof plug, power supply voltage 230 V (1N~) +/- 10 %, 50/60 Hz. Unit fuse 10 Amp
- **VD 23 (CUL version), VD 53 (CUL version):**
NEMA plug 5-15P, power supply voltage 115 V (1N~) +/- 10 %, 60 Hz. Unit fuse 12.5 Amp
- **VD 115 (CUL version):**
NEMA plug 5-20P, power supply voltage 115 V (1N~) +/- 10 %, 60 Hz. Unit fuse 20 Amp
- Prior to connection and start-up, check the power supply voltage. Compare the values to the specified data located on the unit's type plate (unit front behind the door, bottom left-hand, see chap. 1.4).
- When connecting, please observe the regulations specified by the local electricity supply company and as well as the VDE directives (for Germany)
- Pollution degree (acc. to IEC 61010-1): 2
- Over-voltage category (acc. to IEC 61010-1): II

	CAUTION
	<p>Danger of incorrect power supply voltage.</p> <p>Damage to the equipment.</p> <ul style="list-style-type: none"> ➤ Check the power supply voltage before connection and start-up. ➤ Compare the power supply voltage with the data indicated on the type plate.


See also electrical data (chap. 20.2).

	<p>To completely separate the unit from the power supply, you must disconnect the power plug. Install the unit in a way that the power plug is easily accessible and can be easily pulled in case of danger.</p>
---	--

4.3 Vacuum connection

Always connect the VD vacuum drying oven to a vacuum pump or to a domestic vacuum system. For this purpose, the vacuum connection (13) with small flange DN16 must be connected to the back of the unit at the top with the vacuum pump or domestic vacuum system via a vacuum suction hose. For connecting to the unit, BINDER recommends the connection kit VD, Art. no. 8012-0146.



With the option "stainless steel tubing" between the vacuum oven and vacuum module, the vacuum connection is already located inside the vacuum module.

	<p>Vacuum pumps with a suction capacity of 1-30 m³/h are suitable for the VD vacuum drying oven. Permissible end vacuum: 10⁻² mbar / 0.0003 inHg.</p>
---	--

4.4 Inert gas connection

When operating the VD vacuum drying oven with inert gas, correctly follow the technical ventilation measures, as described in the guideline BGI/GUV-I 850-0 on safe working in laboratories (formerly BGR/GUV-R 120 or ZH 1/119 laboratory guidelines issued by the employers' liability insurance association) (for Germany).

Connect the inert gas supply to the inert gas connection (adapter with hose olive diameter 8 mm / 0.31 in) via a pressure reducer. Screw the enclosed adapter with hose olive on the thread (12) at the unit rear. Set the pressure reducer to a pressure slightly above ambient pressure. Ensure that the pressure reducer will certainly open. Do not alter this setting in order to avoid perturbation inside the oven and release of big quantities of inert gas after flooding the VD.

	 WARNING
	<p>Release of inert gas.</p> <p>Danger of poisoning.</p> <ul style="list-style-type: none"> ➤ Ensure technical ventilation measures. ➤ When decommissioning the vacuum drying oven, shut off the inert gas valve (4) or (6).

5. Start up

After connecting the supply lines (chap 4), turn on the unit via the main power switch (1):

- **Position 0:** Oven without function
- **Position I:** Oven operating

Warming chambers may release odors in the first few days after commissioning. This is not a quality defect. To reduce odors quickly we recommend heating up the chamber to its nominal temperature for one day and in a well ventilated location.

5.1 Settings at the RD3 program controller

After turning on the unit at the main power switch (1), the controller is in Normal Display / Fixed value operation mode.

Depending on the temperature value entered before, LED (7a) is lit if the heating is active, or no LED is lit if the actual temperature is equal to or above the set-point.

In **Display 1** of the controller the actual temperature value is displayed.

- With inactive week program timer:

In **Display 2** of the controller the actual date and time are displayed. Example:

15.05.06 13:52

- With active week program timer:

In **Display 2** of the controller the actual date and time and the states of the week program timer channels are displayed. Examples:

15.05.06 13:52 - -

Channel 1 Off,
Channel 2: Off

15.05.06 13:52 - □

Channel 1: Off,
Channel 2: On

15.05.06 13:52 □ -

Channel 1: On,
Channel 2: Off

15.05.06 13:52 □ □

Channel 1 On,
Channel 2: On





Figure 9: RD3 program controller

LED function indications and their signification:

(7a) (yellow)  Heating active

(7b) (yellow)  Operation line 1 ON

(7c) (yellow)  Operation line 2 ON

(7d) (green)  Illuminates: program operation

Flashes: exceeding of the tolerance limits in "Fixed value entry mode" or in "Program operation". In program operation: program interruption.

The program controller RD3 permits programming temperature cycles.

You can enter two programs with up to 10 sections each or one program with up to 20 sections (setting in the user level, chap. 10).



When changing from 2 programs to 1 program or vice-versa, existing programs are deleted.

The maximum length of an individual program section can be set to either 99 h 59 min or to 999 h 59 min (setting in the user level, chap. 10). This setting is then valid for all program sections.

Programming can be done directly through the keypad of the controller or graphically through the software APT-COM™ 3 DataControlSystem (option, chap. 16.8) specially developed by BINDER.

5.2 General indications

The program controller RD3 offers several functional levels:

Normal Display / Fixed value operation:

- Display of the temperature actual value (display 1) and of the actual date and time (display 2).
- The oven is in fixed value operating mode, equilibrating to the entered set-points.

Fixed value entry mode (chap. 6)

- Entry of the temperature set-point for fixed value operating mode
- Entry of temperature set-points 1 and 2 for week program operation

Program editor (chap. 8)

- You can enter two programs with up to 10 sections each or one program with up to 20 sections (selection in the user level, chap. 10). Entry of temperature set-points in all program sections (chap. 8.1).
- Deleting a program section (chap. 8.4)

Program start level (chap. 9)


- Selection of an entered program
- Entry of settings affecting the program course, as "start delay time" or "number of program cycles"
- Program start

Week program editor (chap.7)

- Setting the shift points

User level (chap. 10)

- User specific controller settings
- Setting the real time clock



If no button is touched during more than 120 sec., the controller returns from the current level to Normal Display.

6. Fixed value entry mode



If you do not want to use the week program timer, deactivate it (factory setting, setting in the user level, chap. 10) before entering any set-points. Any setting of the operation lines in fixed value entry mode is ineffective with active week program timer.

Basic entry principle: Access the individual parameters with button X/W. Enter the value with the arrow keys. A value flashing once after 2 seconds indicates that it has been applied by the controller.


► Normal Display

Display 1 shows	e.g. 39.8 °C	(actual temperature value)
Display 2 shows	e.g. 15.05.06 13:52 --	(actual date and time) (actual switching state of week program timer channel 1: Off, channel 2: Off, visible only if week program timer is activated in the user level, chap. 10)

Press key  ↓

Display 1 shows	e.g. 40.0 °C	(actual temperature set-point 1)
Display 2 shows	SP1 TEMPERATURE	(variable: temperature in °C)

Enter temperature set-point in °C using arrow keys   ↓ Value is shown in display 1.

Press key  ↓


Display 1 shows	e.g. 50.0 °C	(actual temperature set-point 2) (visible only if week program timer is activated in the user level, chap. 10)
Display 2 shows	SP2 TEMPERATURE	(variable: temperature in °C)

Enter temperature set-point in °C using arrow keys   ↓ Value is shown in display 1.

Press key  ↓

Display 1 shows	e.g. 000	(actual switching state of operation lines)
Display 2 shows	OPERATION LINE	(variable: switching state of operation lines)

Enter switching state of operation lines using arrow keys   ↓ (see chap. 15, switching outputs via operation lines)

Press key  ↓

If no button is pressed within more than 120 sec, or if the **EXIT** button is pressed, the controller changes to Normal Display.




When changing the set-point, check the setting of the safety device (chap. 12).



The values entered in fixed-value entry mode remain valid after program run-off and are then equilibrated.

If the week program timer is active, depending on the running week program another set-point (SP2) may be targeted. Temperatures too high or too low for the introduced solvent quantity can occur. Deactivate the week program timer if you do not use it (default setting, setting in the User level, chap. 10).


	CAUTION	
	Too high or too low temperature.	
	Damage to the charging material.	
	➤ Deactivate the week program timer if you do not use it.	

7. Week program editor

The Week program editor permits defining up to 4 shift point for each week day. A shift point defines a moment and the switching state ON or OFF of the channels that become active in this instance.


Channel function:

- Channel 1 On = Set-point SP2 is equilibrated.
- Channel 1 Off = Set-point SP1 is equilibrated
- Channel 2 = reserve


	The week program timer is initially set to inactive (factory setting). Therefore, you need to activate the week program timer in the user level (chap. 10).
---	---

Normal Display


Display 1 shows	e.g. 39.8 °C	(actual temperature value)
Display 2 shows	e.g. 15.05.06 13:52 --	(actual date and time, actual state of week program timer channel 1: Off, channel 2: Off)

Press down key  ↓ for 5 sec



Display 1 shows	e.g. 0000	
Display 2 shows	PROGRAM EDITOR	(you are in the program editor)

Press down key  ↓ for 5 sec

Display 1 shows	0000	Menu visible only if week program timer is activated in the user level (chap. 10)
Display 2 shows	WEEK PROG. EDITOR	(you are in the week program editor)


Press program key  ↓


Display 1 shows	0000	
Display 2 shows	UserCod? 0000	(enter user code, display flashes)


Enter the user code using arrow keys   ↓ e.g. **0001** (basic setting, adjustable in the user level, chap. 10).
Value is shown in both displays.

Automatically forward after 2 sec

Display 1 shows	0000	
Display 2 shows	Monday	(selection of day of the week) (actual selection: Monday)

Select the day of the week (Monday up to Sunday) with key  ↓ Day of the week is shown in display 2.

Press program key  ↓



To exit the menu, Press several times key **EXIT** or wait for 120 seconds. Controller returns to normal display.

7.1 Program table template for Week program Editor

Program editor	
Program title	
Project	
Date:	

Day of the week	Time			Channel 1 (temperature)	Channel 2*
	hh:mm	AM	PM	ON = SP2 OFF = SP1	ON OFF
Monday	S1				
	S2				
	S3				
	S4				
Tuesday	S1				
	S2				
	S3				
	S4				
Wednesday	S1				
	S2				
	S3				
	S4				
Thursday	S1				
	S2				
	S3				
	S4				
Friday	S1				
	S2				
	S3				
	S4				
Saturday	S1				
	S2				
	S3				
	S4				
Sunday	S1				
	S2				
	S3				
	S4				

* Channel 2 is non-functional in the standard unit

7.2 Programming example of the Week program editor

7.2.1 Desired time function

During the day (12 hours) the oven shall maintain a temperature of +80 °C / 176°F, and during the night (12 hours) it shall cool down / stop heating (set-point 30 °C / 86°F).

This program shall automatically run during the whole year, i.e. it shall be programmed just once.

7.2.2 Proceeding overview

1. Settings in the user level (see chap. 10)

- Activating the week program timer
- Checking and, if necessary, setting the real time clock

2. Enter the set-points for the week program in “Fixed value entry mode” (see chap. 6)

Set-points for the example program:

SP1 (night / weekend) = 30 °C (Channel 1 ON = Controller adjusts to set-point SP2)


SP2 (day / week) = 80 °C (Channel 1 OFF = Controller adjusts to set-point SP1)

3. Enter the time program to the program editor

Program table for the example program:

Day of the week	Time			Channel 1 (temperature)
	hh:mm	AM	PM	
Monday	S1 06:00			ON
	S2 18:00			OFF
Tuesday	S1 06:00			ON
	S2 18:00			OFF
Wednesday	S1 06:00			ON
	S2 18:00			OFF
Thursday	S1 06:00			ON
	S2 18:00			OFF
Friday	S1 06:00			ON
	S2 18:00			OFF
Saturday	S1 06:00			ON
	S2 18:00			OFF
Sunday	S1 06:00			ON
	S2 18:00			OFF



Make sure that no other shift points have been pre programmed. If so, they must be deleted:
Set the time of the respective shift point to “--:--” using key .


7.2.3 Proceeding in detail

1. Settings in the user level

- Activating the week program timer
- Checking and, if necessary, setting the real time clock

Normal Display


Display 1 shows	e.g. 39.8 °C	(actual temperature value)
Display 2 shows	e.g. 15.05.06 13:52 - -	(actual date and time, actual switching state of week program timer channel 1: Off, channel 2: Off)

Press down key  ↓ for 5 sec


Display 1 shows	e.g. 0000	
Display 2 shows	PROGRAM EDITOR	(you are in the program editor)

Press down key  ↓ for 5 sec



Display 1 shows	0000	Menu visible only if week program timer is activated.
Display 2 shows	WEEK PROG. EDITOR	(you are in the week program editor)

Press down key  ↓ for 5 sec

Display 1 shows	0000	
Display 2 shows	USER – LEVEL	(you are in the user level)


Press program key  ↓

Display 1 shows	0000	
Display 2 shows	UserCod? 0000	(enter user code, display flashes)

Enter the user code using arrow keys   ↓ e.g. **0001** (basic setting, or the valid code in case it has been previously changed in this menu).
Value is shown in both displays.

Automatically forward after 2 sec

Display 1 shows	1	(actual address)
Display 2 shows	Adress 1	(entry of unit address) (actual address: 1)

Press several times key  ↓ until **Prog.Clk** appears:

Display 1 shows	0000	
Display 2 shows	Prog.Clk Active	(Week program timer active or inactive? (actual setting: Active)


Select **Active** using arrow keys   ↓ Setting is shown in display 2.


Press key  ↓

Display 1 shows	0000	
Display 2 shows	12h/24h 24h	(Display mode 12 hours or 24 hours? (actual setting: 24h)

Press key  ↓

Display 1 shows	0000	
Display 2 shows	Date	(Main menu: Setting the date of the real time clock)

Press program key  ↓




2. Enter the set-points for the week program in Fixed value entry mode (see chap. 6)

Set-points for the example program:

SP1 (night / weekend) = 30 °C (Channel 1 ON = Controller adjusts to set-point SP2)

SP2 (day / week) = 80 °C (Channel 1 OFF = Controller adjusts to set-point SP1)

Normal Display



Enter temperature set-point **30 °C** using arrow keys   ↓ Value is shown in display 1.

Press key  ↓

Display 1 shows	80.0 °C	(actual temperature set-point 2)
Display 2 shows	SP2 TEMPERATURE	(variable: temperature in °C)


Enter temperature set-point **80 °C** using arrow keys   ↓ Value is shown in display 1.

Press the EXIT button. The controller changes to Normal Display.


3. Enter the time program to the week program editor

Normal Display


Display 1 shows	e.g. 39.8 °C	(actual temperature value)
Display 2 shows	e.g. 15.05.06 13:52 --	(actual date and time, actual state of week program timer channel 1: Off, channel 2: Off)

Press down key  ↓ for 5 sec

Display 1 shows	e.g. 0000	
Display 2 shows	PROGRAM EDITOR	(you are in the program editor)

Press down key  ↓ for 5 sec

Display 1 shows	0000	
Display 2 shows	WEEK PROG. EDITOR	(you are in the week program editor)


Press program key  ↓


Display 1 shows	0000	
Display 2 shows	UserCod? 0000	(enter user code, display flashes)

Enter the user code using arrow keys   ↓ e.g. **0001** (basic setting, adjustable in the user level, chap. 10). Value is shown in both displays.


Automatically forward after 2 sec

Display 1 shows	0000	
Display 2 shows	Monday	(selection of day of the week) (actual selection: Monday)

Select the first day of the week (**Monday**) with key  ↓ Day of the week is shown in display 2.


Press program key  ↓

Display 1 shows	0000	
Display 2 shows	Shiftpt.	(no function)


Press program key  ↓


Display 1 shows	0000	
Display 2 shows	Shiftpt. 1	(selection of the shift point) (actual shift point: 1)


Select shift point **1** with key  ↓ Value is shown in display 2.

Press program key  ↓

Display 1 shows	e.g. --:--	(time of the selected shift point)
Display 2 shows	S1: --:--	(actual selection of the shift point: S1) (actual setting: shift point not programmed)

Press program key  ↓







8. Program editor

8.1 Selecting between set-point ramp and set-point step

You can program various kinds of temperature transitions. In the user level (chap. 10) you can select between the settings “Ramp” (default setting) and “Step”.

	<p>Setting “Ramp” permits programming all kinds of temperature transitions.</p> <p>With setting “Step” the controller will equilibrate only to constant temperatures; programming ramps is no longer possible.</p>
---	--

	<p>Switching between settings “Ramp” and “Step” will influence all programs. Please note that this can cause the time courses of existing programs to change significantly.</p>
---	---

8.1.1 Programming with setting “Ramp” (default setting)

Set-points always refer to the start of a program section, i.e., at the beginning of each program section, the entered set-point is reached. During program section operation, the temperature gradually passes to the set-point entered for the subsequent program section.

You can program all kinds of temperature transitions by the appropriate design of the program section timing:

- **Gradual temperature changes “set-point ramp”**

The set-point gradually moves from one set-point to the one of the following program section during a given interval. The actual temperature value (X) follows the continually moving set-point (W) at any moment.

- **Program sections with constant temperature**

The initial values of two subsequent program sections are identical; therefore the temperature remains constant during the whole time of the first program section.

- **Sudden temperature changes “set-point step”**

Steps are temperature changes (ramps) that occur during a very short interval. Two program sections with an identical set-point are followed by a section with a different set-point. If the duration of this transitional program section is very short (minimum entry 1 min), the temperature change will proceed rapidly in the minimum amount of time.





Figure 10: Possible temperature transitions
(with default setting “ramp” in the user level (chap. 10))

Program entry as set-point ramp (example):




Program table corresponding to the diagram (with default setting "Ramp"):

Section	Temperature set-point [°C]	Section length [hh.mm]	Operation lines
SEC	TEMP	TIME	O.LINE
S01	40	00:30	000
S02	60	01:30	000
S03	90	01:00	000
S04	90	03:20	000
S05	20	00:01	000

You can now enter the values of such a program table to the RD3 program controller (chap. 8.2).

Program entry as set-point step (example):



Program table corresponding to the diagram (with default setting "Ramp"):

Section	Temperature set-point [°C]	Section length [hh.mm]	Operation lines
SEC	TEMP	TIME	O.LINE
S01	40	00:30	000
S02	40	00:01	000
S03	60	01:30	000
S04	60	00:01	000
S05	80	01:00	000
S06	80	00:01	000
S07	20	03:20	000
S08	20	00:01	000

You can now enter the values of such a program table to the RD3 program controller (chap. 8.2).

Program the end point of the desired cycle with an additional section (in our examples S05 for set-point ramp and S08 for set-point step) with a section time of at least one minute. Otherwise, the program will stop one section too early because the program line is incomplete.

8.1.2 Programming with setting "step"


With setting "Step" selected, you don't need to program the transition section in the Program Editor.



With setting "step" the controller will equilibrate only to constant temperatures; programming ramps is no longer possible.

The set-points are maintained constant for the duration of a program section. At the start of each program section, the unit heats up with the maximum speed in order to attain the entered set-point

Program entry as set-point step (example):



Program table corresponding to the diagram (with setting "Step"):

Section	Temperature set-point [°C]	Section length [hh.mm]	Operation lines
SEC	TEMP	TIME	O.LINE
S01	40	00:30	000
S02	60	01:30	000
S03	80	01:00	000
S04	20	03:20	000

You can now enter the values of such a program table to the RD3 program controller (chap. 8.2).

8.1.3 General notes on programming temperature transitions

When exceeding the tolerance limits set in the user level (chap. 10), the program is interrupted until the actual temperature value returns to within the tolerance range. During this program interruption, the LED (7d) flashes. Therefore, the duration of the program may be extended due to the programming of tolerances

The programming is saved even in case of power failure or after turning off the unit.

After program rundown the controller returns to fixed value operation showing Normal Display and equilibrates to the temperature value previously entered in fixed value entry mode.



Before starting the program, check the set-point value entered in fixed value entry mode. After program rundown temperature will equilibrate to this value.



Deactivate the week program timer (factory setting, setting in the user level, chap. 10) before starting a program.

8.2 Set-point entry for program operation

From Normal Display, press down button X/W for 5 sec to access the program editor. Then enter the set-points one after the other in all program sections of a selected program.

You can enter two programs with up to 10 sections each or one program with up to 20 sections (setting in the user level, chap. 10).

In order to avoid incorrect programming, we recommend entering the values of the program course into a table (template in chap. 8.3).

Example of program table (with default setting "Ramp"):


Section	Temperature set-point [°C]	Section length [hh.mm]	Operation lines
SEC	TEMP	TIME	O.LINE
S01	40	00:30	000
S02	60	01:30	000
S03	90	01:00	000
S04	90	03:20	000
S05	20	00:01	000

You can now enter the values of the program table to one of the program places of the RD3 program controller.


Step 1 – Selecting the program and the first program section to be entered:

Normal Display



Display 1 shows	e.g. 39.8 °C	(actual temperature value)
Display 2 shows	e.g. 15.05.06 13:52 - -	(actual date and time, actual switching state of week program timer channel 1: Off, channel 2: Off)

Press down key  ↓ for 5 sec.

Display 1 shows	e.g. 0000	
Display 2 shows	PROGRAM EDITOR	(you are in the program editor)

Press program key  ↓

Display 1 shows	0000	
Display 2 shows	UserCod? 0000	(enter user code)

Enter user code using arrow keys   ↓ e.g. **0001**
(basic setting, adjustable in the user level, chap. 10).
Value is shown in both displays.

Automatically forward after 2 sec.



Display 1 shows	e.g. 01	(program P01 selected)
Display 2 shows	--- : --- PRG.	(program can be selected)
alternating	CONTINUE X/W	(information: to 1 st program section with X/W)

Select program P01 or P02 using arrow keys   ↓ Value is shown in display 1.



Press key  ↓

In the selected program P01 or P02, program sections can be selected:

Display 1 shows	e.g. 01	(section S01 selected)
Display 2 shows	P01: --- SEC.	Section S01 has already been created.
alternating	CONTINUE X/W	Enter new set-points for the individual variables with button X/W

or:

Display 1 shows	e.g. 01	(section S01 selected)
Display 2 shows	P01: --- SEC.	Section S01 has not yet been created.
alternating	NEW SEC. X/W	Enter set-points for the individual variables with button X/W

Select sections S01 to S10 or to S20 using arrow keys   ↓

As long as no program section has been entered, the display switches back to 01 in case of any entry > 01, because all sections need to be entered one after the other, and each new section is created as NEWSEC.

Example: If three programs sections have been already entered, the next section to be entered is S04. Before this, no section > S04 can be selected.





Next step – set-point entry in the desired program sections:

Basic entry principle: Access the parameters of individual program sections with button X/W one after the other. Enter the values of the individual parameters with the arrow keys. A value flashing once after 2 seconds indicates that it has been adopted by the controller. If several parameters are to be skipped (e.g. in order to change a parameter in a posterior program section), the parameters can be rapidly jumped over by holding down the X/W key. If no button is pressed for more than 120 sec the controller switches back to Normal Display. The program entered to this point remains stored.

Press key  ↓


Display 1 shows	e.g. 40.0 °C	(actual temperature set-point)
Display 2 shows	S01: TEMP 40.0	(variable: temperature in °C)
alternating	CONTINUE X/W	(information: go on with X/W)

Enter temperature set-point of S01 in °C using arrow keys  ↓

Press key  ↓


Display 1 shows	e.g. 00.30	(actual section length set-point)
Display 2 shows	S01: TIME 00:30	(variable: section length in hh:mm)
alternating	CONTINUE X/W	(information: go on with X/W)

Enter section length set-point of S01 in hh:mm using arrow keys  ↓ Value is shown in both displays.

Press key  ↓

Display 1 shows	e.g. 000	(actually set switching state)
Display 2 shows	S01: O.LINE 000	(variable: switching state)
alternating	CONTINUE X/W	(Information: go on with X/W)

Enter switching state of operation lines using arrow keys  ↓ (see chap. 15, switching outputs via operation lines)


Press key  ↓

Selecting the next program sections to be entered


Display 1 shows	e.g. 02	(section S02 selected)
Display 2 shows	P01: --- SEC.	Section S02 has already been created.
alternating	CONTINUE X/W	Enter new set-points for the individual parameters with X/W.

or:

Display 1 shows	e.g. 02	(section S02 selected)
Display 2 shows	P01: --- SEC.	Section S02 has not yet been created.
alternating	NEW SEC. X/W	Enter set-points for the individual parameters with X/W

Select the next section to be entered using arrow keys  ↓

Display 1 shows	e.g. 60.0 °C	(actual temperature set-point)
Display 2 shows	S02: TEMP 60.0	(variable: temperature in °C)
alternating	CONTINUE X/W	(information: go on with X/W)

Enter the temperature set-point of S02 in °C using arrow keys  ↓

Etc.

If all sections up to S10 or up to S20 have been programmed, section S01 follows again. In order to quit the entry mode, press the **EXIT** button several times or wait 120 sec → the controller will then return to Normal Display.



When changing the set-point, check the setting of the safety device (chap. 12).

8.3 Program table template

Program editor	
Program title	
Project	
Program No.	
Date:	

Section	Temperature set-point [°C]	Section length [hh.mm]	Operation lines *
SEC	TEMP	TIME	O.LINE
S01			
S02			
S03			
S04			
S05			
S06			
S07			
S08			
S09			
S10			
S11			
S12			
S13			
S14			
S15			
S16			
S17			
S18			
S19			
S20			

* Switching contacts 24V DC via operation lines, see chap. 15.


8.4 Deleting a program section

A program section is deleted from the program by setting the section duration to Zero.



Normal display

Press down key  ↓ for 5 sec.

Display 1 shows	e.g. 0000	
Display 2 shows	PROGRAM EDITOR	(you are in the program editor)



Press program key  ↓

Display 1 shows	0000	
Display 2 shows	UserCod? 0000	(enter user code)

Enter the user code using arrow keys   ↓ e.g. **0001** (basic setting, adjustable in the user level, chap. 10).
Value is shown in both displays.

Automatically forward after 2 sec

Display 1 shows	e.g. 01	(program P01 selected)
Display 2 shows	--- : --- PRG.	(program can be selected)
alternating	CONTINUE X/W	(information: to 1 st program section with X/W)

Select the desired program, e.g. P01, using arrow keys   ↓ Value is shown in display1.

Press key  ↓

In the selected program P01 or P02, program sections can be selected:

Display 1 shows	e.g. 01	(actual selection of the section: S01)
Display 2 shows	P01: --- SEC.	(program section can be selected)
alternating	CONTINUE X/W	(information: set-point entry with X/W)

Select desired section, e.g. S03, using arrow keys   ↓ (omitted if section S01 shall be deleted).

Press key  ↓

Display 1 shows	e.g. 90.0 ^C	(actual temperature set-point)
Display 2 shows	S03:TEMP 90.0	(variable: temperature)
alternating	CONTINUE X/W	(information: continue with X/W)

No entry ↓


Press key  ↓


Display 1 shows	e.g. 01.00	(actual section length)
Display 2 shows	S03:TIME 01:00	(variable: section length)
alternating	CONTINUE X/W	(information: continue with X/W)

Enter set-point **Zero** for section length in hh:mm of S03 using arrow keys   ↓ Value is shown in display 2 or in both displays (display depends on maximum time setting in the user level chap. 10)

Display 1 shows	e.g. 00.00	(actual section length)
Display 2 shows	S03:TIME 00:00	(variable: section length)
alternating	DELETE SEC. X/W	(information: delete section with X/W)

Press key  ↓




 If you delete a program section which is followed by further sections, those following move up in place of the deleted section.

In our example, section S03 has been deleted. If sections S04, S05, etc. have been programmed earlier, they will now replace the preceding sections, i.e., S04 is now called S03 etc.


Deletion leads to overwriting the section by the following one. It is therefore not possible to temporarily inactivate a program section. To enter a section later to a program, all the sections following the new one must be entered again.

9. Program start level

Before starting the program, check the set-point entered in Fixed value operation mode. After end of the program, the temperature will equilibrate to this value.

	CAUTION
	<p>Too high or too low temperature after the program ends.</p> <p>Damage to the charging material.</p> <p>➤ Check the set-point of Fixed value operation and if necessary adapt it.</p>

After the program ends, the temperature will equilibrate to the set-point entered in Fixed value operation mode. If the week program timer is active, another set-point (SP2) may be targeted according to programming. Deactivate the week program timer before starting the program (default setting, setting in the User level, chap. 10).

	CAUTION
	<p>Too high or too low temperature after the program ends.</p> <p>Damage to the charging material.</p> <p>➤ Deactivate the week program timer before starting the program.</p>

In the first step, select a program. This is on condition that a program has been entered previously (chap. 8.2) and that program type "2 programs with 10 sections each" has been selected in the user level (chap. 10).

Then define the settings for the program course. Two parameters can be set:

- Program delay time, i.e. a defined time before a program starts. It can be entered with a precision of 1 minute, and its maximum value is 99.59 (99 h 59 min). If the value is 00.00, the program will start immediately.
- Number of program cycles, i.e. the desired number of program repeats. Values from 1 to 99 can be entered. If the program is not going to be repeated, enter the value "0". For indefinite repeats enter the value "–1". The program is repeated as a whole, it is not possible to repeat individual sections.


In the last step start the selected program. These steps must be carried out subsequently.



Deactivate the week program timer (factory setting, setting in the user level, chap. 10) before starting a program.

Step 1 – Program selection (only with program type “2 programs” set)


Normal Display

Press program key  ↓


Display 1 shows	e.g. 1	(actual selection of the program)
Display 2 shows	SEL.PRG.	(select program 1 or 2)


Enter program number 1 or 2 with arrow keys   ↓ Value is shown in display 1.

Next step – entry of program course settings

Press program key  ↓

Display 1 shows	e.g. 00.00	(entered delay time hh.mm)
Display 2 shows	RUN TIME	(enter delay time of program start)


Set delay time in hh.mm using arrow keys   ↓ Value is shown in display 1.

Press program key  ↓


Display 1 shows	e.g. -1	(actual selection of the number of program cycles)
Display 2 shows	REPEAT	(enter number of program cycles)

Select number of cycles -1, 0, 1 etc. using arrow keys   ↓ Value is shown in display 1.

Last step – program start

Press program key  ↓

Display 1 shows	e.g. 1	(selected program)
Display 2 shows	RUN PRG.	(Question: start selected program?)

Press program key  ↓

Display 1 shows	e.g. 25.5 °C	actual temperature value
Display 2 shows	P01:S01 00:29:39 (time running backwards)	(actual program P01, actual section S01, and remaining time of program section S01)


Program is running. The green LED (7d) lights up.


In addition to the green LED (7d) indicating a running program, the LED (7a) is lit if the heating is active, or not lit if the actual temperature equals the set-point.




During program course the arrow keys and the **EXIT** button are not functional.



By pressing program key  for 3 seconds, you can terminate the program course.

If you press button  during program course, the entered set-point of the actually running program section is shown for 5 sec:



After program rundown (and, if appropriate, of the program repeats) the controller returns to fixed value operation showing Normal Display and equilibrates to the temperature value previously entered in fixed value entry mode.

10. User level

In this menu you can set the following parameters (in brackets the corresponding abbreviated information given in display 2):

- **Unit address** (Adress)
Setting of controller address (1 to 255) for operation with the communication software APT-COM™.
- **User code** (User-cod)
Modification of the user code setting (factory setting 0001) for access to the user level and the program editor.



Keep in mind any modification of the user code. There is no access to these levels without a valid user code.

- **Decimal point position** (Decimal)
Selection if integer values or one position after the decimal point can be entered. The integer representation is shown in Display 2 (set-point entry) while the actual value in Display 1 is always shown with one decimal point.
- **Audio Alert** (Buzzer)
Inactive: no audible signal (buzzer) in case of an alarm event.
Active: in case of an alarm event (see chap. 11.2) an audible signal (buzzer) will sound. It can be reset by pressing the **EXIT** button.
- **Selection of controller menu language** (Language)
German, English, or French can be selected.
- **Counter of operating hours** (Oper.hs)
Information about the number of operating hours currently reached or since the last reset (no setting, display only).
- **Max. number of operating hours** (Op.limit)
Entry of a limit number of operating hours, i.e., the maximum number of operating hours that can be run. Maximum setting: 9999. Reaching the limit has no effect.
- **Reset operating hours** (Op.back)
Reset operating hours to zero.
- **Interface protocol** (Protocol)

“**Modbus**”: The unit interface can be used as a communication interface to connect it to a computer. This serves to control the unit by the communication software APT-COM™. It is possible to read and write the values of all parameters.

“**Printer**”: A protocol printer (option) for data printouts can be connected to the unit interface. At the printer the actual temperature value is regularly protocolled with fixed formatting and with adjustable print intervals (see chap. 16.9).

In both cases an interface converter RS 422 / RS 232 is used.
- **Print interval** (Prt.-Inv.)
Setting of the print interval in minutes. Function is available only if setting “Printer” has been selected in the previous menu point.
- **Display illumination** (Disp.LED)
Selection between continuous display illumination and limited illumination that will automatically go off 300 sec after the last entry.

- **Program type selection** (PrgSelec)

Select between entry of two programs with up to 10 sections each or of one program with up to 20 sections.



When changing from 2 programs to 1 program or vice-versa, existing programs are deleted in the program editor!

- **Maximum section duration** (Prg.Time)

The maximum length of an individual program section can be set to either 99 h 59 min or to 999 h 59 min. This setting is then valid for all program sections.



When changing the maximum duration setting, pre-existing programs will be deleted in the program editor.

- **Set-point programming type** (Setp.sim)

Selection between "Ramp" and "Step". With setting „Step“ selected, you don't need to program the transition section in the Program Editor.



If you select setting "step", the controller will equilibrate only to constant temperatures; programming ramps becomes impossible.



A change between settings "ramp" and "step" will influence all programs. Note that significant change in time courses may arise in existing programs.

- **Tolerance limit range** (Tol.band)

Entry of a tolerance limit value in °C. If the actual value of temperature exceeds the set-point of a program section by more than the entered tolerance limit value, the program is halted (LED (7d) flashes) until the actual temperature value is again within in the tolerance range

Entry of "0" means tolerance limits are off.

- **Activating or inactivating the week program timer** (Prog.Clk)

"Inactive": The week program timer is turned off (factory setting). The corresponding setting menu (chap. 7) is not visible, nor is is set-point 2 in the "Fixed value entry mode" (chap. 6).

"Active": The week program timer is activated.



When deactivating the week program timer, any programming made in advance will remain in memory and take effect when the week program timer is activated again.



Deactivate the week program timer before entering set-points in fixed value entry mode (chap. 6). Otherwise, any setting of the operation lines is ineffective.



Inactivate the week program timer before starting a program (chap. 9).

- **Display mode** (12h/24h)

Select between 12 hours (display "AM" or "PM") or 24 hours.

- **Date of the real time clock** (Date)

Main menu. Use the program key to access the settings of year, month, and day in the corresponding submenus.

- **Year of the real time clock** (Year)

Enter the year (2006 up to 2050)

- **Month of the real time clock (Month)**

Enter the month (1 up to 12).

- **Day of the real time clock (Day)**

Enter the day (1 up to 31).

- **Time of the real time clock (Time)**

Main menu. Use the program key to access the settings of hour and minute in the corresponding submenus.



There is no automatic switch between daylight saving time and regular time.

- **Hour of the real time clock (Hour)**

Enter the hour (0 up to 23).

- **Minute of the real time clock (Minute)**


Enter the minute (0 up to 59).

Normal Display


Display 1 shows	e.g. 39.8 °C	(actual temperature value)
Display 2 shows	e.g. 15.05.06 13:52 --	(actual date and time, actual switching state of week program timer channel 1: Off, channel 2: Off)

Press down key  ↓ for 5 sec


Display 1 shows	e.g. 0000	
Display 2 shows	PROGRAM EDITOR	(you are in the program editor)

Press down key  ↓ for 5 sec



Display 1 shows	0000	Menu visible only if week program timer is activated.
Display 2 shows	WEEK PROG. EDITOR	(you are in the week program editor)

Press down key  ↓ for 5 sec

Display 1 shows	0000	
Display 2 shows	USER – LEVEL	(you are in the user level)

Press program key  ↓

Display 1 shows	0000	
Display 2 shows	UserCod? 0000	(enter user code, display flashes)





















Enter the user code using arrow keys   ↓ e.g. **0001** (basic setting, or the valid code in case it has been previously changed in this menu). Value is shown in both displays.























Automatically forward after 2 sec



Display 1 shows	1	(actual address: 1)
Display 2 shows	Adress 1	(entry of unit address) (actual address: 1)

Enter the unit address (1 up to 254) using arrow keys   ↓ Address is shown in both displays.

Press key  ↓

Display 1 shows	1	(actually valid user code: 1)
Display 2 shows	User-cod 1	(change user code) (actually set: 1)
Enter a new value using arrow keys   ↓ Value is shown in both displays.		
Press key  ↓		
Display 1 shows	0000	(no function)
Display 2 shows	Saf.mode: Limit	(no function)
Press key  ↓		
Display 1 shows	0	(no function)
Display 2 shows	Saf.setp 0	(no function)
Press key  ↓		
Display 1 shows	0000	(no function)
Display 2 shows	Decimal: XXX.X	(setting of decimal point position) (actual setting: XXX.X)
Select decimal point position using arrow keys   ↓ Decimal point position XXX.X or XXXX. is shown in display 2.		
Press key  ↓		
Display 1 shows	0000	(no function)
Display 2 shows	Buzzer : Active	(setting of the alarm buzzer) (actual setting: „Active“)
Select between “Active” and “Inactiv” using arrow keys   ↓ Setting is shown in display 2.		
Press key  ↓		
Display 1 shows	0000	(no function)
Display 2 shows	Language : English	(selection of controller language) (actual setting: English)
Select between languages German, English, and French using arrow keys   ↓ Setting is shown in display 2.		
Press key  ↓		
Display 1 shows	e.g. 0004	(unit operating hours)
Display 2 shows	Oper.hs 0004:28	(operating hours up to now hhhh:mm) (actually displayed: 4 hs 28 min)
Press key  ↓		
Display 1 shows	1000	(actual setting: 1000 hs)
Display 2 shows	Op.limit 1000:00	(maximum number of operating hours hhhh:mm (actual setting: 1000 hs)
Set value using arrow keys   ↓ Setting is shown in both displays.		
Press key  ↓		
Display 1 shows	0000	(no function)
Display 2 shows	Op.back : No	(reset counter of operating hours ?) (actual setting: No)
Select between “Yes” and “No” using arrow keys   ↓ Setting is shown in display 2.		

Press key  ↓		
Display 1 shows	0000	(no function)
Display 2 shows	Protocol: MODBUS	(Selection of interface mode) (actual setting: Modbus)
Select between protocols "MODBUS" and "Printer" using arrow keys   ↓ Setting is shown in display 2.		
Press key  ↓		
Display 1 shows	e.g. 3	(actual setting: 3 min)
Display 2 shows	Prt-Inv. 3	(print interval) (actual setting: 3 min)
Select value between 0 and 255 minutes using arrow keys   ↓ Setting is shown in displays 1 and 2.		
Press key  ↓		
Display 1 shows	0000	
Display 2 shows	Disp.LED: No	(continuous display illumination?) (actual setting: No)
Select between "Yes" and "No" using arrow keys   ↓ Setting is shown in display 2.		
Press key  ↓		
Display 1 shows	0000	
Display 2 shows	PrgSeleC: 2Prg10S	(1 program with max. 20 sections or 2 programs with max. 10 sections each?) (actual setting: 2Prg10S)
Select between "2Prg10S" and "1Prg20S" using arrow keys   ↓ Setting is shown in display 2.		
Press key  ↓		
Display 1 shows	0000	
Display 2 shows	Prg.Time: 99:59	(max. section length 99:59 or 999:59?) (actual setting: 99:59)
Select between 99:59 in hh:mm or 999:59 in hhh:mm using arrow keys   ↓ Setting is shown in display 2.		
Press key  ↓		
Display 1 shows	0000	
Display 2 shows	Setp.sim Ramp	(ramp or step?) (actual setting: ramp)
Select between Ramp and Step using arrow keys   ↓ Setting is displayed in display 2.		
Press key  ↓		
Display 1 shows	0000	
Display 2 shows	Tol.band 0	(Tolerance limits in °C) (actual setting: 0)
Set value in °C using arrow keys   ↓ Setting is shown in display 2.		
Press key  ↓		
Display 1 shows	0000	
Display 2 shows	Prog.Clk Inactive	(Week program timer active or inactive?) (actual setting: Inactive)

Select between "Active" and "Inactive" using   ↓ Setting is shown in display 2.

Press key  ↓

Display 1 shows	0000	
Display 2 shows	12h/24h 24h	(Display mode 12 hours or 24 hours? (actual setting: 24h))

Select between 12 hours and 24 hours using arrow keys   ↓ Setting is shown in display 2.



Press key  ↓


Display 1 shows	0000	
Display 2 shows	Date	(Main menu: Setting the date of the real time clock)





Press program key  ↓


Display 1 shows	e.g. 2006	(Actual setting: 2006)
Display 2 shows	Year 2006	(Setting the year of the real time clock)

Set year (2006 up to 2050) using arrow keys   ↓ Setting is shown in display 2.

Press key  ↓

Display 1 shows	e.g. 5	(Actual setting: may)
Display 2 shows	Month 5	(Setting the month of the real time clock)


Set month (1 up to 12) using arrow keys   ↓ Setting is shown in display 2.

Press key  ↓


Display 1 shows	e.g. 15	(Actual setting: 15)
Display 2 shows	Day 15	(Setting the day of the real time clock)

Set day (1 up to 31) using arrow keys   ↓ Setting is shown in display 2.

Press key **EXIT** ↓

Press key  ↓

Display 1 shows	0000	
Display 2 shows	Time	(Main menu: Setting the time of the real time clock)



Press program key  ↓

Display 1 shows	e.g. 13	(Actual setting: 13, i.e. 1 p.m.)
Display 2 shows	Hour 13	(Setting the hour of the real time clock)

Set hour (0 up to 23) using arrow keys   ↓ Setting is shown in display 2.

Press key  ↓

Display 1 shows	e.g. 30	(Actual setting: 30 minutes)
Display 2 shows	Minute 30	(Setting the minute of the real time clock)

Set minute(0 up to 59) using arrow keys   ↓ Setting is shown in display 2.

Press several times key **EXIT** ↓ or wait for 120 seconds

Controller returns to normal display.

11. Performance in case of failures

11.1 Performance after power failure

Power failure during fixed-value operation (Normal Display):

The entered parameters remain saved. After power returns operation continues with the set parameters.

Power failure during program operation:

After the power returns, program course continues with the set-points that have been reached previously during program operation.

11.2 Alarm messages

Alarm messages, e.g. "RANGE ERROR CH1" in case of sensor rupture, are shown in Display 2 only in Normal Display.

A buzzer can be activated / deactivated in the user level (chap. 10). It can be reset by pressing the **EXIT** button. The alarm text shown in Normal Display goes off only if the cause of the alarm does not exist any longer.

12. Safety device class 2 (DIN 12880)

The safety device protects the vacuum drying oven, its environment and the charging material from exceeding the maximum permissible temperature.

Please observe the guideline BGI/GUV-I 850-0 on safe working in laboratories (formerly BGR/GUV-R 120 or ZH 1/119 laboratory guidelines issued by the employers' liability insurance association) (for Germany).

In the event of a fault in the temperature controller, the safety device (2) **permanently** turns off the vacuum drying oven. This status is reported visually by the indicator lamp (2a).

Check the operation of the safety device (2) by moving it slowly counter-clockwise until it is turned off. The safety device cut-off is reported visually by the indicator lamp (2a).

Then release the safety device by pressing the reset button (2b), and turn on the VD vacuum drying oven as described previously.




Figure 11: Temperature safety device class 2

Function:

The safety device is functionally and electrically independent of the temperature control device and turns off the unit at all poles.

If you turn the control knob (2) to its end-stop (position 10), the safety device will protect the appliance. If you set it to a temperature a little above the set-point temperature, it will protect the charging material.

If the safety device has turned off the oven, identifiable by the red alarm lamp (2a) lighting up, proceed as follows:

- Disconnect the oven from the power supply
- Have an expert examine and rectify the cause of the fault
- Release the safety device by pressing the reset button (2b)
- Restart the oven as described in chap. 5.

Adjustment:

To check the response temperature of the safety device, turn on the chamber and set the desired set point on the temperature controller.

The scale division from 1 to 10 corresponds to the temperature range from 30° / 86°F up to 320 °C / 608°F and serves as a setting aid.

- Turn the control knob (2) of the safety device using a coin to its end-stop (position 10) (unit protection).
- When the set point is reached, turn back the control knob (2) until its trip point (turn it counter-clockwise) is reached.
- The red alarm lamp (2a) lighting up identifies the trip point; and the reset button (2b) pops out.
- The optimum setting of the safety device is obtained by turning the knob clockwise by approx. one graduation mark on the scale.
- Push the reset button (2b) in again.




Figure 12: Setting the safety device class 2



The unit is only active when the reset button (2b) is pushed in.

When the safety device responds, the red alarm lamp (2a) illuminates, the reset button (2b) pops out, and the oven is turned off permanently at all poles.



Check the setting regularly and adjust it following changes of the set-point or charge.

13. Reference measurements. Checking the temperature in the inner chamber


The controller display was adjusted in the factory to the temperature in the center of the usable volume (chap. 20.1). The sensor probe of the reference measuring device was connected tightly to an expansion rack positioned in the middle of the unit.


Checking the controller display

- Conduct the reference sensor into the inner chamber through the measuring port (17). The port must be largely vacuum tight to enable a typical operation vacuum for the calibration. For a high vacuum, use a measuring access port. Usually, a silicone plug with a hole for the sensor wire is sufficient.
- Fix the sensor to the center of an expansion rack in the middle of the useable volume with adhesive aluminum tape or thermal conductive paste to ensure sufficient thermal conductivity.
- Perform the measurement in a thermally stable condition with 3 expansion racks and empty oven.
- Equilibrating time: at least 12 hours.

Checking the spatial temperature exactitude

- Fix at least 9 sensor probes on 3 racks with adhesive aluminum tape or thermal conductive paste to ensure sufficient thermal conductivity
- The distance of the sensor probes to all inner chamber walls must be at least 10% of the corresponding inner chamber dimension (see DIN 12880).
- Perform the measurement in a thermally stable condition with 3 expansion racks and empty oven.
- Response time: at least 12 hours.

	Do NOT use the temperature probe of the reference measurement device without any contact to the expansion rack, i.e., do NOT measure vacuum values!
---	---

	In case the temperature probe is a thermo element, mount it so it is electrically insulated from the rack.
---	--

If you note an excessive divergence between the controller and reference temperatures, please contact BINDER Service to calibrate the temperature controller.

14. Commissioning the vacuum

With regard to operation, please observe the guideline BGI/GUV-I 850-0 on safe working in laboratories (formerly BGR/GUV-R 120 or ZH 1/119 laboratory guidelines issued by the employers' liability insurance association) (for Germany).

Starting situation: The vacuum source is connected and ready for operation.

For the vacuum module with chemical membrane pump option, see chap. 16.3 and 16.4.

14.1 Evacuation

- VD 23: Close the air/gas valve (4).
- VD 53 and VD 115: Close the aeration valve (5) and the fine dosing valve for inert gas (6).
- Turn on the vacuum pump.
- Put the lever of the vacuum shut off valve (8) to "ON" position (valve open).
- Monitor the internal pressure on the pressure display (3). The analog manometer displays the running evaporation respectively the end of the drying procedure. The scale of the manometer (3) refers to an ideal ambient pressure of 1013 mbar / 29.9 inHg. Tolerance: 50 mbar / 37.5 mm Hg (Torr) / 1.48 inch Hg (2.5% of the final scale value + reading precision). The optional digital pressure display (chap. 16.5) offers an absolute scale.
- When the desired end vacuum is obtained, turn the VDL vacuum shutoff valve (8) to the "OFF" position (valve closed). The reached vacuum is now maintained.





Figure 13: Manometer display

	The permissible end vacuum is 10^{-2} mbar / 0.0003 inHg.
---	---

14.2 Breaking the vacuum (flooding)



When the drying procedure is complete, the vacuum in the inner container is broken (flooded).

- VD 23: open air/gas valve (4)
- VD 53 and VD 115: open aeration valve (5) and fine dosing valve for inert gas (6)

Fresh air is introduced into the lower part of the rear panel of the inner chamber and is evenly distributed in the inner chamber. This supply of fresh air by under-flooding prevents turbulence of pulverized drying material.

14.3 Operation with inert gas


When operating the VD vacuum drying oven with inert gas, correctly follow the technical ventilation measures, as described in the guideline BGI/GUV-I 850-0 on safe working in laboratories (formerly BGR/GUV-R 120 or ZH 1/119 laboratory guidelines issued by the employers' liability insurance association) (for Germany).

	 WARNING
<p>Release of inert gas.</p> <p>Danger of poisoning.</p> <ul style="list-style-type: none"> ➤ Ensure technical ventilation measures. ➤ When decommissioning the VD vacuum drying oven, shut off the inert gas valve (4) or (6). 	

Install a pressure reducer for inert gas operation. Set the pressure reducer to a pressure slightly above ambient pressure. Ensure that the pressure reducer will open. Do not change this setting in order to avoid perturbation inside the oven and release of big quantities of inert gas after flooding the VD.

Following evacuation, an inert gas, e.g., nitrogen, is led into the inner chamber via the air/gas valve (4) (VD 23) or the fine dosing valve for inert gas (6) (VD 53, VD 115), until pressure compensation with the atmosphere occurs. Depending on the individual application, you can perform a second evacuation and repeat the inert gas flooding.

When the inert gas fine dosing valve is open, a maximum of approx. 0.6 m³/h gas flows into the inner chamber. The introduction of inert gas by under-flooding in the lower region of the inner chamber rear wall and the extraction at the inner chamber ceiling allow an effective inert gas flushing.

	<p>If the oven is charged to full capacity, depending on the load, deviations from the specified heating up times may occur.</p>
---	--

15. Switching contacts 24V DC via operation lines

Operation lines 1 and 2 are used to switch on and off electrical equipment (nominal voltage 24 V DC, current consumption max. 0.4 A). The switching contacts are connected with two DIN sockets (13) and (14) at the unit rear.

The operation lines permit switching on and off the switching contacts by program control. You can program the operation lines in "Fixed value entry mode" (chap. 6) as well as in the "Program editor" (chap. 8.2) via the operation lines (switching state "0" = Off, switching state "1" = On).

Set the positions “100” or “010” or “110” or “000” as follows:

Operation line 1	Operation line 2	Operation line 3 (no function)	
1	0	0	Operation line 1 ON
0	1	0	Operation line 2 ON
1	1	0	Operation lines 1 and 2 ON
0	0	0	Operation line OFF

You can combine any of the switching states of the operation lines. You can recognize switching state ON when the LED (7b) for operation line 1 and the LED (7c) for operation line 2 light up.

Operation lines 1 and 2 are designed for the following options:

- Operation line 1: Program controlled evacuation (option “vacuum module with pump”, see chap. 16.3)
- Operation line 2: Program controlled venting (option “program controlled venting”, available via BINDER INDIVIDUAL customized solutions)

You can connect any other device or electrical equipment with a nominal tension of 24 V DC and a current consumption of max. 0.4 A.

Establish the connection via the DIN sockets at the rear of the oven:




Figure 14: Pin configuration of the DIN sockets (15) and (16)




Figure 15: Legend at the DIN socket (15)





Figure 16: Legend at the DIN socket (16)

A suitable DIN plug is enclosed.

Maximum loading capacity of the switching contacts: 0.4 Amp.

	CAUTION
	<p>Overloading the switching contacts.</p> <p>Damage to the switching contacts and connection sockets.</p> <ul style="list-style-type: none"> ⊘ DO NOT exceed the maximum switching load of 0.4 Amp. ⊘ DO NOT connect any device with a higher load. ➤ ONLY connect devices with a nominal tension of 24 V DC.

16. Options

16.1 Connection kit VD (option)

The VD connection kit VD (Art. no. 8012-0146) consists of:

- Aluminum straining ring DN10/16
- Outer centering ring DN10/16
- Small flange with hose tules DN16/8
- 2.5 m / 98.4 in caoutchouc hose 6/12 mm
- 2 hose clamps



Figure 17: VD connection kit VD

16.2 Vacuum module empty (without pump) (option)



The mounting instructions Art. no. 7001-0137 supplied with the vacuum module describe how to mount the VD vacuum drying oven onto the vacuum module and installing the suction line into the vacuum module.

A switch (18) is located at the front of the vacuum module for switching a vacuum pump via the socket (19) permanently fitted in the vacuum module.




Figure 18: Vacuum module with the switch and socket for the vacuum pump

(18) Switch for the vacuum pump

(19) Socket for the vacuum pump

Maximum admissible load of the socket:

Standard 230 V / 50 Hz - 16 Amp

CUL-version 120 V / 60 Hz - 13 Amp



With CUL-version, connect only a UL listed vacuum pump with ratings of 120 V AC, 60 Hz, and less or equal 12 Amp, 0.5 HP.





Connection to a vacuum source

Connect the vacuum connection (13) (small flange DN 16) at the rear of the unit at the top to a vacuum pump or to a domestic vacuum system via a vacuum hose or a fixed vacuum pipe.

When using a vacuum hose, we recommend using the BINDER connection kit VD Art. no. 8012-0146 (chap. 16.1. The module has an appropriate hose outlet at the back.


Figure 19: VD 53 with option "Vacuum module", mounted, and installed vacuum hose

	<h3>CAUTION</h3>
	<p>Technical defects due to excessive negative pressure.</p> <p>Danger of implosion.</p> <p>Damage to the unit.</p> <ul style="list-style-type: none"> ⊗ The end vacuum must NOT fall below the permissible level of 10^{-2} mbar / 0.0003 inHg. ➤ Install the pump according to the permissible end vacuum or limit the end vacuum via a vacuum controller.
	<h3>WARNING</h3>
	<p>Release of extracted vapors.</p> <p>Danger of injury.</p> <p>Damage to oven and pump by corrosion.</p> <ul style="list-style-type: none"> ➤ Remove the extracted vapors from the module via a suitable hose into e.g., a fume extractor facility. ➤ Connect the hose to the vacuum pump outlet.

16.3 Vacuum module with chemical membrane pump VP 1.1 or VP 2.1 (option)



The mounting instructions Art. no. 7001-0137 supplied with the vacuum module describe how to mount the VD vacuum drying oven onto the vacuum module and installing the suction line into the vacuum module.



- (15) DIN socket (operation line 2) for option program controlled venting
- (16) DIN socket (operation line 3) for option vacuum module with pump
- (20) DIN socket at the vacuum module for option vacuum module with pump
- (21) Power supply at vacuum module
- (22) Fuse

Figure 20: VD 53 with option "Vacuum module with chemical membrane pump", mounted

A switch (18) is located at the front of the vacuum module for switching the vacuum pump via the socket (19) permanently fitted in the vacuum module.




Figure 21: Vacuum module with switch and socket for vacuum pump

- (18) Switch for vacuum pump
- (19) Socket for vacuum pump

Maximum admissible load of the socket:

Standard **230 V / 50 Hz - 16 Amp**


CUL-version **120 V / 60 Hz - 13 Amp**


	With CUL-version, connect only a UL listed vacuum pump with ratings of 120 V AC, 60 Hz, and less or equal 12 Amp, 0.5 HP.
---	---



The MZ2C or MD4C membrane pump is located in a separate transport packaging. With this option, the mounted system, consisting of VD and vacuum module, has a total of two power supply leads.


Installation of the supplied vacuum pump


- The vacuum drying oven is mounted onto the vacuum module as described in the mounting instructions Art. No. 7001-0137.
- The suction line is installed to the vacuum module as described in the mounting instructions Art. No. 7001-0137.
- When the pump is removed from the original packaging, place it in the vacuum module.
- Push the pre-installed suction line onto the opening of the vacuum pump (13) hose olive above the suction-side condensate piston).
- Insert the shockproof plug of the vacuum pump into the permanently installed socket (19) in the vacuum module.
- Push a suitable hose for removing the extracted vapors from the module onto the pressure-side connection of the vacuum pump (hose olive at the back of the emission condenser at the top).
- Lead the hose end into an exhaust air unit.
- Connect DIN socket (20) at the vacuum module to DIN socket (16) at the unit rear via the supplied 1.2 m cable.

	As soon as the connection between DIN sockets (16) and (20) is established, it is not possible to manually switch the pump via switch (18).
---	---

	To permit switching on and off the pump via operation line 1, keep switch (18) switched on (position I).
---	--

	 WARNING
	<p>Release of extracted vapors.</p> <p>Danger of injury.</p> <p>Damage to oven and pump by corrosion.</p> <ul style="list-style-type: none"> ➤ Remove the extracted vapors from the module via a suitable hose into e.g., a fume extractor facility. ➤ Connect the hose to the vacuum pump outlet (hose olive at the back of the emission condenser at the top).


	You can connect a laboratory cooling system to the emission condenser of the vacuum pumps MZ2C or MD4C.
---	---

	For operating the chemical membrane pumps MZ2C and MD4C, please refer to the enclosed pump manufacturer's operating manual.
---	---

Observe the permitted gas temperature. The following values refer to the maximum ambient temperature of the pump of 40 °C / 104°F.

Operation condition	Inlet pressure	Permitted gas temperature
Continuous operation	> 100 mbar / 2.95 inHg (high gas load)	+10 °C to +40 °C / 50°F to 104°F
Continuous operation	< 100 mbar / 2.95 inHg (low gas load)	0 °C to +60 °C / 32°F to 140°F
Short-time operation (< 5 min.)	< 100 mbar / 2.95 inHg (low gas load)	-10 °C to +80 °C / 50°F to 176°F


Do not exceed the permitted gas inlet temperature. An excessive gas inlet temperature may diminish the lifetime of the pump.

	CAUTION
	<p>Exceeding the gas inlet temperature.</p> <p>Damage to the vacuum pump.</p> <ul style="list-style-type: none"> ⊘ Do NOT exceed the set-point temperature of the permitted gas temperature. ➤ With higher set-point temperature, take appropriate measures to cool down the sucked-in gas before its entry to the vacuum pump


16.4 Vacuum module with speed controlled chemical membrane pump VP 3.1 and vacuum controller (option)


This option consists of:


- Pump stand PC 3004 Vario with speed-controlled chemical vacuum pump MD4C Vario (suction power 4.6 m³/h) and vacuum controller CVC3000
- Vacuum module with accompanying mounting instructions

	<p>The mounting instructions 7001-0137 delivered with the vacuum module describe mounting the vacuum drying oven onto the vacuum module and installing the suction line to the vacuum module.</p>
---	---

The chemical vacuum pump and the vacuum controller are delivered ready-assembled as a vacuum pump stand PC 3004 Vario in separate transport packaging. For installation and connection, see chap. 16.3.

	<p>Do NOT connect DIN sockets (16) and (20) when using this option.</p>
---	---


	<p>To permit switching on and off the pump, keep switch (18) switched on (position I).</p>
---	--

	<p>For operating the chemical membrane pump MD4C Vario, please refer to the enclosed pump manufacturer's operating manual.</p>
---	--


Observe the permitted gas temperature. The following values refer to the maximum ambient temperature of the pump of 40 °C / 104°F.

Operation condition	Inlet pressure	Permitted gas temperature
Continuous operation	> 100 mbar / 2.95 inHg (high gas load)	+10 °C to +40 °C / 50°F to 104°F
Continuous operation	< 100 mbar / 2.95 inHg (low gas load)	0 °C to +60 °C / 32°F to 140°F
Short-time operation (< 5 min.)	< 100 mbar / 2.95 inHg (low gas load)	-10 °C to +80 °C / 50°F to 176°F

Do not exceed the permitted gas inlet temperature. An excessive gas inlet temperature may reduce the pump's lifetime.

	CAUTION
	<p>Exceeding the gas inlet temperature.</p> <p>Damage to the vacuum pump.</p> <ul style="list-style-type: none"> ⊘ Do NOT exceed the set-point temperature of the permitted gas temperature. ➤ With higher set-point temperature, take appropriate measures to cool down the sucked-in gas before its entry to the vacuum pump

Programming of descendant pressure cycles as well as documentation of pressure data are possible via the RS 232 serial interface of the vacuum controller CVC 3000 by use of the BINDER communication software APT-COM™ DataControlSystem (option, chap. 16.8).

	<p>In combination with the option object temperature measurement a T-formed connection tube adapter (small flange DN16 (Art. No. 6009-0060) NOT included) is necessary to connect the pressure sensor of the vacuum controller to the measuring access port.</p>
---	--

Settings of the vacuum controller for control via APT-COM™:


Following settings are necessary to set the vacuum controller to remote control via its RS232 interface and to enable the venting valve:

Setting for remote control:

- With the MODE key select the menu "Configuration".
- Select the menu point "RS – 232" with the selection knob and set the setting "Remote" to "On".
- Set the Baud rate to 9600.

Configuration	
Adjustment	936 mbar
RS – 232 . . .	
Sensors . . .	
Display . . .	
Autostart	Off
Defaults	Cancel
----- Back -----	

RS - 232	
Baud	9600
Parity	8 - N - 1
Handshake	RTS - CTS
Remote	On
----- Back -----	

	<p>The vacuum controller can no longer be operated manually in this mode.</p>
---	---

Resetting to manual operation:

Turn off the vacuum controller with the ON/OFF key. When turning it on again, press down simultaneously the ON/OFF key and the selection knob. Then select the menu point "RS - 232" with the selection knob and set the setting "Remote" to "Off".



RS - 232	
Baud	9600
Parity	8 - N - 1
Handshake	RTS - CTS
Remote	Off
----- Back -----	

16.5 Digital pressure display (option)

With this option, a digital display indicates the internal pressure with the accuracy of 1 mbar / 0.03 inHg. The pressure is measured by a permanently fitted internal pressure sensor.

A service engineer can calibrate and internally adjust the digital pressure display.




Figure 22: Digital display of internal pressure

16.6 Additional measuring channel for digital object temperature display with flexible Pt 100 temperature sensor (option)

The object temperature display permits recording the object temperature directly on or in the drying material. The object temperature is measured via a flexible Pt100 sensor inside the inner chamber. The sensor needs to be in thermally conducting contact with the charging material. It can be plunged into humid charging material up to the length of its protecting tube.

The object temperature is indicated on Display 2 of the RD3 controller.

Display 1 shows	e.g. 24.6 °C	(actual temperature value)
Display 2 shows	24.4 15:41	(actual object temperature in °C, actual time)



Figure 23:
Standard Display without the
object temperature display option



Figure 24:
Display with the
object temperature display option

The object temperature data is put out combined with the temperature data of the temperature controller to the RS 422 interface as a second measuring channel. This permits recording by the BINDER documentation software APT-COM™ DataControlSystem (option, chap. 16.8).

Assembly and connection of the object temperature recording

- Insert the Pt 100 temperature sensor from the rear through the measuring connection (17) into the inner chamber.
- The 3 contacts of the Pt 100 sensor are conducted outside via a measuring access port. From there, establish the connection to the DIN socket at the top of the rear panel of the unit marked "Pt100".




Figure 25: Measuring connection (17) with measuring access port



Figure 26: Pt100 connection (14) at the rear of the unit

Technical data of the Pt 100 sensor:

- Three-wire technique
- Class B (DIN EN 60751)
- Temperature range up to 300 °C / 572°F
- Stainless steel protective tube, length 45 mm / 1.77 in, stainless steel material no. 1.4501

16.7 Measuring access port vacuum 9 poles (option)

The measuring access port allows creating electrical connections for low voltages or sensors between the exterior and interior of the VD vacuum drying oven. A 9 poles plug for the outside is included.






Figure 27: Measuring connection (17) with measuring access port and supplied plug

Connections at the measuring access port

- At the inner side of the measuring access port you can solder up to 9 cables. The inside connections must be insulated against each other and against ground. Use 300 °C / 572°F solder.
- The 9 contacts are conducted outside via the measuring access port. You can use them to connect a device via the delivered plug.

Maximum load capacity of the switching contacts: 42 V AC/DC - 2A

	 DANGER
	<p>Electrical hazard.</p> <p>Danger of death.</p> <p>Damage to switching contacts and connection socket.</p> <ul style="list-style-type: none"> ⊘ Do NOT exceed the maximum switching load of 42 AC/DC – 2Amp. ⊘ Do NOT connect any devices with a higher load capacity. ➤ Insulate the inside connections against each other and against ground. Use 300 °C / 572°F solder.

16.8 Communication software APT-COM™ 3 DataControlSystem (option)

The unit is regularly equipped with a serial interface RS 422 (9) that can connect the BINDER communication software APT-COM™ 3 DataControlSystem. The actual temperature value is given at adjustable intervals. Programming can be performed graphically via PC. Up to 30 chambers with RS 422 interface can be cross-linked. For further information, refer to the operating manual of the BINDER communication software APT-COM™ 3.



Confirm that the interface mode is correctly set to “Modbus” in the user level (chap. 10).

Pin allocation of the RS 422 interface (9):

pin 2:	RxD (+)
pin 3:	TxD (+)
pin 4:	RxD (-)
pin 5:	TxD (-)
pin 7:	GND

16.9 Protocol printer (available via BINDER INDIVIDUAL customized solutions)

Connect the protocol printer using the VD interface RS 422 (9) via an interface converter RS422 / RS232.



Make sure that the interface mode is correctly set to “Printer” in the user level (chap. 10).

The actual temperature values are put out regularly with fixed formatting.



See “Manual for Setting Matrix Printer Epson LX-300+“, Art. No. 7001-0041.

Printout: one printed line for each print interval with relative time stamp, temperature value with one decimal point, curve representation. In every 5th line the set print interval “Ptime” in minutes is noted. The printer interval is set in the user level (chap. 10).



Figure 28: Protocol printer

Example:

Temp.: 34.7	*
Temp.: 35.6	*
Temp.: 32.8	*
Temp.: 30.1	*
Ptime : 001.	*
Temp.: 27.4	*
Temp.: 26.9	*
Temp.: 26.6	*
Temp.: 26.4	*
Ptime : 001.	*
Temp.: 26.2	*

In this example the print interval is set to 1 min, i.e., every minute a new temperature value is printed.






In conjunction with the specified print interval, real-time reference can be achieved by noting down the starting time of recording.


Interface configuration:	Baud rate:	9600
	Stop bit:	1
	Parity:	none


17. Maintenance, cleaning, and service

17.1 Maintenance intervals, service

 	<div style="background-color: red; color: white; padding: 5px; text-align: center;">  DANGER </div> <p>Electrical hazard. Danger of death.</p> <ul style="list-style-type: none"> Ø The unit must NOT become wet during operation or maintenance work. Ø Do NOT remove the rear panel of the unit. ➤ Disconnect the unit before conducting maintenance work. Disconnect the power plug. ➤ Ensure all maintenance work is conducted by licensed electricians or experts authorized by BINDER.
---	--

Ensure regular maintenance work is performed at least once a year.

	<p>The warranty becomes void if maintenance work is conducted by non-authorized personnel.</p>
---	--





	<p>Replace the door gasket only when cold. Otherwise, the door gasket may become damaged.</p>
--	---

We recommend taking out a maintenance agreement. Please consult BINDER Service.

BINDER telephone hotline:	+49 (0) 7462 2005 555
BINDER fax hotline:	+49 (0) 7462 2005 93555
BINDER e-mail hotline:	service@binder-world.com
BINDER service hotline USA:	+1 866 885 9794 or +1 631 224 4340 (toll-free in the USA)
BINDER service hotline Spain	+34 9492 677 23
BINDER service hotline Asia Pacific:	+852 39070500 or +852 39070503
BINDER service hotline Russia and CIS	+7 495 98815 17
BINDER Internet website	http://www.binder-world.com
BINDER address	BINDER GmbH, post office box 102, D-78502 Tuttlingen

International customers, please contact your local BINDER distributor.

17.2 Cleaning and decontamination


  	<div style="background-color: red; color: white; padding: 5px; text-align: center;">  DANGER </div> <p>Electrical hazard. Danger of death.</p> <ul style="list-style-type: none"> Ø Do NOT spill water or cleaning agents over the inner and outer surfaces. ➤ Disconnect the unit before cleaning. Disconnect the power plug. ➤ Completely dry the appliance before turning it on again.
---	---


Cleaning


Disconnect the oven from the power supply before cleaning. Disconnect the power plug.


Wipe the surfaces with a moistened towel. In addition, you can use the following cleaning agents:

Exterior surfaces, inner chamber, door gaskets	Standard commercial cleaning detergents free from acid or halogenides. Alcoholic solutions. We recommend using the neutral cleaning agent Art. No. 1002-0016.
Expansion racks, rack holders	Standard commercial cleaning detergents free from acid or halogenides, no salt solution or chlorinated solvents. We recommend using the neutral cleaning agent Art. No. 1002-0016.
Instrument panel	Standard commercial cleaning detergents free from acid or halogenides. We recommend using the neutral cleaning agent Art. No. 1002-0016.

	For surface protection, perform cleaning as quickly as possible. After cleaning completely remove cleaning agents from the surfaces with a moistened towel.
---	--


	Soapsuds may contain chlorides and must therefore NOT be used for cleaning.
---	---

	CAUTION
	Danger of corrosion. Damage to the unit. ⊘ Do NOT use cleaning detergents with acids or halogenides.

	We recommend using the neutral cleaning agent Art. No. 1002-0016 for a thorough and mild cleaning. Any corrosive damage that may arise following use of other cleaning agents is excluded from liability by BINDER GmbH.
---	---

Decontamination

Vacuum drying ovens VD can be hot air sterilized at 190 °C / 374°F for at least 30 minutes. Remove any inflammable goods from the interior before.

	With every decontamination method, always use adequate personal safety controls.
---	--

17.3 Sending the unit back to BINDER GmbH

If you return a BINDER product to us for repair or any other reason, we will only accept the product upon presentation of an authorization number that has previously been issued to you. An authorization number will be issued after receiving your complaint either in writing or by telephone **prior** to your sending the BINDER product back to us. The authorization number will be issued following receipt of the information below:

- BINDER product type and serial number
- Date of purchase
- Name and address of the dealer from which you bought the BINDER product
- Exact description of the defect or fault
- Complete address, contact person and availability of that person
- Exact location of the BINDER product in your facility
- A contamination clearance certificate (chap. 21) must be faxed in advance


The authorization number must be applied to the packaging in such a way that it can be easily recognized or be recorded clearly in the delivery documents.



For security reasons we cannot accept a unit delivery if it does not carry an authorization number.

18. Disposal

18.1 Disposal of the transport packing

Packing element	Material	Disposal
Straps to fix packing on pallet	Plastic	Plastic recycling
Wooden transport box (option)	Non-wood (compressed matchwood, IPPC standard)	Wood recycling
with metal screws	Metal	Metal recycling
Pallet	Solid wood (IPPC standard)	Wood recycling
with foamed plastic stuffing	PE foam	Plastic recycling
Shipping box	Cardboard	Paper recycling
with metal clamps	Metal	Metal recycling
Top cover	Cardboard	Paper recycling
Removal aid (size 115)	Cardboard	Paper recycling
	Plastic	Plastic recycling
Edge protection	Styropor® or PE foam	Plastic recycling
Protection of doors	PE foam	Plastic recycling
Bag for operating manual	PE foil	Plastic recycling
Insulating air cushion foil (packing of optional accessories)	PE foil	Plastic recycling

If recycling is not possible, all packing parts can also be disposed of with normal waste.

18.2 Decommissioning

- Turn off the main power switch (1) (position 0).



When turning off the main power switch (1), the stored parameters remain saved.

- Close the inert gas supply:

VD23: Close the fine dosing valve (4) for inert gas / ambient air supply.

VD53, VD115: Close the fine dosing valve (6) for inert gas supply.

Through the open inert gas connection, inert gas can enter the vacuum drying oven and escape into the ambient air.



WARNING

Release of inert gas.

Danger of poisoning.

- When decommissioning the VD vacuum drying oven, turn off the inert gas supply at the inert gas valve (4) or (6).

- Turn off the vacuum pump. Break the vacuum as described in chap. 14.2
- Disconnect the oven from the power supply. Pull the power plug.
- Remove the vacuum connection (chap. 4.3).
- Remove the inert gas connection and the pressure reducer (chap. 4.4).


Temporal decommissioning: See indications for appropriate storage, chap. 3.3.

Final decommissioning: Dispose of the unit as described in chap. 18.3 to 18.5.


18.3 Disposal of the unit in the Federal Republic of Germany

According to directive 2002/96/EC of the European Parliament and of the Council on waste electrical and electronic equipment (WEEE), BINDER devices are classified as "monitoring and control instruments" (category 9) only intended for professional use". They must not be disposed of at public collecting points.


The vacuum drying oven VD bears the symbol for the marking of electrical and electronic equipment manufactured / placed on the market in the EC after 13 August 2005 and be disposed of in separate collection according to the directive 2002/96/EC on waste electrical and electronic equipment (WEEE) and German national law for electrical and electronic equipment (Elektro- und Elektronikgerätegesetz, ElektroG). WEEE marking: crossed-out wheeled bin with solid bar under. A significant part of the materials must be recycled in order to protect the environment.






At the end of the device's service life, have the device disposed of according to the German national law for electrical and electronic equipment (Elektro- und Elektronikgerätegesetz, ElektroG) from 23 March 2005, BGBl. I p. 762 or contact BINDER Service who will organize taking back and disposal of the unit according to the German national law for electrical and electronic equipment (Elektro- und Elektronikgerätegesetz, ElektroG) from 23 March 2005, BGBl. I p. 762.

	CAUTION
	<p>Violation against existing law.</p> <p>Ø Do NOT dispose of BINDER devices at public collecting points.</p> <p>➤ Have the device disposed of professionally at a recycling company that is certified according to the German national law for electrical and electronic equipment (Elektro- und Elektronikgerätegesetz, ElektroG) from 23 March 2005, BGBl. I p. 762.</p> <p style="text-align: center;"><i>or</i></p> <p>➤ Instruct BINDER Service to dispose of the device. The general terms of payment and delivery of BINDER GmbH apply, which were valid at the time of purchasing the unit.</p>

Certified companies disassemble waste (used) BINDER equipment in primary substances for recycling according to directive 2002/96/EC. The devices must be free from toxic, infectious or radioactive substances in order to eliminate any health hazards to the employees of the recycling companies.


	<p>Prior to handing the unit over to a recycling company, it is the user's responsibility that it is free from toxic, infectious or radioactive substances.</p> <ul style="list-style-type: none"> • Prior to disposal, clean all introduced or residual toxic substances from the unit. • Prior to disposal, disinfect the unit from all sources of infection. Be aware that sources of infection may also be located outside the inner chamber. • If you cannot safely remove all toxic substances and sources of infection from the unit, dispose of it as "special" waste according to national law. • Fill out the contamination clearance certificate (chap. 21) and enclose it with the unit.
---	--

 	<div style="background-color: orange; text-align: center; padding: 5px;">  WARNING </div> <p>Contamination of the device with toxic, infectious or radioactive substances.</p> <p>Danger of intoxication.</p> <p>Danger of infection.</p> <ul style="list-style-type: none"> Ø NEVER take a unit contaminated with toxic substances or sources of infection for recycling according to directive 2002/96/EC. ➤ Prior to disposal, remove all toxic substances and sources of infection from the unit. ➤ A unit from which all toxic substances or sources of infection cannot be safely removed must be considered as "special" waste according to national law. Dispose of it accordingly.
--	---


18.4 Disposal of the unit in the member states of the EC except for the Federal Republic of Germany

According to directive 2002/96/EC of the European Parliament and of the Council on waste electrical and electronic equipment (WEEE), BINDER devices are classified as "monitoring and control instruments" (category 9) only intended for professional use". They must not be disposed of at public collecting points.


The vacuum drying oven VD bears the symbol for the marking of electrical and electronic equipment manufactured / placed on the market in the EC after 13 August 2005 and be disposed of in separate collection according to the directive 2002/96/EC on waste electrical and electronic equipment (WEEE). WEEE marking: crossed-out wheeled bin with solid bar under.






At the end of the device's service life, notify the distributor who sold you the device, who will take back and dispose of the unit according to the directive 2002/96/EC of 27 January 2003 on waste electrical and electronic equipment (WEEE).



	<div style="background-color: yellow; text-align: center; padding: 5px;"> CAUTION </div> <p>Violation against existing law.</p> <ul style="list-style-type: none"> Ø Do NOT dispose of BINDER devices at public collecting points. ➤ Have the device disposed of professionally at a recycling company that is certified according to conversion of the directive 2002/96/EC into national law. <li style="padding-left: 20px;"><i>or</i> ➤ Instruct the distributor who sold you the device to dispose of it. The agreements apply that were agreed with the distributor when purchasing the unit (e.g. his general terms of payment and delivery). ➤ If your distributor is not able to take back and dispose of the unit, please contact BINDER service.
---	--

Certified companies disassemble waste (used) BINDER equipment in primary substances for recycling according to directive 2002/96/EC by. The devices must be free from toxic, infectious or radioactive substances in order to eliminate any health hazards to the employees of the recycling companies.

	<p>Prior to handing the unit over to a recycling company, it is the user's responsibility that it is free from toxic, infectious or radioactive substances.</p> <ul style="list-style-type: none"> • Prior to disposal, clean all introduced or residual toxic substances from the unit. • Prior to disposal, disinfect the unit from all sources of infection. Be aware that sources of infection may also be located outside the inner chamber. • If you cannot safely remove all sources of infection and toxic substances from the unit, dispose of it as "special" waste according to national law. • Fill out the contamination clearance certificate (chap. 21) and enclose it with the unit.
---	--

 	<div style="background-color: orange; text-align: center; padding: 5px;">  WARNING </div> <p>Contamination of the device with toxic, infectious or radioactive substances.</p> <p>Danger of intoxication.</p> <p>Danger of infection.</p> <p>Ø NEVER take a unit contaminated with toxic substances or sources of infection for recycling according to directive 2002/96/EC.</p> <ul style="list-style-type: none"> ➤ Prior to disposal, remove all toxic substances and sources of infection from the unit. ➤ A unit from which all toxic substances or sources of infection cannot be safely removed must be considered as "special" waste according to national law. Dispose of it accordingly.
--	---

18.5 Disposal of the unit in non-member states of the EC

 	<div style="background-color: yellow; text-align: center; padding: 5px;"> CAUTION </div> <p>Alteration of the environment.</p> <ul style="list-style-type: none"> ➤ For final decommissioning and disposal of the vacuum drying oven, please contact BINDER Service. ➤ Follow the statutory regulations for appropriate, environmentally friendly disposal.
--	---

The main board of the vacuum drying oven includes a lithium cell. Please dispose of it according to national regulations.

19. Troubleshooting

Fault description	Possible cause	Required measures
General		
Unit permanently turned off.	No power supply.	Check connection to power supply.
	Wrong voltage.	Check power supply for voltage of 115V or 230V.
	Unit fuse has responded.	Check unit fuse.
	Safety device has turned off the oven.	Allow the oven to cool down the oven and press the “RESET” button. Check temperature set-point and setting of safety device (chap. 12). If appropriate, select suitable limit value.
	Safety device defective.	Contact BINDER Service.
	Controller defective.	
Heating		
Set-point temperature is not reached after specified time.	Unit door not properly closed.	Completely close unit door.
	Door gasket defective.	Replace door gasket,
	Controller not adjusted.	Calibrate and adjust controller.
Chamber heating permanently, set-point not held.	Controller defective.	Contact BINDER Service.
	Pt 100 sensor defective.	
	Semiconductor relay defective	
	Controller not adjusted.	Calibrate and adjust controller.
Chamber doesn’t heat up. LED (7a) “Heating active” lit.	Heating element defective.	Contact BINDER Service.
	Semiconductor relay defective.	
Chamber doesn’t heat up. LED (7a) “Heating active” not lit.	Safety device has turned off the oven.	Allow the oven to cool down the oven and press the “RESET” button. Check temperature set-point and setting of safety device (chap. 12). If appropriate, select suitable limit value.
	Semiconductor relay defective.	Contact BINDER Service.
	Controller defective.	
Deviations from the indicated heating-up times.	Oven fully loaded.	Charge the oven less or consider longer heating-up times.
Deviations from the temperature set-point in equilibrated state.	Invalid calibration	Use the delivered expansion racks only. Do NOT change between aluminum and stainless steel racks
Wrong temperature value measured during calibration.	Reference temperature sensor has insufficient contact to expansion rack.	Fix the reference temperature sensor with thermal conductive paste or adhesive aluminum tape.
	Leakage current when using a thermo element not electrically isolated.	Mount a thermo element electrically isolated from the rack.
Vacuum		
Vacuum not held.	Door gasket defective.	Replace door gasket,
	Safety glass panel defective.	Replace safety glass panel.
	Gaskets of small flange connections (universal eccentric ring) defective.	Replace gaskets of small flange connections.
	Inner tube connection leaky.	Contact BINDER Service.

Fault description	Possible cause	Required measures
Controller		
Program duration longer than programmed.	Inappropriate tolerances have been programmed.	For rapid transition phases, do NOT program tolerance limits in order to permit maximum heating speed.
Program stops one section too early.	Program line is incomplete.	When programming, define the end value of the desired cycle by adding an additional section with a section time of at least one minute (with setting "ramp").
Programs have been deleted.	Change from 2 programs to 1 program or vice-versa	When changing, ensure that the programs are no longer needed.
The controller returns to Normal Display from any level.	No button was pressed for more than 120 sec.	Repeat entries, enter the values rapidly.
Message RANGE ERROR CH1 in Normal Display in Display 2	Sensor rupture between sensor and controller	Contact BINDER Service.
Ramp temperature transitions are only realized as steps.	Set-point programming type set to "Step" in the User level (chap. 10).	Set the set-point programming type to setting "Ramp" in the User level (chap. 10).




Only qualified service personnel authorized by BINDER must perform repair. Repaired units must comply with the BINDER quality standards.

20. Technical description

20.1 Factory calibration and adjustment

This unit was calibrated and adjusted in the factory. Calibration and adjustment were performed using standardized test instructions, according to the QM DIN EN ISO 9001 system applied by BINDER (certified since December 1996 by TÜV CERT). All test equipment used is subject to the administration of measurement and test equipment that is also a constituent part of the BINDER QM DIN EN ISO 9001 systems. They are controlled and calibrated to a DKD-Standard at regular intervals.

Factory adjustment was done in the center of the usable volume and under vacuum conditions. the sensor is fixed in the middle of the expansion rack in a way ensuring good thermal conductivity (heat conduction). Measuring is performed in equilibrated state.

	CAUTION
	<p>Invalid calibration.</p> <ul style="list-style-type: none"> ⊘ Do NOT change between aluminum and stainless steel racks. ➤ Use the delivered expansion racks only.

20.2 VD technical Data

Unit size			23	53	115
External dimensions					
Vacuum oven	Width	mm / inch	515 / 20.28	634 / 24.96	740 / 29.13
	Height (incl. feet)	mm / inch	655 / 25.79	775 / 30.51	900 / 35.43
	Depth	mm / inch	500 / 19.69	550 / 21.65	670 / 26.38
Vacuum module (option)	Width	mm / inch	515 / 20.28	634 / 24.96	740 / 29.13
	Height	mm / inch	624 / 24.57	624 / 24.57	622 / 24.49
	Depth	mm / inch	500 / 19.69	550 / 21.65	670 / 26.38
Vacuum oven with option vacuum module	Width	mm / inch	515 / 20.28	634 / 24.96	740 / 29.13
	Height	mm / inch	1279 / 50.35	1400 / 55.12	1522 / 59.92
	Depth	mm / inch	500 / 19.69	550 / 21.65	670 / 26.38
Plus door handle, connections (depth)		mm / inch	100 / 3.94	100 / 3.94	100 / 3.94
Wall clearance at the back		mm / inch	100 / 3.94	100 / 3.94	100 / 3.94
Wall clearance at the side		mm / inch	135 / 5.31	135 / 5.31	135 / 5.31
Internal dimensions					
Width		mm / inch	285 / 11.22	400 / 15.75	506 / 19.92
Height		mm / inch	285 / 11.22	400 / 15.75	506 / 19.92
Depth		mm / inch	295 / 11.61	340 / 13.38	460 / 18.11
Interior volume		l / cu.ft.	23 / 0.8	53 / 1.9	115 / 4.1
Number of expansion racks (aluminum)		regular / max	2/4	2/5	2/6
Distance between the racks		mm / inch	53 / 2.09	62 / 2.44	68 / 2.68
Usable space per rack (width x depth)		mm / inch	234 x 280 / 9.21 x 11.02	349 x 320 / 13.74 x 12.60	455 x 440 / 17.91 x 17.32
Permissible load per rack		Kg / lbs	20 / 44	20 / 44	20 / 44
Permissible total load		Kg / lbs	35 / 77	45 / 99	65 / 143
Weight (empty)		Kg / lbs	63 / 139	95 / 209	153 / 337
Temperature data					
Temperature range approx. 15 °C / 27 °F above room temperature up to		°C / °F	200 / 392	200 / 392	200 / 392
Temperature fluctuation		± K	0.1	0.1	0.1
Temperature uniformity (variation) ¹⁾	at 100 °C / 212°F	± K	1.5	2	3,5
	at 200 °C / 392°F	± K	3	4.5	9
Heating up time ^{1) 2)}	to 100 °C / 212°F	min	65	80	95
	to 200 °C / 392°F	min	100	115	150
Vacuum data					
Vacuum connection with small flange		DN mm / inch	16 / 0.63	16 / 0.63	16 / 0.63
Measuring access port with small flange		DN mm / inch	16 / 0.63	16 / 0.63	16 / 0.63
Inert gas connection with flow-limiter Adapter with hose olive		Ø mm / inch	8 / 0.31	8 / 0.31	8 / 0.31
Permitted end vacuum		mbar / inHg	1x10 ⁻² / 0.0003	1x10 ⁻² / 0.0003	1x10 ⁻² / 0.0003
Leak rate		bar/h / inHg /h	1x10 ⁻² / 0.295	1x10 ⁻² / 0.295	1x10 ⁻² / 0.295

Unit size		23	53	115
Electrical data				
IP protection type according to EN 60529		IP 20	IP 20	IP 20
Nominal voltage ($\pm 10\%$) 50/60 Hz		V	230	230
Nominal power		kW	0.80	1.20
Unit fuse 5 x 20 mm / 250V / middle-time-lag (M)		Amp	10	10
Power plug		shock proof plug		
Power plug vacuum module (option)		shock proof plug		
Energy consumption	at 100 °C / 212°F	Wh/h	105	150
	at 200 °C / 392°F	Wh/h	280	445
Over-voltage category acc. to IEC 61010-1		II	II	II
Pollution degree acc. to IEC 61010-1		2	2	2

Electrical connection data cUL-version (for the USA and Canada)

Unit size		23	53	115
Electrical data				
Nominal voltage ($\pm 10\%$) 60 Hz / 1N		V	115	115
Nominal power		kW	0.80	1.20
Nominal current		A	7.0	10.5
Unit fuse 6.3 X 32 mm / 250V / super-time-lag TT		A	12.5	12.5
Power plug		NEMA	5-15P	5-15P
Power plug vacuum module (option)		NEMA	5-15P	5-15P
Over-voltage category acc. to IEC 61010-1		II	II	II
Pollution degree acc. to IEC 61010-1		2	2	2


Legend:

- 1) Values only in combination with aluminum racks
- 2) Time to reach 98% of the set point temperature

All technical data is specified for units with standard equipment at an ambient temperature of +25 °C / 77°F and a power supply voltage fluctuation of ± 10 . The temperature data is determined in accordance to BINDER factory standard following DIN 12880, observing the recommended wall clearances of 10% of the height, width and depth of the inner chamber.

All indications are average values, typical for units produced in series. We reserve the right to change technical specifications at any time.

20.3 Equipment and Options


	To operate the vacuum drying oven VD, use only original BINDER accessories or accessories / components from third-party suppliers authorized by BINDER. The user is responsible for any risk arising from using unauthorized accessories.
---	---

Regular equipment
Microprocessor program controller RD3 with LED display
Safety device cl.2 according to DIN 12880
RS 422 printer and communication interface with adjustable printing intervals
Fine-dosing aeration valve

Regular equipment (continued)
Inert gas connection with fine-dosing valve
Analog pressure display (manometer) (not with option digital pressure display)
Measuring connection (DN 16), rear
Safety glass panel
2 switching contacts 24V DC via operation lines
Intelligent adaptation of the heating power by soft heating-up function (selectable on-off)

Options / accessories		
Expansion racks, aluminum or stainless steel 1.4571		
FKM door gasket (temperature resistant up to 200 °C / 392°F)		
Additional measuring channel for digital object temperature display with flexible Pt 100 temperature sensor		
Digital pressure display (adjustable)		
Communication software APT-COM™ for logging and display of temperature data and networking up to 30 units with PC		
Protocol printer for numeric and graphic temperature documentation (BINDER Individual)		
2-channel pen recorder, external (BINDER Individual)		
Connection kit VD with various small flange parts		
Measuring access port vacuum 9 poles		
Vacuum module empty (without pump)		
Vacuum module with chemical membrane pump VP 1.1 (MZ2C) with separator and emission condenser, ready for connection		
• Ready to connect: Suction power	m ³ /h	2.0
• End vacuum	mbar / inHg	7 / 0.21
• Electrical connection (50-60 Hz)	V	115 / 230
Vacuum module with chemical membrane pump VP 2.1 (MD4C) with separator and emission condenser, ready for connection		
• Ready to connect: Suction power	m ³ /h	3.4
• End vacuum	mbar / inHg	1.5 / 0.04
• Electrical connection (50-60 Hz)	V	115 / 230
PC 3004 Vario: Vacuum module with speed controlled chemical membrane pump VP 3.1 (MD4C Vario) with separator and emission condenser including all necessary connection parts, <i>and</i> Digital vacuum controller CVC 3000 (measuring accuracy of ≤ 1mbar / 0.03 inHg) for accurate control of vacuum, with interface RS232 for APT-COM™ DataControlSystem software.		
• Suction power	m ³ /h	4.6
• End vacuum	mbar / inHg	1.5 / 0.04
• Electrical connection (50-60 Hz)	V	115 / 230
Program controlled venting (available via BINDER Individual)		
Factory calibration certificate		
Extension to factory calibration certificate (additional value)		
Factory calibration certificate for digital object temperature display		
Factory calibration certificate for digital pressure display		
Extension to factory calibration certificate for digital pressure display (additional pressure)		
Qualification folder		
Evaporating dish with rim, small or large		
Stable table on wheels with castors and locking brakes		

20.4 Spare parts


	BINDER GmbH is responsible for the safety features of the unit only, provided skilled electricians or qualified personnel authorized by BINDER perform all maintenance and repair, and if components relating to chamber safety are replaced in the event of failure with original spare parts. The user is responsible for any risks arising from using unauthorized accessories/components.
---	---

Accessories and spare parts:


Unit size	23	53	115
Description	Art. No.		
Expansion rack aluminum	8009-0370	8009-0371	8009-0372
Expansion rack stainless steel	8009-0101	8009-0102	8009-0103
Door gasket silicon (temperature-resistant up to 200 °C / 392°F)	6005-0015	6005-0016	6005-0018
Door gasket FKM (temperature-resistant up to 200 °C / 392°F)	6005-0044	6005-0045	6005-0046
Unit fuse 5x20 mm / 250V / 10 Amp semi time lag (M)	5006-0012	5006-0012	--
Unit fuse 5x20mm / 250V / 16 Amp semi time lag (M)	--	--	5006-0013
Safety glass panel	6012-0007	6012-0008	6012-0015
Rack holder	4005-0071	4005-0072	4005-0073
Housing of instrument panel	6002-0067	6002-0016	6002-0016

Shielding of instrument panel	6002-0017
Universal centering ring	6009-0048
Straining ring	6009-0009
Blind flange	6009-0010
Handle	6002-0002
Thermostat class 2 30° / 86°F to 320 °C / 608°F	5006-0008
Turning knob for thermostat class 2	8009-0004
Temperature sensor Pt 100	5002-0007
Temperature sensor Pt 100 heating	5002-0025
Protocol printer	BINDER Individual
2-channel pen recorder, external	BINDER Individual
Manometer	6013-0040
Program controller RD3	5014-0102
Power supply unit	5020-0026
Stable table on wheels with castors and locking brakes	9051-0018
Factory calibration certificate	8012-0031
Extension to factory calibration certificate (additional value)	8012-0044
Factory calibration certificate for digital object temperature display	8012-0442
Factory calibration certificate for digital pressure display	8012-0440
Extension to factory calibration certificate for digital pressure display (additional pressure)	8012-0441
Qualification folder	DL008031
Evaporating dish, small	4022-0125
Evaporating dish, large	4022-0126
Neutral cleaning agent, 1 kg	1002-0016

20.5 Dimensions VD 23



20.7 Dimensions VD 115



21. Contamination clearance certificate


Unbedenklichkeitsbescheinigung

Declaration regarding safety and health

Erklärung zur Sicherheit and gesundheitlichen Unbedenklichkeit

The German Ordinance on Hazardous Substances (GefStoFV), and the regulations regarding safety at the workplace, require that this form be filled out for all products that are returned to us, so that the safety and the health of our employees can be guaranteed.

Die Sicherheit und Gesundheit unserer Mitarbeiter, die Gefahrstoffverordnung GefStoFV und die Vorschriften zur Sicherheit am Arbeitsplatz machen es erforderlich, dass dieses Formblatt für alle Produkte, die an uns zurückgeschickt wird.

	<p>Note: A repair is not possible without a completely filled out form. Ohne Vorliegen des vollständig ausgefüllten Formblattes ist eine Reparatur nicht möglich.</p>
---	--

- A completely filled out form must be transmitted via Fax (+49 (0) 7462 2005 93555) or by letter in advance, so that this information is available before the equipment/component part arrives. A second copy of this form must accompany the equipment/component part. In addition, the carrier should be notified.

Eine vollständig ausgefüllte Kopie dieses Formblattes soll per Telefax (Nr. +49 (0) 7462 2005 93555) oder Brief vorab an uns gesandt werden, so dass die Information vorliegt, bevor das Gerät/Bauteil eintrifft. Eine weitere Kopie soll dem Gerät/Bauteil beigelegt sein. Ggf. ist auch die Spedition zu informieren.

- Incomplete information or non-conformity with this procedure will inevitably lead to substantial delays in processing. Please understand the reason for this measure, which lies outside our area of influence, and will help us to speed up this procedure.

Unvollständige Angaben oder Nichteinhalten dieses Ablaufs führen zwangsläufig zu beträchtlichen Verzögerungen in der Abwicklung. Bitte haben Sie Verständnis für Maßnahmen, die außerhalb unserer Einflussmöglichkeiten liegen und helfen Sie mit, den Ablauf beschleunigen.

- Please print and fill out this form completely.**

Bitte unbedingt vollständig ausfüllen!

1. Unit/ component part / type: / Gerät / Bauteil / Typ:
2. Serial No. / Serien-Nr.:
3. Details about utilized substances / biological substances / Einzelheiten über die eingesetzten Substanzen/biologische Materialien:
3.1 Designations / Bezeichnungen: a) _____ b) _____ c) _____
3.2 Safety measures required for handling these substances / Vorsichtsmaßnahmen beim Umgang mit diesen Stoffen: a) _____ b) _____ c) _____

3.3	Measures to be taken in case of skin contact or release into the atmosphere / Maßnahmen bei Personenkontakt oder Freisetzung: a) _____ b) _____ c) _____ d) _____
3.4	Other important information that must be taken into account / Weitere zu beachtende und wichtige Informationen: a) _____ b) _____ c) _____
4.	Declaration on the risk of these substances (please checkmark the applicable items) / Erklärung zur Gefährlichkeit der Stoffe (bitte Zutreffendes ankreuzen) : <input type="checkbox"/> 4.1 For non toxic, non radioactive, biologically harmless materials / für nicht giftige, nicht radioaktive, biologisch ungefährliche Stoffe: We hereby guarantee that the above-mentioned unit / component part... / Wir versichern, dass o.g. Gerät/Bauteil... <input type="checkbox"/> Has not been exposed to or contains any toxic or otherwise hazardous substances / weder giftige noch sonstige gefährliche Stoffe enthält oder solche anhaften. <input type="checkbox"/> That eventually generated reaction products are non-toxic and also do not represent a hazard / auch evtl. entstandene Reaktionsprodukte weder giftig sind noch sonst eine Gefährdung darstellen. <input type="checkbox"/> Eventual residues of hazardous substances have been removed / evtl. Rückstände von Gefahrstoffen entfernt wurden.
	<input type="checkbox"/> 4.2 For toxic, radioactive, biologically harmful or hazardous substances, or any other hazardous materials / für giftige, radioaktive, biologisch bedenkliche bzw. gefährliche Stoffe oder anderweitig gefährliche Stoffe. We hereby guarantee that ... / Wir versichern, dass ... <input type="checkbox"/> The hazardous substances, which have come into contact with the above-mentioned equipment/component part, have been completely listed under item 3.1 and that all information in this regard is complete / die gefährlichen Stoffe, die mit dem o.g. Gerät/Bauteil in Kontakt kamen, in 3.1 aufgelistet sind und alle Angaben vollständig sind. <input type="checkbox"/> That the unit /component part has not been in contact with radioactivity / das Gerät/Bauteil nicht mit Radioaktivität in Berührung kam
5.	Kind of transport / transporter / Transportweg/Spediteur: Transport by (means and name of transport company, etc.) Versendung durch (Name Spediteur o.ä.) _____ Date of dispatch to BINDER GmbH / Tag der Absendung an BINDER GmbH: _____ _____

We hereby declare that the following measures have been taken / Wir erklären, dass folgende Maßnahmen getroffen wurden:

- ☐ Hazardous substances were removed from the unit including component parts, so that no hazard exists for any person in the handling or repair of these items / das Gerät/Bauteil wurde von Gefahrstoffen befreit, so dass bei Handhabung/Reparaturen für die betreffenden Person keinerlei Gefährdung besteht
- ☐ The unit was securely packaged and properly identified / das Gerät wurde sicher verpackt und vollständig gekennzeichnet.
- ☐ Information about the hazardousness of the shipment (if required) has been provided to the transporter / der Spediteur wurde (falls vorgeschrieben) über die Gefährlichkeit der Sendung informiert.

We hereby commit ourselves and guarantee that we will indemnify BINDER GmbH for all damages that are a consequence of incomplete or incorrect information provided by us, and that we will exempt BINDER GmbH from eventual damage claims by third parties./ Wir versichern, dass wir gegenüber BINDER für jeden Schaden, der durch unvollständige und unrichtige Angaben entsteht, haften und BINDER gegen eventuell entstehende Schadenansprüche Dritter freistellen.

We are aware that, in accordance with Article 823 of the German Civil Code (BGB), we are directly liable with regard to third parties, in this instance especially the employees of BINDER GmbH, who have been entrusted with the handling / repair of the unit / component. / Es ist uns bekannt, dass wir gegenüber Dritten – hier insbesondere mit der Handhabung/Reparatur des Geräts/des Bauteils betraute Mitarbeiter der Firma BINDER - gemäß §823 BGB direkt haften

Name: _____

Position/Title: _____

Date / Datum: _____

Signature / Unterschrift: _____

Company stamp / Firmenstempel:



Equipment that is returned to the factory for repair must be accompanied by a completely filled out contamination clearance certificate. For service and maintenance on site, such a contamination clearance certificate must be submitted to the service technician before the start of any work. No repair or maintenance of the equipment is possible, without a properly filled out contamination clearance certificate.