

Digital Tally Counters



These hand-held digital tally counters have been designed for ease of use with large, easy-to-operate count buttons, a backlit LCD display for low light conditions and a shaped case which allows a firm and comfortable grip of the tally counter.

- Lightweight, pocket-sized hand-held tally counters
 - **TLD-1** Digital Tally Counter – counts up 0 to 9999
 - **TLD-2** Up/Down Digital Tally Counter – adds and subtracts 0 to 9999
- Impact-resistant ABS case with wrist strap
- Large 4-digit 15mm backlit LCD display
- Shaped case with wide 55mm head and narrower 37mm body for improved grip
- Display backlight – auto off after 5 seconds – allows checking in low light conditions
- On/Off/Reset button
- Large count button (**TLD-1**) or \pm buttons for add/subtract (**TLD-2**)
- Maximum count 9999
- Count confirmation bleep or silent operation
- Cannot accidentally reset or switch off – press on/off/reset button for 3 seconds to activate
- Auto off after 2 hours of no activity – returns to the last counted number when the counter is switched on again
- Dimensions 85mm x 37mm (55mm head)) x 18mm
- Weight 40g
- Supplied with 2 x 1.5V button cell batteries