

Wireless Digital Thermometer



Wireless Digital Thermometer	TH-25W
Calibration Certificate	CAL-WH

Features:

- **Wireless** signal transmits temperatures from two remote temperature sensors to base station
- Both channels displayed simultaneously on base station
- 60mm display updated every 8 minutes
- Selectable °C or °F
- Audible and visual alarm - triggered when temperature exceeds pre set maximum and minimum temperatures after 15mins (this prevents false alarms when door opened for loading) - alerting you to high or low temperatures that could affect the product quality
- Licence free frequency
- Displays error warning E if transmission fails
- Low battery indication
- Base station can be mounted magnetically, wall mounted or used free standing
- Remote sensors fitted with spring action clips and suction cups for securing in place

· Requires batteries

· Optional Calibration Certificate available

CAL-WH Calibration Certificate - Issued at 2 points for each sensor: -15°C & 20°C. (Additional points are available if required. These must be specified at the time of order. Please call for price and details.)

Wireless Digital Thermometer

Technical Specifications

Range	-30°C to +40°C (-22°F to +104°F)
Resolution	1°C/1°F
Accuracy	±1°C/1.8°F
Transmission Range	up to 20m
Transmission Frequency	every 8 minutes
Power Base station	2 x 1.5V AAA batteries (ALR-3 x 2)
Sensors	2 x 1.5V AA batteries per sensor (ALR-6 x 4)
Dimensions	
Base station	150 x 59 x 27mm
Sensor	105 x 35 x 18mm
Weight Base station	137g
Sensor	92g