

MEDIBOX 73 & 93

Temperature Controlled Pharmaceutical Transporters



Specifically designed for use in vehicles

**73 & 93 Litre CAPACITY
12-24 / 240 Volt**

Professional Specification



MEDIBOX 73

The Abacus MEDIBOX range has been specifically designed to meet the ever-demanding role of transporting temperature sensitive products in non-refrigerated or un-heated vehicles. It is built to cope with the aggressive ambient temperatures and the rough handling of every day life. Its sophisticated temperature control and alarm systems ensure that your product reaches its destination in perfect condition. And to prove it the internal data logger provides you with a vital link in your quality audit chain. The steel anchor brackets provide secure fixing for permanent van installations, alternatively a quick release system can be supplied for semi-permanent use.

General Specification: -

- Power Supply 12-24 Volt dc / 240 Volt ac (auto switching.)
- Ambient operating specification - 15 °C to + 45 °C
- Internal temperature selectable between 2 and 8 °C (-10 °C to + 35 °C available to order)
- Temperature Stability Password Locked
- Hi and low temperature alarm +/- 1.5 °C
- Temperature Data Logger (Audible)
- Battery Condition Monitor Fixed / removable
- Lockable Lid Low voltage cut off with emergency over-ride
- Capacity TOC Circular Keys
- Capacity 73 or 93 Litres

Technical Data:-

- Maximum power consumption 65 Watts
- Heater on time at amb of -5 °C 15 %
- Compressor run time at amb of 20 °C 12% (MB73) 14% (MB93)
- Compressor run time at amb of 32 °C 22% (MB73) 25% (MB93)
- Internal air stirring DC Brushless Fan
- Rugged Construction Coated Sheet Steel Body
- Top Entry Reversible Hinged Lid
- Fixing Brackets Coated Steel
- Weight Empty 33Kg (MB73) 39Kg (MB93)

Factory & Offices: 13C Old Bridge Way, Shefford, Bedfordshire SG17 5HQ, England

Tel: 01462 638200 Fax: 01462 638201 Website www.abacusinstruments.com

sales@abacusinstruments.com