

Chest freezers for bulk storage

Liebherr chest freezers are designed to withstand heavy loads. Made of the very best quality components to ensure a long service life in any conditions – ideal for bulk storage. Every business is bound to find exactly the right appliance for its own individual needs in Liebherr's wide range of display chest freezers. These freezers have a temperature range from -10°C to -24°C.

Freezing in the catering business

Smoothly foamed in

The heat exchange condenser is foamed into the insulation. So our chest freezers are accessible from all sides and are particularly quiet-running. No condensation forms on the outside, and the smooth outer skin is easy to clean.

Castors

Liebherr's commercial chest freezers are fitted with twin castors and can be moved effortlessly.

Constantly low energy consumption

The 63 mm insulation on our chest freezers is one of the main reasons why these appliances are so economical.

Spacious, corrosion free and easy to clean

Liebherr's chest freezers make optimum use of the space on the inside. Cooling takes place evenly on all sides. So even the goods at the top of the stack are perfectly frozen. The aluminium sheet cladding on the inside is wear-resistant. The corners of the interior are rounded for easy and convenient cleaning.

Interior temperature display

The standard thermometer on the inside tells you exactly what the internal temperature is.

Insulated sliding lid

Stable, light-weight and tightly closing: the 30 mm insulated sliding lids are a particularly effective, energy saving cover. Fitted on all GTE ..00 models as standard.

Accessories

Baskets

The stable, spacious wire baskets are the perfect place to store different loose items of frozen food separately and neatly, and make your frozen food easy to access. GTI chest freezers are equipped with baskets as standard.

Cylinder lock

A cylinder lock can be installed on all models to secure the content of the freezer.

More detailed information on our chest freezers can be found in our Chest Freezer Special.

GTE 1501
<ul style="list-style-type: none"> Gross capacity: 146 l Flip-flap lid Single castors Exterior dimensions in cm: h/w/d 89.5/64/54.7

GTE 2402	not ill.
<ul style="list-style-type: none"> Gross capacity: 240 l Sliding glass lid Exterior dimensions in cm: h/w/d 89.5/83/66.5 	

GTE 2400	not ill.
<ul style="list-style-type: none"> Gross capacity: 231 l Exterior dimensions in cm: h/w/d 90.5/83/66.5 	

GTE 3702	not ill.
<ul style="list-style-type: none"> Gross capacity: 376 l Sliding glass lid Exterior dimensions in cm: h/w/d 89.5/117/66.5 	

GTE 3700	not ill.
<ul style="list-style-type: none"> Gross capacity: 362 l Exterior dimensions in cm: h/w/d 90.5/117/66.5 	

GTE 3002	not ill.
<ul style="list-style-type: none"> Gross capacity: 308 l Sliding glass lid Exterior dimensions in cm: h/w/d 89.5/100/66.5 	

GTE 3000
<ul style="list-style-type: none"> Gross capacity: 296 l Exterior dimensions in cm: h/w/d 90.5/100/66.5

GTE 5002	not ill.
<ul style="list-style-type: none"> Gross capacity: 512 l Sliding glass lid Exterior dimensions in cm: h/w/d 89.5/151/66.5 	

GTE 5000	not ill.
<ul style="list-style-type: none"> Gross capacity: 493 l Exterior dimensions in cm: h/w/d 90.5/151/66.5 	

GTE 4302	not ill.
<ul style="list-style-type: none"> Gross capacity: 444 l Sliding glass lid Exterior dimensions in cm: h/w/d 89.5/134/66.5 	

GTE 4300	not ill.
<ul style="list-style-type: none"> Gross capacity: 427 l Exterior dimensions in cm: h/w/d 90.5/134/66.5 	

GTI 5003	not ill.
<ul style="list-style-type: none"> Gross capacity: 472 l Curved sliding glass lid 4 large baskets Exterior dimensions in cm: h/w/d 90.1/150.9/66.4 	

GTI 3703	not ill.
<ul style="list-style-type: none"> Gross capacity: 346 l Curved sliding glass lid 3 large baskets Exterior dimensions in cm: h/w/d 90.1/116.9/66.4 	

GTI 3002	not ill.
Identical with GTI 3003, but sliding glass lid not curved	

GTI 4303	not ill.
<ul style="list-style-type: none"> Gross capacity: 409 l Curved sliding glass lid 3 large baskets 1 small basket Exterior dimensions in cm: h/w/d 90.1/133.9/66.4 	

GTI 3702
Identical with GTI 3703, but sliding glass lid not curved

GTI 2403	not ill.
<ul style="list-style-type: none"> Gross capacity: 220 l Curved sliding glass lid 2 large baskets Exterior dimensions in cm: h/w/d 90.1/82.9/66.4 	

GTI 4302	not ill.
Identical with GTI 4303, but sliding glass lid not curved	

GTI 3003	not ill.
<ul style="list-style-type: none"> Gross capacity: 283 l Curved sliding glass lid 2 large baskets 1 small basket Exterior dimensions in cm: h/w/d 90.1/100/66.4 	

GTI 2402	not ill.
Identical with GTI 2403, but sliding glass lid not curved	

