

Table-height freezers with SmartFreeze

Electronic control system with Premium table-height freezers

- Digital “actual-temperature” display (premium models)
- Automatic SuperFrost function
- Control lamps for mains, SuperFrost, alarm, FrostControl and child-proof function
- Audible and visual temperature alarm

Electronic control system with Comfort table-height freezers and GX 811

- Automatic SuperFrost function
- SuperFrost control lamps for mains, alarm and SuperFrost

Freezer

- SmartFreeze system
- VarioSpace with removable drawers and glass intervening shelves
- Easy defrosting with smooth and easy-to-clean interior
- FrostSafe system with completely enclosed, transparent drawers

Model benefits

- Interchangeable door hinges
- Flush with wall and with front ventilation, suitable for installation in a row of kitchen units
- Adjustable feet at front



SmartFreeze. The drawers and intervening glass shelves are removable, creating **VarioSpace**; the practical system offering lots of extra storage area, for even the biggest item.



The **SuperFrost Automatic** with Premium table-height freezers makes freezing a simple and energy-saving pleasure when it comes to housework. It quickly reduces the temperature and in the process creates the cold reserve required for vitamin preserving freezing. As soon as the food is completely frozen the SuperFrost Automatic switches back to normal operation and therefore saves energy.



Table-height freezers	GPes 1456 Premium	GP 1456 Premium	GP 1356 Premium	G 1221 Comfort	GX 811 Comfort
Total gross/net capacity					
Freezer compartment	104/101 l	104/101 l	104/101 l	101/98 l	70/67 l
Energy consumption (in 365 days)	135 kWh	135 kWh	189.8 kWh	211.7 kWh	189.8 kWh
Energy efficiency class	<A+>	<A+>	<A+>	<A>	<A>
Climate rating	SN-T	SN-T	SN-T	SN-ST	SN-T
Exterior dimensions in cm (h/w/d)	85/60/61	85/60/62.5	85/55.5/62.5	85.1/55.4/62.3	63/55.5/61
Equipment, accessories					
Number of drawers	4	4	4	3	2
2 cold storage accumulators	●	●	●		
Ice cube tray	●	●	●		
Design	HardLine	SwingDesign	SwingDesign	SwingDesign	HardLine
Finish	stainless steel	white	white	white	white