

WOLF LABORATORIES

Tel: 01759 301142 Fax: 01759 301143 Email: sales@wolflabs.co.uk
Website: www.wolflabs.co.uk

Oldham GasBadge Plus Personal Single Gas monitor



GasBadge® Plus is a two-year, maintenance-free, single gas monitor ideal for personal protection from unsafe levels of carbon monoxide, hydrogen sulfide, oxygen, nitrogen dioxide or sulfur dioxide. The unit's compact size and light weight allow it to be worn comfortably with a variety of clip attachments, and the top-mounted sensor provides continuous and unobstructed protection even when placed in a shirt pocket.

The rugged enclosure is extremely durable and resistant to water and radio frequency interference. A protective concussion-proof overmold protects the unit from extreme abuse in a variety of harsh industrial environments. The large LCD display features a graphical interface and can be set up to show both gas type and direct gas readings, or just the gas type. The instrument's two-button operation allows for easy navigation and setup, which can be password-protected for added security.

Continuous event-logging is a standard feature for the GasBadge Plus with the past 15 alarm events recorded. Optional Cal Plus™ calibration station and datalink accessories enable easy instrument maintenance, configuration and data downloading. Two year warranty.

Accessory Equipment

PART NUMBER	DESCRIPTION
18100050-1	GasBadge® Plus – Carbon Monoxide (CO)
18100050-2	GasBadge® Plus – Hydrogen Sulfide (H ₂ S)
18100050-3	GasBadge® Plus – Oxygen (O ₂)
18100050-4	GasBadge® Plus – Nitrogen Dioxide (NO ₂)
18100050-5	GasBadge® Plus – Sulfur Dioxide (SO ₂)
18106500	GasBadge® Constant-Flow Hand Aspirated Pump
17121963	GasBadge® Neck Lanyard w/Safety Release
18106401	GasBadge® Plus Nylon Carrying Case
18106419	GasBadge® Plus 2-unit Nylon Carrying Case
17124504	Replacement water/dust sensor barriers (5 count)
18106260	GasBadge® Datalink
18106344-0X+	Cal Plus™ Calibration Station (calibration gas and regulator not included)
18106344-1X+	Cal Plus™ Calibration Station w/on-board dot matrix printer (calibration gas and regulator not included)
17117714	Serial data thermal printer with infrared interface (battery powered only)
17117722	Serial data dot matrix printer, 120 VAC powered

+ Ordering Information – X = Power Cord [0 (North America), 1 (United Kingdom), 2 (European), 3 (Australian)]

All GasBadge® Plus Monitors Include: attached suspender clip, stainless steel belt clip, calibration adapter and tubing, and operating instructions.

⇒ **CalPlus Calibration Station**

- Stand-alone operation – no PC is required
- Simple, push-button calibration or function (bump) testing
- Immediate report generation
- Built-in printer option



Cal Plus™ shown with built-in printer option for immediate report documentation



⇒ **GasBadge Datalink**

- Instantly download alarm events and instrument details
- Quickly and easily configure instrument preferences