

Two in one!

SCALTEC Industrial Scales SSH



*easy
& speedy*

We keep the world of weighing in motion!

SCALTEC

The SCALTEC Industrial Scales SSH

Precision – the fastest way!

Place the sample on the scale – and in fractions of seconds the result will appear on the large, backlighted display. Stable and easy to read. Weighing was never this simple and fast until now.

Two balances in One!

It is rarely the case that you need the entire weighing range of a scale – that's why with this scale you can halve the weighing range just by menu setting – and at the same time the readability will be doubled.

The Polyrange function (e. g. SSH 92):

Weighing range (Standard):	60 kg
Accuracy:	2 g
with Polyrange function	
Weighing range:	30 kg
Accuracy:	1 g

The All-Inclusive Scale!

Whether you just want to weigh – or if you need to count, control filling volumes or formulations – a number of additional functions are standardly integrated into scales as:

- Counting
- Totalizing
- %-Weighing
- Gross/Net value Toggling
- Weighing in different mass units
- 2nd Tare for net total
- Formular Factor Calculation

Quality for Industrial Applications!

These scales don't just look good – in addition to their built-in precision they are also user friendly and robust. The weighing platform is made of strong stainless steel. The display is removable and can be mounted on a column or at the wall. Built-in interface to connect printers or a PC are a matter of course. And an additional highlight: 2 lines of the printer are free programmable, for your company name or sample labelling.



8 Models. 16 Weighing Ranges.

Model	Capacity	Readability	Weighing platform W x D mm	Extra Built-in Polyrange function	
	kg	g		Capacity kg	Readability g
SSH 81	150	50	500 x 400	75/150	20/50
SSH 82	60	20	500 x 400	30/60	10/20
SSH 83	35	10	400 x 300	17,5/35	5/10
SSH 84	15	5	320 x 240	7,5/15	2/5
SSH 91	150	5	500 x 400	75/150	2/5
SSH 92	60	2	500 x 400	30/60	1/2
SSH 93	35	1	400 x 300	17,5/35	0,5/1
SSH 94	15	0,5	320 x 240	7,5/15	0,2/0,5

Accessories:

Printer	SPR 02	Display holder	SWH 02
Column		Cable for PC-connection 25-pin	SCA 01
for SSH 83/93 & SSH 84/94	SST 01	Battery pack for SSH	SBP 01
Column			
for SSH 81/91 & SSH 82/92	SST 02		

SCALTEC

Applied expertise is our philosophy

SCALTEC INSTRUMENTS GmbH
 Rudolf-Diesel-Straße 1 · D-37308 Heiligenstadt/Germany
 Phone: +49 (0) 36 06/67 01-0 · Fax +49 (0) 36 06/67 01-60
 Internet www.scaltec.com · E-Mail Scaltecbal@aol.com