

Star Series Specifications



Orion 3-Star pH

Portable Meter (Cat. No. 1212000)
Portable Meter Kit (Cat. No. 1212001)

- Durable, waterproof, IP67 meter stands up to the most demanding field applications while delivering over 2,000 hours of continuous operation.
- Easy to use, 3-button function
- Ergonomic design for comfortable handling
- SMART STABILITY™ and SMART AVERAGING™ functions for automatically optimized accuracy, precision and response time
- Storage of up to 10 password protected methods for easy retrieval of operation procedures
- Simultaneous display of pH and temperature measurements

Environmental Instruments Water Analysis Instruments

166 Cummings Center
Beverly, MA 01915 USA

Toll Free: 1-800-225-1480
Tel: 1-978-232-6000
Dom. Fax: 1-978-232-6015
Int'l. Fax: 1-978-232-6031

www.thermo.com/water



© 2005 Thermo Electron Corporation. All rights reserved.
S-3S1212000E 02/05 RevB

Specifications	
pH	
Readout Range / Resolution	-2.000 to 19.999 or 0 to 14 in aqueous solutions / 0.1,0.01,0.001
Relative Accuracy	± 0.002
SMART STABILITY™ and SMART AVERAGING™	Resolution dependent / automatic
AUTO-CAL™ and/or Manual Calibration	1 to 5 points; US/NIST, DIN, and custom buffers recognized
mV	
Range – mV / RmV	± 1999.9
ORP	E _H autocalibration to standard hydrogen electrode
Resolution	0.1
Relative Accuracy	± 0.2 mV or 0.05%, whichever is greater
Temperature	
Range / Resolution	-5 to 105 °C / 0.1 up to 99.9 °C, 1.0 over 99.9 °C
Relative Accuracy	± 0.1 °C
Temperature Compensation	Auto/Manual
Display	Custom backlit LCD, for easy viewing
Inputs/Outputs	
Sensor Inputs	pH - BNC; ATC-miniDIN-Locking
Communications	Waterproof bi-directional RS232 - Stereo jack, optional USB interface Cable
Special GLP Software Features	
# Of Data Logging Points	200 points by time, stability or manual read with time/date stamp
Calibration Log	Last 10 Calibrations
User Method Storage	10 Saved
Advanced Self-test and Diagnostics	YES
GLP Electrode Verification	YES
Password Protection	YES
Internet Software Updates / Downloadable Methods	YES
Power	4 x AA batteries, powerless date protection
Regulatory and Safety	CE, CSA, UL, TÜV, FCC Class A limits
Environmental Operating Conditions	
Ambient Operating Temperature	5 to 45 °C
Relative Humidity	5 to 85% Non-Condensing
IP Rating	IP67, waterproof and dustproof
Warranty	36 months (from date of purchase)

Above data generated under optimal/controlled circumstances.

pH Portable Meter Kit (1212001) Includes:

Cat. No.	Description
1212000	3-Star pH portable meter
1210004	Hard field kit
9107BNMD	Low maintenance Triode™ pH/ATC electrode
204947-001	Beaker
1210001	Portable electrode stand
910710	pH 7.00 buffer, 10 pack

Analyze • Detect • Measure • Control™

Thermo
ELECTRON CORPORATION