

WOLF LABORATORIES

Tel: 01759 301142 Fax: 01759 301143 Email: sales@wolflabs.co.uk
Website: www.wolflabs.co.uk

Probe-type Thermo-Hygrometer

Improved specification



A hand held combined temperature, humidity and dew point meter. The detachable probe has a vented protection grill covering the sensors. Ideal for environmental monitoring or taking measurements within an air stream.

- Measures humidity as %RH
- Measures temperature in °C or °F (switchable)
- Impact resistant ABS case with probe retention void, flip-out desk stand and membrane function buttons
- Probe is connected to the main unit by a 80 cm cable
- A precision NTC thermistor sensor for temperature
- A capacitance sensor for humidity
- 22mm LCD display with function indicators and backlight
- Indicates dew point and wet bulb temperatures
- Data hold function
- Min/max memory since power on or last reset for both temperature and humidity
- Dry, comfort and wet indication (comfort displayed 40% to 70%)

- Supplied with batteries ALR-3 x 2

- Optional Calibration Certificate available

ACAL-HT Calibration Certificate - Issued at 2 Temperature points: 20°C & 40°C and 2 RH Points: 35% & 75% @20°C. (Additional points are available if required. These must be specified at the time of order. Please call for price and details.)

Technical Specifications for AP-330

Humidity	0 to 99% RH
Resolution	0.1% RH
Accuracy	±3% RH (20 to 80%), ±4% remaining range
Temperature	-40° to +70°C
Resolution	0.1°C
Accuracy	±0.5°C
Power	2 x 1.5V AAA batteries ALR-3
Dimensions	130 x 70 x 25mm unit, 170L x 25mm Ø probe
Weight	196g

Related Product Codes

- ACAL-HT Humidity Calibration Certificate
- ASCC-2 Soft Carry Case
- ALR-3 1.5V AAA Alkaline Battery x 2