



ECO MIDI K 82 CCG 4S

With an energy consumption of only 327 kWh/year (Energy test Ecodesign) the ECO MIDI 82 refrigerator already now ranks in energy class A.

The Ecodesign test method records the 24 hour energy consumption and multiplies it by 365 to get the annual energy consumption (AEC). The 24 hour consumption is calculated from 2 test periods of 12 hours each. The first period has sequences of door openings while the second is a stabilization period with closed door.

ECO MIDI 82 cabinets combine stylish design with high functionality and low energy consumption.

- The controls are concealed behind the top panel, protected against splashing water.
- Design principle of "no broken surfaces" makes the cabinets easy to clean.
- The distinctive aluminum profiles stretching from top to bottom on both sides of the cabinet impart strength and enhance appearance.
- The modular rails can go directly in the dishwasher.
- Easy access to stored items as the storage compartment is raised 37 cm above the floor.

ECO MID 82 is suitable for the 2/1 GN wide GN system where two 1/1 GN pans can be placed side by side on each shelf.

TECHNICAL INFORMATION

Varenummer	962820011
Category	Storage Cabinets
Type	Refrigerator
Line	2/1 GN wide
Series	ECO MIDI
Equipped with	Right hand hinged reversible door, automatic door closing, 4 stainless shelves, LED lighting
Temperature range	+2/+12°C
Volume, gross	603 ltr.
Net usable volume	459 ltr.
Exterior/Interior	Stainless/Stainless
Dim. W x D x H, mm	820 x 771 x 2000
Weight, packed	137 kg
Refrigerant / GWP	R 290 (propane)/0.11 kg/CO2e 0.37 kg/3
Ref.capacity at -10°	333 Watt
Connection	230V, 50 Hz
Connection load	224 Watt
Energy Efficiency Class	A
Energy consumption / year (AEC)	327 kWh
Sound level	45.6 dB(A)



WolfLabs

Pricing on any accessories shown can be found by keying the part number into the search box on our website.

The specifications listed in this brochure are subject to change by the manufacturer and therefore cannot be guaranteed to be correct. If there are aspects of the specification that must be guaranteed, please provide these to our sales team so that details can be confirmed.

www.wolflabs.co.uk

Tel : 01759 301142

Fax : 01759 301143

sales@wolflabs.co.uk

Please contact us if this literature doesn't answer all your questions.