

HI151

# Folding Pocket Thermometer

- CAL Check™
  - Alerts users of calibration status

The folding Checktemp®4 provides practical temperature measurement for the food service industry.

Special attention was given to the ergonomic form of Checktemp 4. This thermometer fits comfortably and securely in your hand while the LCD on the side of the handle remains easy to see and read. The fast-responding, fold-away probe is made of high quality stainless steel and can penetrate semi-frozen and semi-solid foods such as meats, ice cream and cheeses. When you are finished using your Checktemp 4, wipe the probe clean and fold it away. Checktemp 4 automatically turns off so you can safely carry it in your pocket.

## CAL Check

As you unfold the stainless steel probe, the Checktemp 4 automatically turns on and immediately performs a calibration test. This unique Hanna feature, CAL Check, provides the security of knowing you have accurate measurements. CAL Check also lets you know if your battery level is low or if your meter requires recalibration.



Turns on and off by opening and closing the probe

Specifications	HI151-00 (Checktemp 4C)	HI151-01 (Checktemp 4F)	HI151-02 (Checktemp 4C)
Range	-50.0 to 220°C	-58.0 to 428°F	-50.0 to 220°C
Resolution	0.1°C (-50.0 to 199.9°C); 1°C (200 to 220°C)	0.1°F (-58.0 to 199.9°F); 1°F (200 to 428°F)	0.1°C (-50.0 to 199.9°C); 1°C (200 to 220°C)
Accuracy	±0.3°C ±1 digit (-20.0 to 90.0°C); ±1% F.S. ±1 digit (outside)	±0.5°F ±1 digit (-4.0 to 194.0°F); ±1% F.S. ±1 digit (outside)	±0.3°C ±1 digit (-20.0 to 90.0°C); ±1% F.S. ±1 digit (outside)
CAL Check	automatic, at start-up	automatic, at start-up	–
Probe	stainless steel probe with penetration tip; 117 x dia 3.5 mm (4.6 x dia 0.14")		
Battery Type / Life	1.5V AA / approx. 25,000 hours of continuous use; auto-off after 8 minutes of non-use		
Environment	0 to 50°C (32 to 122°F); RH max 95%		
Dimensions	165 x 50 x 20 mm (6.5 x 2.0 x 0.8")		
Weight	100 g (3.5 oz.)		
Ordering Information	<b>HI151-00</b> (Checktemp 4 C) is supplied complete with battery and instructions <b>HI151-01</b> (Checktemp 4 F) is supplied complete with battery and instructions <b>HI151-02</b> (Checktemp 4 C without CAL Check) is supplied complete with battery and instructions		



**Wolflabs**

# Wolf Laboratories Limited

[www.wolflabs.co.uk](http://www.wolflabs.co.uk)

Tel: 01759 301142

Fax: 01759 301143

[sales@wolflabs.co.uk](mailto:sales@wolflabs.co.uk)



**Use the above details to contact us if this literature doesn't answer all your questions.**

**Pricing on any accessories shown can be found by keying the part number into the search box on our website.**

The specifications listed in this brochure are subject to change by the manufacturer and therefore cannot be guaranteed to be correct. If there are aspects of the specification that must be guaranteed, please provide these to our sales team so that details can be confirmed.

