

TECHNICAL FEATURE

7EG 35GHLE 01 905



The :

- Comfortable and airy surface
- Without staples nor seams
- Abrasion-resistant
- Easily adjustable
- Résiste à un usage intensif

ESD CHAIRS / POLYURETHANE

Chrome, 5-branch, scuff-resistant, reinforced base with antistatic glides
Chrome gas-lift column with height adjustment from 560 to 800 mm and shock absorber
Height adjustable aluminium foot-ring
Ergonomic seat in antistatic black KANGO soft polyurethane
Articulated backrest in antistatic soft polyurethane, adjustable in depth and height
Special conductive polyurethane connects to the metal parts of the chair, allowing electricity to be discharged through carbon castors or pads



Wolflabs

Wolf Laboratories Limited

www.wolflabs.co.uk

Tel: 01759 301142

Fax: 01759 301143

sales@wolflabs.co.uk



Use the above details to contact us if this literature doesn't answer all your questions.

Pricing on any accessories shown can be found by keying the part number into the search box on our website.

The specifications listed in this brochure are subject to change by the manufacturer and therefore cannot be guaranteed to be correct. If there are aspects of the specification that must be guaranteed, please provide these to our sales team so that details can be confirmed.

