

## Bench scale KERN FKB



PREMIUM



EasyTouch



## High-resolution bench scale with large weighing range and robust stainless steel weighing plate

### Features

- Thanks to the high resolution of up to 360.000 points it is ideal for high-precision weighing in the industrial field
- Housing with robust aluminium diecast housing trough, maintains the stability, protects the weighing technology elements and is robust enough to cope with everyday use
- Particularly practical: thanks to the large weighing ranges and compact dimensions, you can accurately weigh heavy loads in the most restricted of spaces. Useful for determining very small weight differences, such as, for example, gas wastage, abrasion of mechanical parts, rock samples, minerals, druses, silver etc.
- PRE-TARE function for manual subtraction of a known container weight, useful for checking fill-levels

- Freely programmable weighing unit, e.g. display direct in special units such as length of wire g/m, surface weight g/m<sup>2</sup>, or else
- Model with resolution > 240,000 Pt.: Level indicator and levelling feet for precise levelling of the scale, fitted as standard
- Protective working cover included with delivery

### Technical data

- Backlit LCD display, digit height 25 mm
- Dimensions weighing surface, stainless steel, WxD 340x240 mm
- Dimensions housing WxDxH, 350x390x120 mm
- Optional battery operation, 6x1.5 V Size C not included in scope of delivery, operating time up to 80 h
- Permissible ambient temperature 10 °C/40 °C

### Accessories

- Protective working cover, scope of delivery: 5 items, KERN FKB-A02S05
- Rechargeable battery pack external, operating time up to 48 h without backlight, charging time approx. 8 h, KERN PCB-A01
- USB data interface, for transferring weighing to the PC, printer etc., must be ordered at purchase, KERN CKE-A02
- WiFi data interface for wireless data transmission from balance to printer, PC or other peripheral devices, must be ordered at purchase, KERN YMI-A01
- Ethernet interface to connect to an IP-based Ethernet network, must be ordered at purchase, KERN FKB-A01
- Tare pan made from stainless steel. Ideal for weighing loose small parts as well as fruit, vegetables, etc., KERN RFS-A02
- Further details, plenty of further accessories and suitable printers see *Accessories*


## STANDARD



## OPTION





































## FACTORY



Model	Weighing capacity [Max] kg	Readability [d] g	Reproducibility g	Linearity g	Smallest part weight [Normal] g/piece	Net weight approx. kg	Option	
							DAkKS Calibr. Certificate	
KERN							DAkKS KERN	
FKB 6K0.02	6	0,02	0,04	± 0,1	0,2	7	963-128	
FKB 8K0.05	8	0,05	0,05	± 0,15	0,5	7	963-128	
FKB 8K0.1	8	0,1	0,1	± 0,3	2	6	963-128	
FKB 15K0.5	15	0,5	0,5	± 1,5	10	6	963-128	
FKB 16K0.05	16	0,05	0,1	± 0,25	0,5	7	963-128	
FKB 16K0.1	16	0,1	0,1	± 0,3	1	7	963-128	
FKB 30K1	30	1	1	± 3	20	6	963-128	
FKB 36K0.1	36	0,1	0,2	± 0,5	1	7	963-128	
FKB 36K0.2	36	0,2	0,2	± 0,6	2	7	963-128	
FKB 65K0.2	65	0,2	0,4	± 1	2	7	963-129	
FKB 65K1	65	1	1	± 3	20	6	963-129	

## Pictograms

 <b>Internal adjusting:</b> Quick setting up of the balance's accuracy with internal adjusting weight (motordriven)	 <b>KERN Communication Protocol (KCP):</b> It is a standardized interface command set for KERN balances and other instruments, which allows retrieving and controlling all relevant parameters and functions of the device. KERN devices featuring KCP are thus easily integrated with computers, industrial controllers and other digital systems	 <b>Suspended weighing:</b> Load support with hook on the underside of the balance
 <b>Adjusting program CAL:</b> For quick setting up of the balance's accuracy. External adjusting weight required		 <b>Battery operation:</b> Ready for battery operation. The battery type is specified for each device
 <b>Easy Touch:</b> Suitable for the connection, data transmission and control through PC or tablet.	 <b>GLP/ISO log:</b> The balance displays serial number, user ID, weight, date and time, regardless of a printer connection	 <b>Rechargeable battery pack:</b> Rechargeable set
 <b>Memory:</b> Balance memory capacity, e.g. for article data, weighing data, tare weights, PLU etc.	 <b>GLP/ISO log:</b> With weight, date and time. Only with KERN printers.	 <b>Universal plug-in power supply:</b> with universal input and optional input socket adapters for A) EU, CH, GB; B) EU, CH, GB, USA; C) EU, CH, GB, USA, AUS
 <b>Alibi memory:</b> Secure, electronic archiving of weighing results, complying with the 2014/31/EU standard.	 <b>Piece counting:</b> Reference quantities selectable. Display can be switched from piece to weight	 <b>Plug-in power supply:</b> 230V/50Hz in standard version for EU, CH. On request GB, USA or AUS version available
 <b>Data interface RS-232:</b> To connect the balance to a printer, PC or network	 <b>Recipe level A:</b> The weights of the recipe ingredients can be added together and the total weight of the recipe can be printed out	 <b>Integrated power supply unit:</b> Integrated in balance. 230V/50Hz standard EU. More standards e.g. GB, USA or AUS on request
 <b>RS-485 data interface:</b> To connect the balance to a printer, PC or other peripherals. Suitable for datatransfer over large distances. Network in bus topology is possible	 <b>Recipe level B:</b> Internal memory for complete recipes with name and target value of the recipe ingredients. User guidance through display	 <b>Weighing principle: Strain gauges:</b> Electrical resistor on an elastic deforming body
 <b>USB data interface:</b> To connect the balance to a printer, PC or other peripherals	 <b>Totalising level A:</b> The weights of similar items can be added together and the total can be printed out	 <b>Weighing principle: Tuning fork:</b> A resonating body is electromagnetically excited, causing it to oscillate
 <b>Bluetooth* data interface:</b> To transfer data from the balance to a printer, PC or other peripherals	 <b>Percentage determination:</b> Determining the deviation in % from the target value (100 %)	 <b>Weighing principle: Electromagnetic force compensation:</b> Coil inside a permanent magnet. For the most accurate weighings
 <b>WiFi data interface:</b> To transfer data from the balance to a printer, PC or other peripherals	 <b>Weighing units:</b> Can be switched to e.g. nonmetric units. See balance model. Please refer to KERN's website for more details	 <b>Weighing principle: Single cell technology:</b> Advanced version of the force compensation principle with the highest level of precision
 <b>Control outputs (optocoupler, digital I/O):</b> To connect relays, signal lamps, valves, etc.	 <b>Weighing with tolerance range:</b> (Checkweighing) Upper and lower limiting can be programmed individually, e.g. for sorting and dosing. The process is supported by an audible or visual signal, see the relevant model	 <b>Verification possible:</b> The time required for verification is specified in the pictogram
 <b>Analogue interface:</b> to connect a suitable peripheral device for analogue processing of the measurements	 <b>Hold function:</b> (Animal weighing program) When the weighing conditions are unstable, a stable weight is calculated as an average value	 <b>DAKkS calibration possible (DKD):</b> The time required for DAKkS calibration is shown in days in the pictogram
 <b>Interface for second balance:</b> For direct connection of a second balance	 <b>Protection against dust and water splashes IPxx:</b> The type of protection is shown in the pictogram.	 <b>Factory calibration (ISO):</b> The time required for Factory calibration is shown in days in the pictogram
 <b>Network interface:</b> For connecting the scale to an Ethernet network		 <b>Package shipment:</b> The time required for internal shipping preparations is shown in days in the pictogram
		 <b>Pallet shipment:</b> The time required for internal shipping preparations is shown in days in the pictogram

\*The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by KERN & SOHN GmbH is under license. Other trademarks and trade names are those of their respective owners.

## KERN – Precision is our business

## Your KERN specialist dealer:

To ensure the high precision of your balance KERN offers you the the appropriate test weight in the international OIML error limit classes E1-M3 from 1 mg – 2500 kg. In combination with a DAKkS calibration certificate the best pre-requisite for proper balance calibration.

The KERN DAKkS calibration laboratory today is one of the most modern and best-equipped DAKkS calibration laboratories for balances, test weights and force-measurement in Europe.

Thanks to the high level of automation, we can carry out DAKkS calibration of balances, test weights and force-measuring devices 24 hours a day, 7 days a week.

## Range of services:

- DAKkS calibration of balances with a maximum load of up to 50 t
- DAKkS calibration of weights in the range of 1 mg – 2500 kg
- Volume determination and measuring of magnetic susceptibility (magnetic characteristics) for test weights
- Database supported management of checking equipment and reminder service
- Calibration of force-measuring devices
- DAKkS calibration certificates in the following languages DE, EN, FR, IT, ES, NL, PL
- Conformity evaluation and reverification of balances and test weights



# Wolf Laboratories Limited

[www.wolflabs.co.uk](http://www.wolflabs.co.uk)

Tel: 01759 301142

Fax: 01759 301143

[sales@wolflabs.co.uk](mailto:sales@wolflabs.co.uk)



**Use the above details to contact us if this literature doesn't answer all your questions.**

**Pricing on any accessories shown can be found by keying the part number into the search box on our website.**

The specifications listed in this brochure are subject to change by the manufacturer and therefore cannot be guaranteed to be correct. If there are aspects of the specification that must be guaranteed, please provide these to our sales team so that details can be confirmed.

