

Liebherr’s commercial freezers enable even large quantities of frozen food to be stored safely and economically: the static freezing system can be set to temperatures of between -14°C and -28°C.



Castors

The GG 52.. models are fitted with castors for easy, convenient cleaning underneath the appliances and for versatile use in different locations.



User-friendly and precise

The digital controller on the GG 52.. and GGU models allows the temperature to be set to exactly the degree wanted. Optical and acoustic alarms warn you if the temperature rises too high or if the door is left open. An all-round user-friendly solution.



Under lock and key

The freezers can be locked with a sturdy lock which is fitted separately from the strong handle.



Trayslides

The TGS 4000 comes with extra strong, adjustable trayslides for GN 1/1 size Gastronorm containers and bakery trays (600 x 400mm). The frozen food can be stored on up to 22 trays. Trays are not included.



Drawers

The completely enclosed drawers of the G 5216 and GGU 1500 models are very sturdy. Ideal for storing loose or small items of frozen food.

Undercounter installation

The GGU models can be sited beneath a worktop. In this case, a vent grill with cross-section of min. 200 cm² is required in the worktop for ventilation at the rear of the appliance. If no ventilation grill is fitted in the worktop, the aperture must be at least 860 mm high to ensure adequate heat dissipation to the front.

Freezers with static cooling – range overview					
Model	Total gross/net capacity in litre	Exterior dimensions in mm (w/d/h)	Interior dimensions in mm (w/d/h)	Number of Baskets / drawers	Matching refrigerator
GG 5260	513/472 litre	750/750/1864	607/560/1510	14/0	GKv 5790/5760 p. 17/18
GG 5210	513/472 litre	750/750/1864	607/560/1510	14/0	GKv 5730/5710 page 18
G 5216	513/472 litre	750/750/1725	607/560/1510	0/14	
GG 4060	382/348 litre	600/680/1900	457/480/1686	3/0	GKv 4360 page 19
GG 4010	382/348 litre	600/680/1900	457/480/1686	3/0	GKv 4310 page 19
TGS 4000	400/385 litre	752/710/1510	613/530/1312	0/0	BKv 4000 page 23
GGU 1550	143/133 litre	600/615/830	474/443/676	4/0	FKUv 1662/1660 p. 37
GGU 1500	143/133 litre	600/615/830	474/443/676	1/3	FKUv 1612/1610 p. 38



Freezers with static cooling	GG 5260	GG 5210	G 5216
Total gross/net capacity	513/472 litre	513/472 litre	513/472 litre
Exterior dimensions in mm (w/d/h)	750/750/1864	750/750/1864	750/750/1725
Interior dimensions in mm (w/d/h)	607/560/1510	607/560/1510	607/560/1510
Energy consumption in 24 h	1.147 kWh	1.147 kWh	1.103 kWh
General			
Cooling system	static	static	static
Defrosting	manual	manual	manual
Temperature range	-14°C to -28°C	-14°C to -28°C	-14°C to -28°C
Cabinet finish	stainless steel	steel/white	steel/white
Door/lid material	stainless steel	steel	steel
Liner material	commercial grade moulded polystyrol	commercial grade moulded polystyrol	commercial grade moulded polystyrol
Type of control	electronic controller	electronic controller	electronic controller
SuperFrost			quantity-controlled
Temperature display	external digital	external digital	external digital
Temperature and door-open alarm	visual and audible	visual and audible	visual and audible
Drawers	0	0	14
Number of baskets	14	14	0
Shelves, freezer compartment	7	7	7
Shelf material	evaporator plates	evaporator plates	evaporator plates
Shelf loading	60 kg	60 kg	60 kg
Compartment height in mm	6 x 187, 1 x 237	6 x 187, 1 x 237	6 x 187, 1 x 237
Height of adjustable legs	150 – 180 mm	150 – 180 mm	
Handle	stainless steel slimline door handle	ergonomic slimline handle	slimline handle with integrated opening mechanism
Lock	fitted	fitted	
Self-closing door	yes	yes	
Door hinges	right, reversible on site	right, reversible on site	right, reversible on site
Gross/net weight	115/107 kg	116/109 kg	111/104 kg
Climate rating	SN-ST	SN-ST	SN-ST
Sound power level	45 dB(A)	45 dB(A)	45 dB(A)
Refrigerant	R 600a	R 600a	R 600a
Connection rating	1.0 A/150 W	1.0 A/150 W	1.5 A/150 W
Frequency/voltage	50 Hz/220–240V~	50 Hz/220–240V~	50 Hz/220–240V~
Also available with castors	yes	yes	
Accessories			
Optional castor set	9086457	9086457	
Neutral retrofit control panel	9086661	9086659	
Basket/short basket	9141791 / 7112423	9141791 / 7112423	9141791 / 7112423
Drawer/short drawer	9792795 / 9792797	9792795 / 9792797	9792795 / 9792797



WolfLabs

Pricing on any accessories shown can be found by keying the part number into the search box on our website.

The specifications listed in this brochure are subject to change by the manufacturer and therefore cannot be guaranteed to be correct. If there are aspects of the specification that must be guaranteed, please provide these to our sales team so that details can be confirmed.

www.wolflabs.co.uk

Tel : 01759 301142

Fax : 01759 301143

sales@wolflabs.co.uk

Please contact us if this literature doesn't answer all your questions.