

NUGGET ICE MAKER, MODULAR FM-750AKE-N-SB

Product series: FM

Item number: F054-C107



This modular ice maker produces nugget ice, which is often used to prepare cocktails and drinks because of the quickness of cooling and limited dilution of drinks. Utilizing the most efficient ice making process due to the unique auger system, the water consumption is equal to the ice production. This model has a stainless steel bottom and is configured with our storage bins.

- Efficient ice making process due to Hoshizaki's unique FM auger system.
- Utilises all water brought into the machine; therefore water consumption is equal to ice production.
- Auger is made of double hardened stainless steel. Combined with carbon bearings, they work optimally in a tough and wet environment. Benefits include: longer product life expectancy and reduced maintenance costs.
- Hoshizaki ice makers are micro computer controlled, controlling the ice making process to perform at its best under varying circumstances, without having to make physical adjustments.
- Quality stainless steel auger and evaporator increase the life expectancy of these components and the whole ice maker, as well as reducing costly maintenance visits.
- An easily cleanable air filter allows end users to carry out a routine cleaning schedule, extending product life expectancy and reducing the frequency and costs of maintenance call-outs.

SPECIFICATIONS

Product title	Nugget Ice Maker, Modular
Production capacity (kg/24h) approx.	590
Electric connection	1/220 - 240V/50Hz
Electric connection Load (kW)	2.01
Outside Dimensions W x D x H (mm)	763 x 700 x 480
Ice type	Nugget
Refrigerant	R404A

CO2 equivalent (kg)	4508
Cooling system	Air Cooled
Product configuration	Modular
Net weight (kg)	133
Gross Weight Packed (kg)	143
Corresponding bin(s)	B501SA, B801SA



WolfLabs

Pricing on any accessories shown can be found by keying the part number into the search box on our website.

The specifications listed in this brochure are subject to change by the manufacturer and therefore cannot be guaranteed to be correct. If there are aspects of the specification that must be guaranteed, please provide these to our sales team so that details can be confirmed.

www.wolflabs.co.uk

Tel : 01759 301142

Fax : 01759 301143

sales@wolflabs.co.uk

Please contact us if this literature doesn't answer all your questions.