



HULME MARTIN HEAT SEALERS

# HULME MARTIN HEAT SEALERS

## HM 1000P-TWIN



(Hand Operated, Portable\* "TWIN" Heat Sealer) – Part No. 10002082T

<b>Maximum Sealing Length</b>	300mm (12")
<b>Seal Width</b>	6mm (Wide)
<b>Film Thickness</b>	2 x 1000 gauge (2 x 250 micron)
<b>Voltage</b>	240V, 110V (Conversion)
<b>Power Consumption (Watts)</b>	315W (per seal)
<b>Fuse Rating</b>	T 3.15 amp
<b>Footprint</b>	241mm (L) x 139mm (W) x 150mm (H)
<b>Weight</b>	7.5 Kg
<b>Operation</b>	Hand Operated
<b>Mounting</b>	Bench Mounted & <b>Portable*</b>

The **HM 1000P-TWIN** – Hand Operated, **Portable\*** "TWIN" Heat Sealer

Much like the HM 1000 P, this model is designed for repetitive seals on large, heavy or irregularly shaped packages. Giving a "TWIN" seal.

It also has the added benefit of utilising both jaws, allowing both sides to make a "TWIN" seal together - Ideal for tougher laminate materials.

Designed for polythene bags, sheeting, pallet covers, etc. whilst providing maximum flexibility of operation.

Dual Electronic Timer for complete control of heating & cooling cycle, so that the settings can be fine-tuned to the material being used.

Robust cast aluminium jaws with lever action for reduced manual effort.

Used for export packaging, protective storage & vacuum packing of humidity sensitive equipment.

This machine is simple to maintain with consumable spares being easy to fit & available from stock.

**\*Must be connected to Mains Power Supply, is NOT battery operated\***

**IMPULSE • CONSTANT HEAT SEALERS • VACUUM SEALERS • SHRINK CHAMBERS  
SACK SEALERS • BESPOKE SOLUTIONS • SEMI-AUTOMATIC MACHINES • SECURITY SEALERS**  
Registered office: Unit 5B Country Business Centre, White Cottage Farm, Lucas Green Road, West End, Woking, Surrey, GU24 9LZ  
Registered in England No. 5484051 VAT No. GB 864 4792 82



# WolfLabs

**Pricing on any accessories shown can be found by keying the part number into the search box on our website.**

The specifications listed in this brochure are subject to change by the manufacturer and therefore cannot be guaranteed to be correct. If there are aspects of the specification that must be guaranteed, please provide these to our sales team so that details can be confirmed.

**[www.wolflabs.co.uk](http://www.wolflabs.co.uk)**

**Tel : 01759 301142**

**Fax : 01759 301143**

**[sales@wolflabs.co.uk](mailto:sales@wolflabs.co.uk)**

Please contact us if this literature doesn't answer all your questions.