



HULME MARTIN HEAT SEALERS

# HULME MARTIN HEAT SEALERS

## HM 3100 CDS



**HM 3100 CDS (Semi-Automatic Heat Sealer) – Part No. 31032251**

<b>Maximum Sealing Length</b>	310mm (12.5")
<b>Seal Width</b>	3mm (Standard Seal)
<b>Film Thickness</b>	2 x 1000 gauge (2 x 250 micron)
<b>Voltage</b>	240V, 110V (Conversion)
<b>Power Consumption (Watts)</b>	300W (per seal)
<b>Fuse Rating</b>	T 3.15 amp
<b>Footprint</b>	400mm (L) x 340mm (W) x 150mm (H)
<b>Weight</b>	15.5 Kg
<b>Operation</b>	Foot or Hand Operated via Pad Switch
<b>Mounting</b>	Bench Mounted
<b>Options</b>	Rollers & Brackets (For Lay Flat Tubing)

The **HM 3100 CDS** – Semi-Automatic Heat Sealer

General purpose Semi-Automatic Solenoid operated machine, with many applications.

Used extensively by hospitals, laboratories, retailers, engineering & other industries.

Simple bench mounting.

This CDS model has a Dual Electronic Timer, for complete control of the heating & cooling cycle.

It is controlled via a one touch Pad Switch that can be operated by hand or foot.

A Cutter function is fitted for ease of use.

This machine is simple to maintain with consumable spares being easy to fit & available from stock.



# WolfLabs

**Pricing on any accessories shown can be found by keying the part number into the search box on our website.**

The specifications listed in this brochure are subject to change by the manufacturer and therefore cannot be guaranteed to be correct. If there are aspects of the specification that must be guaranteed, please provide these to our sales team so that details can be confirmed.

**[www.wolflabs.co.uk](http://www.wolflabs.co.uk)**

**Tel : 01759 301142**

**Fax : 01759 301143**

**[sales@wolflabs.co.uk](mailto:sales@wolflabs.co.uk)**

Please contact us if this literature doesn't answer all your questions.