



HULME MARTIN HEAT SEALERS

# HULME MARTIN HEAT SEALERS

## HM 4750 SM



(Hand Operated, Stainless Steel with Magnet) – Part No. 47502052

|                                  |  |
|----------------------------------|--|
| <b>Maximum Sealing Length</b>    | 475mm (18")                                      |
| <b>Seal Width</b>                | 6mm (Wide)                                       |
| <b>Voltage</b>                   | 240V, 110V (Conversion)                          |
| <b>Power Consumption (Watts)</b> | 650 (per seal)                                   |
| <b>Fuse Rating</b>               | T 3.15 amp                                       |
| <b>Footprint</b>                 | 680mm (L) x 160mm (W) x 180mm (800 – arm up) (H) |
| <b>Weight</b>                    | 9.5 Kg   |
| <b>Operation</b>                 | Hand Operated (with Hold Down Magnet)            |
| <b>Body Construction</b>         | 304 Stainless Steel                              |
| <b>Mounting</b>                  | Bench Mounted                                    |
| <b>Options</b>                   | T-Wire (Seal-Cut-Seal), Round Wire (Cut-&-Seal)  |

The **HM 4750 SM** – Hand operated Stainless Steel (with Magnet) Impulse Sealer



A general purpose, hand operated Impulse Heat Sealer – for industrial, food & basic medical applications.

Manufactured from Stainless Steel, with an electromagnet to hold the jaw closed during the sealing application.

Utilizing a Dual Electronic Timer for independent & complete control of the heat & cool cycles.

Plug in Heater Bar Assemblies on press fit rubber, mean maintenance can be done in seconds to reduce down time if required.

This machine is simple to maintain with consumable spares being easy to fit & available from stock.

**IMPULSE • CONSTANT HEAT SEALERS • VACUUM SEALERS • SHRINK CHAMBERS  
SACK SEALERS • BESPOKE SOLUTIONS • SEMI-AUTOMATIC MACHINES • SECURITY SEALERS**  
Registered office: Unit 5B Country Business Centre, White Cottage Farm, Lucas Green Road, West End, Woking, Surrey, GU24 9LZ  
Registered in England No. 5484051 VAT No. GB 864 4792 82



# WolfLabs

**Pricing on any accessories shown can be found by keying the part number into the search box on our website.**

The specifications listed in this brochure are subject to change by the manufacturer and therefore cannot be guaranteed to be correct. If there are aspects of the specification that must be guaranteed, please provide these to our sales team so that details can be confirmed.

**[www.wolflabs.co.uk](http://www.wolflabs.co.uk)**

**Tel : 01759 301142**

**Fax : 01759 301143**

**[sales@wolflabs.co.uk](mailto:sales@wolflabs.co.uk)**

Please contact us if this literature doesn't answer all your questions.